

# **2254, 2256, 2258, 2264 and 2266 Combines (Standard and Hillmaster) - Part 2**

(210 to 340)

For complete service information also see:

6068 Engine - (2254) . . . . .	CTM104
6081 Engine - (2256, 2258, 2264, 2266)	
Repair. . . . .	CTM86
Operation and Tests. . . . .	CTM134
Cam Lobe Motor . . . . .	CTM19
Alternators and Starting Motor . . . . .	CTM77

**John Deere Werke Zweibrücken  
TM4544 (27DEC00)**

Printed in Germany  
ENGLISCH

## FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the

beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

“Right-hand” and “left-hand” refer to the machine as seen in forward travel.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

# Note

**TECHNICAL MANUAL TM4544 (JULY-98)  
2254, 2256, 2258, 2264 AND 2266 COMBINES  
(STANDARD AND HILLMASTER)**

This Technical Manual is divided into two parts.

This part includes Sections 05 to 140.

Sections 210 to 340 are included in Part 2.

ZX,DLR1,TM4543 -19-10JUL98

*Note*

# Note

**TECHNICAL MANUAL TM4544 (JULY-98)  
2254, 2256, 2258, 2264 AND 2266 COMBINES  
(STANDARD AND HILLMASTER)**

This Technical Manual is divided into two parts.

This part includes Sections 210 to 340.

Sections 05 to 140 are included in Part 1.

ZX,DLR2, TM4543 -19-10JUL98

*Note*

# Contents

## **SECTION 05—Safety**

Group 05—Safety Information

## **SECTION 10—General**

Group 05—Lubricants and Coolant  
Group 10—Torques for Hardware  
Group 15—Type Plates  
Group 20—Serial Numbers

## **SECTION 20—Engine**

Group 05—Special Tools  
Group 10—Engines on 2200 Series Combines  
Group 15—Removing and Installing Engine

## **SECTION 30—Fuel, Air Intake and Cooling Systems**

Group 05—Fuel System  
Group 10—Air Intake System  
Group 15—Cooling System

## **SECTION 40—Electrical System**

Group 05—Connectors  
Group 10—Alternator  
Group 15—Starting Motor  
Group 20—Main Electrical System  
Group 25—Hillmaster Control  
Group 26—Automatic Header Control (Lateral Tilt)  
Group 30—Low Shaft Speed Monitor System  
Group 35—Harvest Performance Monitor

## **SECTION 50—Power Train**

Group 05—Intermediate Transmission  
Group 10—Transmission and Differential  
Group 15—Planetary Final Drives  
Group 20—Final Drives  
Group 25—Hydrostatic Drive, Variable Pump  
Group 30—Hydrostatic Drive, Fixed-Displacement Motor  
Group 35—Hydrostatic Drive, Oil Change  
Group 40—Cam Lobe Motor

## **SECTION 60—Brakes, Steering, Rear Axle**

Group 05—Brake Operating Assembly  
Group 10—Brakes

Group 15—Hydrostatic Steering

Group 20—Rear Axle

## **SECTION 70—Hydraulic System**

Group 05—Hydraulic Reservoir and Lines  
Group 10—Triple Hydraulic Pump  
Group 15—Electro-Magnetic Control Valve  
Group 20—Hydraulic Cylinders  
Group 21—Hillmaster Hydraulic Cylinder  
Group 25—Accumulators

## **SECTION 80—Miscellaneous**

Group 05—Bearings and Shafts  
Group 10—Drive Belts  
Group 15—Drive Chains  
Group 20—Side Guard

## **SECTION 90—Operator's Cab and Air Conditioning**

Group 05—Air Conditioning System - R134a  
Group 10—Operator's Cab Heating System  
Group 15—Gear Shift Mechanism

## **SECTION 110—Feeder House**

Group 05—Removing the Feeder House  
Group 10—Bottom Feeder Drum  
Group 15—Upper Feeder Shaft and Slip Clutch  
Group 20—Drives  
Group 25—Reverser  
Group 30—Pivoting Shield

## **SECTION 120—Separator and Cleaning Unit**

Group 05—Stone Trap  
Group 10—Threshing Cylinder and Concave  
Group 15—Beater/Second Cylinder and Second Concave  
Group 20—Electric Clutch  
Group 25—Countershaft, L.h. Drive Belt Pulley and Belt Guide  
Group 30—Variable Cylinder Drive  
Group 35—Cylinder Drive and Reduction Gear

Continued on next page

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

TM4544-19-27DEC00

COPYRIGHT© 1998  
DEERE & COMPANY  
European Office Mannheim  
All rights reserved  
A John Deere ILLUSTRATION® Manual

- Group 40—Countershaft for Straw Walker and Cleaning Shoe Drive
- Group 45—Straw Walkers and Straw Walker Crankshaft
- Group 50—Cleaning Fan and Drive Fan

**SECTION 130—Grain Recovery and Unloading System**

- Group 05—Tailings Elevator
- Group 10—Clean Grain Elevator
- Group 15—Filling the Grain Tank
- Group 20—Unloading the Grain Tank
- Group 25—Unloading Auger

**SECTION 140—Special Equipment**

- Group 05—Straw Chopper
- Group 10—Chaff Spreader

**SECTION 210—General**

- Group 05—Specifications

**SECTION 220—Engine**

- Group 05—Specifications

**SECTION 230—Fuel, Air Intake and Cooling Systems**

- Group 05—Fuel System

**SECTION 240—Electrical System to Serial Number 066832**

- Group 05 —Test Equipment
- Group 06—Test Equipment
- Group 10—Functional Schematic and Harness Diagrams
- Group 15A—Current Supply/Starting Motor
- Group 15B—Cold Weather Starting Aid
- Group 15C—Engine Shut-Off Device
- Group 15E—Instruments
- Group 15F—Chopper Distributor Adjustment
- Group 15G—Windshield Wiper/Washer System
- Group 15H—Radio, Interior Lighting
- Group 15L—Cigarette Lighter, Seat Compressor
- Group 15M—Lighting System
- Group 15N—Flasher Functions
- Group 15O—Beacon Lights
- Group 15P—Fan, Air Conditioning System
- Group 15Q—Electrical Mirror Adjustment
- Group 15R—Work Lights
- Group 15S—Straw Warning Device
- Group 15T—Reel Speed Adjustment
- Group 15U—Dial-A-Matic
- Group 15V—Separator, Header
- Group 15W—Infotrak Monitor
- Group 15X—Harvest Performance Monitor

- Group 15Y—Hillmaster Leveling System
- Group 15Z—Separator Adjustment
- Group 15AA—Separator Adjustment, Combine Data Center
- Group 15AB—Header Adjustments
- Group 15AC—Grain Tank Unloading System
- Group 15AD—Four-Wheel Drive
- Group 15AE—Header Lateral Tilt Function
- Group 15AF—Header Float Control

**SECTION 241—Electrical System from Serial Number 066833**

- Group 05 —General Information
- Group 06 —Test Equipment
- Group 10 —Functional Schematics and Harness Diagrams
- Group 15H —Radio
- Group 15I —Alarm Module, Stop Function
- Group 15J —Indicator Lights
- Group 15W —Infotrak Monitor, Speed Monitoring System
- Group 15AA—Separator Adjustment, Combine Data Center

**SECTION 250—Power Train**

- Group 05—Hydrostatic Drive
- Group 10—Testing Hydrostatic System
- Group 15—Inspect Parts Subject to Wear
- Group 20—Three-Speed Transmission

**SECTION 260—Brakes, Steering, Rear Axle**

- Group 05—Brake operating system
- Group 10—Drum Brakes

**SECTION 270—Hydraulic System**

- Group 05—General Information
- Group 10—Solenoid Valves
- Group 15—Hillmaster Leveling System
- Group 20—Hydraulic Tests

**SECTION 290—Operator's Cab**

- Group 05—Operator's Cab and Seat
- Group 10—Air Conditioning and Heating
- Group 15—Troubleshooting - Ventilation and Heating Systems
- Group 20—Operational Tests and Troubleshooting
- Group 25—Operation — Air Conditioning System

**SECTION 340—Optional Equipment**

- Group 05—Chaff Spreader

**Index**



# Section 05 Safety

## Contents

Page

Group 05—Safety Information . . . . . 05-05-1

*Contents*

### LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.




DX,LIVE -19-15APR98

TS231 -19-07OCT88

### SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



DX,LOWER -19-04JUN90

TS229 -UN-23AUG88


### WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



DX,WEAR -19-10SEP90

TS206 -UN-23AUG88


## Safety Information

### PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.




DX,FIRE2 -19-03MAR93

TS291 -UN-23AUG88

### PARK MACHINE SAFELY

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.



DX,PARK -19-04JUN90

TS230 -UN-24MAY89

### USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



DX,REPAIR -19-04JUN90


TS779 -UN-08NOV89

## Safety Information

### WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.




DX,AIR -19-04JUN90

TS220 -UN-23AUG88

### WORK IN CLEAN AREA

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.



DX,CLEAN -19-04JUN90

T6642EJ -UN-18OCT88

### HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90

TS227 -UN-23AUG88

## REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

TS220 -UN-23AUG88


## AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID -19-03MAR93

X9811 -UN-23AUG88

## Safety Information

### PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



DX,SPARKS -19-03MAR93

TS204 -UN-23AUG88

### PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



DX,POISON -19-21APR93

TS203 -UN-23AUG88

## Safety Information

### AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.




DX,TORCH -19-03MAR93

TS953 -UN-15MAY90

### ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




DX,LIGHT -19-04JUN90

TS223 -UN-23AUG88

### REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.




DX,SIGNS1 -19-04JUN90

TS201 -UN-23AUG88

### USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



DX,LIFT -19-04JUN90

TS226 -UN-23AUG88



## SERVICE TIRES SAFELY


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



-UN-23AUG88

TS211

DX,RIM -19-24AUG90

## PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



-UN-23AUG88

TS218

DX,SERV -19-03MAR93

## DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.




DX,DRAIN -19-03MAR93

TS1133 -UN-26NOV90

## SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



DX,LOOSE -19-04JUN90

TS228 -UN-23AUG88

# Section 10 General

## Contents

### Page

Group 05—Lubricants and Coolant . . .	10-05-1
Group 10—Torques for Hardware . . . . .	10-10-1
Group 15—Type Plates . . . . .	10-15-1
Group 20—Serial Numbers . . . . .	10-20-1

*Contents*

**DIESEL ENGINE OIL**

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oil is preferred.

- **John Deere PLUS-50®**

The following oil is also recommended:

- John Deere TORQ-GARD SUPREME®


Other oils may be used if they meet one or more of the following:

- API Service Classification CG-4
- API Service Classification CF-4
- ACEA Specification E3
- ACEA Specification E2

**Multi-viscosity diesel engine oils are preferred.**

If diesel fuel with sulfur content greater than 0.5% is used, reduce the service interval by 50%.

Extended service intervals may apply when John Deere preferred engine oils are used. Consult your John Deere dealer for more information.



TS1661 -UN-10OCT97

DX,ENOIL -19-10OCT97

## TRANSMISSION AND HYDRAULIC OIL

Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oils are preferred:


- John Deere HY-GARD®
- John Deere Low Viscosity HY-GARD®

Other oils may be used if they meet one of the following:

- John Deere Standard JDM J20C
- John Deere Standard JDM J20D

Use the following oil when a biodegradable fluid is required:

- John Deere BIO-HY-GARD™<sup>1</sup>



<sup>1</sup>BIO-HY-GARD meets or exceeds the minimum biodegradability of 80% within 21 days according to CEC-L-33-T-82 test method. BIO-HY-GARD should not be mixed with mineral oils because this reduces the biodegradability and makes proper oil recycling impossible.

DX,ANTI -19-10OCT97

## TRANSMISSION OIL


Use oil viscosity based on the expected air temperature range during the period between oil changes.

The following oils are preferred:

- John Deere EXTREME-GARD™
- John Deere GL-5 GEAR LUBRICANT

Other oils may be used if they meet the following:

- API Service Classification GL-5



ZX,DX,GEOIL -19-01JUL96

## GREASE


Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

The following greases are preferred:

- John Deere HIGH TEMPERATURE EP GREASE
- John Deere MOLY HIGH TEMPERATURE EP GREASE
- John Deere GREASE-GARD™

Other greases may be used if they meet one of the following:

- NLGI Performance Classification GC-LB



DX,GRE1 -19-18MAR96

TS1654 -UN-14MAR96


## BRAKE FLUID FOR BRAKE SYSTEM

**IMPORTANT:** Use only brake fluid that meets SAE Standard J 1703 (DOT 4).

Capacity:

- Complete system 1.0 L (0.26 U.S. gal)
- Reservoir 0.5 L (0.13 U.S. gal)

- A—Service flap, vehicle electrics
- B—Brake fluid reservoir
- C—Reservoir cap with float



ZX,OMXZC0002385-19-04DEC92

## ALTERNATIVE AND SYNTHETIC LUBRICANTS

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic oils.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-18MAR96

## MIXING OF LUBRICANTS

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Consult your John Deere dealer to obtain specific information and recommendations.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

DX,LUBMIX -19-18MAR96

## LUBRICANT STORAGE

Your equipment can operate at top efficiency only when clean lubricants are used.

Make certain that all containers are properly marked to identify their contents.

Use clean containers to handle all lubricants.

Properly dispose of all old containers and any residual lubricant they may contain.

Whenever possible, store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

DX,LUBST -19-18MAR96




## USE GENUINE JOHN DEERE PARTS

Genuine John Deere parts have been specifically designed for John Deere machines.

Other parts are neither examined nor released by John Deere. Installation and use of such products could have negative effects upon the design characteristics of the machine and thereby affect its safety.

Avoid this risk by using only genuine John Deere parts.



**ES 118 837**

ES118837 -UN-04APR95

FX,ORI -19-04DEC90

## ENGINE COOLANT

John Deere COOL-GARD is filled into the cooling system at the factory. It protects against corrosion and against frost down to  $-37^{\circ}\text{C}$  ( $-34^{\circ}\text{F}$ ).

**IMPORTANT: Use only John Deere COOL-GARD in the cooling system, independent of the season. Drain system and refill with fresh coolant every 2 years.**

If no John Deere COOL-GARD is available, use independent of the season a mixture of 50% ethylene-glycol antifreeze/corrosion inhibitor and 50% clear, soft water. This mixture also provides protection against corrosion and against frost down to  $-37^{\circ}\text{C}$  ( $-34^{\circ}\text{F}$ ).

Never use any cooling system sealing additives.

### Operating in Tropical Conditions

If no John Deere COOL-GARD or antifreeze is available, use the following mixture when refilling the cooling system: Use clean soft water and add 3% John Deere ENGINE COOLANT CONDITIONER TY16004 (30 ml per liter of water).

**IMPORTANT: Drain system and refill with fresh coolant mixture every year. This coolant mixture protects the system against corrosion, but not against frost.**











ES111859 -UN-05JAN89

RC4690 -UN-14DEC88

FX,COOLG -19-29SEP94

# Group 10 Torques for Hardware

## UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

<b>SAE Grade and Head Markings</b>	NO MARK	1 or 2 <sup>b</sup> 	5    5.1    5.2 	8    8.2 
<b>SAE Grade and Nut Markings</b>	NO MARK	2 	5  	8  

TS1162 -19-04/MAR91

Size	Grade 1				Grade 2 <sup>b</sup>				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	240	175	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	400	300	510	375	400	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.


<sup>a</sup> "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

<sup>b</sup> Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

DX.TORQ1 -19-20/JUL94

### METRIC BOLT AND CAP SCREW TORQUE VALUES



TS1163 -19-04MAR91

Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>		Lubricated <sup>a</sup>		Dry <sup>a</sup>	
	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	255	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

<sup>a</sup> "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

## TYPE PLATES

Serial numbers identifying combine harvester components or assemblies are stamped on components or factory serial number plates.


These numbers and letters are required when ordering parts or components for the combine harvester.

To ensure that you always have these numbers at hand, enter the appropriate serial numbers in the spaces provided in each illustration.

ZX.OMXZC0002360-19-05OCT92

## COMBINE TYPE PLATE

- A—Model
- B—Product identification number
- C—Absorption coefficient
- D—Permissible trailer load
- E—Permissible drawbar load
- F—Engine power
- G—Homologation number (in certain countries only)
- H—Version (in certain countries only)
- J—Permissible front axle load
- K—Permissible rear axle load
- L—Permissible total weight
- M—Year of production



ZX008582

-JUN-31JUN96  
ZX008582




ZX.OMXZC0003401-19-02MAY96

*Type Plates*

**PRODUCT IDENTIFICATION NUMBER**

The product identification number is located on the front right-hand side of the operator's platform.


*NOTE: In addition, the last six figures of the product identification number are stamped into right-hand frame near the clean grain elevator.*



ZX,OMXZCO003411-19-01JUL94

**ENGINE SERIAL NUMBER — ENGINE TYPE 6068**

The engine serial number is located near the fuel filter.




ZX,OMXZCO002362-19-04DEC92

## Serial Numbers

### ENGINE SERIAL NUMBER — ENGINE TYPE 6081


The engine serial number is located on the engine block between the oil filter and the injection pump.



### OPERATOR'S CAB SERIAL NUMBER


The operator's cab serial number is located on the inside of the left-hand side panel.

*NOTE: The operator's cab serial number is the same as that for the air conditioning system.*




### FOUR WHEEL DRIVE MOTOR SERIAL NUMBER

The serial number of the four wheel drive motor is located on top of the motor.



### THREE-SPEED TRANSMISSION SERIAL NUMBER

The three-speed transmission serial number is located on right-hand side of transmission.






## Serial Numbers

### FINAL DRIVE SERIAL NUMBER


The final drive serial number is located on the transmission housing opposite the input shaft.



ZX,OMXZC0007001-19-01NOV96

### STRAW CHOPPER SERIAL NUMBER


The straw chopper serial number is located on the outside of the chopper, on the right.



ZX,OMXZC0002363-19-05OCT92

### FEEDER HOUSE SERIAL NUMBER


The feeder house serial number is located on the outside of the feeder house, on the left-hand side.



ZX,OMXZC0007002-19-01NOV96

### SERIAL NUMBER OF THRESHING CYLINDER REDUCTION GEAR

The serial number of the cylinder reduction gear is located on the outside of the gear cover at the right-hand side.



ZX,OMXZC0007005-19-01NOV96

*Serial Numbers*

# Section 20 Engine

## Contents

Page

Group 05—Special Tools . . . . .	20-05-1
Group 10—Engines on 2200 Series Combines . . . . .	20-10-1
Group 15—Removing and Installing Engine . . . . .	20-15-1

*Contents*

**SPECIAL OR ESSENTIAL TOOLS**


*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

Lifting eye . . . . . JD-244-1

LX002476 -UN-07NOV94

**LX002476**




ZX,TMXZCO003887-19-15FEB95

Lifting eye . . . . . JD-244-2

LX002297 -UN-07NOV94

**LX002297**




ZX,TMXZCO003888-19-15FEB95

Lifting sling . . . . . JDG23

ZX005462 -UN-28APR95

**ZX005462**



ZX,TMXZCO003889-19-15FEB95

*Special Tools*

## Group 10 Engines on 2200 Series Combines

### ENGINES ON 2200 SERIES COMBINES

Combine Model	Engine Type	kW	hp
2254	CD 6068 H Z 001	132	180
2256	RG 6081 H Z 003	154	210
2258	RG 6081 H Z 005	173	235
2264	RG 6081 H Z 002	184	250
2266	RG 6081 H Z 001	199	270

ZX, TMXZCO009436-19-01AUG97

### ENGINE DESIGNATION CODES

CD	- Saran
RG	- Engine Works
6	- Number of cylinders
068	- Displacement = 6.8 liters
081	- Displacement = 8.1 liters
H	- Turbocharged, air-to-air intercooled
A	- Turbocharged, air-to-water intercooled
000000	- Serial number
Z	- Engine user (Zweibrücken factory)
001	- Engine version
002	- Engine version
003	- Engine version
005	- Engine version

ZX, TMXZCO009437-19-01AUG97






## Group 15 Removing and Installing Engine


### PREPARATIONS FOR ENGINE REMOVAL

- Swing unloading auger to the side
- Drain coolant
- Disconnect battery
- Remove the muffler system
- Remove the air intake system
- Disconnect the fuel lines
- On 2264 and 2266, unbolt the additional belt pulley



ZX, TMXZC0009438-19-01AUG97

Remove snap ring (G) from hollow shaft and use an M10x50 screw to pull the drive shaft out of the hollow shaft.






ZX, TMXZC0009439-19-01AUG97

## Removing and Installing Engine

- Unbolt the intermediate transmission from the engine
- Unbolt the fan and alternator
- Remove attaching screws at engine mountings
- Attach lifting device (A) to existing brackets (B) and (C) and lift out the engine

**⚠ CAUTION:** Depending on model, the engine weighs between 600 and 816 kg (1323 and 1799 lb).



ZX, TMXZCO009440-19-01AUG97

## INSTALLING THE ENGINE

Install engine. Same as removal procedure, but in reverse order.

ZX, TMXZCO009441-19-01AUG97

### PREPARATIONS FOR ADJUSTING BELT GUIDES ON MAIN COUNTERSHAFT AND UNLOADING DRIVE

Start the engine and allow pressure to build up in the hydraulic system.

Shut off engine.


Attach bridge (A).

Put road safety switch in field position.

Switch on ignition.

To adjust the belt guide on the main countershaft, press the separator switch on the switch console.

To adjust the belt guide on the unloading drive, press the unloading drive switch on the switch console.



ZX,OMXZCO002250-19-05OCT92

### ADJUSTING THE BELT GUIDES

— Adjust belt guides until 4 - 6 mm (0.16 - 0.24 in.) clearance is obtained in relation to the belt (when the belt is tensioned).

— Once adjustment is completed, remove the bridge from the alternator.

ZX,TMXZCO009442-19-01AUG97

*Removing and Installing Engine*

# Fuel, Air Intake and Cooling Systems

## Section 30


### Contents

#### Page

Group 05—Fuel System . . . . .	30-05-1
Group 10—Air Intake System . . . . .	30-10-1
Group 15—Cooling System . . . . .	30-15-1

*Contents*

**SPECIAL TOOL (SELF-MANUFACTURED)**



ZX005391

ZX005391 -UN-03MAY95

- A—75 mm (2.95 in.) dia.
- B—65 mm (2.56 in.) dia.
- C—35 mm (1.38 in.)
- D—8 mm (0.3 in.) dia., length 100 mm (3.94 in.)
- E—3 mm (0.12 in.)
- F—50 mm (1.97 in.)
- G—30 mm (1.20 in.)

Tool for removal and installation of fuel gauge sending unit

ZX, TMXZCO003912-19-15FEB95

**GENERAL INFORMATION**

**⚠ CAUTION:** When repairing the fuel system, never permit smoking, naked flames or playing with fire.

**Fuel Tank Capacity**

2254 - 2264	.....	450 L (119 U.S. gal)
2266	.....	550 L (145.3 U.S. gal)

ZX, TMXZCO009443-19-01AUG97

## REMOVING FUEL TANK

**IMPORTANT: Drain fuel from tank before removal.**

Loosen fuel line at filter (A).

Loosen fuel return line at tank (B).

Disconnect electrical cable from fuel gauge sending unit (C).

Remove rear panel (D).




Remove rear handrails (E).

Remove stays (F).

Remove filter assembly.

Remove two screws from hood.

- A—Filter
- B—Tank
- C—Fuel gauge sending unit
- D—Panel
- E—Handrails
- F—Stays



ZX, TMXZCO003914-19-15FEB95




## REMOVING TANK SUPPORT

Place lift fork (A) below tank support.


Remove four screws from the two supports (B) and lower tank until tank filler neck is clear of floor plate.

Remove tank sideways.

Remove straps (C) from lower tank attaching points on right and left-hand side.



ZX005407 -UN-21APR95



ZX005408 -UN-21APR95

ZX, TMXZCO003917-19-15FEB95

## INSTALLING FUEL TANK

Install fuel tank, reversing removal procedure.


ZX, TMXZCO003919-19-15FEB95

## FUEL TANK FILLER NECK

The fuel tank filler neck is closed with a tank cap.

The fuel tank is vented through an opening in the cap.

Clean dust and chaff from the surrounding area before removing tank cap.



ZX003836 -UN-08MAY95

ZX, OMXZCO002089-19-13NOV92


## Fuel System

### REMOVING FUEL GAUGE SENDING UNIT

Drain fuel until fuel level is well below the fuel gauge sending unit.

Disconnect the three cable connectors.

Using special tool (A), turn the sending unit all the way counter-clockwise and remove it.



ZX, TMXZCO003920-19-15FEB95

ZX005409  
-UN-21APR95

### INSTALLING FUEL GAUGE SENDING UNIT

Install fuel gauge sending unit with O-ring.

Using special tool, turn the sending unit clockwise until contacts (A) and (B) are in vertical position.



ZX, TMXZCO003921-19-15FEB95


ZX005410  
-UN-21APR95

### CONNECTING CABLES

Connect brown cable (031) to red connection "A".

Connect red cable (033) to white connection "B".

Connect black cable to ground "C".




ZX, TMXZCO003922-19-15FEB95

ZX005390  
-UN-03MAY95

**FUEL FILTER WITH WATER TRAP,  
EXPLODED VIEW**

- A—Gasket set
- B—Repair set
- C—Special screw
- D—Filter element
- E—Holding strap
- F—Hose connection
- G—O-ring
- H—Sight glass
- J—Knurled nut
- K—Drain tap



ZX005416 -UN-28APR95

ZX.TMXZC0009444-19-01AUG97

## WATER TRAP IN FUEL SYSTEM

The fuel system has an integral water trap (A). This filter operates as follows:

### 1st stage:


Solid foreign matter is separated out by centrifugal force.

### 2nd stage:

Tiny particles float up with the fuel into the cone-shaped insert, where they accumulate on the oblique surfaces. This sediment gradually becomes heavier and the larger particles fall slowly into the 1st stage on the base of the sight-glass.


### 3rd stage:

The finest fuel filter stage takes place in the filter insert. This insert can be removed and replaced.



ZX,OMXZC0004144-19-01MAR95

**BOWDEN CABLE FOR SPEED ADJUSTMENT**



A—Console  
B—Handle  
C—Ball joint

D—Joint  
E—Bowden cable  
F—Ball socket

G—Retainer  
H—Special washer

J—Spring  
K—Throttle lever

## REPLACING BOWDEN CABLE FOR SPEED ADJUSTMENT

**IMPORTANT:** Do not bend the bowden cable.

Remove console.

Disconnect throttle lever at thread and remove together with rubber boot. Remove handle from lever.

Remove right-hand cover (A). Remove plastic clamping device (B) from bowden cable.

Disconnect ball joint at throttle lever and remove together with cable joint.


Slacken feeder house drive idler.

Remove all clamps from bowden cable.

Disconnect bowden cable at fuel injection pump bracket. Disconnect ball joint.

Pull bowden cable to the rear out of retainers.

Bowden cable installation is the same, but in reverse order.



ZX, TMXZCO009445-19-01AUG97

## ADJUSTING BOWDEN CABLE

Adjust bowden cable so that speed control lever at injection pump contacts adjusting screw stop (at full throttle position).

ZX, TMXZCO003927-19-15FEB95

### ADJUSTING ENGINE SPEEDS

Slow idle . . . . .	1250 ± 50 rpm
Fast idle . . . . .	2350 + 50 rpm
Rated speed . . . . .	2200 rpm

Check engine speeds with separator engaged.


ZX,TMXZCO009446-19-01AUG97

### ADJUSTING THROTTLE LEVER

Tighten throttle lever (A) by means of nut (F) so that lever does not move out of full throttle position.

Secure nut (F).

- A—Throttle lever
- B—Retaining strap
- C—Special washers
- D—Spring
- E—Washer
- F—Nut



ZX005414


ZX,TMXZCO003929-19-15FEB95

ZX005414 -UN-28APR95

*Fuel System*



**AIR INTAKE SYSTEM WITH AIR-TO-AIR AFTERCOOLER (6.8-L ENGINE)**




ZX007416

- |   |   |  |   |
|---|---|--|---|
| <p><b>A</b>—Stationary radiator screen with driven cleaning fan<br/><b>B</b>—Suction pipe and channel from stationary radiator screen</p> | <p><b>C</b>—Air-to-air aftercooler<br/><b>D</b>—Eddy fan for oil cooler/condenser<br/><b>E</b>—Hydraulic oil cooler<br/><b>F</b>—Air conditioning condenser (if equipped)</p> | <p><b>G</b>—Eddy fan for radiator<br/><b>H</b>—Radiator<br/><b>J</b>—Air cleaner with safety element</p> | <p><b>K</b>—Turbocharger<br/><b>L</b>—Muffler<br/><b>M</b>—Air cleaner suction pipe</p> |
|---|---|--|---|

ZX007416 -JUN-20/JUN95

ZX.OMXZCO002115-19-01NOV96

**AIR INTAKE SYSTEM WITH AIR-TO-AIR AFTERCOOLER (8.1-L ENGINE)**



ZX009866

A—Stationary radiator screen with driven cleaning fan  
 B—Suction pipe and channel from stationary radiator screen

C—Air-to-air aftercooler  
 D—Eddy fan for hydraulic oil cooler/condenser  
 E—Hydraulic oil cooler  
 F—Air conditioning condenser (if equipped)

G—Eddy fan for radiator  
 H—Radiator  
 J—Air cleaner with safety element

K—Turbocharger  
 L—Muffler  
 M—Air cleaner suction pipe

ZX.OMXZC0002116-19-01NOV96

## ENGINE COOLANT

John Deere COOL-GARD is filled into the cooling system at the factory. It protects against corrosion and against frost down to  $-37^{\circ}\text{C}$  ( $-34^{\circ}\text{F}$ ).

**IMPORTANT: Use only John Deere COOL-GARD in the cooling system, independent of the season. Drain system and refill with fresh coolant every 2 years.**

If no John Deere COOL-GARD is available, use independent of the season a mixture of 50% ethylene-glycol antifreeze/corrosion inhibitor and 50% clear, soft water. This mixture also provides protection against corrosion and against frost down to  $-37^{\circ}\text{C}$  ( $-34^{\circ}\text{F}$ ).

Never use any cooling system sealing additives.

### Operating in Tropical Conditions

If no John Deere COOL-GARD or antifreeze is available, use the following mixture when refilling the cooling system: Use clean soft water and add 3% John Deere ENGINE COOLANT CONDITIONER TY16004 (30 ml per liter of water).

**IMPORTANT: Drain system and refill with fresh coolant mixture every year. This coolant mixture protects the system against corrosion, but not against frost.**



ES111859 -UN-05JAN89




RC4690 -UN-14DEC88

FX,COOLG -19-29SEP94

## LAYOUT OF COOLING ELEMENTS (2254 — 2266)

- A—Fan
- B—Radiator
- C—Hydraulic oil cooler (top)
- D—Air conditioning condenser (below, when equipped)
- E—Intercooler
- X—Direction of travel



ZX002575 -UN-19JUN95

ZX,OMXZCO002105-19-01NOV96

## ENGINE COOLANT

**CAUTION:** Danger of scalding. Do not loosen or remove the radiator filler cap when coolant temperature is near or above boiling point. Always loosen the cap slightly to relieve pressure before removing cap completely.

Add coolant only when the engine is shut off.


When the engine is cool, the coolant level should be up to the "COLD" mark.

### Checking coolant quality


**IMPORTANT:** Regardless of the season, use only John Deere COOL-GARD in the cooling system. Drain cooling system and refill with fresh coolant every 2 years.

Check condition of coolant mixture before the winter season. Coolant should protect engine against frost down to  $-36^{\circ}\text{C}$  ( $-35^{\circ}\text{F}$ ).

Never use any cooling system sealing additives.



-UN-19JUN95  
ZX003883



-UN-19JUN95  
ZX003884


ZX,OMXZC0002107-19-01AUG92

## ADDING COOLANT

**CAUTION:** Danger of scalding. Do not loosen or remove the radiator filler cap when coolant temperature is near or above boiling point. Always loosen the cap slightly to relieve pressure before removing cap completely.

**IMPORTANT:** Add a recommended coolant. Never use a cooling system sealing additive. Never pour cold liquid into a hot engine, as this may crack the cylinder head or block. Never operate engine without coolant.

When the system is cool, coolant level should be up to the "COLD" mark on the expansion tank.



-JUN-16-JUN95  
ZX002386

ZX.TMXZCO009447-19-01AUG97

## FLUSHING SEQUENCE — COOLING SYSTEM

Drain and flush the cooling system at least every two years.

Having drained off all coolant, close drain tap or replace plug. Fill system with clean water.

Start engine and run until it reaches operating temperature.

Turn cab heater on and leave on until cleaning of cooling system is finished.

Stop engine and drain system immediately before rust and sediment deposits settle.

Close drain tap or replace plug. Clean system with commercial cooling system cleaner, following the instructions supplied with the cleaner.


Drain cooling system cleaner and refill system again with clean water. Shut off engine when water reaches operating temperature and drain system again.

Refill system with the specified coolant (see "Engine Coolant").

**IMPORTANT:** The cooling system must always be filled with John Deere COOL-GARD, irrespective of the season.

ZX.OMSPFH001283-19-01NOV91

**DRAIN VALVE FOR ENGINE COOLANT AT RADIATOR**




ZX 003885

ZX,OMXZC0002109-19-01AUG92

-JUN-19-JUN95  
ZX003885

**DRAIN PLUG FOR ENGINE COOLANT (6.8-L ENGINE)**

A—In oil cooler inlet line





ZX 003887

ZX,OMXZC0002110-19-01AUG92

-JUN-19-JUN95  
ZX003887


**DRAIN VALVES FOR ENGINE COOLANT  
(8.1-L ENGINE)**

- A—At r.h. side of cylinder block
- B—At coolant pump



ZX,OMXZC0002111-19-01NOV96

**SUCTION SYSTEM, EXPLODED VIEW**



A—Suction screen  
B—Suction blade

C—Crossbeam  
D—Electric motor

E—Suction hose  
F—Hose clamp

G—Nut

ZX005418 -UN-28APR95

ZX, TMXZCO003934-19-15FEB95

**REPLACING SUCTION BLADE**

Remove crossbeam.

Remove nut and lift off suction blade.

For installation, reverse removal procedure.

ZX, TMXZCO003935-19-15FEB95




## **ADJUSTING SUCTION BLADE**

Adjust suction blade at crossbeam until a clearance of 7 - 8 mm (0.27 - 0.31 in.) is obtained between blade and suction screen (measured at outer ends of blade).

ZX, TMXZCO003936-19-15FEB95

**RADIATOR, EXPLODED VIEW**



ZX005451

-UN-28APR95  
ZX005451

- |                      |                      |                        |                |
|----------------------|----------------------|------------------------|----------------|
| A—Radiator           | D—Pipe (2256 - 2266) | G—Rubber hose sections | J—Drain tap    |
| B—Hose (2254)        | E—Pipe (2254)        | H—Hose clamps          | K—Radiator cap |
| C—Pipe (2256 - 2266) | F—Expansion tank     |                        |                |

ZX.TMXZCO009448-19-01AUG97

## **REMOVING RADIATOR**

Drain coolant.

Disconnect engine coolant connection.

Remove support with fan.

Remove lateral radiator attaching screws (bottom and top).

Pull out radiator from the top.

ZX, TMXZCO003938-19-15FEB95

## **INSTALLING RADIATOR**

For installation, reverse removal procedure.

Check if seals are in good condition. Replace, if necessary.

ZX, TMXZCO003939-19-15FEB95

*Cooling System*

# Section 40 Electrical System

## Contents

	Page		Page
<b>Group 05—Connectors</b>			
Special tools . . . . .	40-05-1	Operational check . . . . .	40-35-6
Electrical repair tool kit . . . . .	40-05-1		
Electrical connector handling . . . . .	40-05-3		
Insulated and non-insulated connectors . . . . .	40-05-4		
 <b>Group 10—Alternator</b>			
Battery . . . . .	40-10-1		
Alternator . . . . .	40-10-1		
Drive belts . . . . .	40-10-2		
 <b>Group 15—Starting Motor . . . . .</b>			
	40-15-1		
 <b>Group 20—Main Electrical System</b>			
Electronic board . . . . .	40-20-1		
Fuse board . . . . .	40-20-2		
Relay and diode board . . . . .	40-20-5		
 <b>Group 25—Hillmaster Control</b>			
Wiring harness . . . . .	40-25-1		
Control box . . . . .	40-25-2		
Removing the dashpot . . . . .	40-25-2		
Transistor . . . . .	40-25-2		
Switch element . . . . .	40-25-2		
Aligning the control box . . . . .	40-25-3		
Tilt limit switches . . . . .	40-25-3		
 <b>Group 26—Automatic Header Control (Lateral Tilt)</b>			
Automatic lateral control . . . . .	40-26-1		
Sensors . . . . .	40-26-2		
Settings . . . . .	40-26-3		
 <b>Group 30—Low Shaft Speed Monitor System</b>			
Low shaft speed monitor system . . . . .	40-30-2		
Threshing cylinder alarm speed . . . . .	40-30-4		
Fan alarm speed . . . . .	40-30-4		
 <b>Group 35—Harvest Performance Monitor</b>			
Harvest performance monitor . . . . .	40-35-1		
Preliminary adjustments . . . . .	40-35-2		
Operational adjustment . . . . .	40-35-3		
Sensors . . . . .	40-35-5		


*Contents*

**SPECIAL OR ESSENTIAL TOOLS**

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

Repair kit ..... AZ50578  
Connector repair



AZ50578

-JUN-12JAN96  
AZ50578


ZX,TMSPFH004747-19-31JAN96

**ELECTRICAL REPAIR TOOL KIT**

Holding plate for SURE-SEAL™ connectors (A) ..... JDG107  
Contact insertion tool (B) ..... JDG139  
Contact extraction tool (C) ..... JDG140  
Contact extraction tool (D) ..... JDG142  
Contact extraction tool (E) ..... JDG143

*NOTE: All tools are part of electrical repair tool kit JDG155.*

*NOTE: SURE-SEAL™ is a trade name of the ITT Cannon company.*



Z106569


-JUN-28APR95  
Z106569

ZX,TMSPFH000369-19-22SEP95

Connectors/Electrical repair tool kit

Electrical repair tool kit . . . . . JDG359  
 Repairing DEUTSCH connectors


T6606AB -UN-23AUG88



ZX,53T,JDG359 -19-31JAN96

Weatherpack Extraction Tool . . . . . JDG364  
 Used to remove contacts from Weatherpack electrical connectors.


T6606AC -UN-23AUG88



53T,JDG364 -19-20OCT92

Extraction tool . . . . . JDG777  
 Removing METRI PACK male or female connectors

JDG777 -UN-12OCT94




**JDG777**

ZX,TMSPFH004748-19-31JAN96

Crimping pliers . . . . . FKM10467  
 For non-insulated electrical connectors

FKM10467 -UN-12JAN96




**FKM10467**

ZX,TMSPFH004749-19-31JAN96

Crimping pliers . . . . . FKM10468  
 For insulated electrical connectors

FKM10468 -UN-12JAN96




**FKM10468**

ZX,TMSPFH004750-19-31JAN96

Crimping pliers . . . . . JDG783 or JDG707  
 For WEATHER PACK connectors

JDG783 -UN-12JAN96




**JDG783**

ZX,TMSPFH004751-19-31JAN96

Crimping pliers . . . . . FKM10469  
 For METRI PACK connectors

FKM10469 -UN-12JAN96




**FKM10469**

ZX,TMSPFH004752-19-31JAN96

Crimping pliers . . . . . JDG707  
 For Schlemmer connectors with a diameter of 3.5 mm (0.14 in.).

JDG707 -UN-12JAN96



**JDG707**

ZX,TMSPFH004759-19-31JAN96



## ELECTRICAL CONNECTOR HANDLING

Electrical connectors must not be forcibly mated or unmated. All are designed to be mated easily. If you have to use tools, you may be doing something wrong. Prying or forcing connectors may cause permanent damage to the locking mechanism, contacts, or both.

When working on connectors, make sure you are working on the correct terminal. Remember that male and female halves are mirror images of each other. Look for the terminal number on the connector body. The connection of improper electrical circuits can cause unusual electrical symptoms.

When an electrical connector is repaired, it is important that the proper terminals are used. In some of these connectors, different terminals are used to carry different currents. If contacts of different materials are mated, corrosion may develop that could affect performance.

When removing terminals from connectors, it is very important to use the correct extraction tool and gently remove the terminal. The connector body can be damaged if terminals are just "jerked" out of it. The damage caused will prevent the new terminal from staying in the connector, making replacement of the connector body necessary.

When installing a new terminal on a wire, make sure the insulation crimp and wire crimp are both made properly. Each part of the terminal crimps is designed for a specific purpose. Failure to properly crimp the wire contact area can result in poor or no electrical contact. Failure to crimp the insulation support properly can result in problems getting the terminal into the connector body, thus causing premature failure.




H37083  
-UN-01FEB89

HX.1401.4020.H -19-20OCT92

### DISCONNECTING ELECTRICAL CIRCUIT

Disconnect battery ground strap before carrying out any electrical repairs on the machine.



Z100210


ZX.TMSPFH000370-19-01FEB91

-UN-27APR95  
Z100210

### REPLACING CONNECTORS

1. Using a small screwdriver, depress locking tang on terminal. Remove wire from connector.
2. Bend locking tang back in original position before installing new connector body.

A—Female terminal  
B—Male terminal




R25972N

ZX.TMSPFH000371-19-22JUL91

-UN-12MAY95  
R25972N

### INSULATED AND NON-INSULATED CONNECTORS

1. Remove insulation from end of wire.
2. Install non-insulated connector (A) on wire end, using crimping pliers FKM10467.
3. Install insulated connector (B) on wire end, using crimping pliers FKM10468.



ZX008391


ZX.TMSPFH004753-19-31JAN96

-UN-12JAN96  
ZX008391

### REPLACING SMALL MATE-N-LOK™ CONTACTS IN CONNECTOR HOUSINGS

1. Using extraction tool JDG142, press contact (A) out of connector. Position tool JDG142 opposite the contact slot.
2. Push new contact in connector.

*NOTE: MATE-N-LOK™ is a trade name of the AMP company.*





ZX,TMSPFH000373-19-22FEB92

ZX001706 -UN-27APR95

### REPLACING SURE-SEAL™ CONNECTOR BODIES

1. Pull out all wires from defective connector body.
2. Put both new connector body halves together.
3. Place connector body (A) in relevant bore (B) of holding plate JDG107.
4. Using insertion tool JDG139, press individual contacts into connector body.



ZX,TMSPFH000374-19-22FEB92


Z106571 -UN-27APR95

Z106572 -UN-27APR95

## REPLACING MATE-N-LOK™ AND CPC™ PIN AND SOCKET CONTACTS

1. Depending upon type of connector, select correct extraction tool (JDG140 or JDG143).
2. Slide sleeve (A) of extraction tool over contact.
3. Turn hand grip (B) to disconnect contact and press out by means of knob (C).
4. Install new contact in plug.

**NOTE:** MATE-N-LOK™ AND CPC™ are trade names of the AMP company.



-UN-27APR95  
Z106573

ZX.TMSPFH000375-19-22FEB92


## REPLACING DEUTSCH™ CONNECTORS

1. Select an extraction tool suitable for the size of the cable to be removed.
  - a. Extraction tool JDG361 for size 2.5 mm<sup>2</sup> (12 to 14 AWG).
  - b. Extraction tool JDG362 for size 1.0 mm<sup>2</sup> (16 to 18 AWG).
  - c. Extraction tool JDG363 for size 0.5 mm<sup>2</sup> (20 AWG).
2. Position extraction tool against cable as shown in illustration.
3. Slide extraction tool to the rear along the cable until the tip of the tool engages in the cable.

**IMPORTANT:** When inserting the tool into the connector, take care NOT to twist the tool.


4. Slide the extraction tool along the cable into the connector until it is located over the contact.
5. Remove the cable from the connector using the extraction tool.

**NOTE:** DEUTSCH is a trade name of DEUTSCH CO.



ZX005483

-UN-17MAY95  
ZX005483




ZX005484

-UN-03MAY95  
ZX005484

ZX.TMXZCO003994-19-31JAN96

**IMPORTANT: Using a sleeve of the appropriate size, insert the contact at the correct location.**

6. Slide contact into the pin-and-socket contact until resistance is encountered.
7. Check that the contact is seated firmly in the pin-and-socket contact by pulling gently on the cable.
8. In the same way, insert the remaining cables into the new pin-and-socket contact.



ZX005485


-JUN-03MAY95

ZX005485

ZX,TMXZCO003995-19-28FEB95

### INSTALL DEUTSCH CONTACT

1. Strip 6 mm (1/4 in.) insulation from wire.
2. Adjust selector (A) on JDG360 Crimper for correct wire size.
3. Loosen lock nut (B) and turn adjusting screw (C) in until it stops.




DX,ECONN,W -19-04JUN90

-UN-23AUG88

TS117

**IMPORTANT: Select proper size contact "sleeve" or "pin" to fit connector body.**

4. Insert contact (A) and turn adjusting screw (D) until contact is flush with cover (B).
5. Tighten lock nut (C).



DX,ECONN,X -19-04JUN90

-UN-23AUG88

TS0134

**IMPORTANT: Contact must remain centered between indentors while crimping.**

6. Insert wire in contact and crimp until handle touches stop.
7. Release handle and remove contact.



TS118  
-UN-23AUG88

DX,ECONN,Y -19-04JUN90

**IMPORTANT: If all wire strands are not crimped into contact, cut off wire at contact and repeat contact installation procedures.**

*NOTE: Readjust crimping tool for each crimping procedure.*

8. Inspect contact to be certain all wires are in crimped barrel.



TS0135  
-UN-23AUG88

DX,ECONN,Z -19-04JUN90

## REPLACE WEATHER PACK™ CONNECTOR

**IMPORTANT: Identify wire color locations with connector terminal letters.**

1. Open connector body.
2. Insert JDG364 Extraction Tool over terminal contact in connector body.
3. Hold extractor tool fully seated and pull wire from connector body.

*NOTE: If terminal cannot be removed, insert wire or nail through extractor tool handle and push terminal contact from connector.*



TS0128  
-UN-23AUG88


*WEATHER PACK is a trademark of PACKARD ELECTRIC*

DX,ECONN,O -19-03NOV94

**IMPORTANT: Carefully spread contact lances to assure good seating on connector body.**

*NOTE: Connector bodies are "keyed" for proper contact mating. Be sure contacts are in proper alignment.*

4. Push contact into new connector body until fully seated.
5. Pull on wire slightly to be certain contact is locked in place.
6. Transfer remaining wires to correct terminal in new connector.
7. Close connector body.



TS0130 -UN-23AUG88

DX,ECONN,R -19-04JUN90

## WEATHER PACK MALE AND FEMALE CONNECTORS

*NOTE: Wire seals are color coded for three sizes of wire:*

- Green - Wire size 0.75 mm<sup>2</sup> (18 to 20 AWG)
- Grey - Wire size 1.5 mm<sup>2</sup> (14 to 16 AWG)
- Blue - Wire size 4.0-6.0 mm<sup>2</sup> (10 to 12 AWG)

1. Slip correct size seal on wire.

**IMPORTANT: The seal must fit snug over the wire insulation, without a gap between the seal and the insulation.**

2. Strip insulation from wire to expose 6 mm (1/4 in.) length of wire. Align seal with edge of insulation.



TS0136 -UN-23AUG88


ZX,15004005,3 -19-31JAN96

3. Put proper size contact on wire and crimp in place, using crimping pliers JDG783.

4. Seal is crimped in place together with the wire in a one-step action, using crimping pliers JDG783.

*NOTE: When using crimping pliers JDG707, crimping is a two-step action. Use lower recess to crimp wire and upper recess to crimp seal.*

**IMPORTANT: The illustration shows proper installation of sleeve (A) and pin (B).**



ZX,ECONN,AB -19-31JAN96

-UN-02NOV94

TS1623


-UN-02DEC88

TS0139

## REPLACING METRI PACK CONNECTORS<sup>1</sup>

*NOTE: 4 to 6-pin connectors are installed on the machines.*

**A—Male terminal**  
**B—Female terminal**



<sup>1</sup> METRI PACK is a trade name of the PACKARD ELECTRIC company


ZX,TMXZCO004127-19-22SEP95

-UN-26APR95

LX000873

## Removing Male or Female Terminal

**A—JDG777<sup>1</sup>**



<sup>1</sup> For METRI PACK connectors, 150 series

LX,40,05004247 -19-01MAR93


-UN-12OCT94

LX005650



### Removing a Female Terminal on Multiple-Pin Connectors for Electronic Units

Using a pointed tool (A), depress locking tang and pull out terminal.



LX000879 -UN-26APR95

ZX,TMSPFH004761-19-31JAN96

### Installing METRI PACK Male or Female Terminal

*NOTE: Wire seals are color coded for three sizes of wire:*

- Green - Wire size 0.75 mm<sup>2</sup> (18 to 20 AWG)
- Grey - Wire size 1.5 mm<sup>2</sup> (14 to 16 AWG)
- Blue - Wire size 4.0-6.0 mm<sup>2</sup> (10 to 12 AWG)

*NOTE: On multiple-pin connectors of electronic units, seal is installed in connector housing.*

1. Slip correct size seal on wire.

**IMPORTANT: The seal must fit snug over the wire insulation, without a gap between the seal and the insulation.**

2. Strip insulation from wire to expose 6 mm (1/4 in.) length of wire. Align seal with edge of insulation.




-UN-23AUG88

ZX,TMSPFH004754-19-31JAN96

**NOTE:** On multiple-pin connectors of electronic units, first insert wire through connector housing before crimping contact.

3. Put proper size contact (A) or (B) on wire and crimp in place, using crimping pliers FKM10469.

4. Seal is crimped in place together with the wire in a one-step action, using crimping pliers FKM10469.



ZX008383

-UN-12JAN96  
ZX008383

ZX.TMSPFH004760-19-31JAN96


## REPLACING SCHLEMMER™ CONNECTORS

1. Depending on contact used, select proper extraction tool (JDG140 or JDG143).

2. Slide sleeve (A) of extraction tool over contact.

3. Loosen contact by turning handle (B) and push it out, using button (C).

**NOTE:** SCHLEMMER is a trade name of Josef Schlemmer GmbH.



ZX008387


-UN-15APR96  
ZX008387

ZX.TMSPFH004762-19-31JAN96

4. Put a new proper size contact (A) or (B) on wire and crimp in place, using crimping pliers (JDG707 or FKM10467):

- JDG707 for contact with 3.5 mm (0.14 in.) dia.
- FKM10467 for contact with 1.6 mm (0.06 in.) dia.

5. Install contact in connector housing.




ZX008388

-UN-12JAN96  
ZX008388

ZX.TMSPFH004763-19-31JAN96

Connectors/Insulated and non-insulated connectors

6. Apply sealant at locations where wires enter connector housing.





## GENERAL INFORMATION

**CAUTION:** Before working on the electrical system, always disconnect the battery ground cable.


*NOTE:* Refer to relevant component manual for information on repairing the alternator and starting motor.

ZX, TMXZCO003940-19-15FEB95

## INSTALLING BATTERIES AND CONNECTING TO CORRECT POLES

**IMPORTANT:** Make sure batteries are connected to the correct poles. The positive cable (from starter motor) to the positive (+) poles, the negative cable (from ground) to the negative (—) poles.

Reversed polarity will result in permanent damage to the electrical system.



-UN-04APR95  
ZX001599


ZX, OMXZCO002185-19-05OCT92

## REMOVING THE ALTERNATOR

Disconnect ground cable from battery.

Disconnect cables "B+" and "D+".

Loosen attaching screws and lift out alternator.



-UN-08MAY95  
ZX003937

ZX, TMXZCO003941-19-15FEB95

## REPAIRING THE ALTERNATOR

*NOTE: Refer to relevant component manual for information on repairing the alternator.*

ZX, TMXZCO003942-19-15FEB95


## DRIVE BELTS (6.8-L ENGINE)

**IMPORTANT: Belts must be cool when tension is adjusted. Exert pressure on mounting brackets only.**

To retension, slacken off attaching and adjusting screws. Pull alternator outwards. Tighten screws.

Check tension of belt (B) at point (X). Flexion on the belt should not exceed 5 mm (0.2 in.).

- A—Drive belts for fan (2 x) and air conditioning compressor (if equipped)
- B—Drive belts for coolant pump and alternator



ZX 003891

ZX003891 -UN-19JUN95

ZX, OMXZCO002113-19-02MAR95


## DRIVE BELTS (8.1-L ENGINE)

**IMPORTANT:** Belts must be cool when tension is adjusted. Exert pressure on mounting brackets only.

To retension, slacken off attaching and adjusting screws. Pull alternator outwards. Tighten screws.

Check tension of belt (A) at point (X). Flexion on the belt should not exceed 5 mm (0.2 in.).

- A—Drive belt for fan and alternator
- B—Drive belt for air conditioning compressor (if equipped)



ZX 003892

ZX,OMXZC0002114-19-01NOV96

ZX003892 -UN-19JUN95

*Alternator/Drive belts*



## STARTING MOTOR

**IMPORTANT:** When working on the electrical system, always disconnect the ground cable. This prevents damage from occurring.

If the starting motor does not function or operates only sluggishly, the fault may lie not in the starting motor but in one of the causes suggested below.

**Loose, dirty or corroded connections:** Clean and tighten all connections.

**Low battery output:** Check electrolyte level and specific gravity of batteries. Recharge batteries if necessary.


**Run down battery:** Recharge battery.

**Engine crankcase oil of wrong viscosity:** Drain and refill crankcase with specified oil.


**Low ambient temperature:** Use cold-weather starting aid.

**Defective start safety relay:** Replace relay.

If the remedies suggested above fail to improve starting motor operation, remove motor and replace it with a new one.



From front, looking back



From rear, looking forward

I—8.1-L engine (495 cu in.)  
II—6.8-L engine (414 cu in.)

ZX.TMXZCO009449-19-01AUG97


## REPAIRING THE STARTING MOTOR

**NOTE:** For instructions on how to repair the starting motor, refer to Component Technical Manual.

ZX.TMXZCO009450-19-01AUG97

*Starting Motor*

ELECTRONIC BOARDS



ZX011524

A—Fuse board  
B—Speed monitoring board  
C—Reel function resume control board

D—Not used  
E—ContourMaster control board  
F—Reel speed board


G—Combine data center control board  
H—Relay board

J—Relay diode board  
K—Harvest performance monitor board

ZX011524 -UN-22APR97

ZX,OMXZCO002188-19-01NOV97

## FUSES ON FUSE BOARD



A—Fuse tester

B—Luminous diode


- F 1 — 7.5 A fuse, spare
- F 2 — 7.5 A fuse, spare
- F 3 — 7.5 A fuse, spare
- F 4 — 7.5 A fuse, spare
- F 5 — 15 A fuse, spare
- F 6 — 15 A fuse, spare
- F 7 — 30 A fuse, spare
- F 8 — 7.5 A fuse, fan and cylinder speed adjustment
- F 9 — 7.5 A, fuse, right parking light
- F 10 — 7.5 A fuse, left parking light
- F 11 — 30 A fuse, fan adjustment
- F 12 — 15 A fuse, brake lights, reel speed adjustment
- F 13 — 30 A fuse, work lights on cab roof
- F 14 — 7.5 A, fuse, straw warning device, electronic infotrak monitor
- F 15 — 15 A fuse, chopper distributor adjustment

- F 16 — 7.5 A fuse, engine shut-off solenoid
- F 17 — 7.5 A fuse, dash panel lighting
- F 18 — 7.5 A fuse, radio, CB, clock
- F 19 — 30 A fuse, work lights on platform and rear lights
- F 20 — 7.5 A fuse, turn signals
- F 21 — 15 A fuse, radiator cleaner
- F 22 — 7.5 A fuse, radio, CB, clock
- F 23 — 15 A fuse, separator and header clutch
- F 24 — 7.5 A fuse, indicator lights, temperature gauge
- F 25 — 7.5 A fuse, left low-beam

**IMPORTANT:** Never use fuses stronger than those specified. If fuses keep blowing in one circuit, have the electrical system inspected by your John Deere dealer.

ZX.OMXZCO002189-19-02MAY96

FUSES ON FUSE BOARD (CONTINUED)



A—Fuse tester


B—Luminous diode

- F 26 — 7.5 A fuse, cutting platform controls
- F 27 — 15 A fuse, horn
- F 28 — 7.5 A fuse, combine data center
- F 29 — 15 A fuse, combine leveling system
- F 30 — 7.5 A fuse, four-wheel drive
- F 31 — 7.5 A fuse, speed monitoring system
- F 32 — 7.5 A fuse, right-hand low beam
- F 33 — 15 A fuse, raising/lowering header
- F 34 — 15 A fuse, hazard warning flashers
- F 35 — 15 A fuse, beacon lights
- F 36 — 30 A fuse, windshield wipers, grain tank light
- F 37 — 7.5 A fuse, adjustable mirror
- F 38 — 7.5 A fuse, harvest performance monitor
- F 39 — 15 A fuse, grain tank unloading system
- F 40 — 30 A fuse, starter switch

- F 41 — 15 A fuse, concave adjustment
- F 42 — 30 A fuse, air conditioning system
- F 43 — 7.5 A fuse, DIAL-A-MATIC™
- F 44 — 7.5 A fuse, left-hand high beam
- F 45 — 15 A fuse, reel control
- F 46 — 15 A fuse, starting aid
- F 47 — 15 A fuse, spare
- F 48 — 7.5 A fuse, D+ alternator
- F 49 — 15 A fuse, cigarette lighter, power outlets, seat compressor
- F 50 — 7.5 A fuse, right-hand high beam

**IMPORTANT:** Never use fuses stronger than those specified. If fuses keep blowing in one circuit, have the electrical system inspected by your John Deere dealer.

**RELAYS ON FUSE BOARD, FROM SERIAL NO. 064253**




- K 2 — Basic relay
- K 3 — Basic relay
- K 7 — Work light relay

- K 53 — Field/road relay
- K 54 — Field/road relay
- K 55 — Separator clutch relay
- K 56 — Separator clutch relay

ZX.OMXZCO002191-19-01SEP96


**RELAY AND DIODE BOARD FROM SERIAL NUMBER 064253**



- K 4 — Buzzer timer relay
- K 5 — Flasher
- K 6 — Relay, straw warning device
- K 8 — Relay, float control
- K 9 — Hillmaster relay
- K 10 — Relay, fan speed alarm
- K 11 — Relay, cylinder speed alarm
- K 13 — Relay, lower header quickly
- K 14 — Relay, lower header slowly
- K 15 — Relay, raise header quickly
- K 16 — Relay, raise header slowly
- K 17 — Relay, lower reel
- K 18 — Relay, raise reel
- K 19 — Relay, move reel to the rear
- K 20 — Relay, move reel to the front

- K 22 — Relay, straw warning device
- K 25 — Timer relay, unloading auger swing
- K 28 — Relay, reducing feeder house speed
- K 29 — Relay, increasing feeder house speed
- K 32 — Relay, increasing reel speed
- K 33 — Relay, reducing reel speed
- K 35 — Timer relay, header drive
- K 49 — Header relay
- K 50 — Header relay
- K 51 — Unloading auger drive relay
- K 52 — Unloading auger drive relay

## RELAY AND DIODE BOARD (CONTINUED)




A 10 — Harvesting unit float control  
K 40 — Relay, leveling header to left

K 41 — Relay, leveling header to right  
K 48 — Relay, beacon light when grain tank is 3/4 full

ZX.OMXZCO006512-19-01SEP96

## ELECTRICAL BOX IN ENGINE COMPARTMENT

F 51 — 7.5 A fuse, header electrical clutch  
F 52 — 7.5 A fuse, reverse travel alarm  
K 01 — Starting motor relay  
K 42 — Relay, header electrical clutch  
K 45 — Relay D+




ZX.OMXZCO006511-19-01APR98



## ELECTRICAL BOX FOR FAN ADJUSTMENT

- K 36 — Relay, increasing speed of fan
- K 37 — Relay, decreasing speed of fan
- K 44 — Timer relay




ZX009240

ZX.OMXZC0006513-19-02MAY96

ZX009240 -JUN-23MAY96

*Main Electrical System/Relay and diode board*

WIRING HARNESS, HILLMASTER CONTROL



ZX012210

A—Control box  
B—Tilt limit switches

C—Cable connection to main  
electronic control box

D—Cable connection to  
electric valve

E—Plug connection

ZX012210 -UN-25SEP97

ZX.TMXZCO009451-19-01AUG97

## REPAIRING THE CONTROL BOX


**IMPORTANT:** Repair work inside the control box should be performed only with the control box removed from the machine. The utmost cleanliness is essential.

ZX, TMXZCO009452-19-01AUG97

## REPLACING THE DASHPOT

Disconnect piston rod (A) at pendulum. Remove dashpot cylinder and take out dashpot (B).

Install new dashpot and tighten screw connections.




ZX, TMXZCO009453-19-01AUG97

## REPLACING THE TRANSISTOR

Remove circuit board and pendulum from control box housing.

Take out the screws and unsolder transistors (A) or (B) as required. Solder on new transistor(s) using a soldering iron with a rating of 20 - 30 W.




ZX, TMXZCO009454-19-01AUG97

## REPLACING THE SWITCH ELEMENT

Disconnect piston rod at pendulum. Remove the pendulum.

Replace the switch element and re-install the pendulum.



ZX012211


ZX, TMXZCO009455-19-01AUG97

## REPLACING THE CONTROL BOX ASSEMBLY

When installing a new control box, unscrew screw (A) by 15 mm (0.6 in.) and tighten the locknut.

The screw is a transport safety device.

- I—Operating position
- II—Transport position





ZX, TMXZC0009456-19-01AUG97

Z114411  
-UN-26FEB98

## ALIGNING THE CONTROL BOX

Park the combine on a level surface and use a spirit level to align the control box.

Tighten screw (A) on the control box.



ZX, TMXZC0009457-19-01AUG97

ZX012212  
-UN-25SEP97

ZX012739  
-UN-27SEP97

## TILT LIMIT SWITCHES

R.h. and l.h. tilt limit switches are located in front of the switch levers. When one cylinder is fully extended, the tilt limit switch shuts off current to the solenoid on the levelling control valve, stopping the levelling action.

A defective tilt limit switch cannot be repaired; it must be replaced with a new one.

ZX, TMXZC0009459-19-01AUG97

## ADJUSTING THE TILT LIMIT SWITCHES

1. Start the engine and move the tumbler switch for automatic levelling control to the "manual" position.


**IMPORTANT: Make sure that the transmission is in neutral and the parking brake released before actuating the manual levelling control switch.**

2. Push manual levelling control switch at "L" until combine reaches its levelling limit (l.h. levelling cylinder fully retracted, r.h. levelling cylinder fully extended). Hold switch in "L" position for approx. 15 seconds to make sure that r.h. levelling cylinder is fully extended.

3. Loosen lock nut (A) and turn adjusting screw (B) until tilt limit switch (C) just touches the extended switch lever.

4. Turn adjusting screw (B) an additional 1-1/2 turns and tighten lock nut (A).

5. Adjust r.h. tilt limit switch in the same way.



ZX.TMXZCO009460-19-01AUG97

# Group 26 Automatic Header Control (Lateral Tilt)

## GENERAL INFORMATION

Automatic header control (lateral tilt) is available as an option with 818 - 825 cutting platforms.


ZX.TMXZCO009461-19-01AUG97

## COMPONENTS, AUTOMATIC LATERAL CONTROL


- Feeder house with pivoting shield
- Electronic board (A7)

This board is inserted between boards (D) and (E).

- A—Fuse board (A15)
- B—Speed monitor (A3)
- C—Cutting platform control board (A6)
- D—Dial-A-Matic (A2)
- E—Reel speed control (A1)
- F—On-board computer (A9)
- G—Board relay (A11)
- H—Relay for hydraulic function (A14)
- J—Board for performance monitor (A4)



ZX009882 -UN-13NOV96



ZX009881 -UN-14NOV96



ZX.TMXZCO009462-19-01AUG97

**Sensors**


The sensors operate between 350 mm and 900 mm (13.78 and 35.43 in.) above the ground.

If the sensors are raised above 900 mm (35.43 in.) by means of the cutting platform, the system switches itself off automatically.

The system is activated again when the operating height comes in range again. It can also be activated by pressing the “header float control” switch on the multi-function lever.



ZX014678



ZX.TMXZCO009463-19-02AUG97

-UN-11FEB98

ZX014678


-UN-13NOV96

ZX009883

**SETTINGS ON THE ELECTRONIC BOARD (A7)**

*NOTE: These settings are appropriate for most operating conditions.*

- 1—OFF
- 2—OFF
- 3—ON
- 4—OFF
- 5—ON



ZX014679

ZX.TMXZCO009464-19-02AUG97

-UN-13FEB98

ZX014679



Automatic Header Control (Lateral Tilt)/Settings

**SUMMARY OF POSSIBLE SETTINGS**


Switch 1	Switch 2	Switch 3	Switch 4	Switch 5	Sensitivity
OFF	OFF	OFF	OFF	ON	low
OFF	ON	OFF	OFF	ON	low
OFF	OFF	ON	OFF	ON	medium
OFF	OFF	OFF	ON	ON	high
OFF	ON	ON	ON	ON	high

ZX.TMXZC0010096-19-01AUG97



**Group 30**  
**Low Shaft Speed Monitor System**

**LOW SHAFT SPEED MONITOR SYSTEM — PROTECTED COMPONENTS**



ZX007938

ZX.OMXZC0001971-19-02MAY96

*Low Shaft Speed Monitor System/Low shaft speed monitor system*

A—Straw chopper/chaff  
spreader (option)  
B—Tailings elevator  
C—Straw walkers

C1—With cross-shaker  
C2—Without cross-shaker  
D—Clean grain elevator

E—Fan  
F—Threshing cylinder  
F1—Second cylinder with  
constant speed

F2—Second cylinder with  
variable speed

In the event of a malfunction, the low shaft speed monitor system activates corner post indicator lights and a continuous acoustic warning signal.

*NOTE: Reset the alarm threshold at the infotrak monitor every time the threshing cylinder and/or fan speed are altered.*

With engine shut off, electrical circuit on and separator engaged, all five or six indicator lights must glow and the warning signal must sound. With engine running (at fast idle) and separator engaged, all indicator lights should go out and the warning signal cease.




ZX,OMXZC0001988-19-13NOV92

### SETTING THRESHING CYLINDER ALARM SPEED

With engine running, engage separator.

Press key (A) to display cylinder speed. Continue to press key (A) (for approx. 2 seconds) until an "A" appears at the last digit of the displayed speed. Now alarm speed is 75% of the displayed speed.

If cylinder speed drops below alarm speed during operation, the cylinder speed indicator light will glow and a continuous warning signal will be heard.



ZX 002354

ZX,OMXZC0001520-19-14NOV92




-UN-16JUN95  
ZX002354

### SETTING FAN ALARM SPEED

With engine running, engage separator.

Press key (A) to display fan speed. Continue to press key (A) (for approx. 2 seconds) until an "A" appears at the last digit of the displayed speed. Now alarm speed is 75% of the displayed speed.

If fan speed drops below alarm speed during operation, the fan speed indicator light will glow and a continuous warning signal will be heard.




ZX 002469

ZX,OMXZC0001833-19-14NOV92

-UN-16JUN95  
ZX002469

HARVEST PERFORMANCE MONITOR



ZX007939

A—Cleaning shoe sensor  
B—Straw walker sensors

C—Display unit

D—Adjusting/selecting unit

E—Ground speed sensor

ZX.OMXZCO001973-19-02MAY96

**General Description**

The harvest performance monitor records the amount of grains that hit its sensors at the cleaning shoe (A) and straw walkers (B). Ground speed is measured via sensor (E). Once this factor has been taken into account, the loss rate is displayed at display unit (C). Display unit (C) indicates the loss level that is acceptable to the user in relation to the area harvested.

The performance monitor enables the operator to use maximum combine capacity within the performance


range selected by him. After the operator has adjusted the combine and cutting platform to suit the harvesting conditions, he must set the monitor to these conditions by means of the adjusting/selecting unit (D).

Incorrect adjustment and inadequate servicing of the combine always result in grain loss and reduced harvester performance. The causes of grain loss are dealt with in detail in the "Preparations and Field Operation" section. Particular attention should be paid to the information provided on "Determining Grain Losses" and "Prevention of Grain Losses — General".

ZX,OMXZC0001974-19-02MAY96

**PRELIMINARY ADJUSTMENTS ON COMBINE HARVESTER**

Before performing any adjustments on the harvest performance monitor, adjust the combine so that it is operating at peak efficiency. The adjustments must correspond to the relevant crop and field conditions.



Z109503

-UN-22MAY95


Z109503

ZX,TMXZC0010097-19-01AUG97



**SWITCHING ON THE HARVEST PERFORMANCE MONITOR**

The system can operate only when the

- engine is running (I)
- road safety switch is in the field position (II)
- threshing unit is engaged (III)
- harvest performance monitor is switched on (IV)



ZX009171



-UN-22MAY96  
ZX009171

ZX,OMXZC0001976-19-02MAY96



## OPERATIONAL ADJUSTMENT OF HARVEST PERFORMANCE MONITOR

Precondition: combine harvester is adjusted to peak efficiency.

While threshing, adjust potentiometers (A) and (B) one after the other so that the needle on display unit (C) moves to the center of the green sector (X) when there are grain losses.

I — Set potentiometer for straw walker losses:

- Use potentiometer (A) to bring the needle into the green sector (X).



II — Set potentiometer for cleaning shoe losses:

- Use potentiometer (B) to bring the needle into the green sector (X).

Grain losses vary all the time. This means that the sensors on the cleaning shoe and straw walkers will transmit signals of varying intensity to the display unit. If these signals rise or fall in relation to the preset value, the needle on the display unit will swing to the left or right.

**NOTE:** If no losses occur (and therefore none are displayed) even at maximum sensitivity, leave the two potentiometers (A) and (B) set no higher than the "two o'clock" position.

- A—Potentiometer for straw walker sensitivity
- B—Potentiometer for cleaning shoe sensitivity
- C—Display unit
- X—Green sector



ZX.OMXZC0001980-19-02MAY96

## OPERATIONAL ADJUSTMENT OF HARVEST PERFORMANCE MONITOR (CONTINUED)

1. If the needle moves towards “—” and stays there for more than 20 seconds, the combine harvester’s ground speed is too low, i.e the harvester is not working hard enough. In this case, increase the combine harvester’s ground speed until the needle returns to the center of the green sector.
2. If the needle moves towards “+” and stays there for more than 20 seconds, the combine harvester’s ground speed is too high and grain losses are increasing. Reduce the combine harvester’s ground speed until the needle returns to the green sector.
3. If the needle remains in the “+” sector even after ground speed has been reduced, this may be due to plugging at the straw walkers or sieve (cleaning shoe). In this case, check which of these components is causing the blockage by selecting them with the selector switch. If necessary, clean the relevant component. Once an acceptable performance level has been achieved, adjust the potentiometers of the display unit as described above.
4. If the harvesting conditions change during the course of the day (straw lying down or damp), or if the machine adjustment changes (fan speed), re-adjust the performance monitor. The sieve sensors may be moved fore-and-aft to any one of the three cut-outs in the sensor mountings (on right and left sides of combine).
5. Measure the losses from time to time to determine whether the combine harvester needs to be re-adjusted.




Sensor mounting, left



Sensor mounting, right

ZX,OMXZC0001981-19-01APR98

**SETTING SENSOR SENSITIVITY**



ZX014272

ZX014272 -UN-09FEB98

Sensor sensitivity is preselected in the cab at the adjusting/selecting unit of harvest performance monitor (A).

X — Higher sensor sensitivity for finer grain crops

Y — Medium sensor sensitivity for medium grain crops (covers a wide range of standard crops)  
 Z — Lower sensor sensitivity for coarse grain crops

*NOTE: Always leave the sieve and straw walker sensors at a medium setting.*

ZX,OMXZCO001978-19-01APR98

## OPERATIONAL CHECK OF HARVEST PERFORMANCE MONITOR

**CAUTION:** Before carrying out the operational check, remove fuse F23. This prevents the cylinder from being switched on while at the same time ensuring that the harvest performance monitor is supplied with power.

Start the engine.  
Put road safety switch in field position.  
Switch threshing unit to ON position.

### I — Check straw walker sensors:



- Turn potentiometer (A) clockwise as far as it will go.
- Set selector switch (B) to the position for medium-sized grains.
- Rotary switch (C) should be in the medium position at both sides.
- Actuate the left and right straw walker sensors by tapping them lightly with a hard object or by dropping kernels on them. A second person is required to observe the needle at the display. The needle must be seen to move.

### II — Check cleaning shoe sensor:



- Turn potentiometer (D) clockwise as far as it will go.
- Set selector switch (B) to the position for medium-sized grains.
- Tumbler switch (E) should be in the middle position.
- Check cleaning shoe sensor in the same way as the straw walker sensors.
- Switch on the parking light and check whether the display light is on.
- Switch off the parking light. Disengage the threshing unit and remove the switch key.
- If a fault occurs during the check described above, have the fault rectified by your John Deere dealer.

**NOTE:** Once the operational check is completed, put fuse F23 back in place.

- A—Potentiometer for straw walker sensitivity
- B—Selector switch
- C—Rotary switch
- D—Potentiometer for cleaning shoe sensitivity
- E—Tumbler switch



ZX009174



ZX009534

-UN-22MAY96  
ZX009174

-UN-08NOV96  
ZX009534

ZX.OMXZCO001982-19-01NOV96

# Section 50 Power Train

## Contents


	Page	Page	
<b>Group 05—Intermediate Transmission</b>			
Special tool (self-manufacture) . . . . .	50-05-1	Hydrostatic drive components . . . . .	50-25-4
Intermediate transmission and components . . . . .	50-05-2	Remove variable pump . . . . .	50-25-5
Removing intermediate transmission . . . . .	50-05-3	Remove servo control valve . . . . .	50-25-8
Components of intermediate transmission . . . . .	50-05-6	Remove charge pump . . . . .	50-25-8
General assembly instructions . . . . .	50-05-7	Remove check valve . . . . .	50-25-8
Installing 62-tooth central gear . . . . .	50-05-7	Remove end cap . . . . .	50-25-9
Adjusting axial play of hollow shaft . . . . .	50-05-8	Remove bearing . . . . .	50-25-9
Input housing assembly . . . . .	50-05-9	Remove servo cylinders . . . . .	50-25-10
Installing 25-tooth pinion . . . . .	50-05-9	Remove front cover . . . . .	50-25-10
Adjusting axial play at pinion . . . . .	50-05-10	Remove servo piston . . . . .	50-25-11
Assembling intermediate transmission . . . . .	50-05-10	Remove swashplate . . . . .	50-25-11
Installing intermediate transmission . . . . .	50-05-11	Disassemble swashplate . . . . .	50-25-12
Installing belt pulley . . . . .	50-05-11	Exploded view of swashplate . . . . .	50-25-12
Adjusting belt guide . . . . .	50-05-11	Replace spring in cylinder block . . . . .	50-25-13
<b>Group 10—Transmission and Differential</b>			
Removing the transmission . . . . .	50-10-3	Repair variable pump . . . . .	50-25-13
Removing shifter fork and cam . . . . .	50-10-4	Check parts for wear . . . . .	50-25-14
Installing shifter forks . . . . .	50-10-5	Assemble and install swashplate . . . . .	50-25-15
Installing the front cover . . . . .	50-10-6	Check rolling drag torque . . . . .	50-25-16
Remove/install transmission lube pump . . . . .	50-10-6	Install servo piston . . . . .	50-25-16
Removing the pinion shaft . . . . .	50-10-12	Install servo cylinder . . . . .	50-25-17
Disassembling the differential . . . . .	50-10-16	Attach front cover . . . . .	50-25-17
Installing the transmission . . . . .	50-10-20	Check drive shaft bearing end play . . . . .	50-25-18
<b>Group 15—Planetary Final Drives</b>			
Special tools . . . . .	50-15-1	Install end cap . . . . .	50-25-18
Service equipment and tools . . . . .	50-15-1	Install check valves . . . . .	50-25-19
Specifications . . . . .	50-15-3	Install charge pump . . . . .	50-25-19
Remove and install final drive . . . . .	50-15-4	Install servo-control valve . . . . .	50-25-19
Disassemble and assemble final drive . . . . .	50-15-7	Overhaul the seal set . . . . .	50-25-20
<b>Group 20—Final Drives</b>			
Special tools . . . . .	50-20-1	Install seal set . . . . .	50-25-21
Remove and install final drive . . . . .	50-20-4	Repairing the control valve . . . . .	50-25-22
Disassemble and assemble final drive . . . . .	50-20-8	Repairing the charge pump . . . . .	50-25-24
Adjust spindle bearing (alternative method) . . . . .	50-20-17	Install hydrostatic pump . . . . .	50-25-25
<b>Group 25—Hydrostatic Drive, Variable Pump</b>			
Special tools . . . . .	50-25-1	Installing the control cable . . . . .	50-25-25
Specifications . . . . .	50-25-3	<b>Group 30 —Hydrostatic Drive, Fixed-Displacement Motor</b>	
		Specifications . . . . .	50-30-1
		Remove fixed-displacement motor . . . . .	50-30-1
		Disassemble fixed-displacement motor . . . . .	50-30-2
		Remove valve block . . . . .	50-30-2
		Exploded view of valve block . . . . .	50-30-3
		Assemble valve block . . . . .	50-30-3
		Remove end cap . . . . .	50-30-4

Continued on next page

Contents

	Page
Remove bearing . . . . .	50-30-4
Remove swashplate . . . . .	50-30-5
Disassemble swashplate . . . . .	50-30-5
Swashplate assembly, exploded view . . . . .	50-30-6
Replace cylinder block spring . . . . .	50-30-7
Repair fixed-displacement motor . . . . .	50-30-7
Assemble fixed-displacement motor . . . . .	50-30-8
Check parts for wear . . . . .	50-30-8
Check drive shaft axial play . . . . .	50-30-9
Install fixed-displacement motor . . . . .	50-30-9
 <b>Group 35—Hydrostatic Drive, Oil Change</b>	
Specifications . . . . .	50-35-1
Drain the oil . . . . .	50-35-1
Refill hydrostatic drive . . . . .	50-35-2
 <b>Group 40—Cam Lobe Motor</b>	
Specifications . . . . .	50-40-1
Four-wheel drive . . . . .	50-40-2
Installing the cam lobe motor . . . . .	50-40-3

**SPECIAL TOOL (SELF-MANUFACTURE)**



A—125 mm (4.9 in.) dia.  
B—116 mm (4.6 in.)  
C—85 mm (3.35 in.) dia.

D—91 mm (3.6 in.) dia.  
E—99 mm (3.9 in.) dia.


F—30 mm (1.2 in.)  
G—23 mm (0.9 in.)

H—3 mm (0.12 in.)  
J—6 mm (0.24 in.)

Tool for pulling sealing ring into input housing

ZX, TMXZCO003945-19-15FEB95

### INTERMEDIATE TRANSMISSION AND COMPONENTS



A—Engine flywheel  
B—Input shaft

C—Triple hydraulic pump  
D—Countershaft pulley

E—Hydrostatic pump  
F—Additional pulley

G—Hollow shaft

-UN-28APR95  
ZX005436


ZX, TMXZCO003946-19-15FEB95



## REMOVING THE INTERMEDIATE TRANSMISSION

Drain oil. Capacity is 2.4 liter (0.63 US gal.).

Remove muffler assembly.



ZX, TMXZCO003947-19-15FEB95

**IMPORTANT: Do not disconnect any pressure hoses.**


Remove hydrostatic pump and secure it so that it cannot fall.



ZX, TMXZCO003949-19-15FEB95

**IMPORTANT: Do NOT disconnect the suction lines and the two pressure lines.**

Remove the triple hydraulic pump. Disconnect one pressure hose to gain access to the attaching nut.




ZX, TMXZCO003950-19-15FEB95

Intermediate Transmission/Removing intermediate transmission

Remove tensioning screw (B) and take off spring (A).

Remove tensioning roller by taking out screw (C), and disengage cylinder (D).




-UN-21APR95  
ZX005434

ZX, TMXZCO003951-19-15FEB95

Remove engine pulley.

On 2264 and 2266 combines, first remove the additional pulley.




-UN-21APR95  
ZX005433

ZXTMXZCO 011381-19-05MAR98


Unbolt intermediate transmission from engine.

Unbolt sealing plate (E) at both ends of the intermediate transmission.

- E—Sealing plate
- F—Sealing strip



-UN-28APR95  
ZX005426




-UN-28APR95  
ZX005428

ZX, TMXZCO003953-19-15FEB95

## Intermediate Transmission/Removing intermediate transmission

Remove snap ring (G) from hollow shaft and use an M10x50 screw to pull the drive shaft out of the hollow shaft.

Take the two screws out of the engine mounting.




ZX, TMXZCO003954-19-15FEB95

-UN-21APR95  
ZX005439

Raise engine slightly at the intermediate transmission end to relieve pressure.

Place wooden blocks under the engine at left and right, and lower engine onto them.




ZX, TMXZCO003955-19-15FEB95

-UN-21APR95  
ZX005440

**⚠ CAUTION: Intermediate transmission box weighs 130 kg (286.6 lb).**


Secure the intermediate transmission with a wire rope and use a hoist to lift it out.



ZX, TMXZCO003956-19-15FEB95

-UN-21APR95  
ZX005441

**COMPONENTS OF INTERMEDIATE TRANSMISSION**



ZX005442

ZX005442 -UN-28APR95

- |                        |                        |                |                |
|------------------------|------------------------|----------------|----------------|
| A—Housing              | F—Bearing ring         | L—Retainer     | S—Drive shaft  |
| B—Seal ring            | G—Seal                 | M—Pinion       | T—Oil dipstick |
| C—Locking plate        | H—Taper roller bearing | N—Shims        | U—Housing      |
| D—Gear                 | J—Gear                 | P—Cover        | V—O-ring       |
| E—Taper roller bearing | K—Shaft                | R—Hollow shaft | W—Steel ring   |

ZX, TMXZC0003957-19-15FEB95

## GENERAL ASSEMBLY INSTRUCTIONS

Before assembling, coat all bearings with SAE 90 oil.

Before assembling, coat the lips of the seal rings with FWA 160 grease.

ZX, TMXZCO003958-19-15FEB95

## INSTALLING 62-TOOTH CENTRAL GEAR


Install steel ring (D) in gear (C).

Insert taper roller bearings (B) and (E).

Place O-ring (A) in housing and O-ring (G) on shaft (F). Apply grease to both O-rings.

Insert gear (C) and install it together with shaft (F) and screw (J). Tighten to 54 N·m (40 lb-ft) and secure with retainer (H).

Turn shaft so that end of shaft can engage in input housing.



ZX005423

- A—O-ring
- B—Taper roller bearing
- C—Gear (62-tooth)
- D—Steel ring
- E—Taper roller bearing
- F—Shaft
- G—O-ring
- H—Retainer
- J—M10x110 screw

ZX005423 -UN-28APR95

ZX, TMXZCO003959-19-15FEB95

## ADJUSTING AXIAL PLAY OF HOLLOW SHAFT

Insert hollow shaft (L) with seal ring (K) and two taper roller bearings (D) and (J), plus the 36-tooth gear (C) into input housing (G).


Use locking plate (B) to press the assembly together.

The self-made special tool is required to press seal ring (K) into the housing.

Slacken off locking plate and retighten it until there is a clearance of 0.03 - 0.08 mm (0.0012 - 0.0031 in).


Use hex. socket screw (M) to secure the locking plate. Coat screw with Loctite 243 and tighten it to 30 N·m (22 lb-ft).

- A—Seal ring
- B—Locking plate
- C—Gear (36-tooth)
- D—Taper roller bearing
- E—Bearing ring
- F—Seal
- G—Housing
- H—Bearing ring
- J—Taper roller bearing
- K—Seal ring
- L—Hollow shaft
- M—M8x25 hex. socket screw




ZX005419

ZX005419 -UN-28APR95



ZX 005420

ZX005420 -UN-21APR95



ZX005421

ZX005421 -UN-21APR95


ZX, TMXZCO003960-19-15FEB95

## INSTALLING THE INPUT HOUSING ASSEMBLY

**IMPORTANT:** Four guide pins (A) must be installed to prevent the seal ring being damaged during installation. (Make the guide pins yourself).

Slide the assembly evenly over the guide pins and onto the housing.

Bolt the assembly to the housing. Coat the bolts with Loctite 243, and tighten them to 54 N·m (40 lb-ft).



ZX005422 -UN-21APR95

ZX, TMXZCO003961-19-15FEB95


## INSTALLING 25-TOOTH PINION

Install bearing ring (A) in housing.

Install the two taper roller bearings (B) and (D) on the pinion, and insert into housing.

Install bearing ring (E) and seal ring (F) on the cover. Install cover with the word "TOP" facing upward.

Coat screws with Loctite 243 and tighten them to 54 N·m (40 lb-ft).



ZX005424


ZX005424 -UN-28APR95

- A—Bearing ring
- B—Taper roller bearing
- C—Pinion (25-tooth)
- D—Taper roller bearing
- E—Bearing ring
- F—Seal ring
- G—Shims 0.10; 0.15; 0.25; 0.5 mm  
(0.004; 0.006; 0.01; 0.02 in.)
- H—Cover

ZX, TMXZCO003962-19-15FEB95

### ADJUSTING AXIAL PLAY AT PINION


Install cover with shims so that there is a clearance of 0.05 - 0.13 mm (0.002 - 0.005 in).



ZX005425 -UN-21APR95

ZX, TMXZCO003963-19-15FEB95

### ASSEMBLY OF INTERMEDIATE TRANSMISSION



ZX005435

ZX005435 -UN-28APR95

- |                 |                        |                        |                 |
|-----------------|------------------------|------------------------|-----------------|
| A—Hollow shaft  | E—Locking plate        | K—Taper roller bearing | O—Shaft         |
| B—Input housing | F—Hex. socket screw    | L—Shims                | P—M10x110 screw |
| C—Seal          | H—Taper roller bearing | M—62-tooth gear        | Q—Retainer      |
| D—36-tooth gear | J—25-tooth pinion      | N—Taper roller bearing |                 |

ZX, TMXZCO003964-19-15FEB95



## INSTALLING THE INTERMEDIATE TRANSMISSION

To install, follow the removal procedure in reverse.

Fill with oil. Capacity is 2.4 liter (0.63 US gal.) Oil must meet SAE 90 SCL. Check level at dispstick.


ZX, TMXZCO003965-19-15FEB95

## INSTALLING BELT PULLEY

To facilitate installation, screw two M12x120 studs into the hollow shaft.

Put on pulley, and locate it centrally. Then remove studs and tighten the attaching screws.

- A—Engine pulley
- B—Additional pulley for 2264 and 2266
- C—Drive belt
- D—Screw
- E—Spring washer



ZXTMXZCO 011382-19-05MAR98

ZX005427 -UN-28APR95

## ADJUSTING BELT GUIDE

See description in Section 20-05.

ZX, TMXZCO003967-19-15FEB95

*Intermediate Transmission/Adjusting belt guide*

**Group 10**  
**Transmission and Differential**

**OTHER MATERIAL**

<b>Number</b>	<b>Name</b>	<b>Use</b>
TY15130	Form-In-Place Gasket	To seal hydrostatic adapter and front cover to transmission
T43512	Thread Lock and Sealer (medium strength)	To coat threads of cap screws on differential ring gear and on pump housing
TY9374	Thread Sealer	To coat threads of lube pump, bearing cap and differential cradle

ZX, TMSPFH000054-19-01AUG97

## SPECIFICATIONS

Item	Measurement	Specification
Brake assembly-to-transmission cap screws	Torque	620 N·m (460 lb-ft)
Hydrostatic transmission adapter-to-transmission cap screws	Torque	320 N·m (235 lb-ft)
Transmission mounting cap screws	Torque	320 N·m (235 lb-ft)
Differential cradle-to-transmission cap screws	Torque	320 N·m (235 lb-ft)
Ring gear-to-differential cap screws	Torque	130 N·m (97 lb-ft)
Transmission cover-to-transmission cap screws	Torque	75 N·m (55 lb-ft)
Transmission lube pump-to-transmission cap screws	Torque	75 N·m (55 lb-ft)
Input and pinion shaft orifices	Torque	17 N·m (12 lb-ft)
Shifter cam	End play	0.00—0.25 mm (0.00—0.01 in.)
Differential	Preload	0.08—0.25 mm (0.003—0.010 in.)
Pinion shaft	Preload	0.127 mm (0.005 in.)
Input shaft	End play	0.01—0.20 mm (0.0005—0.008 in.)


ZX.TMXZCO010113-19-01AUG97

## DRAIN OIL, REMOVE SUCTION SCREEN


Slide tubes (A) and (B) towards pump (C).

Loosen screw (D) and pull out suction screen.

Catch escaping oil in a suitable container.



-UN-21APR95  
ZX000066




-UN-21APR95  
ZX000067

ZX.TMSPFH000263-19-22JAN91

## REMOVE TRANSMISSION

**⚠ CAUTION: The transmission is heavy (300 kg; 675 lb). Danger of accidents!**

1. Remove drive shafts (A).
2. Remove brake drums (B). Disconnect parking brake cable and brake line (C).
3. Disconnect shift cable (D) from transmission. Disconnect electrical cable to speed sensor.
4. Remove hydrostatic motor and suspend on machine frame.
5. Safely support transmission using a trolley jack. Loosen four attaching screws and roll transmission away from bottom of machine.




-UN-21APR95  
ZX000095

ZX.TMSPFH000264-19-22JUL91

## REMOVE AND REPAIR SHIFTER FORKS AND SHIFTER CAM

**NOTE:** Shifter fork and shifter cam can be replaced without removing transmission.

1. Remove front cover and hydrostatic transmission adapter (A).
2. Remove dowel pin (B).




3. Remove rail (A) and shifter forks (B) and (C).

4. Inspect shifter cam to be certain grooves are free of burrs and there are no flat spots. Also inspect mating shifting surfaces on shifter rail.


Replace shifter forks or rollers (D) if they appear damaged or worn.

5. When replacing a roller (D) or pin, press pin flush with roller. Roller must be able to turn freely on pin. The usual cause for a roller pin to break is clash shifting.

6. Inspect all shift collars in the transmission for wear. They can cause the transmission to "jump" out of gear damaging shift forks. Incorrectly adjusted shift linkage can cause excessive wear to shift collars.




- A—Rail
- B—Shifter Fork
- C—Shifter Fork
- D—Rollers
- E—Front Cover
- F—Spring
- G—Detent Ball
- H—Shifter Cam
- I—O-Ring
- K—Washer
- L—Lever
- M—Spring Pin



ZX.TMSPFH000057-19-22JAN91

## INSTALL SHIFTER FORKS



ZX 000071

A—Shifter Fork  
B—Shifter Fork

C—Roller (2 used)  
D—Pin (2 used)

E—Rail  
F—Dowel Pin

G—Cap

1. Install rollers and pins (C) and (D).  
Roller must turn freely on pin and pin must be flush with top of roller.

2. Install shifter forks (A) and (B) on shifter rail (E) and install dowel pin (F).

3. Check for adequate shifter fork movement. All gears must turn freely when transmission is turned by hand.


*NOTE: Apply 1.5 mm (0.06 in.) bead flexible sealant to counterbore of housing when installing cap (G).*

ZX.TMSPFH000058-19-22JUL91

ZX000071 -JUN-02MAY95

## INSTALL FRONT COVER WITH SHIFTER CAM

1. Install detent ball (G). Ball must rest against spring (F). Install lever (L) with washer and O-ring. Install spring pin (M).
2. Adjust cam and arm to 0.00—0.25 mm (0.00—0.01 in.) endplay.
3. Apply a continuous 1.5 mm (0.06 in.) wide bead of form-in-place gasket to transmission housing. Install front cover (E) and tighten cap screws to 75 N·m (55 lb-ft).
4. Fill transmission with 9.6 l (2.5 US gal.) of recommended lubricant.



ZX000070

- E—Front Cover
- F—Spring
- G—Detent Ball
- H—Shifter Cam
- I—O-Ring
- K—Washer
- L—Lever
- M—Spring Pin


ZX.TMSPFH000059-19-22JUL91

-UN-28APR95  
ZX000070

## REMOVE AND INSTALL TRANSMISSION LUBE PUMP

**NOTE:** If pump is not delivering at least 100 kPa (1.0 bar) (15 psi) oil pressure, it must be repaired.

1. Slide tubes (A) out of pinion carrier and block.
2. Remove three cap screws to remove pump (B).



ZX000072

ZX.TMSPFH000060-19-22JUL91

-UN-21APR95  
ZX000072



3. Carefully pull pump away from transmission to catch drive pin which usually will fall from drive shaft. Be careful not to disturb shim pack.


4. Repair or replace pump as necessary. If a new pump housing is installed, the shim pack must be checked. If necessary, remove or add shims (see Transmission Assembly in this Group).

5. Install shim pack (G) with lube pump housing. Tighten cap screws to 75 N·m (55 lb-ft).

6. Install O-ring. Install lube pump with shim pack determined previously.

7. Apply thread lock and sealer (T43512) to cap screw threads. Install cap screws and tighten to 75 N·m (55 lb-ft).

8. Slide oil tubes into pinion carrier and block.




**ZX 000073**

- A—Bearing Cap
- B—Spring Washer
- C—Bushing
- D—Liner
- E—Gear Pump
- F—O-Ring
- G—Shim
- H—Pump Housing

ZX000073 -UN-28APR95

ZX, TMSPFH000277-19-01AUG97

### TRANSMISSION COMPONENTS



H40090 -JUN-10OCT88

1401,5005,O -19-12SEP91

Transmission and Differential/Remove/install transmission lube pump

1—Housing	18—Snap Ring	36—Pin	55—Pin
2—Washer	19—Cup	37—Input Shaft	56—Shift Rail
3—Snap Ring (4 used)	20—Bearing	38—Key (2 used)	57—Hydrostatic Motor Mount
4—Bearing	21—Cap	39—Orifice (2 used)	58—Stud (4 used)
5—Cup	22—Gear	40—Gear	59—Cap Screw M16 x 45 (4 used)
6—O-Ring (2 used)	23—Screen	41—Gear	60—Breather
7—Shim (as required)	24—Fitting	42—Shift Collar (2 used)	61—Shift Fork
8—Pinion Carrier	25—Cap Screw, M10 x 40	43—Snap Ring	62—Roller (2 used)
9—Cap Screw, M10 x 30 (3 used)	26—Oil Tube	44—Bearing	63—Pin (2 used)
10—O-Ring (8 used)	27—Cap Screw, M10 x 30 (12 used)	45—Cup	64—Shifter
11—Oil Tube	28—O-Ring	46—O-Ring	65—Yoke
12—Cap	29—Spring Pin	47—Snap Ring	66—Cap Screw, M10 x 25 (3 used)
13—Plug	30—Shift Arm	48—Cap	67—Cap Screw, M16, with nut (2 used)
14—Cap Screw, M10 x 30 (3 used)	31—Washer	49—Cup	68—Cap Screw, M16, with nut (2 used)
15—Gear	32—Shift Cam	50—Bearing	
16—Plate	33—Spring	51—Pinion	
17—Washer	34—Detent Ball	52—Gear	
	35—Pin (2 used)	53—Gear	
		54—Gear	

Legend for Transmission Components

1401,HX,5005,B -19-11DEC92

## TRANSMISSION RECONDITION

Transmission recondition includes the input shaft and the pinion shaft.


Refer to shifter forks and shifter cam for removal.

Refer to transmission lube pump for its removal. Remove oil screen.

Remove the remaining bearing carrier on the side of transmission.

1401,5005,Q -19-12SEP91

## DISASSEMBLE AND REPAIR TRANSMISSION



- |                   |                       |                   |                        |
|-------------------|-----------------------|-------------------|------------------------|
| 1—Rotor           | 10—Plug               | 19—Breather       | 28—Gear                |
| 2—Plate           | 11—Tube               | 20—Screw (4 used) | 29—Key                 |
| 3—Washer          | 12—Shim (as required) | 21—Stud (4 used)  | 30—Dowel Pin           |
| 4—Bushing         | 13—O-Ring             | 22—Rail           | 31—Orifice             |
| 5—Bearing         | 14—Tube               | 23—Bearing Cup    | 32—Shaft               |
| 6—Bearing cone    | 15—Cap Screw          | 24—Bearing Cone   | 33—Input Shaft         |
| 7—O-Ring (8 used) | 16—Fitting            | 25—Snap Ring      | 34—Coupling            |
| 8—Oil Pump        | 17—O-Ring (2 used)    | 26—Shift Collar   | 35—Snap Ring (2 used)  |
| 9—Screw (3 used)  | 18—Screen             | 27—Shift Collar   | 36—Flange Nut (4 used) |


Input Shaft Assembly

HX.1401,5005,H -19-11DEC92

HP3771 -JUN-27OCT89

*Transmission and Differential/Remove/install transmission lube pump*


1. Remove shifter forks. (See procedure in this group.)
2. Remove lube pump. (See procedure in this group.)
3. Remove hydrostatic motor. (See procedure in this group.)
4. Remove input shaft assembly.
5. Press bearings off both ends of shaft.



H40167  
-UN-13JAN89


ZX,1401,5005,S -19-01AUG97

6. Remove snap ring from shift collar end of shaft.
7. Press (A) off shaft and slide gear (C) and shift collar (B) off shaft.
8. Check orifice (31) and oil passage through input shaft for restriction. Clean thoroughly. Torque orifice to 17 N-m (12 lb-ft).
9. Replace parts as necessary.
10. Assemble input shaft parts.



H40168  
-UN-13JAN89

HX1401,5005,E -19-13SEP94



H40169 -UN-13JAN89

A—Lube Pump Drive Pin  
B—Bearing Cone  
C—Input Shaft

D—Gear  
E—Shift Collar

F—Gear  
G—Snap Ring

H—Bearing Cone  
I—Key

1401,5005,U -19-12SEP91

## REMOVE PINION SHAFT


Remove attaching screws and lift off bearing cap (A).

Remove snap ring (B).


Drive out bearing cap (C) by tapping lightly on shaft with a lead hammer.

**NOTE:** For pinion shaft removal and installation, bearing supports of differential must be removed.

*Slightly turn differential to the side.*




ZX000074 -UN-21APR95



ZX000075 -UN-21APR95

ZX,TMSPFH000265-19-01AUG97

Transmission and Differential/Removing the pinion shaft



- |                      |                      |                 |                 |
|----------------------|----------------------|-----------------|-----------------|
| 1—Pinion Carrier     | 7—Snap Ring (4 used) | 13—Gear         | 18—Bearing Cone |
| 2—Cap Screw (3 used) | 8—Washer             | 14—Key          | 19—Bearing Cup  |
| 3—Shim (as required) | 9—Gear               | 15—Orifice      | 20—Bearing Cup  |
| 4—O-Ring             | 10—Gear              | 16—Pinion       | 21—O-Ring       |
| 5—Bearing Cup        | 11—Shift Collar      | 17—Pinion Shaft | 22—Snap Ring    |
| 6—Bearing Cone       | 12—Gear              |                 |                 |

Pinion Shaft Assembly

1401,5005,V -19-12SEP91


H40588 -UN-31MAY89

1. Remove right hand differential bearing carrier to allow removal of the pinion shaft.

*NOTE: Move gear end of differential toward rear of transmission.*

2. Press bearings off both ends of shaft.


3. Remove snap rings (7) to remove gears.



ZX,1401,5005,F -19-01AUG97

H40170 -UN-13JAN89

4. Press gear off shaft.
5. Check orifice (15) and oil passage through pinion shaft (16) for restriction. Clean thoroughly. Torque orifice to 17 N·m (12 lb-ft).
6. Replace parts as necessary.
7. Assemble parts on shaft.



H40171  
-UN-13JAN89

ZX,1401,5005,G -19-01AUG97


## REMOVE DIFFERENTIAL

Remove screws (A) and anchor plate (B) on both sides. Turn out sensor (E).

Remove screws (C) and bearing support (D) on both sides.


Remove countershaft and differential from transmission case.

- A—Anchor plate attaching screws
- B—Anchor plate
- C—Bearing support attaching screws
- D—Differential bearing supports
- E—Ground speed sensor



ZX 000076

ZX000076  
-UN-21APR95




ZX 000077

ZX000077  
-UN-21APR95

ZX,TMXZCO010114-19-01AUG97



Transmission and Differential/Removing the pinion shaft



- |                                 |                                  |                           |                             |
|---------------------------------|----------------------------------|---------------------------|-----------------------------|
| 1—Seal (2 used)                 | 7—O-Ring (2 used)                | 12—Shim (as required)     | 18—Snap Ring (2 used)       |
| 2—Snap Ring (4 used)            | 8—Bearing Cone (2 used)          | 13—Housing                | 19—Needle Bearing (52 used) |
| 3—Roller Bearing (2 used)       | 9—Cup (2 used)                   | 14—Thrust Washer (2 used) | 20—Washer (2 used)          |
| 4—Drive Shaft (2 used)          | 10—Cap Screw, M12 x 35 (14 used) | 15—Thrust Washer (2 used) | 21—Gear (2 used)            |
| 5—Cap Screw, M16 x 45 (12 used) | 11—Ring Gear                     | 16—Pinion (2 used)        | 22—Pin                      |
| 6—Cradle (2 used)               |                                  | 17—Thrust Washer (2 used) | 23—Spring Pin               |

Differential

1401,5005,Y -19-12SEP91

H40220 -JUN-17APR89

**CAUTION:** Use a lifting device for heavy components.

**IMPORTANT:** Do not damage plastic or aluminum shims between transmission case and cradles.

- Remove drive shafts and remove cradles.
- Remove snap ring (B) to remove bearing (A).



H40176 -UN-13JAN89

ZX,1401,5005,H -19-01AUG97

## DISASSEMBLE DIFFERENTIAL

Remove ring gear.



H40175 -UN-15MAR89

ZX,TMXZCO010115-19-01AUG97

Drive out spring pin.



H40177 -UN-13JAN89

ZX,TMSPFH000270-19-22JAN91

Remove snap rings.

Take out differential components.



H40178 -UN-13JAN89

ZX,TMSPFH000271-19-22JAN91

### ASSEMBLE DIFFERENTIAL

1. Pack all bearings with grease. Apply a light coat of grease to housing before pressing in bearing cups.

2. Coat thrust surfaces and bores of bevel gears and pinion gears with oil. Thrust washers must be tabbed into housing on early differentials. On later differentials, no tabbing is required.

3. Install bevel gears, pinion gears, thrust washers, and differential pins. Install snap rings. All gears must rotate freely.



H40178 -UN-13JAN89

ZX,1401,5005,L -19-01AUG97

4. Install ring gear. Apply thread lock and sealer (medium strength) to cap screw threads. Install cap screws and tighten to 130 N·m (97 lb-ft).



H40175 -UN-15MAR89

ZX,1401,5005,M -19-01AUG97

5. Install inner snap ring and press bearing cone (A) into cradle. Install outer snap ring (B) and install shaft seal. Press flush with housing. Apply multipurpose grease to seal lip.



H40176 -UN-13JAN89


ZX,1401,5005,N -19-01AUG97

## ASSEMBLE TRANSMISSION

**CAUTION:** Use a lifting device for heavy components.

1. Install differential (A) in transmission case. Use a board (B) to position differential.

*NOTE: Move the gear end of differential toward rear of transmission to allow installation of pinion assembly.*



H40221 -UN-17APR89


ZX1401,5005,AG -19-12SEP91

2. Install pinion assembly. Be sure pinion shaft gear (B) meshes with differential gear (A).

3. If old shims (behind cradle) were not damaged, they may be used. Otherwise, assemble a new pack. Start with several shims to ensure end play.

4. Install cradles. Tighten to 320 N·m (235 lb-ft).

5. Check differential for 0,08-0,25 mm (0.003-0.01 in.) preload. Add or remove shims as needed. Apply thread lock and sealer (medium strength) to cap screw threads. Install cradles. Tighten cap screws to 320 N·m (235 lb-ft).




H40222 -UN-17APR89

ZX,1401,5005,AH-19-01AUG97

6. Install bearing cup, cap, O-ring, and retaining ring (A-D).

**IMPORTANT:** The following procedure must be followed when determining required shim pack for the pinion shaft. This prevents false endplay readings caused by retaining ring (D).

- A—Bearing Cup
- B—Cap
- C—O-Ring
- D—Retaining Ring



HX,1401,5005,K -19-11DEC92

H40223 -UN-17APR89

7. Install bearing cap (B). Leave O-ring (D) off at this time.


8. Evenly tighten cap screws to 2.2 N·m (20 lb-in.)

9. Rotate pinion shaft at least two complete revolutions. Again evenly tighten cap screws to 2.2 N·m (20 lb-in.).

10. Measure gap between bearing cap (B) and housing at two places exactly 180° apart. Install shim pack (C) equal to average of these two readings. This shim pack will provide 0.127 mm (0.005 in.) preload.

11. Install O-ring on cap and install shim pack and cap.

12. Apply Thread Lock and Sealer (Medium Strength) to cap screw threads. Install cap screws and tighten to 73 N·m (55 lb-ft).



- A—Cap Screw (3 used)
- B—Bearing Cap
- C—Shim (as required)
- D—O-Ring
- E—Bearing Cup

ZXHX1401,5005,L-19-08APR92

H41158 -UN-27OCT89

13. Install input shaft assembly in transmission.
14. Apply form-in-place gasket to face of hydrostatic motor mount. Install on transmission. Tighten cap screws to 320 N·m (235 lb-ft).
15. Install transmission oil pump.
16. Adjust transmission oil pump shim pack to provide 0.01 to 0.2 mm (0.0005 to 0.008 in.) axial end play of input shaft assembly.
17. Install hydrostatic motor.

ZXHX1401,5005,O-19-01AUG97

## **INSTALL TRANSMISSION**

Using a trolley jack, roll transmission under machine and attach to front axle.

Connect mechanical parts such as parking brake cables, drive shafts, shift cable as well as hydrostatic motor.

Connect electrical ground speed sensor.

Connect brake line and bleed brake system (see Section 60).

Adjust parking brake.

Fill transmission with specified oil.

ZX,TMSPFH000275-19-22FEB92

# Group 15 Planetary Final Drives


## SPECIAL OR ESSENTIAL TOOLS

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

**Service Jack** ..... **D05070ST**

To remove and install final drives.




H40598 -UN-14SEP89

ZX,TMXZC0002386-19-25NOV92

**Final Drive Adapter** ..... **JT05874**

Use with D05070ST Service Jack to remove and install final drives.



H40599 -UN-05SEP89

1401,5010,AD -19-12SEP91

## SERVICE EQUIPMENT AND TOOLS

*NOTE: Order tools from your SERVICE-GARD™ Catalog. Some tools may be available from a local supplier.*

Name	Use
17-1/2 and 30 Ton Puller Set	To remove and install bearings and seals.
Bushing, Bearing, and Seal Driver Set	To remove and install bearings and seals.
Service Jack Adapter	To remove and install final drive.

1401,5015,A -19-12SEP91

**OTHER MATERIALS**

<b>Number</b>	<b>Name</b>	<b>Use</b>
TY6333	Multipurpose Grease	Pack Bearings
. . . . .	Masking Tape	Wrap shaft splines to prevent damage to seals during assembly.
TY15130	Form-in-Place Gasket	Seal inner and outer halves.
AR41870	Corrosion Inhibitor	Protect components in storage.
TY6304	Flexible Sealant	Seal spindle cap.

1401,5015,B -19-12SEP91



**SPECIFICATIONS**

<b>Item</b>	<b>Measurement</b>	<b>Specification</b>
Front Tire and Wheel . . . .	Approximate Weight . . . . .	340 kg (750 lb)
Final Drive . . . . .	Capacity . . . . .	6.2 L (6.5 qt.)
	Approximate Weight . . . . .	252 kg (555 lb)
Final Drive-to-Axle Top Two Cap Screws . . . . .	Torque . . . . .	405 N·m (300 lb-ft)
Final Drive-to-Axle Bottom Two Rearward Middle Cap Screws . . . . .	Torque . . . . .	200 N·m + 90° (148 lb-ft)
Final Drive-to-Axle Forward Middle Cap Screws . . . . .	Torque . . . . .	200 N·m + 180° (148 lb-ft)
Front Wheel Bolts . . . . .	Torque . . . . .	200 N·m (150 lb-ft) + 1/4 turn.
Quill-to-Inner Housing Cap Screws . . . . .	Torque . . . . .	73 N·m (55 lb-ft)
Pinion Shaft . . . . .	End play . . . . .	0.02—0.2 mm (0.0008—0.008 in.)
Axle Shaft Bearing Cap Screw . . . . .	Torque . . . . .	900 N·m (660 lb-ft) and additionally tighten to align locking plate
Inner Housing-to-Outer Housing Cap Screws . . . . .	Torque . . . . .	305 N·m (225 lb-ft)

1401,5015,C -19-12SEP91

## REMOVE AND INSTALL FINAL DRIVE

*NOTE: It is not necessary to remove the entire final drive to service the outer half of drive unit.*

**CAUTION:** Grain tank must be empty and header removed.

1. Loosen wheel bolts one turn. Do not remove at this time.

**CAUTION:** Block up front axle before removing wheels.

**CAUTION:** Jack must have a minimum rating of 5443 kg (6 ton).


2. Raise combine with jack (A).

3. Block up front axle (B).

**CAUTION:** The approximate weight of tire and wheel is 340 kg (750 lb) (without liquid ballast).

4. Support tire and wheel and remove wheel bolts to remove front tire and wheel.


5. Drain final drive. Approximate capacity is 6.2 L (6.5 qt.)



1401,5015,E -19-12SEP91

**CAUTION:** The approximate weight of final drive is 252 kg (555 lb).

6. Use D05070ST Service Jack with JT05874 Final Drive Adapter (C) to remove final drive (A).



1401,5015,J -19-12SEP91

H41336 -UN-25AUG89

7. Remove spiral snap ring (D).


8. Slide sleeve (E) inward.

9. Remove pin (C).

10. Drive coupler (B) inward.

11. Remove cap screws (A).

12. Repair final drive. (See Disassemble and Assemble Final Drive in this group.)




1401,5015,G -19-12SEP91

H40579 -UN-20APR89

- A—Cap Screw (6 used)
- B—Coupling
- C—Pin
- D—Spiral Snap Ring
- E—Sleeve

**CAUTION:** The approximate weight of final drive is 252 kg (555 lb).

13. Use D05070ST Service Jack (B) with JT05874 Final Drive Adapter (C) to install final drive (A).



1401,5015,K -19-12SEP91

H41336 -UN-25AUG89

14. Install final drive with cap screws (A). (See Specifications in Section 50, Group 15.)


15. Apply multipurpose grease to drive shaft splines and couplers.

16. Drive coupler (B) toward final drive and drive in pin (C).

17. Slide sleeve (E) over coupler and install spiral snap ring (D).

18. Fill final drive with 6.2 L (6.5 qt.) of recommended lubricant. (See Section 10, Group 20.)

19. Install wheel. Tighten bolts to 200 N·m (150 lb-ft) plus 1/4 turn.




A—Cap Screw (6 used)  
 B—Coupling  
 C—Pin  
 D—Spiral Snap Ring  
 E—Sleeve

1401,5015,H -19-12SEP91

H40579 -UN-20APR89

### DISASSEMBLE AND ASSEMBLE FINAL DRIVE



HP 3007

ZX, TMXZC002504-19-01DEC92


*Planetary Final Drives/Disassemble and assemble final drive*

1—Bearing Cup	8—Seal	14—Thrust Washer (6 used)	20—Shim (as required)
2—Bearing Cone	9—Bearing Cup	15—Needle Bearing (72 used)	21—Shim (as required)
3—Oil Cup	10—Bearing Cone	16—Pinion (3 used)	22—Shim (as required)
4—Seal	11—Snap Ring	17—Dowel Pin (3 used)	23—Washer
5—Spindle	12—Pinion Carrier	18—Lube Fitting	24—Lock Plate
6—Cap Screw (12 used)	13—Shaft (3 used)	19—Thrust Washer (2 used)	25—Self-Locking Screw
7—Housing			

*Legend for Planetary Final Drive*

1401,5015,AP -19-12SEP91

Planetary Final Drives/Disassemble and assemble final drive



- 1—Sleeve
- 2—Coupling (2 used)
- 3—Pin (2 used)
- 4—Snap Ring (3 used)
- 5—Drive Shaft
- 6—Pinion Shaft
- 7—Bearing Cone (2 used)
- 8—Bearing Cup

- 9—Snap Ring
- 10—O-Ring
- 11—Cap
- 12—Cap Screw (4 used)
- 13—Quill
- 14—Seal
- 15—Shim (as required)
- 16—Bearing Cup

- 17—Inner Housing
- 18—Pinion
- 19—Plug
- 20—Dust Cap
- 21—Retaining Ring
- 22—Key
- 23—Nut
- 24—Bearing Cone


- 25—Bearing Cup
- 26—Pipe Plug (2 used)
- 27—Dowel Pin (2 used)
- 28—Bearing Cup
- 29—Bearing Cone
- 30—Gear
- 31—Pinion
- 32—Sleeve

1401,5015,AR -19-12SEP91

Planetary Final Drives/Disassemble and assemble final drive

**CAUTION:** The approximate weight of planetary final drive is 252 kg (555 lb).

1. Stand final drive on axle flange.
2. Remove 12 cap screws. Lift off inner housing.




H40305  
-UN-15MAR89

1401,5015,L -19-12SEP91

3. Remove sun gear (A).
4. Install two bolts (D). Place bar between them to hold final drive when removing cap screw and lock plate (C).
5. Remove cap screw, lock plate, washer, and shims (C).
6. Remove pinion carrier (B).

A—Sun Gear  
B—Pinion Carrier  
C—Cap Screw and Lock Plate  
D—Install two Bolts



H40306  
-UN-15MAR89

1401,5015,M -19-12SEP91



Planetary Final Drives/Disassemble and assemble final drive

7. Hoist final drive 25 mm (1 in.) from surface and tap out axle. Hoist housing away from axle.

*NOTE: Lay final drive on its side if hoist is not available to tap axle out of housing using a mallet.*




1401,5015,N -19-12SEP91

H40307 -UN-15MAR89

8. Remove snap ring (A) to remove shafts (B), pinions (C), thrust washers (D), needle bearings (E), and shims (F).

9. Inspect parts for wear or damage. Replace as necessary.

- A—Snap Ring
- B—Shaft (3 used)
- C—Pinion (3 used)
- D—Thrust Washer (6 used)
- E—Needle Bearing (72 used)
- F—Shims (as required)



1401,5015,O -19-12SEP91

H41130 -UN-07SEP89

Planetary Final Drives/Disassemble and assemble final drive


10. Inspect bearing, seals, and ring gear (A-D) for wear or damage.

11. Use a suitable puller to remove bearing (A) if required. Replace seal with cup (C) if bearing is replaced.

*NOTE: Seals may need to be replaced but bearing may not.*

*NOTE: Ring gear (D) is pressed into housing and cannot be replaced without replacing housing.*

12. Wash all parts in a clean, safe solvent.



1401,5015,P -19-12SEP91


-UN-07SEP89  
H41131

13. Pry off cap (C). Remove retaining ring (A), and key (D). Use JDG528 wrench to remove nut (B).

14. Remove bearing cone.

**⚠ CAUTION: Use a lifting device for heavy components.**

15. Lift inner housing off gear.



1401,5015,Q -19-12SEP91

-UN-15MAR89  
H40309

16. Inspect bearing cups (A). If necessary to replace, drive bearing cups from inner housing using a brass drift.




1401,5015,R -19-12SEP91

-UN-15MAR89  
H40310

Planetary Final Drives/Disassemble and assemble final drive

17. Remove bearing cups in inner housing bore.



1401,5015,S -19-12SEP91

H40311 -UN-15MAR89

18. Remove cap with O-ring (A).


19. Remove quill and shims (B).



1401,5015,T -19-12SEP91

H40312 -UN-15MAR89


20. Remove pinion shaft with bearing cone, bearing cup, and seal. Remove gear.



1401,5015,U -19-12SEP91

H40313 -UN-15MAR89

21. Remove snap ring (A) and bearing cup (B) if needed to replace.




1401,5015,V -19-12SEP91

H40314 -UN-15MAR89

Planetary Final Drives/Disassemble and assemble final drive

22. Apply a light coating of multipurpose grease (or equivalent) to pinion shaft bore.

23. Install bearing cup and seal.



1401,5015,W -19-12SEP91

H40315 -UN-15MAR89

24. Apply a light coating of multipurpose grease (or equivalent) to pinion shaft bore.


25. Install bearing cup and snap ring.



1401,5015,X -19-12SEP91

H40316 -UN-15MAR89

26. Place gear (B) in position in inner housing. Install pinion shaft (A).



1401,5015,Y -19-12SEP91

H40317 -UN-15MAR89

27. Be sure gear (B) turns freely. Coat new O-ring with multipurpose grease and install on pinion bearing cap. Install cap (A), indexed as shown.



1401,5015,Z -19-12SEP91

H40312 -UN-15MAR89

28. Install oil seal (A) in quill. Grease seal to aid in assembly.

29. Install old shims (B) if not damaged. If damaged, assemble a new pack as follows:

- 0.13 mm (0.005 in.), 2 used, plastic
- 0.25 mm (0.010 in.), 1 used, steel
- 0.51 mm (0.020 in.), 1 used, steel

**IMPORTANT: Place plastic shims against each cast surface.**

30. Place strips of masking tape over pinion shaft splines to protect seal in quill. Bring tape ends together at end of shaft.

31. Install shim pack on quill. Install quill carefully over pinion shaft. Tighten cap screws to 73 N·m (55 lb-ft). Remove tape.

**IMPORTANT: Quill is aluminum. Do not overtighten cap screws.**



H40318 -UN-15MAR89

1401,5015,AA -19-12SEP91

32. Mount dial indicator on housing and check pinion shaft for 0.02—0.2 mm (0.0008—0.008 in.) end play.

33. Remove or add shims to get correct end play. Tighten cap screws to 73 N·m (55 lb-ft).



H40319 -UN-15MAR89

1401,5015,AB -19-12SEP91

34. Remove bearing cone (A) from gear shaft if necessary to replace.



H40320 -UN-15MAR89

1401,5015,AC -19-12SEP91

Planetary Final Drives/Disassemble and assemble final drive

35. Hand pack bearing cone with multipurpose grease.


36. Install bearing cone on gear. Bearing cone is a press fit.



1401,5015,AD -19-12SEP91

H40320 -UN-15MAR89


37. Inspect bearing cone (A). If necessary to replace, remove bearing cone from axle (B).



1401,5015,AE -19-12SEP91

H40322 -UN-15MAR89

38. Remove seal (A) from axle (B).



1401,5015,AF -19-12SEP91

H40323 -UN-15MAR89

39. Install oil seal (B) with flanged metal portion of seal facing toward axle flange on axle (A). Coat lips of seal with multipurpose grease (or equivalent).



1401,5015,AG -19-12SEP91

H40324 -UN-15MAR89

Planetary Final Drives/Disassemble and assemble final drive

40. Pack bearing cone with multipurpose grease.


41. Install bearing cone (B) on axle (A).



1401,5015,AH -19-12SEP91

H40325 -UN-15MAR89

42. Remove oil cup (A) and bearing cup (B) from outer housing (C).



1401,5015,AI -19-12SEP91

H40326 -UN-15MAR89


43. Apply a light coating of multipurpose grease (or equivalent) to bore of outer housing (B). Install bearing cup (A).



1401,5015,AJ -19-12SEP91

H40327 -UN-15MAR89

44. Install oil cup (A) on outer housing (B) using a mallet.



1401,5015,AK -19-12SEP91

H40328 -UN-15MAR89


45. Remove bearing cup (A) from outer housing (B).



1401,5015,AL -19-12SEP91

H40329 -UN-15MAR89

46. Apply a light coating of multipurpose grease (or equivalent) to bore of outer housing (A). Install bearing cup (B).



1401,5015,AM -19-12SEP91

H40330 -UN-15MAR89



47. Install axle (C) in outer housing.

48. Install two lead balls (6—8 mm [0.24—0.31 in.] diameter) on end of spindle 180° apart. Use grease or flatten slightly to hold in place.

49. Install carrier assembly (A) on top of lead balls.

50. Install cap screw (B). Tighten to 550 N·m (400 lb-ft) while rotating housing.

51. Remove carrier and lead balls. Measure thickness of each lead. Install shim pack equal to average of lead balls measurements. Shim pack must include thrust washer.

Shims available:

- 0.76 mm (0.003 in.) steel
- 0.127 mm (0.005 in.) steel
- 0.508 mm (0.02 in.) steel

52 Install shim pack, carrier and cap screw.

53. Tighten cap screw to 900 N·m (664 lb-ft) while rotating housing.

54. Install lock plate. If plate does not align, turn over or tighten as required.



1401,5015,AN -19-12SEP91


**CAUTION:** Use a lifting device for heavy components.

55. Install gear. Align gear teeth with pinion shaft gear teeth.

56. Apply a continuous bead of Form-in-Place Gasket to outer housing. It must be applied around all cap screw holes.

57. Attach inner housing to outer housing. Tighten 12 cap screws (E) to 305 N·m (225 lb-ft).

58. Install nut (A). Tighten nut until bearing end play is removed. Do not overtighten (preload) bearings. Install key (B), retaining ring (D). Apply 1.5 mm bead of flexible sealant around cap (C). Install cap (C).



- A—Nut
- B—Key
- C—Cover
- D—Retaining Ring
- E—Cap Screw (12 used)

H40228 -UN-06JUL89

# Group 20 Final Drives


## SPECIAL OR ESSENTIAL TOOLS

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

**Service Jack** ..... **D05070ST**

To remove and install final drives.




H40598 -UN-14SEP89

ZX,TMXZC0002386-19-25NOV92

**Final Drive Adapter** ..... **JT05874**

Use with D05070ST Service Jack to remove and install final drives.




H40599 -UN-05SEP89

1401,5010,AD -19-12SEP91

**Final Drive Repair Kit** ..... **JDG690**

To repair final drive.




H44021 -UN-23FEB92

HX,1401,5010A -19-02MAR92

**Axle nut socket** ..... **JDG665**

JDG665 -UN-28APR95



**JDG665**

ZX,TMSPFH000286-19-01MAR94

### SERVICE EQUIPMENT AND TOOLS

*NOTE: Order tools from the U.S. SERVICEGARD™ Catalog or from the European Microfiche Tool Catalog (MTC). Some tools may be available from a local supplier.*

Name	Use
17-1/2 and 30-Ton Puller Set	To remove and install bearings and seals.
Bushing, Bearing, and Seal Driver Set	To remove and install bearings and seals.

1401,5010,A -19-12SEP91

### OTHER MATERIALS

Number	Name	Use
TY6333	Multipurpose Grease	Pack bearings.
AR41870	Corrosion Inhibitor	Protect components in storage.
. . . . .	Masking Tape	Wrap shaft splines to prevent damage to seals during assembly.
TY6304	Flexible Sealant	Seal final drive end cap and final drive pinion cap.
TY15130	Form-in-Place Gasket	Seal inner and outer housings.
TY9374	Thread Sealer	Breather and fill plug.

HX,1401,5010,B -19-02MAR92

**SPECIFICATIONS**

Item	Measurement	Specification
Front Tire and Wheel . . . . .	Approximate Weight . . . . . (without ballast)	340 kg (750 lb)
Final Drive . . . . .	Capacity . . . . . Approximate Weight . . . . .	6 L (1.6 U.S. gal) 218 kg (480 lb)
Final Drive-to-Axle Cap Screws (top two) . . . . .	Torque . . . . .	430 N·m (317 lb-ft)
Front Wheel Bolts . . . . .	Torque . . . . .	720 +0/-60 N·m (531 +0/-55 lb-ft)
Inner Housing-to-Outer Housing Cap Screws . . . . .	Torque . . . . .	320 N·m (235 lb-ft)
Pinion Gear Shaft Adjustment . . . . .	Preload/Endplay . . . . .	0—0.1 mm (0—0.004 in.) Preload to 0—0.05 mm (0—0.002 in.) Endplay
Bearing Cap Screws . . . . .	Torque . . . . .	73 N·m (55 lb-ft)
Spindle Bearing . . . . .	Housing Deflection . . . . .	0.30—0.36 mm (0.012—0.014 in.)
Nut to Axle Bearing . . . . .	Torque . . . . .	300 N·m (221 lb-ft)
Tie Rod . . . . . (wheels off ground)		Finger tight plus two turns (one side only)
Tie Rod Locknut . . . . .	Torque . . . . .	660 N·m (450 lb-ft) (both ends)

ZX, TMXZCO009465-19-01AUG97

## REMOVE AND INSTALL FINAL DRIVE

**CAUTION:** Grain tank must be empty and header removed.

1. Loosen wheel bolts one turn. Do not remove at this time.

**CAUTION:** Block up front axle before removing wheels.


**CAUTION:** Jack must have a minimum rating of 5443 kg (6 ton).

2. Raise combine with a jack.

3. Block up the front axle.

**CAUTION:** The approximate weight of tire and wheel is 340 kg (750 lb) (without liquid ballast).

4. Support tire and wheel and remove wheel bolts to remove front tire and wheel.



ZX012741 -UN-27SEP97


ZX.TMXZC0009466-19-01AUG97

5. Pry out spiral snap ring (D) and slide sleeve (B) inward.

6. Drive out pin (C) and drive coupler (A) inward.

7. Drain final drive. Approximate capacity is 6 L (1.6 U.S. gal).

A—Coupler  
B—Sleeve  
C—Pin  
D—Spiral snap ring




ZX005251 -UN-24APR95

ZX.TMXZC0009467-19-01AUG97

Final Drives/Remove and install final drive

**CAUTION:** The approximate weight of final drive is 218 kg (480 lb).

8. Use D05070ST Service Jack with JT05874 Final Drive Adapter to remove final drive.




ZX.TMXZC0009468-19-01AUG97

9. Remove 6 cap screws (A—C).

10. If dowel pins do not come out with final drive, remove from axle and install in housing.

11. Remove and repair final drive as necessary. (See Disassemble and Assemble Final Drive.)

12. Remove axle spacers if needed.




ZX.TMXZC0010098-19-01AUG97

Final Drives/Remove and install final drive

**CAUTION:** The approximate weight of final drive is 218 kg (480 lb).


13. Use D05070ST Service Jack with JT05874 Final Drive Adapter to install final drive.



ZX.TMXZC0009469-19-01AUG97

14. Install 6 cap screws (A—C).

15. Tighten cap screws to 430 N·m (317 lb-ft).



ZX.TMXZC0010099-19-01AUG97




*Final Drives/Remove and install final drive*

16. Apply multipurpose grease to drive shaft splines and coupler.
17. Drive coupler (D) toward final drive and drive in pin (C) flush with coupler.
18. Slide sleeve (B) on and install spiral snap ring (A).
19. Fill final drive with 6 L (1.6 U.S. gal) of recommended lubricant.

**⚠ CAUTION: The approximate weight of tire and wheel is 340 kg (750 lb) (without liquid ballast).**


20. Install wheel. Tighten bolts to 720 +0/-60 N·m (531 +0/-44 lb-ft), then an additional 90°.



- A—Spiral snap ring
- B—Sleeve
- C—Pin
- D—Coupler

ZX.TMXZC0009470-19-01AUG97

**DISASSEMBLE AND ASSEMBLE FINAL DRIVE**



H43761

- |                  |                       |                   |                        |
|------------------|-----------------------|-------------------|------------------------|
| 1—Axle           | 9—Fitting (2 used)    | 17—Bearing Cup    | 25—Pinion Gear         |
| 2—Seal           | 10—Line               | 18—Bearing Cone   | 26—Bearing Cone        |
| 3—Seal           | 11—Dowel Pin (2 used) | 19—Dust Cap       | 27—Bearing Cup         |
| 4—Bearing Cone   | 12—Ring Gear          | 20—Retaining Ring | 28—Shim (as required)  |
| 5—Bearing Cup    | 13—Inner Housing      | 21—Key            | 29—Cap                 |
| 6—Seal           | 14—Plug               | 22—Nut            | 30—Cap Screw (4 used)  |
| 7—Grease Fitting | 15—Snap Ring          | 23—Bearing Cup    | 31—Cap Screw (12 used) |
| 8—Outer Housing  | 16—Spacer             | 24—Bearing Cone   | 32—Seal                |


HX,1401,5010,BB-19-16DEC92

H43761 -JUN-26AUG91

**CAUTION:** The approximate weight of final drive is 218 kg (480 lb).

1. Stand final drive on axle flange.
2. Pry off cap (C). Remove retaining ring (D) and key (B).
3. Remove nut (A) using JDG665 socket (E).

A—Nut  
B—Key  
C—Cap  
D—Retaining Ring  
E—Socket



HX1401,5010.G -19-13SEP94

-UN-15JUL92  
H44787

-UN-23FEB92  
H44022

4. Use adapter (A) from JDG690 Final Drive Repair Kit on end of shaft to protect shaft when removing inner cover.




HX,1401,5010D -19-16DEC92

-UN-23FEB92  
H44024

Final Drives/Disassemble and assemble final drive

5. Remove 12 cap screws (C).
  6. Attach plate (A) from JDG690 Final Drive Repair Kit to inner cover (B). Attach 17-1/2 and 30 ton puller set to plate.
- Install lifting chains on cross straps of puller set to lift cover after it is disconnected.
7. Thread puller screw (D) into adapter (E) on axle shaft.
  8. Use puller to remove inner cover. Remove bearing cone and spacer.
  9. Clean gasket material off housings. Run a wire through vent/fill plug to be sure it is open.


- A—Plate
- B—Inner Cover
- C—Cap Screw (12 used)
- D—Puller Screw
- E—Adapter



HX,1401,5010E -19-16DEC92

H44025 -UN-23FEB92

10. Inspect bearing cup (A). If necessary to replace, drive bearing cup from inner housing.



HX,1401,5010F -19-16DEC92

H40230 -UN-15MAR89

11. Apply a light coat of multipurpose grease (or equivalent) to inner housing bore.
12. Drive bearing cup into bore of inner housing.



HX,1401,5010G -19-16DEC92

H40231 -UN-15MAR89

Final Drives/Disassemble and assemble final drive

13. Remove pinion gear and bearing cup (A).



HX,1401,5010H -19-16DEC92

-UN-15MAR89  
H40232

14. Remove seal from pinion shaft bore.

15. Inspect bearing cup (A). If necessary to replace, drive bearing cup from pinion shaft bore.


16. Apply a light coat of multipurpose grease (or equivalent), to pinion shaft bore. Drive in bearing cup.



HX,1401,5010I -19-16DEC92

-UN-15MAR89  
H40233


17. Install seal (A) in pinion shaft bore, flush with housing.



HX,1401,5010J -19-16DEC92

-UN-15MAR89  
H40234

18. Remove bearing cones (B) (using bearing cone holding fixture (A) from JDG690 Final Drive Repair kit and a puller) from pinion shaft if necessary to replace bearings.




HX,1401,5010K -19-16DEC92

-UN-23FEB92  
H44026

Final Drives/Disassemble and assemble final drive

19. Pack bearing cones with multipurpose grease (or equivalent) and install bearing cones (A) on pinion shaft using driver from JDG690 Final Drive Repair Kit.
20. Install pinion shaft and bearing cup in inner housing.




HX,1401,5010L -19-16DEC92

H40236 -UN-15MAR89

**CAUTION:** Use a lifting device for heavy components.

21. Lift ring gear (A) off axle.
22. Remove outer housing (J) from axle shaft. Turn housing over and, if necessary, remove bearing cap (H) and shim pack (G).
23. Remove bearing cup and seal from bore of outer housing if necessary to replace.



- |                |                           |
|----------------|---------------------------|
| A—Ring Gear    | G—Shim Pack (as required) |
| B—Bearing Cup  | H—Bearing Cap             |
| C—Bearing Cone | I—Cap Screw (4 used)      |
| D—Pinion Gear  | J—Outer Housing           |
| E—Bearing Cone | K—Inner Housing           |
| F—Bearing Cup  |                           |

HX,1401,5010M -19-16DEC92

H40218 -UN-20APR89

24. Install seal (A) and seal cup (B) in outer housing.



HX,1401,5010N -19-16DEC92

H40246 -UN-15MAR89

Final Drives/Disassemble and assemble final drive

25. Apply a light coat of multipurpose grease to bore of outer housing. Install bearing cup (A).

26. The R99244 seal should be installed on spindle after JD9092 bearing. The V-lip of the seal MUST be pointed away from the bearing.

27. Apply a light coating of grease to the V-lip.




H440247 -UN-15MAR89

HX,1401,50100 -19-29AUG96

28. Remove V-ring seal (A), bearing cone (B), and seal (C) from axle using puller from JDG690 Final Drive Repair Kit and 17-1/2 and 30 ton puller set.

*NOTE: Long puller legs (D) must be used.*


- A—V-Ring Seal
- B—Bearing Cone
- C—Seal
- D—Long Puller Leg  
(2 used)



H44027 -UN-23FEB92

HX,1401,5010P -19-29AUG96

29. Apply multipurpose grease (or equivalent) to seal lips. Install seal (C) using drivers (A and B) from JDG690 Final Drive Repair Kit and 17-1/2 and 30 ton puller set. Metal edge of seal (C) must face toward outer housing when placed over axle.



H44028 -UN-23FEB92

HX,1401,5010Q -19-29AUG96


Final Drives/Disassemble and assemble final drive

**NOTE:** Pack all bearing cones with multipurpose grease (or equivalent) before assembly.

30. Thread puller screw (D) into adapter (C) on axle shaft. Install bearing cone (B) on axle using driver (A) from JDG690 Final Drive Repair Kit and 17-1/2 and 30 ton puller set.

31. Install V-ring (E) seal next to bearing cone. V-lip must be pointed away from bearing cone.

- A—Driver
- B—Bearing Cone
- C—Adapter
- D—Puller Screw
- E—V-Ring Seal




ZX.TMXZC0009471-19-01AUG97

H44029 -UN-12JAN93

32. Install outer housing on axle.

33. Install snap ring in ring gear and install ring gear (C) on axle. Install spacer (A) with chamfered or beveled edge toward bearing.

34. Block up ring gear using a 2 x 4 in. block (B).



HX.1401,5010S -19-29AUG96

H40303 -UN-15MAR89





35. Apply a 1.5 mm (0.06 in.) continuous bead of form-in-place gasket around flange of outer housing. Install inner housing on outer housing. Tighten 12 cap screws to  $320 \pm 64$  N·m ( $235 \pm 47$  lb-ft).

36. Install bearing cone on spindle.

37. Install nut (A). Tighten nut until SNUG with JDG665 socket (E). Do not overtighten bearings. (See Adjust Spindle Bearing in this group.)

- A—Nut
- B—Key
- C—Cap
- D—Retaining Ring
- E—Socket



ZX.TMXZCO009472-19-01AUG97

-UN-15JUL92  
H44787


-UN-23FEB92  
H44022

38. If old shims have not been damaged, they may be used. If damaged, assemble a new pack (C) as follows:

- 0.13 mm (0.005 in.) - Plastic - 2 used
- 0.25 mm (0.010 in.) - Steel - 1 used
- 0.50 mm (0.020 in.) - Steel - 1 used

**IMPORTANT: Install plastic shims against each housing case surface.**

39. Attach bearing cap (B) with shim pack to outer housing (D). TIGHTEN cap screws (A) at this time to 73 N·m (55 lb-ft).



- A—Cap Screw (4 used)
- B—Bearing Cap
- C—Shim (as required)
- D—Outer Housing

ZX.TMXZCO009473-19-01AUG97

-UN-15MAR89  
H40304

## Final Drives/Disassemble and assemble final drive

40. Check pinion gear shaft preload/end play with dial indicator. Adjust within range of 0.1 mm (0.004 in.) preload to 0.05 mm (0.002 in.) end play. If not within specifications, remove bearing cap and add or remove shims as needed. After correct setting is achieved, remove cap and apply 1.5 mm (0.06 in.) bead of flexible sealant to lip of cap and reinstall cap. Tighten cap screws to 73 N·m (55 lb-ft).



H40308 -UN-15MAR89

HX,1401,5010V -19-29AUG96


41. Pump in multipurpose grease (or equivalent) at lubrication fitting. Grease must ooze out around seal.

*NOTE: If final drive is to be placed in service parts storage, add 29.6 mL (1 oz.) of AR41870 corrosion inhibitor.*

HX,1401,5010W -19-29AUG96

### ADJUST SPINDLE BEARING (PREFERRED METHOD)

1. Rotate final drive assembly two revolutions to seat lower bearing.
2. Install flat bar (B) across mounting flange.
3. Install dial indicator (A) on bar and with indicator on axle (D), set dial at zero.
4. Tighten nut (C) until 0.30—0.36 mm (0.012—0.014 in.) housing deflection is observed.
5. Advance nut to next locking position and install key and retainer.
6. Apply a bead of flexible sealant to lip of cap and install cap.




H41196 -UN-06JUL89

A—Dial Indicator  
B—Flat Bar  
C—Nut  
D—Axle

HX,1401,5010AB -19-16DEC92

### ADJUST SPINDLE BEARING (ALTERNATE METHOD)

1. Rotate final drive assembly two revolutions to seat bearings.
2. Tighten nut (C) to 300 N·m (275 lb-ft).
3. Advance nut to next locking position and install key and retainer.
4. Apply a bead of flexible sealant to lip of cap and install cap.




H41196  
-UN-06JUL89

- A—Dial Indicator
- B—Flat Bar
- C—Nut
- D—Axle

ZX.TMXZCO009474-19-01AUG97

### FINAL DRIVE FOR 6-WALKER COMBINES

- A—Dia. 335 mm
- B—380 mm
- C—Wheel bolts (10 used)




ZX012213

ZX012213  
-UN-25SEP97

ZX.TMXZCO009475-19-01AUG97

Final Drives/Adjust spindle bearing (alternative method)

- A—Dia. 275 mm (10.8 in.)
- B—442 mm (17.4 in.)
- C—Wheel bolts (8 used)



ZX012214

-JUN-25SEP97  
ZX012214

ZX.TMXZCO009476-19-01AUG97

## FINAL DRIVES


Change oil after the first 100 hours of operation. Thereafter change oil every 1000 hours of operation or before every harvesting season (whichever occurs first).

Check oil level every 250 hours of operation.

**IMPORTANT: Always use specified oil.**

*NOTE: On Hillmaster machines, check the oil only when the harvester is in its normal working position (equalizing cylinder in middle position).*

- A—Filler/bleed screw
- B—Level screw
- C—Oil drain screw



ZX009621


-JUN-11NOV96  
ZX009621

ZX.OMXZCO006996-19-01NOV96

### FINAL DRIVE ATTACHING SCREWS

At least every 10 hours within the first 50 hours of operation, tighten attaching screws at points (X) and (Z) to the following torque:

430 N·m (317 lb-ft)




ZX009868 -UN-08NOV96

ZX.OMXZC0006997-19-01NOV96

### FINAL DRIVE ATTACHING SCREWS, DUAL TIRES

At least every 10 hours within the first 50 hours of operation, tighten attaching screws at points (X) and (Z) to the following torque:

430 N·m (317 lb-ft)



ZX009867 -UN-11NOV96

ZX.OMXZC0006998-19-01NOV96

*Final Drives/Adjust spindle bearing (alternative method)*

**SPECIAL TOOL**


A—D01045AA Driver set



R28087N -JUN-09FEB90

ZX,TMSPFH000330-19-22FEB92

**SPECIAL TOOL, SELF-MANUFACTURED (HARDWOOD MOUNTING PLATE)**



Z110260 -JUN-07JUN95

A—250 mm (9.85 in.)  
B—70 mm (2.75 in.)  
C—Dia. 130 mm (5.12 in.)


D—165 mm (6.50 in.)  
E—Dia. 10 mm (0.394 in.)

F—10 mm (0.394 in.)  
G—20 mm (0.787 in.)

H—5 mm x 45°  
(0.20 in. x 45°)

ZX,TMSPFH000331-19-31JAN96

**SPECIAL TOOL, SELF-MANUFACTURED (PULLER)**



- |                      |                       |                     |                       |
|----------------------|-----------------------|---------------------|-----------------------|
| A—100 mm (4 in.)     | E—1.5 mm (0.060 in.)  | H—74 mm (2.910 in.) | L—28.5 mm (1.125 in.) |
| B—28.5 mm (1.12 in.) | F—58.7 mm (2.310 in.) | I—19 mm (0.750 in.) | N—M8 thread           |
| C—9.5 mm (0.375 in.) | G—61.7 mm (2.430 in.) | K—13 mm (0.500 in.) | O—12'                 |
| D—3.3 mm (0.130 in.) |                       |                     |                       |

Z 116 429

Z116429 -UN-07JUN95

ZX.TMSPFH000332-19-28JAN91



## SPECIFICATIONS

Item	Measurement	Specification
Variable pump	Weight (approx.)	68 kg (160 lb)
Gap between retaining plate and slipper retainer	Wear tolerance	0.2 mm (0.08 in.)
Screws on retaining plate	Tightening torque	25 N·m (18 lb-ft)
Screws on swashplate	Tightening torque	60 N·m (45 lb-ft)
Swashplate bearing	Rolling drag torque	10 - 20 N (2.5 - 5 lb)
Difference at opposite sides of swashplate	Depth	0.012 mm (0.005 in.)
Screws at front cover	Tightening torque	60 N·m (45 lb-ft)
Drive shaft	End play	0.05 - 0.17 mm (0.002 - 0.007 in.)
Screws at end cap	Tightening torque	85 N·m (63 lb-ft)
Screws at charge pump	Tightening torque	22 N·m (16 lb-ft)
Screws at servo-control valve	Tightening torque	24 N·m (17.7 lb-ft)
Pressure-relief valve	Tightening torque	163 - 197 N·m (120 - 145 lb-ft)
Variable pump attaching screws	Tightening torque	130 N·m (96 lb-ft)


ZX, TMXZCO009477-19-01AUG97

## OTHER MATERIAL

Number	Name	Use
TY9371	Loctite 271	Screws on retaining plate

ZX, TMXZCO009478-19-01AUG97

### HYDROSTATIC DRIVE COMPONENTS



ZX002589

A—Variable pump  
B—Hydrostatic oil tank

C—L.h. wheel motor  
D—Four-wheel drive solenoid

E—R.h. wheel motor  
F—Fixed-displacement motor

G—Oil cooler  
H—Hydrostatic oil filter

ZX.OMXZC0002225-19-05OCT92

## REMOVING THE VARIABLE PUMP

1. Clean pump and surrounding area thoroughly.

**!** **CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.


If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

2. Stop Engine. Operate all controls to release hydraulic pressure.

**IMPORTANT:** When disconnecting a line, hose, or transfer tube from a hydrostatic component, always mark end and port from which it was removed so that it can be connected to proper port when reassembling.

Also, when disconnecting a line, hose, or transfer tube from a component, always plug them and component to keep dirt out of system. Use a plastic plug or plastic bag - never a cloth. Cloth contains lint which can damage hydrostatic system.

High pressure hoses have clamp-type bolted fittings with O-rings. When this type of fitting is disassembled, inner surfaces must be cleaned thoroughly and new O-rings installed. This is to insure a tight seal and reduce possibility of leakage.



X9811  
-JUN-23AUG88

ZX, TMXZCO009479-19-01AUG97

## REMOVING THE VARIABLE PUMP

Drain hydrostatic oil at fixed-displacement motor.  
Remove line (A) from hydrostatic pump (for venting purposes).

Disconnect suction line (B) at charge pump and turn line until open end points upwards.



Disconnect high pressure hoses (D) and control cable (E) at hydrostatic pump (C).

Attach pump to a suitable hoist.

**⚠ CAUTION: Approximate weight of pump is 68 kg (160 lb).**

Remove four cap screws and remove pump.

- A—Line to hydrostatic oil cooler
- B—Charge pump suction line
- C—Hydrostatic pump
- D—High-pressure hose (2 used)
- E—Control cable







ZX.TMXZC0009480-19-01AUG97

## DISASSEMBLE VARIABLE PUMP — PREPARATIONS

**IMPORTANT:** When repairing variable pump, observe utmost cleanliness.

1. Remove snap ring (A).
2. Remove seal retainer (B) with stationary part of seal set.
3. Remove moving part (C) of seal set. Make sure that O-ring of moving seal does not remain on shaft.

A—Snap ring  
B—Seal retainer  
C—Moving part of seal set  
D—Threaded pin 1/4 - 20





ZX, TMXZCO009481-19-01AUG97

## REMOVE SERVO CONTROL VALVE

Loosen attaching screws of servo control valve (A).


Shift pin (B) laterally and pull out of swashplate strap.  
Remove servo control valve (A).



ZX,TMSPFH000300-19-28JAN91

## REMOVE CHARGE PUMP


It is not necessary to remove screws (A) and (B) when removing charge pump. These screws are shorter and hold the charge pump housing together.



ZX,TMSPFH000301-19-28JAN91

## REMOVE CHECK VALVE

Using a piece of strong wire, pull the check valve inserts from their seats.



ZX,TMSPFH000302-19-28JAN91

## REMOVE END CAP



Turn out attaching screws of end cap (A), leaving two opposite screws in place.

Loosen these screws alternately until tension of spring in variable pump has been released, then turn out screws completely.

**IMPORTANT: When removing end cap, be careful not to damage valve plate and bearing plate.**

Remove end cap (A).

Remove valve plate and bearing plate (B).




ZX,TMSPFH000303-19-28JAN91

## REMOVE BEARING

Attach special tool (A) to top of bearing and remove bearing by means of a puller.

Before using the puller, place a back-up washer between the shaft end and the puller.




ZX,TMSPFH000304-19-28JAN91

## REMOVE SERVO CYLINDERS


**IMPORTANT:** Before removing servo cylinders, mark location and mounting depth.

Remove servo cylinders.

**NOTE:** Before placing variable pump housing in horizontal position, secure cylinder block with a self-manufactured strap (A).



-UN-01JUN95  
Z116440



-UN-01JUN95  
Z116441


ZX.TMSPFH000305-19-28JAN91

## REMOVE FRONT COVER


**IMPORTANT:** Do not damage sealing surface of the drive shaft.

Place variable pump housing in horizontal position and remove front cover (A).

Remove drive shaft (B).



-UN-01JUN95  
Z116442



-UN-01JUN95  
Z116443

ZX.TMSPFH000306-19-22JUL91




## REMOVE SERVO PISTON

**IMPORTANT:** Protect sliding surfaces of servo piston against damage.


Remove snap ring from inner side of bolt (A).

Push bolt (A) through bore of pump housing.

Mark servo piston (B) and remove it from pump housing.



Z116444 -UN-01JUN95



Z116445 -UN-01JUN95


ZX,TMSPFH000307-19-22JUL91

## REMOVE SWASHPLATE


Mark trunnions (A) and remove them. Note number of washers.

**CAUTION:** When removing swashplate with cylinder block, make sure not to drop cylinder block, as it is not attached to the swashplate.

Remove swashplate (B) with cylinder block from pump housing.



Z116446 -UN-01JUN95




Z116447 -UN-01JUN95

ZX,TMSPFH000308-19-22JUL91

### DISASSEMBLE SWASHPLATE

Swashplate can be disassembled by turning out four hex. socket screws.




Z116448

-UN-01JUN95

ZX.TMSPFH000309-19-22JUL91

### SWASHPLATE, EXPLODED VIEW



Z116449

-UN-02JUN95

A—Swashplate  
B—Wear plate

C—Retaining plate  
D—Spacer bushings

E—Hex. socket screws  
F—Pistons with slippers

G—Slipper retainer  
H—Cylinder block

ZX.TMSPFH000310-19-22JUL91

## REPLACING THE SPRING IN THE CYLINDER BLOCK

If spring (C) appears damaged or contaminated, press retaining ring (A) down to compress spring.

Remove outer retaining ring (B).


Remove retaining ring, spring, and beveled inner retainer (D).

Wash parts with clean solvent and replace spring.

Install beveled inner retainer (D) with beveled side toward splined end of block.

Install outer retainer (A) with shoulder toward open end of block.

Compress spring and outer retainer, then install retaining ring.



A—Retaining ring  
B—Outer retaining ring  
C—Spring  
D—Inner retainer

N36010 -UN-29SEP88

ZX,TMXZCO009482-19-01AUG97

## REPAIR VARIABLE PUMP

**When repairing variable pump, note the following points:**

- Check shaft seal assembly for scores at sliding surfaces. Replace all O-rings.
- Always use a new gasket between charge pump and end cap. If charge pump is defective, replace complete pump.
- Check valve plate and bearing plate for damage and replace, if necessary. Always use new O-rings and gaskets.


- Check wear plate surface for serviceability and replace plate, if necessary.
- Check drive shaft bearing surfaces and bearings as well as trunnions for roughness and discoloration and replace, if necessary.
- Check cylinder block and pistons with slippers for damage. Pistons may be replaced individually.
- Thoroughly clean all parts prior to assembly.
- Before assembling parts, coat all bearing surfaces with hydraulic oil. Grease O-rings with vaseline.

ZX,TMSPFH000311-19-22JUL91

### CHECKING PARTS FOR WEAR

Distance (X) between retainer plate (B) and slipper retainer (C) must not exceed 0.2 mm (0.08 in.).

- A—Spacer bushing
- B—Retainer plate
- C—Slipper retainer
- D—Slipper
- E—Wear plate
- F—Piston
- G—Hex. socket screw
- X—Distance between slipper retainer and retainer plate
- Y—Height of slipper and slipper retainer
- Z—Height of spacer bushing



Z 116 450

Z116450 -UN-02JUN95

ZX.TMSPFH000312-19-22JUL91

## ASSEMBLE AND INSTALL SWASHPLATE

Insert pistons with slippers (D) and slipper retainers (C) into cylinder block.

Place wear plate (E) on swashplate (F).

Place slippers on wear plate. Install retainer plates (B) with bushings (A).

**IMPORTANT: Do not apply Loctite to wear plate (E).**





Coat screws (G) with Loctite No. 271 and tighten to 25 N·m (18 lb-ft).

### Install Swashplate with Cylinder Block:

Install swashplate (B) with cylinder block in pump housing by inserting trunnions (A), using the same number of washers as installed before and noting marks applied prior to disassembly.

Tighten attaching screws to 60 N·m (45 lb-ft).

- A—Bushings
- B—Retainer plates
- C—Slipper retainers
- D—Slippers
- E—Wear plate
- F—Swashplate
- G—Screws



ZX.TMSPFH000313-19-22JUL91


### CHECK ROLLING DRAG TORQUE OF SWASHPLATE BEARINGS

Attach a spring scale to servo control valve strap and measure the force required to move swashplate.

This force should be 10—20 N (2.5—5 lb).

If rolling drag torque of swashplate bearings is not correct, remove trunnions and adjust by removing or adding washers.

*NOTE: The total thickness of washers used on each trunnion should not differ by more than 0.3 mm (0.01 in.).*




ZX.TMSPFH000314-19-28JAN91

### INSTALL SERVO PISTON

Insert servo piston (B).

Align servo piston strap with swashplate attaching point. Install bolt (A) and secure with spring washers on both sides.



ZX.TMSPFH000315-19-28JAN91

## INSTALL SERVO CYLINDER



Install servo cylinder, noting mark and taking care not to damage O-rings.

Check neutral position of swashplate with a depth gauge.

*NOTE: Difference of depth (measured on two opposite sides of swashplate) must not exceed 0.012 mm (0.0005 in.).*

If necessary, adjust neutral position by turning servo cylinders.

After swashplate adjustment, secure both servo cylinders to keep them in correct position.





ZX.TMSPFH000316-19-22JUL91

## ATTACH FRONT COVER

Slide drive shaft (B) from underneath into swashplate assembly.

Install front cover (A).

Tighten attaching screws to 60 N·m (45 lb-ft).



ZX.TMSPFH000317-19-28JAN91



## CHECK DRIVE SHAFT BEARING END PLAY

Drive bearing on shaft and install end cap (A) without valve plate and bearing plate.

Measure end play of drive shaft.

End play should be between 0.05 and 0.17 mm (0.002 and 0.007 in.).

Adjust end play, if necessary, by placing washers under bearing cup in end cap.



ZX,TMSPFH000318-19-28JAN91



## INSTALL END CAP

After checking bearing end play, remove end cap (A) again.

**IMPORTANT: Before closing variable pump housing, all parts have to be coated with clean hydraulic oil of specified quality.**

Place bearing plate (B) on cylinder block. Slightly coat valve plate with oil so that it sticks to the end cap. Place both parts on variable pump housing.

Tighten end cap attaching screws crosswise to 85 N·m (65 lb-ft).




ZX,TMSPFH000319-19-28JAN91



## INSTALL CHECK VALVES

*NOTE: Install back-up rings on the outside and O-rings on the inside of check valves.*




ZX,TMSPFH000320-19-28JAN91

-UN-01JUN95

## INSTALL CHARGE PUMP

Tighten attaching screws (A) and (B) of charge pump to 22 N·m (16 lb-ft).



ZX,TMSPFH000321-19-28JAN91


-UN-01JUN95

## INSTALLING THE SERVO-CONTROL VALVE

Before installing servo-control valve, make sure that orifices are not clogged and installed correctly.


Insert pin (B) into swashplate strap and attach servo control valve (A).

Tighten screws to 24 N·m (16 lb-ft).



ZX,TMSPFH000321-19-28JAN91

-UN-01JUN95



ZX,TMXZCO010100-19-01AUG97


-UN-01JUN95

## OVERHAULING THE SEAL SET

Position stationary seal assembly on rotating seal (F).

Press stationary seal assembly down, then use a small screwdriver (B) to carefully remove retaining O-ring (A). Do not damage O-ring seat.

- A—Retaining O-ring
- B—Seal retainer
- C—O-ring
- D—O-ring
- E—Rotating seal



ZX.TMXZCO009483-19-01AUG97

-UN-22SEP88  
N37725


Remove stationary seal (A) from seal retainer (D).

Remove O-ring (B).

Remove six springs (C).

Remove O-ring (E) from retainer.

- A—Stationary seal
- B—O-ring
- C—Spring (6 used)
- D—Seal retainer
- E—O-ring



ZX.TMXZCO009484-19-01AUG97

-UN-23JAN89  
N37726

Install new O-ring on stationary seal retainer.


Install six springs in seal retainer (B).

Install new O-ring (D) in seal retainer.

Align dowel pin of seal retainer with notch in stationary seal, then install seal.

Position stationary seal assembly on rotating seal (E). Push assembly down and carefully install retaining O-ring (A).

Install O-ring in I.D. of rotating seal.



- A—Retaining O-ring
- B—Seal retainer
- C—O-ring
- D—O-ring
- E—Rotating seal


ZX.TMXZCO009485-19-01AUG97

-UN-15MAR89  
H40203


## INSTALL SEAL SET

**IMPORTANT: Do not touch sealing surfaces with your hands.**

1. Install moving seal ring (C) with O-ring.
2. Install seal retainer (B) with stationary seal ring.
3. Install snap ring (A) with chamfered side facing outward.




-UN-01JUN95  
Z-110442



-UN-01JUN95  
Z-110415

ZX.TMSPFH000323-19-22JUL91

REPAIRING THE CONTROL VALVE



HP2943

- |                      |                    |                       |                       |
|----------------------|--------------------|-----------------------|-----------------------|
| 1—Cap screw (2 used) | 8—Repair kit       | 15—Snap ring (2 used) | 22—Washer             |
| 2—Housing            | 9—O-ring           | 16—Control link       | 23—Link               |
| 3—Spool              | 10—Adjusting screw | 17—Connector          | 24—O-ring             |
| 4—Washer             | 11—Bolt            | 18—Spring pin         | 25—Shaft              |
| 5—Spring             | 12—Set screw       | 19—O-ring (2 used)    | 26—Cap screw (4 used) |
| 6—Retainer           | 13—Gasket          | 20—Plug (2 used)      | 27—Seal               |
| 7—Cap screw          | 14—Link            | 21—Nut                | 28—Complete valve     |

UN-01 JAN94  
HP2943

ZX, TMXZCO009576-19-01AUG97

*Hydrostatic Drive, Variable Pump/Repairing the control valve*

The servo-control valve may be removed from pump without removing pump from combine. Disconnect control linkage.

1. Remove six screws to loosen valve.
2. Unhook link (16) from control link.
3. Discard drained oil and cover opening in pump housing to keep dirt out.
4. Unhook link (14) from connector (17), loosen set screw (12), remove spring pin (18) and pull shaft (25) out of valve.
5. Scribe two lines on adjusting screw (10) to indicate setting.
6. Loosen set screw and remove adjusting screw (10) and spool (3).
7. Clean all part in solvent and dry thoroughly. Replace all worn or damaged parts and install new O-rings.

8. Insert spool kit (8) into housing. Screw centering spring adjusting screw (10) until scribe marks align. Tighten set screw.

9. If new spool, spring or adjusting screw is installed, turn adjusting screw into housing until just contacting spring. DO NOT compress spring.

10. Install pivot shaft, new sealing washer and O-ring. Tighten set screw (12) and install pin (18) and connect link (14) in connector (17).


11. Check spool (3) for end play by moving it back and forth. If there is end play, tighten adjusting screw (10) until it touches spring. Exert a slight back and forth force on spool while adjusting screw. DO NOT compress spring beyond its installed length.

12. Hook link (16) into control link. Make sure control link is pointing toward end cover of housing or unit will not function properly.

13. Tighten attaching bolts to 24 N·m (17.7 lb-ft).

ZX, TMXZCO009577-19-01AUG97

## REPAIRING THE CHARGE PUMP



HP2955

HP2955 -UN-01JAN94

- |                                |                              |                       |                  |
|--------------------------------|------------------------------|-----------------------|------------------|
| 1—Shaft                        | 7—Bushing                    | 14—Rotor              | 22—Test port     |
| 2—Pin                          | 8—Needle bearing             | 15—Seal               | 23—Dust cap      |
| 3—O-ring                       | 9—O-ring (2 used)            | 16—Snap ring (2 used) | 24—Filter        |
| 4—O-ring                       | 10—Spacer                    | 17—O-ring             | 25—Pump assembly |
| 5—Charge pressure relief valve | 11—Cover with needle bearing | 18—Filter base        | 26—Pin           |
| 6—Housing with needle bearing  | 12—Cap screw                 | 19—Cap screw          | 27—Gasket        |
|                                | 13—Cap screw                 | 20—O-ring             | 28—Gasket        |
|                                |                              | 21—Plug               |                  |

1. Scribe a line across pump sections.
2. Remove cap screws (12 and 13).
3. Inspect rotor assembly (14), shaft (1) and body (6) for excessive wear or scoring. Replace if necessary.
4. Remove and clean pressure relief valve (5).
5. Install new O-rings and packings.
6. Assemble pump, aligning scribe marks.
7. Tighten pressure relief valve (5) to 163-197 N·m (120-145 lb-ft).
8. Tighten cap screws (12 and 13) to 22 N·m (192 lb-in.).



ZX.TMXZCO009578-19-01AUG97

## INSTALL HYDROSTATIC PUMP

**CAUTION:** The approximate weight of the pump is 68 kg (160 lb).

1. Attach pump with four cap screws. Tighten screws to 130 N·m (96 lb-ft).
2. Connect lines and control cable to pump (C). Use new O-rings. Before connecting line (A), fill hydrostatic pump housing with clean hydrostatic oil.
3. Check oil level. Start engine and bleed system.

A—Line to Hydrostatic Oil Cooler  
B—Charge Pump Suction Line  
C—Hydrostatic Pump  
D—High Pressure Hose (2 used)  
E—Control Cable



ZX.TMXZCO002396-19-25NOV92

## INSTALLING THE CONTROL CABLE


1. Adjust the cable to be sure combine will not “creep” with hydrostatic drive lever in neutral.

Place hydrostatic drive lever in neutral.

Attach ball joint (A) on cable to bore of arm (B).

2. Do not move the arm when attaching the ball joint. It must pass freely into the bore. Turn ball joint off or on rod to adjust.

3. Start engine. The combine should not “creep” with hydrostatic drive lever in neutral. If creeping does occur, readjust cable at ball joint.



ZX.TMXZCO009579-19-01AUG97





# Group 30

## Hydrostatic Drive, Fixed-Displacement Motor

### SPECIFICATIONS

Item	Measurement	Specification
Pressure relief valve . . . . .	Identification stamp . . . . .	016-160 psi (1100 kPa; 11 bar) 500-5000 psi (35000 kPa; 350 bar)
Low pressure relief valve . . . . .	Tightening torque . . . . .	100 N·m (75 lb-ft)
High pressure relief valve . . . . .	Tightening torque . . . . .	35 N·m (25 lb-ft)
Gap between retaining plate and slipper retainer . . . . .	Wear tolerance . . . . .	0.2 mm (0.08 in.)
Drive shaft . . . . .	End play . . . . .	0.05-0.18 mm (0.002-0.007 in.)
Fixed displacement motor . . . . .	Weight . . . . .	40 kg (90 lb)
Screws at valve block . . . . .	Tightening torque . . . . .	42 N·m (31 lb-ft)
Screws at end cap . . . . .	Tightening torque . . . . .	70 N·m (50 lb-ft)

ZX, TMXZCO009580-19-01AUG97

### REMOVING THE FIXED DISPLACEMENT MOTOR

**IMPORTANT:** Thoroughly clean fixed displacement motor and surrounding area.


Drain hydrostatic oil.

Disconnect all hoses at fixed displacement motor.

**IMPORTANT:** Plug all open lines and connectors.

Support fixed displacement motor by means of a jack, separate from transmission and remove from bottom of machine.

**CAUTION:** Approximate weight of motor is 40 kg (90 lb).



ZX013623

- A—High pressure line
- B—High pressure line
- C—Flushing oil line to variable pump
- D—Pilot line to four-wheel-drive solenoid


ZX013623 -UN-05DEC97

ZX, TMXZCO009581-19-01AUG97

## DISASSEMBLE FIXED DISPLACEMENT MOTOR — PREPARATIONS


**IMPORTANT:** Cleanliness is a must when working on the fixed displacement motor.

1. Remove snap ring (A).
2. Remove seal retainer (B) with stationary part of seal set.



-UN-01JUN95

Z116458




-UN-01JUN95

Z116459

ZX,TMSPFH000335-19-22JUL91

3. Remove moving part of seal set (C).
4. Place fixed displacement motor on mounting plate.




-UN-01JUN95

Z116460

ZX,TMSPFH000336-19-28JAN91

## REMOVE VALVE BLOCK




-UN-01JUN95

Z116461

ZX,TMSPFH000337-19-28JAN91

## VALVE BLOCK, EXPLODED VIEW

- A—Housing
- B—High pressure relief valves
- C—Low pressure relief valve
- D—Springs
- E—Plugs
- F—Valve seats
- G—O-rings
- H—Seal ring
- I—Back-up rings



ZX,TMSPFH000338-19-28JAN91

Z116462 -UN-01JUN95

## ASSEMBLING THE VALVE BLOCK

Observe utmost cleanliness when assembling valve block.

If seal rings were removed, install new ones.

When installing high pressure relief valves, be sure to install one back-up ring on each side of the O-ring.

On low pressure relief valve, no back-up rings are used. This valve is only provided with an O-ring.

A number is stamped on the pressure relief valves for identification:

016—160 psi (1100 kPa; 11 bar)

500—5000 psi (35 000 kPa; 350 bar)

Tighten low pressure relief valve to 100 N·m (75 lb-ft).

Tighten high pressure relief valves to 35 N·m (25 lb-ft).

Tighten valve block to 42 N·m (31 lb-ft).

ZX,TMXZCO009582-19-01AUG97

## REMOVE END CAP

1. Remove all but two of the screws (which should be opposite each other).

The end cap is spring-loaded, therefore loosen the last two opposite screws alternately until the load has been released.


**IMPORTANT: When removing end cap, be careful not to damage valve plate and bearing plate.**

2. Remove end cap (A).


3. Remove valve plate (B) and bearing plate (C).

*NOTE: To avoid damaging valve plate and bearing plate, both parts should be wrapped separately in clean fiberless paper.*

A—End cap  
B—Valve plate  
C—Bearing plate



-UN-01JUN95  
Z116463



-UN-01JUN95  
Z110267

ZX,TMSPFH000340-19-22JUL91

## REMOVE BEARING

Install special tool on bearing. Remove bearing, using a puller.





-UN-01JUN95  
Z116465

ZX,TMSPFH000341-19-28JAN91

## REMOVE SWASHPLATE

Remove the two hex. socket screws and take swashplate with drive shaft and cylinder block out of motor housing.




ZX,TMSPFH000342-19-28JAN91

## DISASSEMBLE SWASHPLATE PARTS


**IMPORTANT:** Do not damage drive shaft sealing surface.

Remove drive shaft from swashplate assembly.



ZX,TMSPFH000343-19-22JUL91

**SWASHPLATE ASSEMBLY, EXPLODED VIEW**



A—Swashplate  
B—Wear plate


C—Retainer plates  
D—Spacer bushings

E—Hex. socket screws  
F—Piston with slippers

G—Slipper retainer  
H—Cylinder block

## REPLACE CYLINDER BLOCK SPRING

1. Press outer retaining ring (A) down to compress spring (C).
2. Remove spiral retaining ring (B).
3. Remove retaining ring, spring, and beveled inner retainer (D).
4. Replace spring and reinstall parts.
5. Install beveled inner retainer (D) with beveled side toward splined end of block.
6. Install outer retaining ring (A) with shoulder towards open end of block.
7. Compress spring and outer retaining ring, then install spiral retaining ring.



A—Outer Retaining Ring  
B—Spiral Retaining Ring  
C—Spring  
D—Inner Retainer (Beveled)

1401,5020,BZ -19-12SEP91

N36010 -UN-29SEP88

## REPAIR FIXED DISPLACEMENT MOTOR

**For repair of fixed displacement motor, note the following:**

- When removing O-rings and seals, install new parts.
- Check shaft seal assembly. Sliding surfaces should not be damaged or scored.
- Check motor shaft bearing surfaces and bearings for roughness and discoloration. Replace parts as necessary.
- Check wear plate surface for proper condition and replace plate, if necessary.
- Check cylinder block and pistons for damage. Replace parts as necessary. Pistons may be replaced individually.
- Check valve plate and bearing plate for damage and replace, if necessary.

ZX,TMSPFH000345-19-22JUL91

## ASSEMBLE FIXED DISPLACEMENT MOTOR

Prior to assembly, thoroughly clean and dry all parts.

Coat all parts with hydraulic oil of specified quality to prevent them from running dry.


Grease all O-rings, using non-acid grease.

ZX.TMSPFH000346-19-22JUL91

## CHECKING PARTS FOR WEAR

Distance (X) between retainer plate (B) and slipper retainer (C) must not exceed 0.2 mm (0.08 in.).

- A—Spacer bushing
- B—Retainer plate
- C—Slipper retainer
- D—Slipper
- E—Wear plate
- F—Piston
- G—Hex. socket screw
- X—Distance between slipper retainer and retainer plate
- Y—Height of slipper and slipper retainer
- Z—Height of spacer bushing



Z116450 -UN-02JUN95

ZX.TMSPFH000312-19-22JUL91

For further assembly of fixed displacement motor, reverse disassembly procedure.

Check drive shaft axial play.

ZX.TMSPFH000348-19-22JUL91




### CHECK DRIVE SHAFT AXIAL PLAY

Drive bearing on shaft and attach end cap without valve plate and bearing plate.

Check drive shaft axial play.

Permissible axial play: 0.05 to 0.17 mm (0.002 to 0.007 in.).

If necessary, adjust axial play by adding spacer washers under bearing cup in end cap.



Z116457 -UN-02JUN95

ZX,TMSPFH000349-19-28JAN91

### INSTALL FIXED DISPLACEMENT MOTOR

Install fixed displacement motor, reversing removal procedure.

Before operating forage harvester, fill hydrostatic system with oil. Refer to "Hydrostatic Drive, Oil Change".

ZX,TMSPFH000350-19-22JUL91

*Hydrostatic Drive, Fixed-Displacement Motor/Install fixed-displacement motor*

# Group 35 Hydrostatic Drive, Oil Change

## SPECIFICATIONS

Item	Measurement	Specification
Hydrostatic drive system	Capacity	24 L (6.34 U.S. gal)

ZX.TMSPFH000966-19-22JUL91


## DRAINING OIL

Open filler cap.


Remove return hose (A) or drain plug (harvester without four wheel drive) and drain oil from tank.

Remove drain plug (B) at fixed-displacement motor and drain oil from variable pump and fixed displacement motor.

Replace oil filter element at variable pump.



-UN-31MAY95  
ZX000065



-UN-31MAY95  
ZX000824

ZX.TMSPFH000967-19-01JUL91

## REFILLING THE HYDROSTATIC SYSTEM

1. Remove hose (A) from fixed-displacement motor.  
Fill fixed-displacement motor with clean hydraulic oil.  
Reconnect hose (A).
2. Remove hose (B) from variable pump.  
Fill variable pump with clean hydraulic oil.  
Reconnect hose (B).
3. Fill hydrostatic oil tank up to sight glass.
4. Crank engine with starting motor until hydrostatic charge pressure indicator light goes out.

**IMPORTANT:** To prevent the engine from starting, on 2254 machines remove fuse F16 from the fuse board. On 2256, 2258, 2264 and 2266 machines, disconnect plug (C; solenoid for injection pump).

5. Insert fuse F16 or reconnect plug (C), and then start the engine.


With transmission in first gear drive harvester slowly backward and forward.

6. Shut off engine.


Check hydrostatic system for leaks.

Check oil level in hydrostatic oil tank.


System is now ready for operation.



ZX000831 -UN-31MAY95



ZX007680 -UN-20JUN95



ZX005363 -UN-06JUN95

ZX,TMXZCO009458-19-05MAR98

**SPECIFICATIONS**

Item	Measurement	Specification
Cam lobe motor . . . . .	Weight . . . . .	170 kg (370 lb)
Attachment of cam lobe motor to axle . . . . .	Tightening torque . . . . .	560 N·m (410 lb-ft)
Slotted nut . . . . .	Tightening torque . . . . .	150 N·m (110 lb-ft)
Screws at steering cyl. support . . .	Tightening torque . . . . .	325 N·m (240 lb-ft)
		163 N·m (120 lb-ft)

ZX, TMXZC0009583-19-01AUG97

## FOUR-WHEEL DRIVE

**IMPORTANT:** Do not switch 4-wheel drive on or off while driving in 3rd gear (road gear) at maximum travel speed.

Move ground speed control lever to a position midway between neutral and max. speed before switching 4-wheel drive on or off.

*NOTE:* The road safety switch must be in the field (off-road) position before four-wheel drive can be engaged.



The 4-wheel drive system is designed for use in conditions where traction is poor or when needed to improve steering control.

To engage the drive, depress the foot switch.

To disengage the drive, depress foot switch once again.

It is not necessary to engage 4-wheel drive when driving the combine harvester unless conditions are soft or muddy.

In most conditions, it is normal for front wheels to spin before rear wheels spin. When this occurs, shift into 3rd gear. In extremely muddy conditions, it may be necessary to apply both brakes momentarily to increase hydrostatic pressure.



ZX,OMXZC0001582-19-02MAY96

## INSTALLING THE CAM LOBE MOTOR

Bolt the cam lobe motor to the rear axle.


Tighten the four cap screws (D) to 560 N·m (410 lb-ft).

Connect the hydraulic hoses to the cam lobe motor.

Bolt the tie rod and steering cylinder to the steering lever.

Tighten slotted nut to 150 N·m (110 lb-ft), and then secure.


Finally, fill with hydraulic oil.



ZX,TMSPFH001717-19-22FEB92

## STEERING CYLINDER SUPPORT ATTACHING SCREWS TO WHEEL MOTOR

After the first 10 hours of operation, tighten cap screws (A) at both sides to 325 N·m (240 lb-ft) and cap screws (B) to 163 N·m (120 lb-ft).



ZX,OMXZC0002221-19-05OCT92

*Cam Lobe Motor/Installing the cam lobe motor*



# Section 60

## Brakes, Steering, Rear Axle

### Contents

	Page	Page	
<b>Group 05—Brake Operating Assembly</b>			
Brake fluid for brake system . . . . .	60-05-1	Installing spool assembly . . . . . 60-15-16	
Removing brake master cylinder . . . . .	60-05-1	Installing the check valve . . . . . 60-15-16	
Repairing brake master cylinder . . . . .	60-05-2	Installing safety valves . . . . . 60-15-17	
Installing brake master cylinder . . . . .	60-05-3	Installing O-ring . . . . . 60-15-17	
Adjusting the yoke . . . . .	60-05-3	Installing distributor plate and drive shaft . 60-15-17	
Repairing pressure equalizing valve . . . . .	60-05-4	Installing rotor and stator . . . . . 60-15-18	
Removing brake operating cylinder . . . . .	60-05-4	Installing spacer ring . . . . . 60-15-18	
Repairing brake operating cylinder . . . . .	60-05-5	Installing metering unit cover . . . . . 60-15-18	
Bleeding the brake system . . . . .	60-05-5	Testing the safety valves . . . . . 60-15-19	
<b>Group 10—Brakes</b>			
Removing the brake drum . . . . .	60-10-1	Adjusting the safety valves . . . . . 60-15-19	
Removing the brake shoe . . . . .	60-10-1	Testing the pressure-control valve . . . . . 60-15-20	
Repairing the brakes . . . . .	60-10-2	Adjusting the pressure-control valve . . . . . 60-15-20	
Assembling the brakes . . . . .	60-10-4	Bleeding the hydrostatic steering system . 60-15-21	
<b>Group 15—Hydrostatic Steering</b>			
Special tools . . . . .	60-15-1	Removing the hydraulic steering pump . . 60-15-21	
Specifications . . . . .	60-15-2	Hydraulic lines to steering cylinders . . . . 60-15-22	
Steering column components . . . . .	60-15-3	Dismantling the steering cylinders . . . . . 60-15-23	
Steering hydraulic components . . . . .	60-15-5	Steering cylinder with ball joints . . . . . 60-15-23	
Removing the steering valve . . . . .	60-15-6	Adjusting steering angle at steering cylinders . . . . . 60-15-24	
Steering valve components . . . . .	60-15-7	Exploded view of tie rod . . . . . 60-15-25	
Disassembling the steering unit . . . . .	60-15-8	Adjusting toe-in . . . . . 60-15-26	
Removing the safety valves . . . . .	60-15-8	Checking rear-wheel toe-in . . . . . 60-15-26	
Removing the check valve . . . . .	60-15-9	<b>Group 20—Rear Axle</b>	
Removing spool and sleeve . . . . .	60-15-9	Special tool (self-manufactured) . . . . . 60-20-1	
Disassembling the spool assembly . . . . .	60-15-9	Rear axle support (standard) . . . . . 60-20-2	
Removing leaf springs . . . . .	60-15-10	Rear axle support (Hillmaster) . . . . . 60-20-3	
Removing seal ring . . . . .	60-15-10	Standard rear axle - exploded view . . . . . 60-20-4	
Removing the safety valves . . . . .	60-15-10	Adjustable rear axle - exploded view . . . . . 60-20-5	
Removing pressure-control valve . . . . .	60-15-11	Removing the rear axle . . . . . 60-20-6	
Repairing the steering unit . . . . .	60-15-12	Installing the rear axle . . . . . 60-20-7	
Assembling the steering unit . . . . .	60-15-12	Adjusting rear axle width . . . . . 60-20-8	
Installing pressure-control valve . . . . .	60-15-13	Attaching screws . . . . . 60-20-9	
Installing safety valves . . . . .	60-15-13	Rear wheel tread . . . . . 60-20-9	
Arranging leaf springs . . . . .	60-15-14	Spindle and wheel hub - exploded view . . 60-20-10	
Installing leaf springs . . . . .	60-15-14	Installing spindle . . . . . 60-20-11	
Assembling the spool assembly . . . . .	60-15-14	Assembling wheel hub . . . . . 60-20-11	
Installing retaining ring and cross-pin . . . . .	60-15-15		
Assembling the thrust bearing . . . . .	60-15-15		
Installing the seal ring . . . . .	60-15-15		
Installing O-ring and back-up ring . . . . .	60-15-16		

*Contents*


**BRAKE FLUID FOR BRAKE SYSTEM**

**IMPORTANT:** Use only brake fluid that meets SAE Standard J 1703 (DOT 4).

Capacity:

- Complete system 1.0 L (0.26 U.S. gal)
- Reservoir 0.5 L (0.13 U.S. gal)

- A—Service flap, vehicle electrics
- B—Brake fluid reservoir
- C—Reservoir cap with float



ZX\_OMXZCO002385-19-04DEC92

**REMOVING BRAKE MASTER CYLINDER**

1. Drain brake fluid at bleed valve in a suitable container.

2. Unhook spring (A).



Remove pin (B).

Remove hose (C).

Remove brake line on pressure side. If necessary, disconnect cable to brake light switch.


Remove brake master cylinder attaching screws and brake master cylinder.

- A—Spring
- B—Pin
- C—Hose



ZX\_TMSPFH001097-19-23SEP91

**REPAIRING BRAKE MASTER CYLINDER**



A—Brake master cylinder housing  
B—Double-stage piston

C—Washer  
D—Snap ring

E—Boot  
F—Rod

G—Bleed screw  
H—Oil inlet

After snap ring (D) has been removed brake master cylinder can be disassembled.

**IMPORTANT:** To ensure exact operation do not repair double-stage piston (B). Replace double-stage piston (B) as a unit, if necessary.

If brake master cylinder is worn, rusty or has visible scores, replace it as a unit.

When assembling brake master cylinder make sure bore in boot (E) is at the bottom to drain condensation water.

ZX001618

ZX001618 -UN-03MAY95

ZX, TMSPFH001098-19-30AUG94

### INSTALLING BRAKE MASTER CYLINDER


Install brake master cylinder by reversing removal procedure.

Bleed brake system after yoke adjustment has been completed.

Check adjustment of yoke after installation and correct adjustment, if necessary.

ZX,TMSPFH001099-19-23SEP91

### ADJUSTING YOKE AT BRAKE MASTER CYLINDER



ZX001623

A—Yoke  
B—Brake master cylinder

C—Retracting spring  
D—Brake pedal

E—Pin  
F—Lock nut

G—Distance 0.5—1 mm  
(0.02—0.04 in.)

Adjust yoke (A) at brake master cylinder until a clearance (G) of 0.5—1 mm (0.02—0.04 in.) is


obtained between rod and brake piston with brake pedal in home position.

ZX,TMSPFH001100-19-23SEP91

## REPAIRING PRESSURE EQUALIZING VALVE

Replace pressure equalizing valve with a new one, when defective.

- A—Housing
- B—Piston
- C—Stop washer
- D—Spring






ZX, TMSPFH001101-19-23SEP91

ZX001619 -UN-24APR95

## REMOVING BRAKE OPERATING CYLINDER

1. Open bleeding valve and drain brake fluid in a suitable container.
2. Remove brake drum and brake linings.
3. Remove brake line (A) and bleed line (B).
4. Remove brake operating cylinder after having removed attaching screws (C).

- A—Brake line
- B—Bleed line
- C—Attaching screws



ZX, TMSPFH001102-19-01OCT91


## REPAIRING BRAKE OPERATING CYLINDER

Disassemble brake operating cylinder.

Check all parts for wear, scores or rust.

Use suitable repair kit if any parts are damaged.



- A—Rod
- B—Dust boot
- C—Brake piston
- D—Boot
- E—Brake operating cylinder housing
- F—Plate washer
- G—Spring



ZX,TMSPFH001103-19-23SEP91

## BLEEDING BRAKE SYSTEM

1. Fill brake fluid reservoir.
2. Attach a transparent plastic hose to bleed valve to catch escaping oil in a container.
3. Unlock brake pedals.
4. Depress brake pedal of brake being bled approx. five times and keep in depressed position.
5. For a short time open bleed valve of brake being bled, then close again.
6. Release brake pedal and repeat steps 4 and 5 until escaping brake fluid is free of bubbles.




ZX,TMSPFH001104-19-23SEP91

*Brake Operating Assembly/Bleeding the brake system*



## REMOVING BRAKE DRUM

1. Remove snap ring (F) to slide coupling (E) from sleeve (C).
2. Remove pin (B) from sleeve (C).
3. Remove drive shaft (D) from brake drum (A).
4. Remove brake drum.
5. Pry plug out of hole in brake drum. Disconnect parking brake cable at equalizer bar. Disconnect brake line. Remove five cap screws that secure brake assembly to transmission. Lower assembly to the ground and remove brake drum.



A—Brake drum  
B—Pin  
C—Sleeve  
D—Drive shaft  
E—Coupling  
F—Snap ring

ZX,1401,6010,C -19-12SEP91

H40510 -UN-06SEP89


## REMOVING BRAKE SHOE

1. Remove brake drum (see this Group).
2. Remove springs (H and O—R) to remove brake shoes (A) from backing plate.

*NOTE: Only remove anchor bolt (D) if it is necessary to repair park brake mechanism.*

**IMPORTANT: Keep hands clean when handling brake shoes. Do not permit oil or grease to come in contact with linings.**


A—Brake shoe (2 used)	K—Cable
B—Cable	L—Support pin
C—Eccentric plate	M—Adjuster bolt
D—Anchor bolt	N—Brake adjusting lever
E—Park brake lever	O—Spring
F—Piston	P—Spring
G—Hook (2 used)	Q—Spring
H—Spring (2 used)	R—Spring
I—Washer (4 used)	
J—Cap screw (5 used)	



ZX,1401,6010,D -19-12SEP91

H40511 -UN-06SEP89

REPAIR BRAKES



HP3237

HP3237 -UN-10OCT88

ZX,1401,6010,E -19-12SEP91

## Brakes/Repairing the brakes

1—Snap ring	9—Hook	17—Spring	25—Brake to transmission cap screws (5 used)
2—Washer	10—Spring	18—Brake adjusting lever	26—Washer
3—Eccentric plate	11—Spring	19—Adjusting screw kit	27—Guide
4—Park brake lever	12—Spring kit	20—Adjusting screw	28—Backing plate
5—Spring	13—Cover	21—Support pin	29—Cable (to pedal)
6—Anchor bolt	14—Pin	22—Brake drum	30—Fluid line
7—Park brake kit	15—Cable	23—Snap ring	
8—Spring	16—Guide	24—Brake shoes	


### Legend for Exploded View of Brakes

- |  |   |
|--|---|
| <p>1. Clean backing plate (28). Be sure shoe support points are smooth and free of rough edges.</p> <p>2. Clean support pin (21) threads and check for thread damage. The adjusting screw (20) must turn freely.</p> <p>3. Check springs (5, 8, 10, 11 and 17) and other parts for loss of tension and damage. Replace weak springs and any damaged or worn parts.</p> <p>4. Shoe linings must not be glazed, soiled with grease or brake fluid or otherwise damaged. There must be a minimum of 0,8 mm (1/32 in.) lining remaining above rivet heads at the thinnest point.</p> | <p>5. Brake shoes (24) must not be distorted, cracked or have broken welds.</p> <p>6. Check slave cylinder by pulling back edge of dust boot. There should be no brake fluid inside the boot. If inside of boot is wet, repair cylinder as described.</p> <p>7. Each brake drum (22) can be turned down a maximum of 1,52 mm (0.060 in.) from the diameter or 0,76 mm (0.030 in.) on each side.</p> <p>Rebore or replace the drum if the out of roundness exceeds 0,15 mm (0.006 in.). Measure out of roundness with a dial indicator with brake drum mounted on a lathe.</p> |
|--|---|

ZX,1401,6010,F -19-12SEP91

8. Rebore or replace brake drum if the contact surface has scoring deeper than 0,25 mm (0.010 in.) (A). The best method of checking scoring depth is to mount the brake drum on a lathe.
9. Rebore or replace brake drum if the inside diameter of the drum at the open end exceeds the inside diameter at the closed end by more than 0,25 mm (0.010 in.) (B). Measure diameters with a micrometer.

A—Scored brake drum  
B—Bell shaped brake drum




H38267

H38267 -UN-10OCT88

ZX,1401,6010,G -19-12SEP91

10. Rebore or replace the drum if the surface variance exceeds 0,13 mm (0.005 in.) on the side. Measure this with a straight edge and a narrow feeler gauge.

- A—Convex brake drum
- B—Concave brake drum



H38268


-UN-10OCT88  
H38268

ZX.1401.6010.H -19-12SEP91

11. Rebore or replace the drum if hard or chill spots (A) cause noticeable effects of pedal pulsations or brake roughness.

12. Rebore or replace the drum if heat checks (B) are plainly visible or can be felt with a fingernail.

- A—Hard or chill spots
- B—Heat checks



H38269

-UN-10OCT88  
H38269

ZX.1401.6010.I -19-12SEP91

## ASSEMBLING BRAKES


1. Apply a small amount of SAE multipurpose type grease to eccentric plate (C) mechanism behind the anchor bolt (D). Be certain parts are moving freely, but do not over-lubricate. Also apply a small amount of this grease to the dimples on the backing plate on which the brake shoes (A) ride.

2. Install parts (A—R).

3. Tighten nut on anchor bolt (D) to 45 N·m (33 lb-ft).

4. Tighten cap screws (J) to 620 N·m (460 lb-ft) anziehen.

- |                       |                         |
|-----------------------|-------------------------|
| A—Brake shoe (2 used) | K—Cable                 |
| B—Cable               | L—Support pin           |
| C—Eccentric plate     | M—Adjusting screw       |
| D—Anchor bolt         | N—Brake adjusting lever |
| E—Park brake lever    | O—Spring                |
| F—Piston              | P—Spring                |
| G—Hook (2 used)       | Q—Spring                |
| H—Spring (2 used)     | R—Spring                |
| I—Washer (4 used)     |                         |
| J—Cap screw (5 used)  |                         |



-UN-06SEP89  
H40511

ZX.1401.6010.J -19-12SEP91


**Group 15**  
**Hydrostatic Steering**

**SPECIAL OR ESSENTIAL TOOLS**

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*


DX,TOOLS -19-20JUL95

Tool kit . . . . . KML10018  
Installation of hydrostatic steering valve.



ZX,TMSPFH001105-19-23SEP91

Test fitting . . . . . KJD10113  
Use with R. Bosch nozzle tester JT25510




ZX,TMSPFH003505-19-05JUL94

## **SPECIFICATIONS**

<b>Item</b>	<b>Measurement</b>	<b>Specification</b>
Pressure-control valve	Pressure adjustment range	13000-14000 kPa (130-140 bar; 1885-2030 psi)
Safety valve	Pressure adjustment range	18000-20000 kPa (180-200 bar; 1960-2900 psi)
Cover to housing	Torque	30 N·m (23 lb-ft)
Threaded plug on safety valves	Torque	30 N·m (23 lb-ft)
Straight screw connections to steering valve	Torque	55 N·m (40 lb-ft)
Steering wheel to spindle, hex. nut	Torque	50 N·m (35 lb-ft)
Adjusting ring on spindle, self-locking hex. nut	Torque	20 N·m (15 lb-ft)
Slotted nut to ball joints	Torque	180 N·m (133 lb-ft)
Slotted nut to adjustable tie rod	Torque	180 N·m (133 lb-ft)
Steering cylinder screws to wheel motor	Torque	325 N·m (240 lb-ft)
Lower screws, tie rod to wheel motor	Torque	136 N·m (100 lb-ft)
Clamp screw for clamp on ball joint	Torque	45 N·m (33 lb-ft)
Clamp screws on adjustable axle	Torque	420 N·m (177 lb-ft)
Screws, wheel motor to sliding sleeve	Torque	575 N·m (424 lb-ft)
Rear wheel nuts	Torque	180 N·m (133 lb-ft)

ZX, TMSPFH003471-19-29JUN94

**STEERING COLUMN COMPONENTS**




ZX005277

- |                                    |                  |                  |            |
|------------------------------------|------------------|------------------|------------|
| 1—Panel                            | 6—Starter switch | 12—Plate         | 18—Disk    |
| 2—Cover                            | 7—Cam            | 13—Sliding plate | 19—Cover   |
| 3—Upper section of steering column | 8—Rod            | 14—Pedal         | 20—Disk    |
| 4—Lower section of steering column | 9—Guide          | 15—Shaft         | 21—Bracket |
| 5—Indicator light mounting         | 10—Cover         | 16—Screw         | 22—Spring  |
|                                    | 11—Bracket       | 17—Plate         | 23—Spring  |

ZX005277 -UN-02MAY95

ZX.TMSPFH003415-19-29JUN94

**STEERING COLUMN COMPONENTS (CONTINUED)**



ZX005278

ZX005278 -UN-02MAY95

- 1—Cap
- 2—O-ring
- 3—Adjusting ring
- 4—Retainer
- 5—Wheel
- 6—Snap ring


- 7—Turn indicator switch
- 8—Shaft
- 9—Snap ring
- 10—Bearing
- 11—Bearing
- 12—Shaft

- 13—Ring
- 14—Shaft
- 15—Washer
- 16—Shaft
- 17—Bearing
- 18—Snap ring

- 19—Universal joint shaft
- 20—Guide
- 21—Coupler
- 22—Connector
- 23—Coupler



**STEERING HYDRAULIC CIRCUIT**



- |                           |                  |                 |               |
|---------------------------|------------------|-----------------|---------------|
| A—Hydraulic oil reservoir | D—Pressure line  | G—Return line   | K—Hose clamp  |
| B—Suction line            | E—Steering valve | H—T-fitting     | L—Screw union |
| C—Steering pump           | F—Filter         | J—Elbow fitting |               |

ZX 005367

-JUN-03MAY95


ZX005367

ZX, TMXZCO003969-19-15FEB95

## REMOVING THE STEERING VALVE


Unscrew hydraulic lines (A), seal all openings with stoppers mark the hoses.

Take four screws (B) out of steering valve plate and lift off steering valve together with the plate.




ZX, TMSPFH003417-19-29JUN94

Unscrew plate (A) from steering valve.



ZX, TMSPFH003418-19-29JUN94

**STEERING VALVE COMPONENTS**



**Z 35589**

- |                           |                          |                            |                    |
|---------------------------|--------------------------|----------------------------|--------------------|
| 1—Flat, round-head screws | 12—Spacer ring           | 22—Spring pin              | 32—Spring          |
| 2—Type plate              | 13—Drive shaft           | 23—Bushing                 | 33—Adjusting screw |
| 3—Cap screws              | 14—Valve sleeve          | 24—Spring pin              | 34—Seal ring       |
| 4—Roll pin                | 15—Valve spool           | 25—Ball (2 used)           | 35—Plug            |
| 5—Seal washers            | 16—Leaf springs (6 used) | 26—O-ring and back-up ring | 36—Ball            |
| 6—Cover                   | 17—Cross pin             | 27—Threaded bushing        | 37—Valve head      |
| 7—O-rings                 | 18—Retaining ring        | 28—Ball                    | 38—Spring          |
| 8—Stator                  | 19—Bearing race          | 29—Housing                 | 39—Adjusting screw |
| 9—Rotor                   | 20—Thrust bearing        | 30—Seal ring               | 40—Seal ring       |
| 10—Distributor plate      | 21—Bearing race          | 31—Valve piston            | 41—Plug            |

-UN-03MAY95  
Z35589

ZX.TMSPFH003419-19-29JUN94

## DISASSEMBLING THE STEERING UNIT

### Disassembling the metering unit


Thoroughly clean exterior of steering unit and install in clamping device KML10018-1 for dismantling.

**IMPORTANT: Always use clamping device KML10018-1. Never attempt to clamp pump housing in a vice as this would seize the honed valve spool and render the unit unserviceable.**

Remove the seven cap screws of cover (A).

*NOTE: One of the seven cap screws is longer than the others. A roll pin is located in this screw.*

Remove cover (A), rotor (C), stator (B) and, if required, spacer ring (E). Then remove distributor plate (D) and drive shaft (F).



- A—Cover
- B—Stator
- C—Rotor
- D—Distributor plate
- E—Spacer ring
- F—Drive shaft

ZX,TMSPFH003420-19-29JUN94

## REMOVING SAFETY VALVES


Hold steering unit (B) at an angle and shake it to remove both safety valves (A).



ZX,TMSPFH003421-19-29JUN94

### REMOVING CHECK VALVE


Remove threaded bushing and shake out check valve ball (A).



ZX,TMSPFH003422-19-29JUN94

### REMOVING SPOOL AND SLEEVE

Press against spool to press spool (A) and the sleeve together with the retaining ring and bearing races out of the housing. Make sure that the cross pin is aligned in sleeve and spool. The cross pin is visible through the open end of the spool.



ZX,TMSPFH003423-19-29JUN94



### DISASSEMBLING THE SPOOL ASSEMBLY

Using special cap screw with roll pin (B) (cover attaching screw), press cross pin (A) out of spool assembly.

Carefully press spool (C) out of sleeve (D).

**IMPORTANT: Do not cant, as this would cause jamming. Press out carefully.**


- A—Cross pin
- B—Cap screw with roll pin
- C—Valve spool
- D—Valve sleeve



ZX,TMSPFH003424-19-29JUN94

### REMOVING LEAF SPRINGS

Press spring pack (B) out of the valve spool (A).



ZX,TMSPFH003425-19-29JUN94

-UN-26APR95  
Z103757

### REMOVING SEAL RING

Use a suitable tool to remove seal ring (A) from the housing.



ZX,TMSPFH003426-19-29JUN94



-UN-26APR95  
Z103758

### REMOVING THE SAFETY VALVES

*NOTE: Disassemble safety valves only when absolutely necessary. These valves are set to a specified pressure.*

Remove safety valve plug (A) and adjusting screw (B) with a 6 mm hex. socket wrench. Shake out spring with piston (C) and ball (D). Do not remove valve seats as these are secured with Loctite.

- A—Valve plug
- B—Adjusting screw
- C—Spring with piston
- D—Ball



ZX,TMSPFH003427-19-29JUN94

-UN-26APR95  
Z103759


-UN-26APR95  
Z103760

## REMOVING PRESSURE-CONTROL VALVE

*NOTE: Disassemble pressure-control valve only when absolutely necessary. These valves are set to a specified pressure.*

Using an 8 mm hex. socket wrench, remove valve plug (A). Remove adjusting screw (B) with a screwdriver.

Shake out spring and piston (C). Do not attempt to remove valve seat as it is secured with Loctite.



ZX.TMSPFH003428-19-29JUN94

## REPAIRING THE STEERING UNIT

Clean all parts thoroughly. Inspect all parts, and replace any that are no longer in perfect condition.

Inspect the following parts closely for excessive wear, scoring or damage:

All housing bores and channels and the edges of the machined surfaces.


Surface condition of valve sleeve and spool. Some burnishing is acceptable.

Check edges and grooves of valve sleeve and spool.

Check valve spool bearing surface for rust, pitting and wear.

Check thrust bearing and bearing races for pitting.

In addition, it is recommended to replace all seals, washers and — if necessary — the leaf springs.



-UN-27APR95  
Z35741

ZX,TMSPFH003429-19-29JUN94

## ASSEMBLING THE STEERING UNIT

### General

Before resuming assembly, again wash all parts in clean, petroleum-based solvent and place on a fiberless absorbent paper for drying.

**IMPORTANT: Do not, under any circumstances, use rags or cotton waste.**

ZX,TMSPFH003430-19-29JUN94



### INSTALLING PRESSURE-CONTROL VALVE



Use tweezers to install piston (A) in pressure-control valve.

Insert spring (B) over the piston and into the bore.

Coat the thread of adjusting screw (C) with T43512 sealant. Screw in adjusting screw (C) until the spring comes under pressure.

Install seal ring in groove of bore. Install plug (D) in bore and tighten to 40 - 60 N·m (29 - 43 ft-lb).

- A—Piston
- B—Spring
- C—Adjusting screw
- D—Plug



ZX.TMSPFH003431-19-29JUN94

### INSTALLING SAFETY VALVES



Use tweezers to install ball (A) in the bore of the safety valves.

Coat springs on valve cones with vaseline, and assemble. Insert spring (B) together with valve cones (C) in the respective bore.

Coat adjusting screw (D) with T43512 sealant. Tighten the screw until the spring is under tension.

Place sealing ring in the groove of the bore, and screw in plug (E). Tighten plug (E) to 30 - 40 N·m (22 - 29 ft-lb).

- A—Ball
- B—Spring
- C—Valve cone
- D—Adjusting screw
- E—Plug




ZX.TMSPFH003432-19-29JUN94

### ARRANGING THE LEAF SPRINGS

Lay leaf springs (A) and (B) down as shown in the illustration.

- A—Straight leaf spring (2 used)
- B—Convex leaf spring (4 used)



Z103768


ZX,TMSPFH003433-19-29JUN94

-UN-27APR95  
Z103768

### INSTALLING THE LEAF SPRINGS

Insert the two straight leaf springs (A) into the slot. Slide the four convex springs (B) between the straight springs (A) and align spring pack.

- A—Straight leaf spring (2 used)
- B—Convex leaf spring (4 used)
- C—Valve spool




Z107326

ZX,TMSPFH003434-19-29JUN94


-UN-27APR95  
Z107326

### ASSEMBLING THE SPOOL ASSEMBLY

Assemble the sleeve and spool (A), pressing spring pack together and inserting it into sleeve (B). Align spring pack (C).



Z107327



Z107328


ZX,TMSPFH003435-19-29JUN94

-UN-27APR95  
Z107327

-UN-27APR95  
Z107328

### INSTALLING RETAINING RING AND CROSS PIN

Slide retaining ring (A) over valve assembly (C). Make sure that the ring rotates freely over the spring pack. Insert cross pin (B) into spool assembly.




ZX,TMSPFH003436-19-29JUN94

### ASSEMBLING THE THRUST BEARING

Slide bearing race (B), thrust washer (C) and axial washer (D) into place.

*NOTE: Chamfer on bearing race (B) must face valve spool end.*


- A—Valve assembly
- B—Bearing race
- C—Thrust bearing
- D—Axial washer



ZX,TMSPFH003437-19-29JUN94

### INSTALLING THE SEAL RING

With lip facing outwards, position new seal ring (A) into groove in housing (B) and tap ring into groove with a suitably sized drift.



ZX,TMSPFH003438-19-29JUN94

### INSTALLING O-RING AND BACK-UP RING

Coat rings (E) with hydraulic oil and slide over small piston (A).



Press sleeve (C) of the special tool into housing (D) until it contacts stop.

Using the small piston (A), press large piston (B) of special tool into sleeve (C) until it contacts stop.

Pull sleeve (C), together with large piston (B), out of housing (D).

**NOTE:** Small piston remains in the steering valve until it is pushed out when the spool assembly is installed.

- A—Small piston KML10018-5
- B—Large piston KML10018-2
- C—Sleeve of KML10018-2
- D—Housing
- E—O-ring with back-up ring




ZX.TMSPFH003439-19-29JUN94

### INSTALLING SPOOL ASSEMBLY

Before installing spool assembly, coat it with oil. Insert pre-assembled spool assembly (A) into the bore in housing (B), applying a slight twisting movement.


**IMPORTANT:** Make sure that the cross pin is horizontal.



ZX.TMSPFH003440-19-29JUN94

### INSTALLING THE CHECK VALVE


Insert ball (A) into bore. Screw threaded bushing (B) into bore until slight resistance is felt. Bushing should not protrude beyond housing surface.



ZX.TMSPFH003441-19-29JUN94

### INSTALLING SAFETY VALVES

Install the two safety valves (A). Do not forget to put the balls in the bores.




ZX,TMSPFH003442-19-29JUN94

Z 103778  
-UN-27/APR95

### INSTALLING THE O-RING

Install O-ring (A) in housing (B).




ZX,TMSPFH003443-19-29JUN94

Z 103779  
-UN-27/APR95

### INSTALLING DISTRIBUTOR PLATE AND DRIVE SHAFT

Install distributor plate (A) so that the bores are aligned with the corresponding bores in the housing. Insert drive shaft (B) so that the slot is parallel to the connection side. Use special tool KML10018-4 to hold drive shaft (B).



ZX,TMSPFH003444-19-29JUN94

Z 103780  
-UN-27/APR95



## INSTALLING ROTOR AND STATOR

Install rotor (A) on drive shaft (B) so that rotor cavity is positioned in slot of drive shaft (B) as shown.

*NOTE: Illustration shows plainly the desired position of rotor and shaft. This assembly, described below, must be reached even although slot of drive shaft and cross pin are not visible.*

Rotor (A) and cross pin (C) must be in the specified position.


**IMPORTANT: It is absolutely necessary for satisfactory performance of the steering unit that the cross pin is in the position shown.**



ZX,TMSPFH003445-19-29JUN94

## INSTALLING SPACER RING


Insert spacer ring (A) as shown.



ZX,TMSPFH003446-19-29JUN94

## INSTALLING METERING UNIT COVER

Use seven cap screws (B) to secure cover (A). Insert cap screw (C) with roll pin in the correct bore. Tighten cap screws to 30 - 35 N·m (22 - 25 ft·lb).




ZX,TMSPFH003447-19-29JUN94

## TESTING THE SAFETY VALVES

*NOTE: Safety valves must always be tested prior to testing the pressure-control valve.*

Connect hose (B) to connection (3), steering cylinder (r.h. turn). Secure plastic hose (D) to return connection (4).

Build up pressure with lever of tester (A). Tester pressure gauge should show 180 - 195 bar (2610 - 2830 psi). Use same procedure to test safety valve for left-hand turn, connecting hose (B) to connection (2), steering cylinder (l.h. turn).



- A—Bosch nozzle tester
- B—Original steering hose (inlet)
- C—Test fitting KJD10113 (see “Special Tools”)
- D—Plastic return hose
- 1—Steering valve
- 2—Steering cylinder connection (l.h. turn)
- 3—Steering cylinder connection (r.h. turn)
- 4—Return connection


ZX.TMSPFH003448-19-29JUN94

## ADJUSTING THE SAFETY VALVES

Adjust pressure of safety valve by turning adjusting screws (B) and (C). First remove respective plug. Use a 6 mm hex. socket wrench to turn screw in to increase pressure or out to decrease pressure. Recheck valve operating pressure after adjustment.

When pressure is correct, install plug and tighten to 30 - 40 N·m (22 - 29 ft-lb).

- A—Steering valve
- B—Adjusting screw (l.h. turn)
- C—Adjusting screw (r.h. turn)




ZX.TMSPFH003449-19-29JUN94

## TESTING THE PRESSURE-CONTROL VALVE

Connect hose (B) to pressure connection (5) and return hose (D) to return connection (4). Seal both connections to the steering cylinder with dealer-manufactured plugs. Use a 5/8" hex. socket wrench to turn steering valve to full left- or right-hand lock and hold in this position. Operate pump lever of tester (A) to build up pressure. With control valve adjusted correctly, pressure should rise to 135 bar (1960 psi).

- A—Bosch nozzle tester
- B—Original steering hose (inlet)
- C—Test fitting KJD10113 (see "Special Tools")
- D—Plastic return hose
- E—Plug (dealer-fabricated)
- 1—Steering valve
- 4—Return connection
- 5—Pressure connection




ZX.TMSPFH003450-19-29JUN94

## ADJUSTING THE PRESSURE-CONTROL VALVE

Remove plug. Use a screwdriver to turn adjusting screw (B). Turn screw in to increase pressure, or out to decrease pressure.

After adjusting the valve, install plug and tighten to 50 N·m (36 ft-lb).


- A—Steering valve
- B—Adjusting screw



ZX.TMSPFH003451-19-29JUN94



## BLEEDING THE HYDROSTATIC STEERING SYSTEM

 **CAUTION: Do not drive the combine harvester after repairs on the hydrostatic steering until the system has been bled.**

Raise the rear axle and start the engine.

Turn the steering wheel several times to the right- and left-hand stops.

*NOTE: Air will bleed out only at the oil reservoir. Oil in the lines to the steering cylinder does not flow in the circuit, but moves back and forth with the air bubbles. Therefore, air in the system may be slow in reaching the steering unit and oil reservoir.*

When the oil in the reservoir is clear (not cloudy or creamy) and no play is noticeable at the steering wheel, the system is free of air.


ZX, TMXZCO004129-19-15FEB95

## REMOVING THE HYDRAULIC STEERING PUMP

See "Removing and Repairing the Pump" in Section 70, Group 10.

ZX, TMSPFH003453-19-29JUN94

**HYDRAULIC LINES TO STEERING CYLINDERS**



ZX 005368

A—Pressure line  
B—Steering valve

C—Pressure line to elbow fitting

D—Pressure line to steering cylinder

E—T-fitting  
F—Screw union

ZX005368 -UN-03MAY95

ZX,TMXZCO003970-19-15FEB95


## DISMANTLING THE STEERING CYLINDERS

Press snap ring (H) out of the groove and slide guide (C) inward.

Use a drift to take ring (G) out of the bore in the housing.

Pull out guide (C) together with grooved ring (E), wiper ring (F) and O-ring (D).

Piston (J), with one sealing ring and one wiper ring, is secured to the piston rod by a self-locking nut.



ZX 005319


- A—Housing
- B—Piston rod with piston
- C—Guide
- D—O-ring
- E—Grooved ring
- F—Wiper ring
- G—Snap ring
- H—Snap ring
- J—Piston with sealing rings

ZX.TMSPFH003458-19-29JUN94

ZX005319 -UN-21APR95

## STEERING CYLINDER WITH BALL JOINTS

- A—Cylinder
- B—Ball joint
- C—Clamp
- D—Slotted nut



ZX005311

ZX.TMSPFH003459-19-29JUN94

ZX005311 -UN-02MAY95

### ADJUSTING STEERING ANGLE AT STEERING CYLINDER



X-545 mm (21.45 in.) with standard axle, adjustable axle and four-wheel drive

Screw ball joint (A) on piston rod end fully onto the thread, and clamp it securely using clamp (B). Tighten the clamp screw to 45 N·m (33 lb-ft).

Screw ball joint (C) in until dimension (X) is achieved from cone to cone (with the piston rod pushed in). Tighten the clamp screw to 45 N·m (33 lb-ft).

Install steering cylinder and tighten slotted nut to 180 N·m (133 lb-ft).


Finally, secure the nut with a cotter pin.



ZX, TMXZCO003971-19-15FEB95

### STEERING CYLINDER SUPPORT ATTACHING SCREWS TO REAR AXLE


Tighten nuts (A) on cap screws (B) at right and left to 240 N·m (170 lb-ft).



ZX, TMXZCO003972-19-15FEB95


### STEERING CYLINDER SUPPORT ATTACHING SCREWS TO WHEEL MOTOR

At both sides, tighten cap screws (A) to 325 N·m (240 lb-ft) and cap screws (B) to 163 N·m (120 lb-ft).



ZX, TMXZCO003973-19-15FEB95

**TIE ROD — EXPLODED VIEW**



ZX005314

-JUN-03MAY95  
ZX005314

- |                             |               |   |                     |
|-----------------------------|---------------|---|---------------------|
| 1—Tie rod for standard axle | 4—Clamp screw | 7—Cotter pin                                      | 9—Tie rod extension |
| 2—Ball joint                | 5—Nut         | 8—Tie rod for adjustable axle<br>(center section) | 10—Screw            |
| 3—Clamp                     | 6—Slotted nut | 11—Clamp plate                                    |                     |


## ADJUSTING TOE-IN

Screw in the ball joints at both ends of the tie rod.  
Screw in by the same distance at both sides.

Adjust the length of the tie rod so that a toe-in of 0 mm  
(0 in.) is reached.

Tighten the ball joint clamps to 45 N·m (33 lb-ft).


Install slotted nut. Tighten to 180 N·m (133 lb-ft) and  
secure with a cotter pin.



ZX, TMXZCO003974-19-15FEB95


## CHECKING REAR WHEEL TOE-IN

Measure track width (A) at the rim lip level with the axle,  
and mark the point of measurement on the tire. Move  
the vehicle until the point of measurement has moved  
through 180°. Now measure distance (B). When toe-in is  
0 mm, dimensions (A) and (B) must be the same.



ZX, TMSPFH003463-19-29JUN94

**SPECIAL TOOL (SELF-MANUFACTURE)**



A—650 mm (25.6 in.)  
B—200 mm (7.9 in.)

C—200 mm (7.9 in.)  
D—140 mm (5.5 in.)


E—16 mm (0.6 in.)

F—30 mm (1.2 in.) dia.

**Tool for raising the rear axle**

ZX,TMXZCO003975-19-15FEB95

### STANDARD REAR AXLE SUPPORT AND REAR AXLE ATTACHMENT



ZX005372

ZX005372 -JUN-28/APR95

A—Standard support  
B—Insert

C—Retaining plate  
D—Bracket

E—Screw  
F—Nut


G—Self-locking nut

*NOTE: The rear axle support is welded to the side panels and cannot be replaced.*

ZX, TMXZCO003976-19-15FEB95



**HILLMASTER REAR AXLE SUPPORT AND REAR AXLE ATTACHMENT**



ZX005373

A—Hillmaster support  
B—Insert

C—Retaining plate  
D—Bracket

E—Screw  
F—Nut


G—Self-locking nut

*NOTE: The rear axle support is welded to the side panels and cannot be replaced.*

ZX005373 -UN-28APR95

ZX,TMXZCO003977-19-15FEB95

**STANDARD REAR AXLE — EXPLODED VIEW**




A—Axle

B—Brass bushing

C—Grease fitting

ZX, TMXZCO003978-19-15FEB95

### ADJUSTABLE REAR AXLE — EXPLODED VIEW



A—Axle center section  
B—Axle extension

C—Extension for four-wheel  
drive

D—Steering cylinder support  
E—Brass bushing



F—Grease fitting  
G—Spacer

ZX, TMXZCO003979-19-15FEB95

## REMOVING THE REAR AXLE

**CAUTION:** Take action to prevent the front wheels from turning (use chocks). Use a jack to raise the combine harvester and support it securely on adjustable support stands.

Raise the combine harvester and support stands high enough to allow the rear axle to be lowered using a jack and support (A).




ZX, TMXZCO003980-19-15FEB95

Place jack and support under the center of the axle and remove the four screws from the brackets.

Remove the four screws (A) from retaining plate (B).

Disconnect the hydraulic lines. Seal the open ends.

Lower the axle and roll it out on its wheels.



ZX, TMXZCO003981-19-15FEB95

## INSTALLING THE REAR AXLE




Check plastic bearings (A) for wear, and replace if necessary.

Use screw (C) and self-locking nut (D) to secure the two brackets (B) and plastic bearings to the axle (E).

Tighten the screws and nuts, then slacken them off until the axle can pivot.

To continue, follow the removal procedure in reverse.

- A—Plastic bearings
- B—Brackets
- C—Screw
- D—Self-locking nut
- E—Axle



## ADJUSTING REAR AXLE WIDTH

**CAUTION:** When changing axle widths, rear frame of harvester must be raised and supported properly.

Block front wheels (use chocks).

Raise rear axle until tires are approx. 2.5 cm (1 in.) off ground.

Remove steering cylinder support attaching screws (A) and rear axle cap screws (B) on both sides.

Also screw out tie rod bolt (C).



Pull or push sliding sleeve (D) in or out to desired width.

Reinstall screws (A), (B) and (C) and tighten.

Lower rear axle.

Make sure screws (A) and (B) are tightened to 240 N-m (170 lb-ft).


- I—L.h. side
- II—R.h. side
- A—Steering cylinder support attaching screws
- B—Sliding sleeve attaching screws
- C—Tie rod bolt
- D—Sliding sleeve



ZX, TMXZCO003983-19-15FEB95

### WHEEL MOTOR YOKE ATTACHING SCREWS TO REAR AXLE SLIDING SLEEVE

Tighten cap screws (A) at both sides to 575 N·m (424 lb-ft).




ZX, TMXZCO003984-19-15FEB95

### REAR WHEEL TREAD

With 14.9-24 tires and an adjustable axle, rear wheel tread can be adjusted between 2.94 m (9.65 ft) and 3.53 m (11.58 ft.).

ZX, TMXZCO003985-19-15FEB95

**SPINDLE AND WHEEL HUB — EXPLODED VIEW**



A—R.h. spindle  
 B—L.h. spindle  
 C—Thrust bearing ring  
 D—Thrust bearing  
 E—Bushing

F—O-ring  
 G—0.5 mm (0.02 in.) or  
 2 mm (0.08 in.) shim  
 H—Sealing ring  
 J—Taper roller bearing cone

K—Bearing cup  
 L—Wheel hub  
 M—Washer  
 N—Slotted nut  
 P—Cotter pin

Q—Cover  
 R—Plug  
 S—Spring pin  
 T—Wheel-attaching bolt



## INSTALLING SPINDLE

Check bushings in spindle mountings for wear, and replace if necessary.

Coat thrust bearings (A) with grease and install on spindle.

Insert spindle in axle mounting.

Install O-ring (B) and shims (C). Install sufficient shims to allow spring pin (D) to be installed without applying pressure to the bearing.



ZX, TMXZCO003987-19-15FEB95

ZX005466 -UN-21APR95

ZX005467 -UN-21APR95

## ASSEMBLING WHEEL HUB AND ADJUSTING BEARINGS

Press in the bearing races and fill wheel hub (C) with approx. 250 g (8.8 oz.) of grease.

Insert the rear taper roller bearing cone (B) and sealing ring (A) into wheel hub (C), with lettering outward.


Slide pre-assembled wheel hub onto spindle and install front taper roller bearing cone (D) with washer (E) and slotted nut (F).

Tighten slotted nut until resistance is encountered. Turn wheel hub at the same time.

Slacken slotted nut by 1/6 of a turn, and secure with a cotter pin.

Install cover (G) and lubricate the wheel hub at the grease fitting.

Finally, replace grease fitting with plug (H).



- A—Sealing ring
- B—Bearing cone
- C—Wheel hub
- D—Bearing cone
- E—Washer
- F—Slotted nut
- G—Cover
- H—Plug

ZX, TMXZCO003988-19-15FEB95

ZX005468 -UN-21APR95

*Rear Axle/Assembling wheel hub*

# Section 70 Hydraulic System

## Contents

### Page

#### Group 05—Hydraulic Reservoir and Lines

Capacity . . . . . 70-05-1

#### Group 10—Triple Hydraulic Pump

Removing the hydraulic pump . . . . . 70-10-1

Disassembling the hydraulic pump . . . . . 70-10-2

Exploded view . . . . . 70-10-4

Assembling the hydraulic pump . . . . . 70-10-5

#### Group 15—Electro-Magnetic Control Valve

Solenoid valve block, standard machine . . 70-15-2

Solenoid valves - standard machine . . . . 70-15-3

Solenoid valves - Hillmaster . . . . . 70-15-4

Repairing solenoid valves . . . . . 70-15-8

Repairing the pressure valves . . . . . 70-15-9

Repairing the flow divider . . . . . 70-15-20

#### Group 20—Hydraulic Cylinders

General information . . . . . 70-20-1

Specifications . . . . . 70-20-1

Disassembly and changing the seals . . . . 70-20-2

Piston assembly . . . . . 70-20-3

Cylinder for raising header . . . . . 70-20-4

Cylinder for swinging out the unloading  
auger . . . . . 70-20-5

Pivoting shield control cylinder . . . . . 70-20-6

Belt tensioning cylinder . . . . . 70-20-7

#### Group 21—Hillmaster Hydraulic Cylinder

Special tool (self-manufacture) . . . . . 70-21-1

Specifications . . . . . 70-21-1

Components of Hillmaster cylinder . . . . . 70-21-2

Check valve components . . . . . 70-21-3

Components of compensating valve . . . . 70-21-4

Compensating valve installed in piston . . . 70-21-5

Attachment of Hillmaster cylinder . . . . . 70-21-5

#### Group 25—Accumulators

Special tools . . . . . 70-25-1

Main drive accumulator . . . . . 70-25-2

Header float system accumulator . . . . . 70-25-3

Header accumulator . . . . . 70-25-5

*Contents*

**CAPACITY OF HYDROSTATIC SYSTEM**

**5-walker combines**

Standard . . . . .	65 L (17.17 U.S. gal)
Hillmaster . . . . .	76 L (20.07 U.S. gal)
Four-wheel drive version . . . . .	73 L (19.28 U.S. gal)
Hillmaster with 4WD . . . . .	78 L (20.61 U.S. gal)

**6-walker combines**

Standard . . . . .	76 L (20.07 U.S. gal)
Hillmaster . . . . .	81 L (22.40 U.S. gal)
Four-wheel drive version . . . . .	84 L (22.19 U.S. gal)
Hillmaster with 4WD . . . . .	89 L (23.51 U.S. gal)


**Reservoir capacity to center of sight-glass**

5-walker combines . . . . .	33.4 L (8.82 U.S. gal)
6-walker combines . . . . .	44.2 L (11.68 U.S. gal)

ZX, TMXZC0010101-19-01AUG97

### HYDRAULIC OIL RESERVOIR

- A—Cap
- B—Screen
- C—Pipe
- D—Hose clamp
- E—Rubber ring
- F—Reservoir
- G—Sealing ring
- H—Sight-glass
- J—Sensor for level indicator



ZX012215

ZX012215 -JUN-25SEP97

ZX,TMXZCO009584-19-01AUG97


## HYDRAULIC OIL LEVEL INDICATOR LIGHT

lights up if hydraulic oil level drops below minimum.

— Add hydraulic oil.

If larger quantities of oil are lost suddenly (e.g by leakage) and hydraulic oil level drops below minimum, “STOP” light of indicator light unit I will glow and the buzzer will sound (continuous tone).

— Shut off engine immediately.



ZX 002340

-JUN-16-JUN95

ZX002340

ZX,OMXZCO001508-19-27JAN92

*Hydraulic Reservoir and Lines/Capacity*



## GENERAL REPAIR INFORMATION


**IMPORTANT:** Prior to opening hydraulic components, thoroughly clean surrounding area. Observe the utmost cleanliness when repairing hydraulic components.

ZX,TMSPFH000674-19-23FEB92

## REMOVING HYDRAULIC PUMP

Disconnect suction and pressure lines from hydraulic pump. Immediately plug openings.

Remove both attaching screws and lift off pump.




ZX,TMXZCO001967-19-01JUN92

*NOTE: Replace complete pump if bushings, gears or housing are defective or worn.*

It is only possible to replace unserviceable seals.


- A—Hydraulic pump
  - Standard machine 35 L/Min. (9.2 gpm)
  - Hillmaster 45 L/Min. (11 gpm)
- B—Hydraulic pump 25 L/Min. (6.5 gpm) (steering)
- C—Hydraulic pump
  - Standard machine 15 L/Min. (3.9 gpm)
  - Hillmaster 35 L/Min. (9.2 gpm)



ZX,TMXZCO001968-19-01JUN92

## MARKING HYDRAULIC PUMP

**IMPORTANT:** Mark all pump parts prior to removal to ensure correct reinstallation.




ZX,TMSPFH000677-19-06JUN91

## DISASSEMBLING HYDRAULIC PUMP

**NOTE:** Two of the four cap screws are longer and hold together the hydraulic pump which consists of three pump units.

To disassemble remove the two longer cap screws.





ZX,TMSPFH000678-19-22JUL91

Disassemble parts of pump which have to be repaired:

Remove screws (A).

Remove intermediate cover (B).

Remove front bushings (C) and (D).




ZX,TMSPFH000679-19-06JUN91

## Triple Hydraulic Pump/Disassembling the hydraulic pump

Press out gears with rear bushings.

**NOTE:** Mark all parts prior to removal to ensure correct reinstallation.

- A—Bushing
- B—Bushing
- C—Drive gear
- D—Driven gear
- E—Gasket
- F—Gasket support




ZX,TMSPFH000680-19-06JUN91

-UN-27APR95  
Z110938

## REPLACE SHAFT SEAL

Remove snap ring (A) and extract seal ring (B), taking care not to damage seal seat surface.

When installing seal ring, make sure sealing lip faces toward the inside.




ZX,TMSPFH000681-19-06JUN91

-UN-26APR96  
Z103722

## INSTALLING GASKET AND SUPPORT

Install gasket (B) and support (A) in bushings, noting position of support (A).


- A—Support
- B—Gasket
- C—Suction side
- D—Pressure side
- E—Bushing set



ZX,TMSPFH000682-19-06JUN91

-UN-02MAY95  
Z103724

TRIPLE HYDRAULIC PUMP, EXPLODED VIEW



ZX012825

ZX012825 -UN-14NOV97

- |                     |                |                      |               |
|---------------------|----------------|----------------------|---------------|
| A—Nut (4 used)      | F—Back-up ring | K—Bushing            | O—Carrier     |
| B—Tie-bolt (2 used) | G—Gasket       | L—Gear               | P—Shaft seal  |
| C—Screw (6 used)    | H—Housing      | M—Intermediate plate | Q—Front plate |
| D—End plate         | J—Cap          | N—O-ring             | R—Snap ring   |
| E—Seal ring         |                |                      |               |

ZX.TMXZCO009586-19-01AUG97

## **ASSEMBLING THE HYDRAULIC PUMP**

Assemble hydraulic pump, noting marks made before disassembly.

Use new gaskets.

Coat all moving parts with clean hydraulic oil before assembling.

Tighten nuts (A) and screws (C) to  $43 \pm 3$  N·m ( $31.7 \pm 2$  lb-ft).


ZX, TMXZC0009587-19-01AUG97

*Triple Hydraulic Pump/Assembling the hydraulic pump*

## Group 15 Electro-Magnetic Control Valve

**CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



-UN-23AUG88

X9811

DX,FLUID2 -19-09AUG91


### GENERAL REPAIR INFORMATION

**IMPORTANT:** Prior to opening hydraulic components, thoroughly clean surrounding area. Observe the utmost cleanliness when repairing hydraulic components.

ZX,TMSPFH000955-19-23FEB92

## REMOVE BASIC MACHINE SOLENOID VALVE BLOCK


1. Lower harvesting unit completely and adjust lowest threshing cylinder speed to relieve pressure in hydraulic lines.
2. Disconnect wiring harness from solenoid valve block at disconnect point (A).
3. Mark hydraulic lines and disconnect at solenoid valve block.
4. Plug all openings immediately.
5. Loosen screws (B) and (C) and remove solenoid valve block.



ZX.TMXZC0002402-19-25NOV92



**SOLENOID VALVES — BASIC MACHINE**




**ZX004160**

- Y 1 — Pressure valve 1
- Y 2 — Pressure valve 2
- Y 3 — Solenoid, raising header
- Y 4 — Solenoid, lowering header
- Y 5 — Solenoid, raising header
- Y 6 — Solenoid, lowering header
- Y 10 — Solenoid, swinging in unloading auger
- Y 11 — Solenoid, swinging out unloading auger
- Y 14 — Solenoid, header leveling, left side
- Y 15 — Solenoid, header leveling, right side
- Y 21 — Solenoid not allocated

- Y 22 — Solenoid, switching on separator
- Y 23 — Solenoid, switching on separator
- Y 26 — Solenoid, unloading grain tank
- Y 27 — Solenoid, unloading grain tank
- Y 28 — Solenoid, reducing cylinder speed
- Y 29 — Solenoid, increasing cylinder speed
- Y 30 — Solenoid, reducing feeder conveyor speed
- Y 31 — Solenoid, increasing feeder conveyor speed

ZX.OMXZCO002193-19-05OCT92

### SOLENOID VALVES — HILLMASTER



**ZX004161**


Y 7 — Pressure valve 3  
Y 12 — Solenoid, combine leveling  
system, left

Y 13 — Solenoid, combine leveling  
system, right  
Y 20 — Solenoid, lowering combine harvester

ZX,OMXZC0002194-19-05OCT92

ZX004161 -JUN-03MAY95

### ACTUATION OF ELECTRO-MAGNETIC VALVES ON BASIC MACHINE



ZX003810

This chart and the two following ones illustrate which electro-magnetic valves are actuated when each particular function is selected.

X — Example: Raise header rapidly  
Y01, Y02, Y03 and Y05 are actuated.


A — Function symbols

B — Electro-magnetic valves


C — These symbols indicate that pressure begins to build up as soon as the road safety switch is actuated. Pressure is monitored by a pressure switch.

D — Adjusting screws: Re-adjust the rate of drop every time the header is changed.

**ACTUATION OF ELECTRO-MAGNETIC VALVES ON FEEDER HOUSE AND CUTTING PLATFORM**



A	Tractor	Reverse	Forward	Right	Left	Up	Down
Y26							
Y27							
Y22							
Y23							
Y29							
Y28							
Y06							
Y05							
Y04							
Y03							
Y01	•	•	•	•	•	•	•
Y02							
Y11							
Y10							



Y14		•					
Y15	•						
Y30					•		
Y31							
Y17			•				
Y16				•			
Y19						•	
Y18							•

ZX003812


A — Function symbols  
B — Electro-magnetic valves

C — Valves on feeder house  
D — Valves on cutting platform


ZX,OMXZC0002206-19-05OCT92

ZX003812 -JUN-23MAY95

**ACTUATION OF ELECTRO-MAGNETIC VALVES ON HILLMASTER**



A					
B					
Y7	•	•	•	•	•
Y12		•			•
Y13	•		•	•	
Y20			•	•	•



ZX003813


A — Function symbols  
B — Electro-magnetic valves

C — Adjusting screw: For adjusting the combine harvester's rate of drop in the transport position

ZX.OMXZC0002207-19-05OCT92

ZX003813 UN-23MAY95

**REPAIRING SOLENOID VALVE PLATE 'SWINGING OUT UNLOADING AUGER'**



- |                     |                           |                               |                     |
|---------------------|---------------------------|-------------------------------|---------------------|
| A—Solenoid          | F—Control plunger         | M—Check valve control plunger | Q—Check valve       |
| B—Solenoid          | G—Oil passage             | N—Return oil passage          | R—Oil passage       |
| C—Needle valve      | H—Check valve             | O—Check valve seat            | S—Needle valve seat |
| D—Needle valve seat | J—Pressure oil connection | P—Pressure oil connection     | T—Needle valve      |
| E—Spring            | L—Check valve seat        |                               |                     |


Disassemble solenoid valve plate.

Once removed, seals must be replaced with new ones.

Check all bores, orifices and valve seats for restriction. Replace damaged parts.

ZX.TMXZCO003030-19-18NOV93

**PRESSURE VALVE REPAIR**



A—Solenoid  
 B—Needle valve  
 C—Needle valve seat  
 D—Pressure test port

E—Control plunger  
 F—Orifice  
 G—Control plunger seat

H—Hydraulic oil inlet  
 J—Return oil passage  
 L—Hydraulic oil outlet (to reservoir)

M—Check valve  
 N—Pressure oil passage

Disassemble solenoid valve plate.


Replace damaged parts.

Check all bores, orifices and valve seats for restriction.

Once removed, seals must be replaced with new ones.

ZX, TMXZCO003031-19-18NOV93

**REPAIRING PRESSURE VALVE WITH PRESSURE RELIEF VALVE**



**ZX 005196**

A—Control plunger  
B—Spring  
C—Plug with test connection

D—Control plunger seat  
E—Check valve plunger

F—Pressure relief valve  
G—Needle valve seat

H—Solenoid  
J—Plug

Remove plugs (C) and (J).

Screw out pressure relief valve (F) and solenoid (H).

Check all bores, orifices and valve seats for restriction.


Replace damaged parts.

Once removed, seals must be replaced with new ones.

ZX.TMXZC0003032-19-18NOV93



**REPAIRING SOLENOID VALVE PLATE 'RAISING/LOWERING HARVESTING UNIT'**



A—Control plunger, raising harvesting unit  
 B—Spring  
 C—Cap with adjusting screw for raising speed

D—Control plunger, lowering harvesting unit  
 E—Spring  
 F—Cap with adjusting screw for lowering speed

G—Plug  
 H—Check valve  
 J—Needle valve seat  
 K—Needle valve seat

L—Solenoid  
 M—Solenoid  
 N—Orifice  
 O—Orifice

Disassemble solenoid valve plate.


Check all bores, orifices and valve seats for restriction.

Replace damaged parts.

Once removed, seals must be replaced with new ones.

ZX.TMXZCO003033-19-18NOV93

**REPAIRING SOLENOID VALVE PLATE 'RAISING/LOWERING HARVESTING UNIT, FLOAT CONTROL'**



- |                            |   |                             |                        |
|----------------------------|---|-----------------------------|------------------------|
| A—Solenoid                 | F—Connecting passage to second solenoid valve plate | J—Pressure oil passage      | O—Connecting passage   |
| B—Solenoid                 | G—Return oil passage                                | K—Control plunger, lowering | P—Bleed screw          |
| C—Needle valve             | H—Pressure oil passage                              | L—Check valve               | X—Adjustment, raising  |
| D—Orifice                  |   | M—Orifice                   | Y—Adjustment, lowering |
| E—Control plunger, raising |   | N—Needle valve              |                        |

Disassemble solenoid valve plate.


Replace damaged parts.

Check all bores, orifices and valve seats for restriction.

Once removed, seals must be replaced with new ones.

ZX.TMXZCO003034-19-18NOV93

**REPAIRING SOLENOID VALVE PLATE 'CYLINDER SPEED ADJUSTMENT'**



ZX 004120

- |                |                           |                      |                               |
|----------------|---------------------------|----------------------|-------------------------------|
| A—Solenoid     | D—Needle valve seat       | G—Return oil passage | K—Pressure oil passage        |
| B—Solenoid     | E—Pressure oil connection | H—Needle valve seat  | L—Return passage to reservoir |
| C—Needle valve | F—Pressure relief valve   | J—Needle valve       |                               |

Disassemble solenoid valve plate.

Replace damaged parts.


Check all bores, orifices and valve seats for restriction.

Once removed, seals must be replaced with new ones.

ZX.TMXZCO003035-19-18NOV93

ZX004120 -JUN-02MAY95

**REPAIR PRESSURE REDUCTION UNIT**



**ZX 004121**

-JUN-02MAY95  
ZX004121

**A—Pressure reduction valve**  
**B—Return oil passage**

**C—Passage for reduced pressure oil**

**D—Pressure oil passage**

**E—Test connection**

Remove pressure reduction valve (A) from housing.

Once removed, seals must be replaced by new ones.


Remove test connection (E).

*NOTE: Pressure reduction valve (A) interrupts oil flow at 6500 kPa (65 bar) (950 psi). Replace complete valve, if defective.*

Check bores in housing and in pressure reduction valve (A) for restriction.

ZX.TMXZCO003036-19-18NOV93

**REPAIR SOLENOID VALVE PLATE FOR ENGAGING/DISENGAGING MAIN DRIVE OR UNLOADING DRIVE**



**ZX 005192**

A—Needle valve seat

B—Needle valve seat

C—Solenoid

D—Solenoid

Disassemble solenoid valve plate.

Replace damaged parts.


Check all bores, orifices and needle valve seats for restriction.

Once removed, seals must be replaced by new ones.

ZX.TMXZCO003037-19-18NOV93

ZX005192 -UN-02MAY95

**REPAIR SOLENOID VALVE PLATE FOR HORIZONTAL REEL ADJUSTMENT**



ZX 005193

ZX005193 -UN-02MAY95

- |                     |                           |                               |                           |
|---------------------|---------------------------|-------------------------------|---------------------------|
| A—Solenoid          | F—Control plunger         | L—Check valve seat            | P—Pressure oil connection |
| B—Solenoid          | G—Oil passage             | M—Check valve control plunger | Q—Check valve             |
| C—Needle valve      | H—Check valve             | N—Return oil passage          | R—Oil passage             |
| D—Needle valve seat | J—Pressure oil connection | O—Check valve seat            | S—Needle valve seat       |
| E—Spring            | K—Thermal relief valve    |                               | T—Needle valve            |

Disassemble valve plate.


Replace damaged parts.

Check all bores, orifices and valve seats for restriction.

Once removed, seals must be replaced by new ones.

ZX.TMXZCO003038-19-18NOV93

**REPAIR SOLENOID VALVE PLATE FOR REEL LIFT**



**ZX 005194**

- |                |                           |                     |                          |
|----------------|---------------------------|---------------------|--------------------------|
| A—Solenoid     | D—Needle valve seat       | G—Needle valve seat | J—Accumulator connection |
| B—Solenoid     | E—Pressure oil connection | H—Needle valve      | K—Pressure oil passage   |
| C—Needle valve | F—Return oil passage      |                     |                          |

Disassemble solenoid valve plate.


Check needle valve seats for restriction.

Replace damaged parts.

ZX.TMXZCO003039-19-18NOV93

ZX005194 -JUN-02MAY95

**REPAIR SOLENOID VALVE PLATE FOR HEADER LATERAL TILT**



ZX 005195

ZX005195 -UN-02MAY95

- |                     |                                       |                               |                           |
|---------------------|---------------------------------------|-------------------------------|---------------------------|
| A—Solenoid          | G—Oil passage                         | L—Check valve seat            | P—Pressure oil connection |
| B—Solenoid          | H—Check valve                         | M—Check valve control plunger | Q—Check valve             |
| C—Needle valve      | J—Pressure oil connection             | N—Return oil passage          | R—Oil passage             |
| D—Needle valve seat | K—Connection to pressure relief plate | O—Check valve seat            | S—Needle valve seat       |
| E—Spring            |                                       |                               | T—Needle valve            |
| F—Control plunger   |                                       |                               |                           |

Disassemble solenoid valve plate.

Replace damaged parts.


Check all bores, orifices and valve seats for restriction.

Once removed, seals must be replaced by new ones.

ZX.TMXZCO003040-19-18NOV93



**REPAIR SOLENOID VALVE PLATE FOR PRESSURE RELIEF (HEADER LATERAL TILT)**



ZX 005197

- A—Solenoid
- B—Needle valve
- C—Needle valve seat

- D—Pressure oil passage
- E—Return oil passage
- F—Control plunger

- G—Connection to hydraulic cylinder
- H—Connection to hydraulic cylinder

- J—Check valve

Disassemble solenoid valve plate.

Replace damaged parts.

Check all bores, orifices and valve seats for restriction.

Once removed, seals must be replaced by new ones.

ZX.TMXZCO003041-19-18NOV93

ZX005197 -UN-02MAY95


## REPAIR SOLENOID VALVE PLATE FOR VARIABLE FEEDER HOUSE DRIVE

*NOTE: The solenoid valve plate for variable feeder house drive is identical with the solenoid valve*

*plate for reel lift (refer to information given in this Group).*

ZX, TMXZC0003042-19-18NOV93

## REPAIR FLOW DIVIDER



### ZX 005200

Remove cap from housing. Take piston (A) and spring (B) out of valve plate.

Check all bores for restriction.

Replace damaged parts.


ZX, TMXZC0003043-19-18NOV93

## **REPAIR PRESSURE VALVE**

*NOTE: The pressure valve of Hillmaster combines is almost identical with the pressure valve of standard combines. The only difference is that no check valve is installed. When ordered as spare part, the valve plate is supplied with a check valve.*

ZX, TMXZC0003044-19-18NOV93

**REPAIR SOLENOID VALVE PLATE FOR HILLMASTER CONTROL**



ZX 005201

ZX005201 -UN-02MAY95

- |                     |                               |                           |                        |
|---------------------|-------------------------------|---------------------------|------------------------|
| A—Solenoid          | G—Oil passage                 | N—Return oil passage      | S—Needle valve seat    |
| B—Solenoid          | H—Check valve                 | O—Check valve seat        | T—Needle valve         |
| C—Needle valve      | J—Pressure oil connection     | P—Pressure oil connection | V—Thermal relief valve |
| D—Needle valve seat | L—Check valve seat            | Q—Check valve             | W—Thermal relief valve |
| E—Spring            | M—Check valve control plunger | R—Oil passage             |                        |
| F—Control plunger   |                               |                           |                        |

Disassemble solenoid valve plate.


Replace damaged parts.

Check all bores, orifices and valve seats for restriction.

Once removed, seals must be replaced by new ones.

ZX.TMXZCO003045-19-18NOV93

**REPAIR RATE-OF-DROP SOLENOID VALVE PLATE**



**ZX 005199**

A—Solenoid  
B—Needle valve

C—Needle valve seat  
D—Control plunger

H—Rate-of-drop adjusting  
screw

X—Adjusting dimension

Disassemble solenoid valve plate.

Replace damaged parts.

Check all bores, orifices and needle valve seats for restriction.

ZX, TMXZC0003046-19-18NOV93

ZX005199 -JUN-02MAY95



**GENERAL INFORMATION**

**A. Damage to the Piston Rod**

Watch out for the following:

- Piston rods must not be subject to mechanical damage, such as dents.
- Prevent ice from forming on the running surface, as ice can damage the wiper ring.
- Piston rods must not be washed with acidic solutions or cleaning solutions that adversely affect chrome.
- Piston rods that are exposed to the elements when extended must be treated with non-corrosive grease if left inoperative for lengthy periods.
- Sticky dirt such as clay etc. must be carefully removed before the cylinder is operated.

Cylinders whose piston rods are extended but inaccessible must be actuated periodically.

**B. Damage to Cylinder Barrels**

- Never perform welding work on cylinder barrels. Cylinder barrels must never be subjected to thermal shocks (e.g. from welding rods etc.).
- Cylinder barrels must never be subjected to mechanical damage.

**C. Mis-aligned Cylinders**

Cylinders that are installed off-center and have no ball-and-socket joints are subject to dangerous lateral forces, which cause wear on the piston rod and guides. (An exception to this is cylinders built to withstand lateral forces).

ZX, TMXZCO006613-19-01AUG96

**SPECIFICATIONS**

Item	Measurement	Specification
Nut in cylinder for swinging out the unloading auger	Torque	114 ± 11 N-m (84 ± 8 lb-ft)
Nut in cylinder that controls the pivoting shield	Torque	114 ± 11 N-m (84 ± 8 lb-ft)

ZX, TMXZCO006623-19-01SEP96

## DISASSEMBLY AND CHANGING THE SEALS

Using a blunt screwdriver, press axially against snap ring (A) and at the same time turn piston rod (B).

It should take about one turn before the snap ring jumps off the piston rod.

Turn the piston rod in the direction of the arrow.



Use a blunt inscribing tool to extract grooved ring (C).

Once the piston rod is removed, wiper ring (D) can be removed easily from the groove.

Fold the new grooved ring (C) into a heart shape (E), leaving no sharp edges. Use snap ring pliers to hold the grooved ring together and push it in through bore (F). It will expand to fill the groove.

Install new wiper ring (D) in the wiper ring groove.

- A—Snap ring
- B—Piston rod
- C—Grooved ring
- D—Wiper ring
- E—Grooved ring in "heart" shape
- F—Piston rod bore
- G—Cylinder barrel



ZX009380 -JUN-28AUG96

ZX.TMXZCO006614-19-01AUG96



### ASSEMBLING THE PISTON

Place snap ring (B) on piston rod (C) and slide the piston rod into cylinder (A).


As shown by the arrow, insert the piston as far as it will go.

Place the end of the piston rod on a wooden surface and strike the end of the cylinder barrel once with a hammer. The blow should be brief but hard.

This causes the snap ring to jump into the snap ring groove.


Look through disassembly hole to check that the snap ring is in its proper position.

- A—Cylinder
- B—Snap ring
- C—Piston rod



ZX009382

ZX009382 -UN-28AUG96




ZX009383

ZX009383 -UN-28AUG96

ZX.TMXZCO006615-19-01AUG96

**CYLINDER FOR RAISING HEADER**



ZX009384

A—Wiper ring  
B—Grooved ring  
C—Rod seal

D—Plug with O-ring  
E—Cylinder barrel  
F—Piston rod

G—Hose connection and  
disassembly hole

H—Snap ring  
J—Cylinder base

**Disassembly and Changing the Seals**

Use a blunt screwdriver to press snap ring (H) down towards cylinder base (J).

Extract piston rod (F) from cylinder barrel (E).

Use a blunt inscribing tool to remove all seals, and replace them with new ones.


**IMPORTANT: Take care not to damage the base of the groove.**

Assemble in reverse order.

ZX,TMXZCO006616-19-01SEP96

ZX009384 -UN-28AUG96

## CYLINDER FOR SWINGING OUT THE UNLOADING AUGER



ZX009385

ZX009385 -UN-29AUG96

A—Wiper ring	E—O-ring	H—Piston rod	L—"Glyd" ring
B—Retaining ring	F—Guide	J—Guide band	M—Nut
C—Grooved ring	G—Cylinder barrel	K—Piston	N—Bushing
D—Snap ring			

### Disassembly and Changing the Seals

Use assembly pliers to remove retaining ring (B).

Push back guide (F) until snap ring (D) is exposed.

Use a blunt screwdriver to pry out snap ring (D).

Pull out piston rod (H) and piston (K).

If necessary, slacken nut (M) and take off piston (K).

Use a blunt inscribing tool to remove all seals, and replace them with new ones.


**IMPORTANT: Take care not to damage the base of the groove.**

Assemble in reverse order.

Tighten nut (M) to  $114 \pm 11$  N·m ( $84 \pm 8$  lb-ft).

ZX,TMXZCO006617-19-01SEP96

## PIVOTING SHIELD CONTROL CYLINDER



ZX009387

ZX009387 -UN-28AUG96

A—Wiper ring  
B—Retaining ring  
C—Grooved ring

D—Snap ring  
E—O-ring  
F—Guide

G—Cylinder barrel  
H—Piston rod  
J—Guide band

K—Piston  
L—“Glyd” ring  
M—Nut

### Disassembly and Changing the Seals

Use assembly pliers to remove retaining ring (B).

Push back guide (F) until snap ring (D) is exposed.

Use a blunt screwdriver to pry out snap ring (D).

Pull out piston rod (H) and piston (K).

Slacken nut (M) and take off piston (K).

Use a blunt inscribing tool to remove all seals, and replace them with new ones.


**IMPORTANT: Take care not to damage the base of the groove.**

Assemble in reverse order.

Tighten nut (M) to  $114 \pm 11$  N·m ( $84 \pm 8$  lb·ft).

ZX, TMXZCO006618-19-01SEP96

## BELT TENSIONING CYLINDER



A—Piston rod  
B—Wiper ring

C—Grooved ring  
D—Cylinder barrel

E—Disassembly hole  
F—Cylinder base

G—Snap ring

### Disassembly and Changing the Seals

Pull piston rod (A) in the direction of the arrow until snap ring (G) becomes visible in disassembly hole (E).

Insert a blunt screwdriver through disassembly hole (E) and press snap ring (G) down towards cylinder base (F).

Extract the piston rod from cylinder barrel (D).

Use a blunt inscribing tool to remove all sealing components.

**IMPORTANT: Take care not to damage the base of the groove.**

Assemble in reverse order.


ZX.TMXZCO006619-19-01AUG96

*Hydraulic Cylinders/Belt tensioning cylinder*

**MAKING A SPECIAL TOOL**

Tool for disassembling and assembling the valve seat and piston in the check valve.

- A—200 mm (7.9 in.)
- B—100 mm (4.0 in.)
- C—Diameter 4 mm (0.16 in.)
- D—M4 thread, 10 mm (0.4 in.)



-UN-28AUG96

ZX, TMXZC0006620-19-01AUG96

**SPECIFICATIONS**

Item	Measurement	Specification
Nut in hillmaster hydraulic cylinders	Torque	1400 ± 140 N·m (1033 ± 103 lb-ft)
Screw plug on check valve	Torque	130 ± 13 N·m (96 ± 10 lb-ft)

ZX, TMXZC0006621-19-01AUG96

**OTHER MATERIALS**

Number	Name	Use
TY9371	Loctite 270	Securing the guide in the hillmaster hydraulic cylinder

ZX, TMXZC0006767-19-01SEP96

## GENERAL INFORMATION


**CAUTION:** Never work on the hillmaster cylinders unless the combine harvester has already been lowered.

*NOTE:* Refer to Operator's Manual, "Operating With Hillmaster Levelling System".

**CAUTION:** Danger! Hillmaster cylinders weigh approx. 55 kg (121 lb).

ZX, TMXZC0006622-19-01AUG96

## COMPONENTS OF HILLMASTER CYLINDER



ZX009055 -JUN-28AUG96

ZX009055

- |                   |                      |               |                       |
|-------------------|----------------------|---------------|-----------------------|
| A—Cylinder barrel | E—Compensating valve | J—O-ring      | N—Spiral back-up ring |
| B—Piston          | F—Check valve        | K—Guide ring  | O—Wiper ring          |
| C—Piston rod      | G—Nut                | L—"Glyd" ring | P—Grooved ring        |
| D—Guide           | H—Washer             | M—Guide band  | Q—Secure with Loctite |

### Disassembly and Changing the Seals

Heat the area of the cylinder around the thread on guide (D) to a temperature of at least 300°C (572°F), break the Loctite seal and use assembly pliers to unscrew guide (D).

Pull out piston rod (C) and piston (B).

Remove nut (G), washers (H), piston (B) and guide (D) from the piston rod.

Use a blunt inscribing tool to remove all seals, and replace them with new ones.

**IMPORTANT:** Take care not to damage the base of the groove.

Assemble the cylinder in reverse order.

Tighten nut (G) to 1400 ± 140 N·m (1033 ± 130 lb-ft).

Apply Loctite 270 (TY9371) to the thread of guide (D) before inserting and tightening the guide.

ZX, TMXZC0006624-19-01SEP96





## CHECK VALVE COMPONENTS

### Removing the Check Valve

Use a hex. socket wrench with a width across flats of 17 mm to take out screw plug (J).

One after the other, remove spring (E), sleeve (H) and valve cone (G).


- A—O-ring
- B—Piston
- C—Bushing
- D—Pin
- E—Spring
- F—Valve seat
- G—Valve cone
- H—Sleeve
- J—Screw plug



ZX009056

ZX009056 -UN-28AUG96

ZX.TMXZC0006625-19-01AUG96



ZX009057 -JUN-28AUG96

### Removing the Check Valve (Continued)

Screw the (self-manufactured) disassembly tool into pin (D; refer to "Check Valve Components").

Pulling on the disassembly tool (fig. I) releases the valve seat (F) and allows spring (E), bushing (C) and pin (D) to be removed.

Now screw the disassembly tool (fig. II) into piston (B), and pull out the piston.

Refer to "Check Valve Components" for the identifying letters.

Use a blunt inscribing tool to remove all seal rings, and replace them with new ones.

**IMPORTANT: Take care not to damage the base of the groove.**


Assemble in reverse order.

Tighten screw plug (J) to  $130 \pm 13$  N·m ( $96 \pm 10$  lb-ft).

ZX, TMXZCO006626-19-01SEP96

### COMPONENTS OF COMPENSATING VALVE

- A—O-ring
- B—Valve seat
- C—Valve cone
- D—Spring




ZX009058

ZX009058 -JUN-28AUG96

ZX, TMXZCO006627-19-01AUG96

### COMPENSATING VALVE INSTALLED IN PISTON

- A—Compensating valve assembly
- B—Piston
- C—Nut
- D—Washer
- E—Cylinder barrel



ZX009059


-JUN-28AUG96  
ZX009059

ZX.TMXZCO006628-19-01AUG96

### ATTACHMENT OF HILLMASTER CYLINDER

The ball-and-socket joint is maintenance-free.

- A—Ball-and-socket joint on piston rod
- B—Retaining ring



ZX009060


-JUN-28AUG96  
ZX009060

ZX.TMXZCO006629-19-01AUG96

*Hillmaster Hydraulic Cylinder/Attachment of Hillmaster cylinder*

The ball-and-socket joint must be lubricated via the grease fitting. Lubricate every 50 hours.

- A—Ball-and-socket joint on base
- B—Retaining ring
- C—Grease fitting



ZX, TMXZC0006630-19-01AUG96

**SPECIAL OR ESSENTIAL TOOLS**

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*


DX,TOOLS -19-20JUL95

Accumulator charging and testing device . . . . . FKM10448



**!** **CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID2 -19-09AUG91


## MAIN DRIVE/UNLOADING SYSTEM ACCUMULATORS

The unloading system accumulators have a capacity of 0,35 L (0.09 US.gal.) and are precharged with nitrogen under a pressure of 3800 kPa (38 bar) (550 psi).


*NOTE: Before connecting testing device FKM10448 to accumulator, slightly loosen accumulator hex. socket screw. This will avoid damage to the testing device when accumulator is opened.*

For checking accumulator (A), connect testing device FKM10448 to accumulator (A). For checking accumulator (B), connect testing device FKM10448 to accumulator (B).

**A**—Accumulator, main drive  
**B**—Accumulator, main drive/unloading system



ZX005190 -UN-21APR95




ZX005214 -UN-24APR95

ZX,TMXZCO003028-19-03JAN94

*NOTE: Before checking accumulator (B), engage and disengage main clutch several times with engine shut off, starter switch in position II and road safety switch in field position to relieve hydraulic pressure.*

Use a ratchet on testing device to open accumulator valve.

Accumulator charging pressure is indicated by the pressure gauge. If charging pressure is too low, the accumulator must be charged with nitrogen.




ZX005215 -UN-24APR95

ZX,TMXZCO003128-19-03JAN94

## Accumulators/Header float system accumulator

The accumulator may be charged by loosening knurled screw. If the accumulator is not connected to an external nitrogen source (under pressure), pressure is reduced by opening knurled screw.



ZX,TMXZCO003129-19-03JAN94


-UN-24APR95

## HEADER FLOAT SYSTEM ACCUMULATOR

The combines are equipped with one or two accumulator(s). Accumulator capacity is 2 L (0.53 US.gal).

Accumulator charging pressure depends on weight of header and lift cylinder diameter.

**A—Accumulator**



ZX,TMXZCO003029-19-03JAN94



-UN-21APR95

## CHECKING HEADER FLOAT SYSTEM ACCUMULATOR(S)

*NOTE: Before connecting testing device FKM10448 to accumulator, slightly loosen accumulator hex. socket screw. This will avoid damage to the testing device when accumulator is opened.*

For checking accumulator (A), connect testing device FKM10448 to accumulator (A). For checking accumulator (B), connect testing device FKM10448 to accumulator (B).

Relieve pressure in hydraulic line to header lift cylinders by actuating switch for lowering header.




ZX,TMXZCO003131-19-03JAN94

-UN-24APR95

Accumulators/Header float system accumulator

Use a ratchet on testing device to open accumulator valve. Accumulator charging pressure is indicated by the pressure gauge. If charging pressure is too low, the accumulator must be charged with nitrogen.




ZX005219

ZX, TMXZCO003133-19-03JAN94

-UN-24APR95  
ZX005219

The accumulator may be charged by loosening knurled screw. If the accumulator is not connected to an external nitrogen source (under pressure), pressure is reduced by opening knurled screw.

Adjust charging pressure according to the following table.



ZX005220

ZX, TMXZCO003134-19-03JAN94

-UN-24APR95  
ZX005220

**CHARGING PRESSURES OF HEADER FLOAT SYSTEM ACCUMULATOR(S)**

14'	6000 kPa (60 bar; 870 psi)
16'	6500 kPa (65 bar; 940 psi)
18'	7000 kPa (70 bar; 1015 psi)
20'	8000 kPa (80 bar; 1160 psi)
25'	9000 kPa (90 bar; 1300 psi)

The pressures given in the table apply to machines with standard feeder house and standard cutting platforms with a lift cylinder diameter of 55 mm.

For machines equipped with 60 mm dia. lift cylinders, subtract 1000 kPa (10 bar; 150 psi) from the values given.

For machines with Hillmaster feeder house (header lateral tilt), add 1000 kPa (10 bar; 150 psi) to the values given.

When cutting platforms with Hardox plates are used, add 1000 kPa (10 bar; 150 psi) to the values given.

When several of the points mentioned above apply to a certain machine, add or subtract the corresponding values as necessary.

ZX, TMXZCO003130-19-03JAN94




## HEADER ACCUMULATOR

An accumulator is integrated in the header hydraulic system lines. With header detached, it prevents an excessive pressure build-up caused by solar radiation.

Accumulator capacity is 75 cm<sup>3</sup> (4.6 cu.in.) and is precharged with a pressure of 500 kPa (5 bar; 70 psi).

The accumulator is maintenance-free and cannot be repaired.

**IMPORTANT: Before removing accumulator, relieve pressure in hydraulic system.**



ZX005191 -UN-21APR95

ZX.TMXZC0003047-19-18NOV93

*Accumulators/Header accumulator*

**Section 80**  
**Miscellaneous**

**Contents**

Page

**Group 05—Bearings and Shafts**  
Remove clamping ring bearings . . . . . 80-05-1  
Repair clamping ring bearings . . . . . 80-05-1

**Group 10—Drive Belts**  
Sheave inspection . . . . . 80-10-1

**Group 15—Drive Chains**  
Safety wires . . . . . 80-15-2  
Drive chains with O-rings . . . . . 80-15-3


**Group 20—Side Guard**  
Removal and installation tool . . . . . 80-20-1  
Removing the side guard . . . . . 80-20-2  
Installing the side guard . . . . . 80-20-2

*Contents*

### REMOVING CLAMPING RING BEARINGS

Use a commercial puller to remove ball bearings from cylinder or beater shafts.

Use a puller combination, as shown, if bearings are hard to remove.



ZX, TMXZCO002707-19-13MAY93

-UN-27APR95  
Z103815


### REPAIRING CLAMPING RING BEARINGS

Check if bearings are in good condition. Replace, if necessary.

ZX, TMXZCO002708-19-13MAY93

### INSTALLING CLAMPING RING BEARINGS WITH SHEET METAL HOUSING (EXAMPLE)

1. Guide one flange half over the shaft and align with corresponding holes.
2. Install bearing with clamping ring on shaft.
3. Assemble other flange half, install attaching screws and tighten finger tight. Repeat procedure on other end of shaft.
4. Firmly tighten attaching screws at both ends.
5. Tighten clamping ring by turning it in rotating direction of shaft. Stake ring with a punch.
6. Lock clamping ring with a setscrew.




ZX, TMXZCO002709-19-13MAY93

-UN-27APR95  
Z103816

## INSTALLING CLAMPING RING BEARINGS WITH CAST IRON HOUSINGS

### Preassembling Clamping Ring Bearings

Insert bearing into cast iron housing as shown in illustration.



ZX, TMXZC0002710-19-13MAY93


### Installing Clamping Ring Bearings

Slide preassembled clamping ring bearings on both ends of shaft.

Secure cast iron housing (A) on both sides with attaching screws.

Tighten clamping ring (B) in direction of shaft rotation and stake with a punch.

Lock clamping ring (B) with a setscrew.



ZX, TMXZC0002711-19-13MAY93

### **SHEAVE INSPECTION**

Before replacing a belt, always check all sheaves for chips, cracks, bent sidewalls, rust, corrosion etc.


Sheaves must have a smooth dry surface to grip to deliver full power. Replace any defective sheaves.

ZX, TMXZC0002712-19-13MAY93

### **SHEAVE ALIGNMENT**

Misaligned sheaves will result in reduced belt life. Use a straightedge or cord to check sheave alignment:

1. Position straightedge or cord to touch sheaves at indicated points. Shafts must be parallel.
2. Rotate each sheave a half revolution and note whether contact of either sheave with straightedge or cord is disturbed. If so, shaft is bent or the sheave wobbling.



- A—Tie cord to shaft**  
**B—Cord must touch sheaves at indicated points**

ZX, TMXZC0002713-19-13MAY93

*Drive Belts/Sheave inspection*



## DRIVE CHAINS

### Chain Tension

Check chains frequently for correct tension during the first several hours of operation.

The amount of slack in a chain should be approx. 2% of the distance between centers of drive and driven sprockets, with all slack removed on the tensioner sprocket side.




Example: If center distance between a drive and a driven sprocket is 250 mm (10 in.), slack should be 5 mm (0.2 in.).

Excessively loose chains will cause rapid and excessive wear of chain rollers, sprocket teeth and possibly chain-driven machine components.

Excessively tight chains cause undue load on bearings, shafts and chains.


### Chain Maintenance

Grease or oil chains at regular intervals.



ZX,TMXZCO002714-19-13MAY93

**SAFETY WIRES**



-JUN-28APR95  
Z114385

**Z 114 385**

A—Connecting link

B—Offset connecting link

C—Chain travel direction

X—Bend wire at this location as shown


Install safety wire for conveyor chain with bent end facing upward and in direction of chain travel.

Bend other end as shown (see X).

ZX,TMXZCO002715-19-13MAY93

**DRIVE CHAINS — CONNECTING LINK**

Certain chains are connected with a connecting link as shown opposite. Always connect chain as shown with closed end of connecting link towards direction of chain travel.



**E11025**

-JUN-20SEP88  
E11025


ZX,TMXZCO002716-19-13MAY93

## CHAINS WITH O-RINGS

The drive chain may have O-rings and connecting link on some drives.

**IMPORTANT:** Do not repair drive chains with O-rings when installed (e.g. replacing pin link). Remove, install or repair these chains without opening them.

*NOTE:* When repairing chain, refer to the following steps.



Z109765

-UN-27APR95  
Z109765


ZX,TMXZCO002717-19-13MAY93

## DISASSEMBLING CHAINS WITH O-RINGS

Use suitable pliers to remove connecting link (A) from pin link.


Remove link section (B) with a screwdriver.

A—Connecting link  
B—Link section



Z107227

-UN-27APR95  
Z107227



Z107228

-UN-27APR95  
Z107228

ZX,TMXZCO002718-19-13MAY93

## ASSEMBLING CHAINS WITH O-RINGS

Slide an O-ring on each pin of pin link against link.



Lubricate bores and pins of pin link with John Deere chain spray or equivalent lubricant.

Insert pins of pin link (B) into both end links (A) of the chain.

Slide the remaining two O-rings (C) on the pins.

Place link section (D) on the pins.

- A—End links
- B—Pin link
- C—O-ring
- D—Link section



## Drive Chains/Drive chains with O-rings

Use the hollow punch (A) (bore of punch must be slightly larger than diameter of link pin) to exert pressure on link section (B).




*NOTE: Pin grooves of pin links must be exposed.*

Using suitable pliers, slide connecting link (C) into pin grooves.

*NOTE: Closed end of connecting link must point in direction of chain travel.*

To make sure that the connecting link is seated correctly in the pin grooves use a hollow punch and a hammer to tap slightly on the connecting link. Install chain closed.


- A—Hollow punch
- B—Link section
- C—Connecting link



ZX,TMXZCO002720-19-13MAY93

*Drive Chains/Drive chains with O-rings*

**REMOVAL AND INSTALLATION TOOL (SELF-MANUFACTURE)**



- |                       |                      |  |                    |
|-----------------------|----------------------|--|--------------------|
| A—1080 mm (42.52 in.) | E—230 mm (9.05 in.)  | K—Length 50 mm (0.2 in.),<br>Width 50 mm (0.2 in.) | M—32 mm (1.26 in.) |
| B—1000 mm (39.37 in.) | F—30 mm (1.18 in.)   | L—Length 80 mm (0.3 in.),<br>Width 50 mm (0.2 in.) | N—12 mm (0.47 in.) |
| C—500 mm (19.68 in.)  | G—600 mm (23.62 in.) |  |                    |
| D—1260 mm (49.61 in.) | J—80 mm (3.15 in.)   |  |                    |

**Device for holding large side guards during  
removal and installation**

ZX, TMXZCO003991-19-15FEB95

## REMOVING SIDE GUARD

**CAUTION:** Guard is heavy, weighing approx. 50 kg (110 lb.).

Disconnect electrical connection for side lights.

Open the guard and insert self-manufactured holding device (A).



Disconnect support cylinder from guard.

Use holding device to raise guard and gain easier access to the upper attachment points.

Take screws out of retaining lugs.

Slacken off clamps (B), which are used to adjust the guard.

Lift out the complete guard at tube (C), and swing it aside.



ZX, TMXZCO003992-19-15FEB95

## INSTALLING SIDE GUARD

To install guard, follow removal procedure in reverse.

Once the guard is installed, align it correctly and adjust it using the clamps.

ZX, TMXZCO003993-19-15FEB95



# Section 90 Operator's Cab and Air Conditioning

## Contents

Page

### Group 05—Air Conditioning System - R134a

General information . . . . .	90-05-1
Special tools . . . . .	90-05-1
Specifications . . . . .	90-05-4
Safety . . . . .	90-05-5
Test and service ports . . . . .	90-05-7
Discharging the system . . . . .	90-05-8
Evacuating the system . . . . .	90-05-9
Filling the system . . . . .	90-05-10
Topping up a partly discharged system . .	90-05-11
Filling with refrigerant oil . . . . .	90-05-12
Leak test . . . . .	90-05-13
Removing the compressor . . . . .	90-05-14
Disassembling the compressor . . . . .	90-05-14
Assembling the compressor . . . . .	90-05-16
Removing and installing the condenser . .	90-05-17
Remove/install the receiver-drier . . . . .	90-05-18
Removing and installing the evaporator . .	90-05-19
Remove/install the pressure switches . . .	90-05-20

### Group 10—Operator's Cab Heating System

Heater components . . . . .	90-10-1
Fan and radiator . . . . .	90-10-2
Cab filters . . . . .	90-10-3

### Group 15—Gear Shift Mechanism

Adjustment . . . . .	90-15-1
Exploded view . . . . .	90-15-3

*Contents*



# Group 05 Air Conditioning System - R134a

## GENERAL INFORMATION

The air conditioning system is filled with R134a refrigerant which does not contain CFC.

The R134a air conditioning system can be identified by the compressor.

**IMPORTANT:** Use only R134a refrigerant in this air conditioning system. When using R12 refrigerant, the entire system including the compressor will be damaged.



ZX005013 -UN-28APR95

ZX,TMXZC0003094-19-01DEC93

## SPECIAL OR ESSENTIAL TOOLS

*NOTE:* Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).


DX,TOOLS -19-20JUL95

Service unit . . . . . FKM10453

Discharging, evacuating, filling, cleaning and checking the air conditioning system

*NOTE:* All work performed with this unit must be carried out in accordance with the service unit operator's manual.

**IMPORTANT:** Use only service units suitable for handling R134a refrigerant.



FKM10453 -UN-28APR95


ZX,TMSPFH002841-19-30AUG94

Air Conditioning System - R134a/Special tools

Leak tester . . . . . FKM10444

Identifying refrigerant leaks.

*NOTE: Leak tester can be used with R12 as well as R134a refrigerant.*



FKM10444


ZX,TMXZCO003095-19-01DEC93

FKM10444 -JUN-17MAR95

Discharging unit . . . . . FKM10442

Discharging refrigerant from the system.

**IMPORTANT: Use only service units suitable for handling R134a refrigerant.**



FKM10442


LX,ROSG 003844-19-02FEB93

FKM10442 -JUN-27APR95

Gauge set . . . . . FKM10445

Evacuating, filling and checking the air conditioning system.

**IMPORTANT: Use only service units suitable for handling R134a refrigerant.**



FKM10445


ZX,TMXZCO003096-19-01DEC93

FKM10445 -JUN-27APR95

Vacuum pump . . . . . FKM10440

Evacuating the system.

*NOTE: The vacuum pump is suitable for both R12 and R134a refrigerant.*



FKM10440


LX,ROSG 003846-19-02FEB93

FKM10440 -JUN-27APR95

Charging valve . . . . . FKM10443

Filling the system.

**IMPORTANT: Use only service units suitable for handling R134a refrigerant.**



FKM10443

LX.ROSG 003849-19-03FEB93

FKM10443 -UN-06MAR96

Refrigerant can (R134a; 920g; 750 ml) . . . . FKM10447

Filling the system.

**IMPORTANT: Use only service units suitable for handling R134a refrigerant.**



FKM10447


LX.ROSG 003848-19-02FEB93

FKM10447 -UN-27APR95

Oil injector . . . . . FKM10436

Filling air conditioning system with refrigerant oil.

**IMPORTANT: Use PAG oil (ND-Oil8) only.**




FKM10436

ZX.TMXZCO003097-19-01DEC93

FKM10436 -UN-27APR95

PAG refrigerant oil (ND-Oil8; 250 ml) . . . . FKM10446

**IMPORTANT: Use PAG oil (ND-Oil8) only.**



FKM10446

LX.ROSG 003850-19-03FEB93


FKM10446 -UN-27APR95

## **SPECIFICATIONS**

<b>Item</b>	<b>Measurement</b>	<b>Specification</b>
Air conditioning system	Refrigerant capacity	2400 g (85 oz)
Hub to pulley	Clearance	0.35—0.65 mm (0.014—0.026 in.)
Compressor	Oil quantity	160 ml (5.4 fl oz)
Air conditioning system, high pressure side	Refrigerant pressure	1500—2000 kPa (15—20 bar) (218—290 psi)
Air conditioning system, low pressure side	Refrigerant pressure	50—200 kPa (0.5—2 bar) (7.5—29 psi)
Compressor clutch coil	Current draw at 12 volts, 20°C (68°F)	2.2 A, 40 W power
Hub attaching screw	Torque	15 N·m (11 lb-ft)
High and low pressure switches	Torque	16 N·m (12 lb-ft)
Hex. socket screw of compressor manifold	Torque	25 N·m (18 lb-ft)
O-ring threaded connections	Width across flats 19 mm, 5/8"	14—20 N·m (10—15 lb-ft)
	Width across flats 22 mm, 3/4"	33—39 N·m (24—29 lb-ft)
	Width across flats 27 mm, 7/8"	35—42 N·m (26—31 lb-ft)

ZX, TMXZC0003098-19-01DEC93

## SAFETY AT WORK

 **CAUTION:** Certain basic safety regulations apply when dealing with air conditioning systems, and must be observed at all times. They are backed up by legislation covering safety precautions for air conditioning systems. The following excerpts are particularly important:

1. Air conditioning systems may be operated, serviced or repaired by authorized, trained personnel only.
2. Adolescents should not be allowed to carry out service work on air conditioning systems involving the discharge of Category 1 or 2 refrigerants, unless trade training of adolescents over 16 years old requires such work. In this case, the adolescent must be supervised by a trained adult.
3. Before repairing components carrying refrigerant, remove refrigerant as far as necessary to ensure that the work can be carried out safely.


4. Refrigerant should be extracted by suction and re-used. When refrigerant is discharged into the air, there is the danger of asphyxiation, especially if work is being performed in an inspection pit, since refrigerant is heavier than air and concentrates at the lowest level. Moreover, refrigerant is odorless and colorless, so small quantities emerging from a leak cannot be detected. In such a case, ensure that there is adequate ventilation at the place of work.

5. Smoking and naked flames are not permitted in enclosed spaces where refrigerant has been released. High temperatures cause chemical reactions in the refrigerant gas, and highly poisonous substances can form. If inhaled, these substances have serious effects on health.

6. High temperatures produced by welding and soldering cause very high pressures inside components of the air conditioning system, and these pressures may result in an explosion.

LX,290,10002639-19-25FEB92

## HANDLING REFRIGERANT

 **CAUTION:** When handling refrigerant, always wear safety glasses and leather gloves. Contact with escaping refrigerant may result in serious frostbite, or even blindness if the refrigerant strikes the eye.

Whenever there is the risk of refrigerant encountering high temperatures, wear a suitable breathing mask while working. However, a breathing mask provides no protection against asphyxiation if large quantities of refrigerant escape.

LX,290,10002718-19-04MAR92


## IN AN EMERGENCY

- Rinse eye with cold water; preferably use a 1% boric acid solution.
- Wash affected parts of the body with water, or preferably with a solution consisting of one part essence of vinegar and five parts water.
- See a doctor as soon as first aid has been administered.


LX.290,10002719-19-04MAR92

## SAFETY EQUIPMENT

This equipment consists of safety glasses, safety gloves and, where appropriate, a breathing mask (if there is the risk of poisonous gases being released).

 **CAUTION: A breathing mask provides NO protection against lack of oxygen.**

Prepare a 1% boric acid solution for rinsing the eyes and a solution consisting of 1 part essence of vinegar and 5 parts water for washing affected parts of the body. Also provide a first aid kit.




**LX002150**

-UN-26JUL94  
LX002150

LX.290,10002576-19-01JUL96

## STORAGE OF REFRIGERANT CONTAINERS

 **CAUTION: Refrigerant containers are under pressure, and this pressure increases rapidly when the temperature of the container rises. The thin-walled refill containers are particularly at risk in this respect. Refrigerant containers must never be exposed to temperatures over 52°C (120°F).**

**Never store pressurized containers in the vicinity of heat sources or in places exposed to direct sunlight. Never open pressurized containers by force or damage them in any way.**

ZX.TMXZCO002464-19-25NOV92



## R134A REFRIGERANT

**IMPORTANT:** The air conditioning system operates using R134a refrigerant (tetrafluorethane). This substance does not contain any chlorine atoms, so it does not have a detrimental effect on the ozone in the Earth's atmosphere.

Even so, the refrigerant must never be discharged straight into the air. It must be trapped in a recycling unit. Refrigerant stored in a recycling unit may be re-used at any time.

The recycling unit used to do this must be of a type suitable for handling R134a refrigerant.

The boiling point of R134a is minus 26.5°C (minus 15.7°F) and its freezing point is minus 101°C (minus 149.8°F).

R134a has a corrosive effect on copper as well as various seals and components used in the R12 system. For this reason, never use R134a refrigerant in a system that has previously used R12. Before replacing any component, it is vital to check whether it is compatible with the type of refrigerant used.


It is still essential to ensure that the correct refrigerant oil is used. R12 systems were lubricated with mineral oil, which is totally unsuitable for R134a systems. The latter require PAG oil, which mixes very well with the refrigerant and provides ideal lubrication throughout the system.

ZX.TMSPFH002887-19-16JUN93

## TEST AND SERVICE PORTS

The test and service ports are located at compressor refrigerant lines.

- A—Test port - high side valve
- B—Test port - low side valve
- C—Compressor



-UN-21APR95  
ZX005675

ZX.TMXZCO003099-19-01DEC93

## DISCHARGING THE SYSTEM

**CAUTION:** To prevent injury, wear protective goggles and gloves when servicing the air conditioning system.

Connect the red hose to the pressure connection and the blue hose to the suction connection (oil separator) of discharge unit FKM10442 (A).

Connect the other ends of the hoses as follows:

Connect the blue hose to low-side valve (C), using connecting valve (B). Connect the red hose to a commercially available R134a recycling container.



*NOTE: The recycling container must be weighed repeatedly during the discharging process to make sure that it is not over-filled.*

Tighten all connections and switch on the discharge unit.

The discharge unit discharges the system until the suction pressure switch trips and switches the unit off at a pressure of approx. -30 kPa (-0.3 bar; -4.5 psi).

*NOTE: If the system is already discharged, i.e. no rise in pressure can be observed, do not attempt to discharge the system further. Avoid air ingestion.*

At the sight-glass in the oil separator, observe how much oil has been sucked out. When the system is subsequently recharged, remember to top up with the same quantity of fresh oil.



- A—Discharge unit (FKM10442)
- B—Connecting valve (blue)
- C—Low-side valve
- D—Oil separator
- E—Connector for recycling container

## EVACUATING THE SYSTEM

**CAUTION:** To prevent the risk of injury, always wear protective goggles and gloves when working on the air conditioning system.

**NOTE:** Evacuating the system means sucking all the air out of the system until a vacuum is obtained. Every time the system is discharged, it must then be evacuated, otherwise air and moisture will enter the openings before they can be capped.

Connect dual gauge set FKM10445 (D) as follows:

Open the two manual valves on the test equipment. Connect the red hose to high-side valve (A) and the blue hose to low-side valve (B).

Connect the yellow hose to vacuum pump FKM10440 (C) and switch on the pump.

The system should reach a vacuum pressure of 100 kPa; 1 bar; 14.5 psi (1000 mbar; 75 cm Hg; 29 in. Hg) within 5 minutes.

**NOTE:** If this vacuum pressure is not reached within 5 minutes, all joints must be checked, and it may be necessary to perform a leak test as well.


Close the valves and switch off the pump. Wait 5 minutes. The gauge should not rise by more than 3.4 kPa; 0.034 bar; 0.5 psi (34 mbar; 2.5 cm Hg; 1 in. Hg).

Switch on the pump again and open the valves.

Extract air from the system for at least 30 minutes.

Close the valves and disconnect the pump.

**NOTE:** Do not open the system; the vacuum must remain until the system is filled.



A—High-side valve  
B—Low-side valve  
C—Vacuum pump FKM10440  
D—Dual gauge set FKM10445

## FILLING THE SYSTEM

**CAUTION:** To prevent the risk of injury, always wear protective goggles and gloves when working on the air conditioning system. To avoid damaging the compressor while putting refrigerant into the high-side section of the system, it is VITAL to shut off the engine first.

Connect dual gauge set FKM10445 (C) and evacuate the system as described in "Evacuating the System".

Screw charging valve FKM10443 (A) into refrigerant can FKM10447 (B) and connect the yellow hose.

**IMPORTANT:** A system using R134a refrigerant must NEVER be filled with R12.

Open charging valve (A) and high-side valve (D). Neither of the two gauges should indicate a pressure vacuum.

*NOTE: If the low-side pressure gauge fails to rise, there must be a blockage in the system. Any blockages must be cleared.*

Wait till the pressure has stopped rising, then close the high-side valve (D).

Run the engine at 2100 rpm and set the system to maximum cooling effect.

Hold refrigerant can (B) upright and open low-side valve (E).


**IMPORTANT:** Liquid refrigerant must not enter the compressor. Liquid refrigerant will damage the compressor.

Specified capacity: 2.4 kg (5.29 lb).

**CAUTION:** The temperature of the refrigerant must not exceed 50°C (120°F), otherwise the refrigerant can may explode.

When the filling process is completed, close charging valve (A).

Check if enough refrigerant is in the system by looking at the sight-glass in the receiver-drier. If bubbles occur, top up with more refrigerant.



A—Charging valve FKM10443  
B—Refrigerant can FKM10447  
C—Dual gauge set FKM10445  
D—High-side valve  
E—Low-side valve

ZX005679 -UN-21APR95

## TOPPING UP A PARTLY DISCHARGED SYSTEM

It may become necessary to top up the system with small amounts of refrigerant in order to compensate for refrigerant lost through leakage or service work. In the event of a major leak or if there are signs of oil loss (e.g. an oil film), check the oil level in the compressor before topping up with refrigerant.

Connect gauge set FKM10445 (C) as described in "Filling the System".

Connect the yellow hose to refrigerant can FKM10447 (B).

**IMPORTANT: Never attempt to fill an R134a system with R12 refrigerant.**


Unfasten the hose connection at gauge set (C). Briefly open charging valve (A) so that air can escape from the yellow hose. Tighten the hose connection.

Run the system at maximum cooling effect.

Hold refrigerant can (B) upright and open low-side valve (E).

Observe the sight-glass at the receiver-drier. When no more air bubbles are visible, add a further 0.2 to 0.4 kg (7 to 14 oz.) of refrigerant.

**CAUTION:** The temperature of the refrigerant must never exceed 50°C (120°F), otherwise the refrigerant can may explode.



A—Charging valve FKM10443  
B—Refrigerant can FKM10447  
C—Dual gauge set FKM10445  
D—High-side valve  
E—Low-side valve

## FILLING WITH REFRIGERANT OIL

**CAUTION:** To prevent the risk of injury, always wear protective goggles and gloves when working on the air conditioning system.

Connect dual gauge set FKM10445 (C) as described in "Evacuating the System".

Evacuate the system as described in "Evacuating the System".

Close the valves and disconnect the pump.


Read how much oil is extracted during the evacuation process at the sight-glass in the oil separator. Add the same amount of new oil plus 10 ml (0.3 fl.oz.) to the oil injector.

**IMPORTANT:** Use PAG oil (ND-Oil8) only. Refrigerant oil is extremely hygroscopic — this means it attracts moisture in large amounts from the atmosphere. For this reason, do not open the system and oil can any longer than necessary.

Connect refrigerant oil injector FKM10436 (B) to the low side of gauge set.

Open charging valve (A) of oil injector (B) and low-side valve (E).

*NOTE: The vacuum within the system will draw oil into the system.*



- A—Charging valve
- B—Oil injector FKM10436
- C—Dual gauge set FKM10445
- D—High-side valve
- E—Low-side valve

## OIL CAPACITIES OF AIR CONDITIONING COMPONENTS

If one of the air conditioning components has been removed, the oil drained and the component cleaned (separately), add the following amounts of oil to the refrigerant circuit:

Component	ml	fl oz
Condenser	60 ml	2 fl oz
Evaporator	60 ml	2 fl oz
Receiver-drier	10 ml	0.3 fl oz
Refrigerant lines	110 ml	3.9 fl oz
Compressor	60 ml	2 fl oz

If a new compressor is installed, it must contain the full capacity of 160 ml (5.4 fl. oz.).

If the entire system is disassembled and all the lines and components (including compressor) are discharged and cleaned individually, add the full capacity of 300 ml (11 fl. oz.) to the system after re-assembly.

ZX.TMSPFH002882-19-16JUN93

## LEAK TEST


**NOTE:** The leak test confirms that an oily patch on the exterior of the system is caused by a leak. Perform a leak test only on systems that are ready for operation. If the system has already lost some of its refrigerant, top it up with refrigerant before testing for leaks.

Connect dual gauge set FKM10445 and evacuate the test hoses.

Read the static pressure at the low-side pressure gauge. If the pressure is less than 340 kPa (3.4 bar; 50 psi), top up with refrigerant.

Go over the entire system with the probe of electronic leak tester FKM10444 (A).

**NOTE:** Always look underneath each potential leak, as R134a refrigerant is heavier than air. Dense concentrations of R134a in the air may affect the result of the test.



-UN-21APR95  
ZX005682

ZX.TMXZCO003105-19-01DEC93

## REMOVING THE COMPRESSOR


Drain the refrigerant (see "Discharging the System").

Remove the drive belt.

Slacken attaching screws of line clamping plate (A) and remove the lines.

Seal all openings and lines so that no dirt can get in.

Remove the compressor.



-UN-21APR95  
ZX005683

ZX, TMXZC0003106-19-01DEC93

## CHECKING OIL LEVEL IN THE COMPRESSOR


Remove the compressor manifold (see "Checking the Compressor Manifold").

Drain compressor oil through the suction line connection.

Dispose of the oil in an environmentally friendly way.

Fill with refrigerant oil as described in "Filling with Refrigerant Oil".

*NOTE: Replace the receiver-drier every time the system is opened.*



-UN-19SEP94  
LX004356


ZX, TMSPFH002855-19-16JUN93

## DISASSEMBLING THE COMPRESSOR CLUTCH

### Removing the Clutch Hub

Remove cover (A).

Remove screw (B) and pull out clutch hub (C).



-UN-21APR95  
ZX005024


ZX, TMSPFH002856-19-16JUN93




### Removing the Clutch Plate

Remove shims (A) and keep them ready for re-installation.

Remove snap ring and take off clutch plate (B).



ZX005025 -UN-21APR95



ZX005026 -UN-21APR95


ZX,TMSPFH002857-19-16JUN93

### Removing Magnetic Coil

Remove snap ring.

Disconnect magnetic coil cable at compressor and take off magnetic coil (A).

*NOTE: When re-installing the snap ring, make sure that the chamfered side of the snap ring is at the top.*



ZX005027 -UN-21APR95

ZX,TMSPFH002858-19-16JUN93

## CHECKING CLUTCH HUB CLEARANCE

*NOTE: Clutch coil is NOT polarity sensitive.*

1. Use a feeler gauge to measure the clearance between pulley and clutch hub. Attach feeler gauge to pulley as shown and connect compressor to a 12 volts battery using a set of jumper wires.
2. Turn the pulley and measure the clearance again at three different points of clutch hub circumference. The distance between the measuring points should be equal. Specified clearance is 0,35—0,65 mm (0.014—0.026 in.). Add or remove shims as required.
3. Tighten the clutch hub retaining bolt to 15 Nm (11 lb-ft) after clearance has been adjusted correctly..



-UN-21APR95  
ZX005028

ZX.TMSPFH002859-19-16JUN93

## CHECKING THE COMPRESSOR MANIFOLD

Take out hex. socket screws (A) and remove manifold (B).


Discard gasket (C). Check the contact surfaces.

Apply oil to new gasket (C), and install.

Install manifold.

Tighten hex. socket screws to 25 Nm (18 lb-ft).

- A—Hex. socket screw
- B—Manifold
- C—Manifold gasket



LX004361

-UN-19SEP94  
LX004361


ZX.TMSPFH002860-19-16JUN93

## INSTALLING THE COMPRESSOR

Before installing, ensure that the compressor contains the specified amount of oil.

Install the compressor (A).

Install drive belt.



ZX, TMXZCO003107-19-01DEC93

## REMOVING AND INSTALLING THE CONDENSER

1. Discharge the air conditioning system.
2. Disconnect refrigerant lines at the condenser.
3. Seal the open ends with plastic caps.
4. Remove condenser (A). Drain the refrigerant oil and dispose of it in an environmentally friendly way.



*NOTE: The condenser and the hydraulic oil cooler are joined to an assembly. Condenser is located in the lower part.*

*NOTE: Fill with new refrigerant oil as described in "Filling with Refrigerant Oil".*

*NOTE: Replace the receiver-drier every time the system is opened.*

5. Evacuate the system, fill with refrigerant, and check.

A—Condenser  
I—2254,2266  
II—2256,2258,2264



ZXTMXZCO 011383-19-05MAR98


## REMOVING AND INSTALLING THE RECEIVER-DRIER

1. Discharge the air conditioning system.
2. Disconnect the refrigerant lines.
3. Seal the open ends with plastic caps.
4. Remove receiver-drier (A).

**IMPORTANT:** As soon as the dessicant material reaches its saturation level, the receiver-drier must be replaced, otherwise the system will become contaminated with moisture. Replace the receiver-drier every time an air conditioning component is removed or replaced.

*NOTE: Fill with new refrigerant oil as described in "Filling with Refrigerant Oil".*

5. Evacuate the system, fill with refrigerant, and check.





ZX.TMXZC0003108-19-01DEC93

## REMOVING AND INSTALLING THE EVAPORATOR AND EXPANSION VALVE

1. Discharge the air conditioning system.
2. Remove the passenger's seat.
3. Remove air conditioning system housing (A) completely. Housing is attached at the floor by means of two screws and at the rear wall by means of one screw.
4. Open housing (A)
5. Disconnect refrigerant lines (C) at expansion valve (D). Drain refrigerant oil and dispose of it in an environmentally friendly way.
6. Seal the open ends with plastic caps.
7. Remove evaporator (B) and expansion valve (D).

**NOTE:** Replace the receiver-drier every time the system is opened.

- A—Housing
- B—Evaporator
- C—Refrigerant lines
- D—Expansion valve




ZX.TMSPFH002864-19-16JUN93

## REMOVING AND INSTALLING THE THERMOSTAT SWITCH

1. Remove the two bowden cables.
2. Disconnect the two wires.
3. Remove thermostat switch (A) and sensing bulb (B).

**IMPORTANT:** Never bend or squash the sensing bulb capillary tube.



ZX.TMSPFH002865-19-16JUN93

## REMOVING AND INSTALLING THE HIGH/LOW PRESSURE SWITCH


*NOTE: There is no need to discharge the system when removing or installing high pressure switch (A) and low pressure switch (B).*

The line connections are equipped with a check valve.


The high pressure switch is located at the compressor refrigerant line.

The low pressure switch is located near the air conditioning system housing in the operator's cab.

Tighten new switches (A) and (B) to 16 Nm (12 lb-ft).



High pressure switch




Low pressure switch

ZX,TMXZC0003109-19-01DEC93

-UN-21APR95  
ZX005688

-UN-21APR95  
ZX005036

**HEATER COMPONENTS**



ZX 002412

**A—Heater valve at cylinder block**

**B—Air conditioning/heater rotary switch**

**C—Heater control in cab**

**D—Radiator**



ZX002412 -UN-08MAY95

ZX, TMXZCO003110-19-01DEC93

## REMOVING AND INSTALLING FAN AND RADIATOR

1. Discharge the cooling system.
2. Remove the passenger's seat.
3. Remove air conditioning/heating system housing (A) completely. Housing is attached at the floor by means of two screws and at the rear wall by means of one screw.
4. Open housing (A).
5. Disconnect and remove fan (B)
6. Disconnect coolant lines from radiator (C) and remove radiator

A—Housing  
B—Fan  
C—Radiator




ZX, TMXZC0003111-19-01DEC93

## REMOVING AND INSTALLING HEATER CONTROL

Coolant control is located next to air conditioning/heating system housing in operator's cab.

1. Drain cooling system.
2. Disconnect heater hoses at heater control (A), disconnect bowden cable (B) and remove heater control (A).



ZX, TMXZC0003112-19-01DEC93




### REMOVING OPERATOR'S CAB MAIN FILTER ELEMENT

Open service cover (A).


Disengage fasteners (B).

Lift out filter housing with element (C).

When reinstalling, make sure filter element is in correct position.



-UN-08MAY95  
ZX002584




-UN-08MAY95  
ZX002585

ZX,TMXZC0003113-19-01DEC93

### REMOVING AND INSTALLING RECIRCULATING FILTER

Press down grille (A) and pull out to the top.

Lift out filter element (B).





-UN-03APR95  
ZX002141

ZX,TMXZC0003114-19-01DEC93

*Operator's Cab Heating System/Cab filters*

**ADJUSTING THE GEAR SHIFT MECHANISM**

- Disengage ball-end (A).
- Move shift lever to position (1).




ZX 002289


ZX, TMXZC0009588-19-01AUG97

## Gear Shift Mechanism/Adjustment


- Transmission to 1st gear.
- In this position, it should be easy to install ball-end (A).
- Re-adjust bowden cable at bracket (B).



ZX012743 -UN-27SEP97




ZX012207 -UN-25SEP97



ZX012208 -UN-25SEP97

ZX,TMXZCO009589-19-01AUG97

**GEAR SHIFT MECHANISM, EXPLODED VIEW**



ZX012209

ZX012209 -JUN-25SEP97

A—Shift lever  
B—Ball-end  
C—Rod

D—Seals  
E—Shaft  
F—Bearing support

G—Ball bearing  
H—Bowden cable

J—Bracket  
K—Clamp

ZX.TMXZCO009590-19-01AUG97

*Gear Shift Mechanism/Exploded view*

# Section 110 Feeder House

## Contents

### Page

#### Group 05—Removing the Feeder House

Removing the feeder house . . . . . 110-05-1

#### Group 10—Bottom Feeder Drum

Specifications . . . . . 110-10-1

Height adjustment, bottom feeder  
conveyor drum . . . . . 110-10-3

Adjusting tension of feeder conveyor  
chain . . . . . 110-10-4

#### Group 15—Upper Feeder Shaft and Slip Clutch

Tension of feeder conveyor chain . . . . . 110-15-2

Drive and slip clutch . . . . . 110-15-3

#### Group 20—Drives

Specifications . . . . . 110-20-1

Drives on feeder house . . . . . 110-20-1

Drive with countershaft, exploded view . . 110-20-2

Variator assembly . . . . . 110-20-6

Adjusting bottom unit of feeder house  
variator . . . . . 110-20-7

#### Group 25—Reverser

Specifications . . . . . 110-25-1

Removing the reverser . . . . . 110-25-1

Exploded view . . . . . 110-25-2

Assembling the reverser . . . . . 110-25-4

#### Group 30—Pivoting Shield

Pivoting shield and associated  
components . . . . . 110-30-1

*Contents*



## Group 05 Removing the Feeder House

### REMOVING THE FEEDER HOUSE


**CAUTION:** Remove feeder house only with combine on level and solid ground.

Disconnect hose connections (A) and (B). Seal open hose ends with metal plugs.

- Metal plugs for connection (A): 38H1147
- Metal plugs for connection (B): 38H1146

On Hillmasters, two additional pressure hoses must be disconnected between the master cylinder and the pivoting shield cylinder.


To avoid damaging the master cylinder, use plastic plugs only to seal these hoses.



ZX004093  
-UN-26APR95

ZX.TMXZC0009591-19-01AUG97

Remove drive belt (V-belt) (C).




ZX004094  
-UN-26APR95

ZX.TMXZC0002722-19-13MAY93

Remove pin (D). Loosen clamping nuts (E).

Remove cable (F). Remove cable retainers from feeder house after turning out attaching screws.




ZX004095  
-UN-26APR95

ZX.TMXZC0002723-19-13MAY93

Removing the Feeder House/Removing the feeder house


Disconnect connector (G).



ZX, TMXZCO002724-19-13MAY93

-UN-26APR95  
ZX004096

Disconnect spring (H).




ZX, TMXZCO002725-19-13MAY93

-UN-26APR95  
ZX004097

Support front end of feeder house, using a suitable jack.


Remove locking screw (I) and drive out pin (K). Place hydraulic cylinder on the ground.



ZX, TMXZCO002726-19-13MAY93

-UN-26APR95  
ZX004098

Lower jack and support front end of feeder house on two wooden blocks.



ZX, TMXZCO002727-19-13MAY93


-UN-26APR95  
ZX004099

*Removing the Feeder House/Removing the feeder house*

Support rear side of feeder house by means of support stands.


Loosen lock nuts (A) and turn threaded pin upwards.

Remove clamps (B) on right and left-hand sides.



ZX, TMXZC0002728-19-13MAY93

Back up combine.



ZX, TMXZC0002729-19-13MAY93

*Removing the Feeder House/Removing the feeder house*

**Group 10**  
**Bottom Feeder Drum**

**SPECIFICATIONS**

<b>Item</b>	<b>Measurement</b>	<b>Specification</b>
Screws in drum carrier	Tightening torque	50 N·m (37 lb-ft)
Screws in bearing flange	Tightening torque	130 N·m (96 lb-ft)


ZX, TMXZC0009592-19-01AUG97

**OTHER MATERIALS REQUIRED**

<b>Order no.</b>	<b>Designation</b>	<b>Application</b>
TY9370	Loctite 242	Screws in bearing flange

ZX, TMXZC0009593-19-01AUG97

**BOTTOM FEEDER DRUM, EXPLODED VIEW**



ZX012216

A—Bottom feeder drum  
B—Bearing flange

C—Ball bearing  
D—Clamping ring

E—Drum carrier  
F—Shaft

G—M10x65 screw  
H—M12x35 screw


— Tighten screws (G) to 50 N·m (37 lb-ft).

— Apply Loctite 242 (TY9370) to screws (H), then insert and tighten to 130 N·m (96 lb-ft).

ZX012216 -UN-25SEP97

ZX.TMXZCO009594-19-01AUG97

Bottom Feeder Drum/Height adjustment, bottom feeder conveyor drum



ZX012217

A—Bottom feeder drum  
B—Shaft

C—Drum carrier  
D—Height adjustment

E—Fore-and-aft adjustment

F—Screw with bore

If you want to move drum (A) further forward, install screw (F) in the rearmost hole in drum carrier (C).

ZX.TMXZCO009595-19-01AUG97

ZX012217 -UN-25SEP97

### ADJUSTING HEIGHT OF BOTTOM FEEDER CONVEYOR DRUM


**IMPORTANT:** This adjustment must be carried out equally on both sides.

The required height depends on the type of crop:

- Normal grain crops: Lower
- Corn, rape etc.: Higher

**IMPORTANT:** Adjust length (X):

- Normal grain crops: 50 mm (1.97 in.)
- Corn, rape etc.: 34 mm (1.3 in.)



X—Adjusted length


ZX.OMXZCO002272-19-01MAR95

ZX004207 -UN-19MAY95

## ADJUSTING TENSION OF FEEDER CONVEYOR CHAIN

**IMPORTANT:** This adjustment must be carried out equally on both sides.

To adjust tension of conveyor chain, loosen hex. nut (A) on both sides. Then turn adjusting nut (B) until correct chain tension has been obtained. Finally tighten all nuts.




ZX.OMXZC0002271-19-05OCT92



**Group 15**  
**Upper Feeder Shaft and Slip Clutch**

**UPPER FEEDER SHAFT AND CONVEYOR CHAIN**



ZX012218

A—Ball bearing  
B—Bearing support

C—Sprocket shaft  
D—Shaft with flange

E—Slat

F—Conveyor chain

ZX012218 -UN-25SEP97



ZX.TMXZCO009596-19-01AUG97

## TENSION OF FEEDER CONVEYOR CHAIN

### Checking chain tension


Chain tension is correctly adjusted when the chain can be raised 30 to 40 mm (1-3/16 to 1-37/64 in.) by exerting a force of approx. 300 N (66 lb) halfway between upper and lower feeder conveyor shafts.

A further check is possible with the header removed. The third slat (as seen from the front) should lightly contact the floor of the feeder house.



ZX,OMXZC0002270-19-05OCT92

**DRIVE AND SLIP CLUTCH FOR UPPER FEEDER SHAFT**



ZX012219

- |                |                   |                   |                    |
|----------------|-------------------|-------------------|--------------------|
| A—Cover        | F—Rubber bushing  | L—Bushing         | Q—Tensioning screw |
| B—Clamping nut | G—Main plate      | M—Brass washer    | R—Bearing flange   |
| C—Washer       | H—Disk with teeth | N—Carrier disk    | S—Ball bearing     |
| D—Plate        | J—Hub             | O—Key             | T—Clamping ring    |
| E—Spring       | K—Sheave          | P—Tensioning roll |                    |

ZX012219 -UN-25SEP97

ZX.TMXZCO009597-19-01AUG97



## SLIP CLUTCH ON UPPER FEEDER SHAFT

Remove cover (A).

### Adjust slip clutch:

- Loosen clamping screw (B).
- Adjust length (X) to 12 mm (0.47 in.) at clamping nut (C).
- Tighten clamping screw (B).
- Install cover (A) and side guard.

A—Cover  
B—Clamping screw  
C—Clamping nut  
X—Adjusted length 12 mm (0.47 in.)  
I—Slip clutch



ZX009540

ZX.OMXZC0002273-19-01NOV96


**SPECIFICATIONS**

Item	Measurement	Specification
Screws to hub	Tightening torque	35 N·m (26 lb-ft)
Cylinder	Tightening torque	200 N·m (150 lb-ft)
Variator extended (middle unit)	Gap	24 mm (0.9 in)
Variator (lower unit)	Gap	3 - 6 mm (0.12 - 0.24 in)

ZX,TMXZCO009598-19-01AUG97

**DRIVES ON LEFT-HAND SIDE OF FEEDER HOUSE**

- A—Direct drive
- B—Drive with countershaft
- C—Drive with variator




ZX012220

-JUN-25SEP97  
ZX012220

ZX,TMXZCO009599-19-01AUG97

### DRIVE WITH COUNTERSHAFT, EXPLODED VIEW



ZX012221

ZX012221 -UN-25SEP97

A—Ball bearing  
B—Snap ring


C—Bushing  
D—V-belt sheave

E—Washer  
F—Spring ring

G—Retaining screw  
H—Dust cap

ZX.TMXZC0009600-19-01AUG97

**CENTRAL UNIT OF VARIATOR DRIVE, EXPLODED VIEW**



ZX01222

ZX012222 -UN-25SEP97

A—Cylinder  
B—Snap ring  
C—Rubber seal  
D—Shims


E—Bracket  
F—O-ring  
G—Ball bearing

H—Hub  
J—Drive belt  
K—Grease fitting

L—Variator half  
M—Seal ring  
N—Variator V-belt

ZX.TMXZCO009601-19-01AUG97

## ASSEMBLING THE VARIATOR DRIVE



A—Hub  
B—Inner sheave  
C—Outer sheave

D—Ball bearing  
E—0.8 mm (0.03 in.) shims

F—Cylinder  
G—Bracket

X—Gap with variator  
extended 24 mm (0.9 in.)

— Tighten the screws at the hub (A) to 35 N·m (26 lb-ft).


— Tighten cylinder (F) to 200 N·m (150 lb-ft).

— Adjust gap (X) by adding or removing shims (E). If the gap is too wide, the variator V-belt will be destroyed.

ZX, TMXZCO009602-19-01AUG97



**LOWER VARIATOR, EXPLODED VIEW**




ZX012224

ZX012224 -UN-25SEP97

- |             |                  |              |                  |
|-------------|------------------|--------------|------------------|
| A—Disks     | E—Seal ring      | J—Set screws | M—Spring pin     |
| B—Cover     | F—Engaging rings | K—Ball       | N—Ring           |
| C—Snap ring | G—Spring         | L—Key        | O—Grease fitting |
| D—Ring      | H—Variator half  |              |                  |

ZX.TMXZCO009603-19-01AUG97

**VARIATOR ASSEMBLY**



ZX012225

ZX012225  
-UN-25SEP97

**A—Inner half of variator**

**B—Outer half of variator**

**C—Spring**


ZX.TMXZC0009604-19-01AUG97

## ADJUSTING BOTTOM UNIT OF FEEDER HOUSE VARIATOR

**CAUTION:** Before adjusting the machine or performing service work, always switch off all drives, shut off the engine and wait until all moving parts have come to a stop.

Run the header drive shaft (A) at the slowest speed.

With the combine stationary and all functions switched off, adjust gap (X) to 3-6 mm (0.12-0.24 in.) by means of the tensioning device.



ZX007398

ZX007398 -UN-19JUN95

ZX.OMXZCO002276-19-01MAR95

*Drives/Adjusting bottom unit of feeder house variator*

## SPECIFICATIONS

Item	Measurement	Specification
Reverser gear attaching screws	Tightening torque	240 N·m (177 lb-ft)
Oil in reverser gear	Capacity	1.75 L (0.46 U.S.gal)

ZX, TMXZCO009605-19-01AUG97

## OTHER MATERIAL

Number	Name	Use
TY15130	Loctite 515 sealant	Sealing the surfaces of the reverser gear housing
TY9371	Loctite 242	Securing the screws on the cover

ZX, TMXZCO010102-19-01AUG97



## REMOVING THE REVERSER

- Remove shields (A) and (B).
- Relieve tension on V-belt (C), and remove.
- Remove bolts from bowden cable underneath the feeder house.
- Take out the three attaching screws (D).
- Remove reverser assembly.

**⚠ CAUTION: The reverser weighs over 50 kg (110 lb), so take care!**


- On reversers up to a certain serial number, the feeder house drive shaft is made in one piece. In this case, the belt pulley and bearing clamping ring must be removed from the r.h. side of the reverser prior to its removal.

- A—Shield
- B—Shield
- C—V-belt
- D—Attaching screws



ZX, TMXZCO009606-19-02AUG97

**REVERSER, EXPLODED VIEW**



ZX012228

- |                         |                  |                |                  |
|-------------------------|------------------|----------------|------------------|
| A—Metal cap             | H—Pin            | O—Ball bearing | U—Oil drain plug |
| B—Ring gear             | J—Washer         | P—Snap ring    | V—Housing        |
| C—Needle roller bearing | K—Spring         | Q—Cover        | W—Fork           |
| D—Input shaft           | L—Seal ring      | R—Bushing      | X—Shift collar   |
| E—Pinion                | M—Planet carrier | S—Dipstick     | Y—Reverser gear  |
| F—Thrust washer         | N—Ball           | T—Vent         | Z—Shaft          |
| G—Needle roller         |                  |                |                  |


ZX012228 -UN-25SEP97

ZX.TMXZCO009608-19-01AUG97

Reverser/Exploded view

- Apply multipurpose grease to threads on fork (F).
- Install parts (A—F) in the order shown. Do not tighten nuts (A) at this time.

- A—Nut (2 used)
- B—Bushing
- C—Washer
- D—Seal
- E—Shift collar
- F—Fork
- G—Housing



ZX,TMXZCO009609-19-01AUG97

H40423 -UN-20MAR89

- Install parts (A—F) in cover.

**NOTE:** Install pinions consecutively (one, two, and three) in a counterclockwise direction.

- A—Ball (3 used)
- B—Washer (3 used)
- C—Needle roller (186 used)
- D—Thrust washer (6 used)
- E—Pinion (3 used)
- F—Pin (3 used)




ZX,TMXZCO009610-19-01AUG97

H40425 -UN-20MAR89

- Line up numbers on pinions (B) with marks (A) made on cover during disassembly. Install gear (C).

**IMPORTANT:** If gears are not installed correctly timed, the gearcase could overheat.


- Install ring gear over planetary assembly.



ZX,TMXZCO009611-19-01AUG97

H40424 -UN-20MAR89

**ASSEMBLING THE REVERSER**



ZX012229

- |                    |                                |                   |                |
|--------------------|--------------------------------|-------------------|----------------|
| A—Fork             | D—Cutting platform drive shaft | F—Oil filler neck | H—M10x20 screw |
| B—Forward position | E—Oil drain                    | G—Sealing face    | J—M16x70 screw |
| C—Reverse position |                                |                   |                |


Coat sealing face (G) with Loctite 515 (TY15130).  
 Insert screws (H), having first coated them with  
 Loctite 242 (TY9371).

ZX.TMXZCO009612-19-01AUG97

ZX012229 -UN-25SEP97



**ATTACHING THE REVERSER**



ZX012230

ZX012230 -UN-25SEP97

A—Retaining plate  
B—Screw

C—Washer  
D—Rubber damper

E—Spacer retainer  
F—Spacer bushing

G—Bracket

Tighten screws (B) to 240 N·m (177 lb-ft).

ZX.TMXZC0009613-19-01AUG97

Reverser/Assembling the reverser


**Reverser**

Capacity: 1.75 L (0.46 U.S. gal)

*NOTE: Before checking the oil level, raise the feeder house until the filler tube is vertical.*

*If the combine harvester is equipped with a pivoting feeder house shield, tilt the shield to the right so that its right end is down and its left end is up.*

- A**—Dipstick and filler neck
- B**—Drain screw



ZX004173 -JUN-19JUN95

ZX,OMXZC0002066-19-21NOV96

## ADJUSTING REVERSER SHIFTER FORK AND CONTROL CABLE

Sit in the operator's seat and depress the right side of the reverser pedal.

Raise feeder house and lower safety rail. All adjustments are made under the feeder house.

Remove cotter pin, pin (A) and washer from yoke (B).

Remove pin (C).

**CAUTION: Bellcrank is spring-loaded and could pinch fingers if released accidentally.**

Pull bellcrank (D) away and hold it firmly.

Using a suitable wrench, loosen lock nuts (E) and (F) on shifter fork (G).

Relax hold on bellcrank (D). Push shifter fork (G) in as far as possible.

Hold shifter fork (G) in firmly and screw down lock nut (F) until spacer (H) is tight against washer (J).



Tighten lock nut (F) further by one complete turn.

Tighten lock nut (E) with the wrench. Be careful not to turn lock nut (F).

Reinsert pin (C) through bellcrank (D) and shifter fork (G).

Use lock nut (K) on yoke or lock nuts (L) to adjust the yoke until the end of the slot furthest from nut (K) is aligned with hole (M) in the arm.


Reinstall pin (A), washer (J) and the cotter pin.



- A—Pin
- B—Yoke
- C—Pin
- D—Bellcrank
- E—Lock nut
- F—Lock nut
- G—Shifter fork
- H—Spacer
- J—Washer
- K—Yoke lock nut
- L—Cable lock nuts
- M—Hole in arm

*Reverser/Assembling the reverser*

**PIVOTING SHIELD AND ASSOCIATED COMPONENTS**



ZX012231


ZX012231 -UN-25SEP97

- |                              |              |          |                  |
|------------------------------|--------------|----------|------------------|
| A—Spigot for pivoting shield | D—Guide roll | G—Spring | K—Washer         |
| B—Bushing                    | E—Retainer   | H—Lock   | L—Nut            |
| C—Pivoting shield            | F—Plate      | J—Screw  | M—Grease fitting |

ZX.TMXZCO009614-19-01AUG97

**PIVOTING SHIELD GUIDE ROLLS**

The guide rolls on the pivoting shield prevent the pivoting shield from rising above the surfaces of the feeder house during reversing. They also act as additional supports when the shield is being pivoted.



ZX009620

ZX009620 -UN-08NOV96

ZX.TMXZCO009615-19-01AUG97

*Pivoting Shield/Pivoting shield and associated components*

# Section 120

# Separator and Cleaning Unit

## Contents

	Page		Page
<b>Group 05—Stone Trap</b> . . . . .	120-05-1		
<b>Group 10—Threshing Cylinder and Concave</b>		<b>Group 40—Countershaft for Straw Walker and Cleaning Shoe Drive</b>	
Separator . . . . .	120-10-1	Exploded view of countershaft . . . . .	120-40-1
Aligning the belt pulley . . . . .	120-10-3	Assembling the countershaft . . . . .	120-40-2
Removing the threshing cylinder . . . . .	120-10-3		
Concave basic setting . . . . .	120-10-12	<b>Group 45—Straw Walkers and Straw Walker Crankshaft</b>	
Changing the concave . . . . .	120-10-15	Specifications . . . . .	120-45-1
Concave adjustment . . . . .	120-10-15	Removing the straw walkers . . . . .	120-45-1
		Installing the straw walkers . . . . .	120-45-2
<b>Group 15—Beater/Second Cylinder and Second Concave</b> . . . . .	120-15-1	Removing the straw walker bearings . . . . .	120-45-2
		Installing the straw walker bearings . . . . .	120-45-3
<b>Group 20—Electric Clutch</b>		Straw walker crankshaft and crankshaft bearings . . . . .	120-45-4
Specifications . . . . .	120-20-1		
Removal . . . . .	120-20-2	<b>Group 50—Cleaning Fan and Drive Fan</b>	
Assembly . . . . .	120-20-3	Specifications . . . . .	120-50-1
Exploded view . . . . .	120-20-5	Removing the cleaning fan variator . . . . .	120-50-1
		Adjusting the cleaning fan variator . . . . .	120-50-2
<b>Group 25—Countershaft, L.h. Drive Belt Pulley and Belt Guide</b>		Exploded view of cleaning fan variator . . . . .	120-50-3
Specifications . . . . .	120-25-1	Assembling the cleaning fan variator . . . . .	120-50-4
Exploded view of idler . . . . .	120-25-2	Adjusting the fan variator . . . . .	120-50-5
Assembling the idler . . . . .	120-25-3		
Exploded view of countershaft drive . . . . .	120-25-4		
Assembling the drive pulley . . . . .	120-25-5		
<b>Group 30—Variable Cylinder Drive</b>			
Special tools . . . . .	120-30-1		
Components of variable cyl. drive, upper unit . . . . .	120-30-6		
Components of ring-shaped piston . . . . .	120-30-7		
Components of variable cyl. drive, lower unit . . . . .	120-30-13		
Assembly, lower unit of variable cylinder drive . . . . .	120-30-18		
<b>Group 35—Cylinder Drive and Reduction Gear</b>			
Specifications . . . . .	120-35-1		
Disassembly . . . . .	120-35-1		
Repair . . . . .	120-35-2		
Instructions for assembly . . . . .	120-35-3		
Adjusting the planet gears . . . . .	120-35-3		
Assembly . . . . .	120-35-4		

*Contents*



## OPENING STONE TRAP BOTTOM PLATE

**⚠ CAUTION:** Watch for falling stones when bottom plate swings downward.



Remove any stones that have been collected.

Pull lever (A) upward. Access to the lever is from either side. The stone trap opens by itself.

When closing the stone trap, push lever (A) beyond the engagement point as far as stop (B).

The engagement point can be adjusted at slots (C).

- A—Lever
- B—Stop
- C—Slots
- I—Bottom plate closed
- II—Bottom plate open



ZX,OMXZC0002280-19-02MAY96

*Stone Trap*


# Group 10 Threshing Cylinder and Concave

## SPECIFICATIONS

Item	Measurement	Specification
Screws in belt pulley and clamping hub	Tightening torque	73 N·m (53.8 lb-ft)
Screw in clamping hub	Tightening torque	85 N·m (62.7 lb-ft)
Screws in bearing housing	Tightening torque	50 N·m (37 lb-ft)
Screws in flanged shaft	Tightening torque	130 N·m (96 lb-ft)
Screws in clamping plate	Tightening torque	80 N·m (59 lb-ft)
Screws on rasp bars	Tightening torque	140 N·m (103 lb-ft)
Screws on cylinder filler plates	Tightening torque	50 N·m (35 lb-ft)
Screws on bracket for adjusting motor	Tightening torque	55 N·m (41 lb-ft)
Concave clearance at front	Gap	3-5 mm (0.12-0.2 in.)
Concave clearance at rear	Gap	2-6 mm (0.08-0.24 in.)

ZX.TMXZC0009616-19-01AUG97

**EXPLODED VIEW OF CYLINDER DRIVE**



ZX009378

ZX009378 -UN-27OCT97

- |                 |                               |                              |                     |
|-----------------|-------------------------------|------------------------------|---------------------|
| A—Belt pulley   | E—M12x90 screw                | H—M12x30 screw               | L—M12x35 screw      |
| B—Clamping hub  | F—Clamping plate              | J—Bearing housing            | M—Clamping ring     |
| C—Key           | G—M10x35 fillister-head screw | K—Self-aligning ball bearing | X—77.5 mm (3.0 in.) |
| D—Flanged shaft |                               |                              |                     |

- Tighten screw (E) to 85 N·m (62.7 lb-ft).
- Tighten screw (G) to 80 N·m (59 lb-ft).
- Tighten screw (H) to 50 N·m (37 lb-ft).
- Tighten screw (L) to 130 N·m (96 lb-ft).

**IMPORTANT: Tighten fillister-head screws (G) evenly, otherwise the clamping plate will become skewed.**

ZX.TMXZCO009617-19-01AUG97

### ALIGNING THE BELT PULLEY


Slacken off fillister-head screws (A), clamping plate (B) and set-screw (C).

Align the belt pulley to suit the power band.

Tighten fillister-head screws (A) evenly to 80 N-m (59 lb-ft).

Tighten clamping screw (B) to 85 N-m (62.7 lb-ft).

Then tighten set-screw (C).




ZX.TMXZC0006648-19-01AUG96

### REMOVING THRESHING CYLINDER


*NOTE: Prior to threshing cylinder removal, feeder house must be removed. If the threshing cylinder is equipped with filler plates, remove these plates prior to threshing cylinder removal.*

Remove cover bar (A).



ZX.TMXZC0002730-19-13MAY93



Turn out attaching screws (B) of stone trap locking mechanism on right and left-hand sides.



ZX.TMXZC0002731-19-13MAY93



Threshing Cylinder and Concave/Removing the threshing cylinder

Remove attaching screws (C) of stone trap on right and left-hand sides. Lift stone trap out of machine frame. Two persons are required to perform this job.



ZX,TMXZCO002732-19-13MAY93


Remove straps (A) and (B).



ZX,TMXZCO002733-19-13MAY93

Threshing Cylinder and Concave/Removing the threshing cylinder

Completely relieve spring tensioner (C).




ZX004108

-UN-24APR95  
ZX004108

ZX,TMXZC0002734-19-13MAY93

Turn out attaching screws (D). Lift pulley off hub and leave it suspended in the V-belt.




ZX004109

-UN-24APR95  
ZX004109

ZX,TMXZC0002735-19-13MAY93

Turn out hex. socket screw (A). Loosen cap screw (B) and lift hub off the shaft.




ZX004110

-UN-24APR95  
ZX004110

ZX,TMXZC0002736-19-13MAY93

Raise concave to highest position from the cab.

Turn out attaching screws (C).




ZX004111

-UN-24APR95  
ZX004111

ZX,TMXZC0002737-19-13MAY93

## Threshing Cylinder and Concave/Removing the threshing cylinder


Separate stub shaft from threshing cylinder by loosening screws (D) and take stub shaft out of combine frame.



Loosen lock nuts of speed sending unit (E). Remove speed sending unit.


Turn out attaching screws (F).

Remove bearing housing half.




Turn out flange screws (G). Separate stub shaft from threshing cylinder.

- The threshing cylinder touches the concave -



Pull out two plastic grids (H) of grain pan.

Place two 10 x 12 cm (0.4 x 0.5 in.) wooden supports with a length of 4 m (1.6 in.) against grain pan at the points where the grids have been removed.







## Threshing Cylinder and Concave/Removing the threshing cylinder

**CAUTION:** Secure threshing cylinder to prevent it from rolling out of combine.

Move concave to lowest position from the cab.


Roll threshing cylinder out of machine over concave front edge and the two wooden supports. Two persons are required to perform this job.

*NOTE: When removing threshing cylinder from combine, make sure that a deep spot of the cylinder is rolled over the concave front edge.*



ZX.TMXZC0002741-19-13MAY93

**THRESHING CYLINDER, EXPLODED VIEW**



ZX012232

A—Threshing cylinder  
B—R.h. flanged shaft  
C—L.h. flanged shaft

D—M12x35 screw, to flanged shaft

E—Rasp bar (right-serrated)  
F—Rasp bar (left-serrated)

G—M12x35 screw  
H—M12 nuts (2 used)

— Tighten screws (D) to flanged shafts (B and C) to 130 N·m (96 lb-ft).

— Tighten screws (G) to 140 N·m (103 lb-ft), and lock.

ZX012232 -UN-26SEP97


ZX.TMXZCO009618-19-01AUG97

## CYLINDER RASP BARS

The cylinder is equipped with right-serrated and left-serrated rasp bars, installed alternately. When replacing a rasp bar, replace the corresponding bar on the opposite side as well to maintain proper cylinder balance.

Rasp bars can be replaced without removing the cylinder.

**IMPORTANT:** After the first 10 hours of operating with new rasp bars, retighten the attaching screws to 140 N·m (103 lb-ft).



ZX 004254

-UN-19JUN95  
ZX004254

ZX,OMXZCO002282-19-01MAR95

## CYLINDER FILLER PLATES


To harvest corn, the cylinder must be fitted with filler plates (A). These plates rub the kernels off the cobs and prevent the cobs from breaking up.

Tighten screws (C) to 50 N·m (35 lb-ft), and retighten them after the first half hour of operation.

**IMPORTANT:** Make sure the filler plates have been removed before harvesting grain crops.


**NOTE:** Leave clips (B) in place, as they suffer damage in the removal process.

- A—Filler plate
- B—Clip
- C—Cap screw
- X—Direction of rotation



ZX 004263

-UN-19JUN95  
ZX004263



ZX004264

-UN-22MAY95  
ZX004264

ZX,TMXZCO010118-19-01AUG97


## CONCAVES

Three different concaves are available, providing ideal threshing and cleaning characteristics for every type of crop.

### I. Grain crop concave

Two-position (engaged/disengaged) de-awning plates are integrated into the grain crop concave.

Either a booster bar or a special rasp bar may be installed at the concave inlet.



ZX004257 -UN-19JUN95


ZX, TMXZC0010103-19-01AUG97

### II. Corn (maize) concave

This concave may be used to harvest both corn (maize) and sunflowers.

The corn (maize) concave has integral de-awning plates (A) which can be engaged or disengaged.

Either a booster bar or a special rasp bar may be installed at the concave inlet.



ZX014333 -UN-26/JAN98

ZX, OMXZC0002288-19-01APR98


### III. Universal concave

Either a booster bar or a special rasp bar may be installed at the concave inlet.

The corn concave has integral de-awning plates (A) which can be engaged or disengaged.

The rear part of the concave can be shielded by concave inserts (B) for corn harvesting.

**IMPORTANT: Concave inserts (B) must be removed for harvesting grain crops.**




Universal concave

ZX007399

ZX,OMXZC0002289-19-02MAR95

ZX007399 -JUN-19-JUN95

**CONCAVE BASIC SETTING**



ZX014340

A—Adjusting motor  
B—Bracket  
C—Holder

G—Attaching screws  
X—Punch-mark on highest rasp bar

I—Adjusting point, rear right  
II—Adjusting point, rear left  
III—Adjusting point, front left

IV—Adjusting point, front right

ZX.OMXZC0002296-19-01APR98

## CONCAVE BASIC SETTING (CONTINUED)

**NOTE:** When measuring, select the highest rasp bar at either side. This rasp bar (or these rasp bars) are marked with an "X" punch-mark before leaving the factory. Different rasp bars may be marked either on the left or right ends.

Install the concave and attach it at the adjusting points (see above). At adjusting point IV, attach the mountings to the center of the slots.

Install adjusting motor (A) at bracket (B), holders (C) and at the adjusting lever.

### Adjusting points I and II

With the highest cylinder rasp bar at each end, set a gap of 3 mm (0.12 in.) at the last concave rasp bar.

Measure the gap between the 3rd concave rasp bar and the highest cylinder rasp bar. Concave clearance should be 4 mm (0.16 in.). If clearance is OK at both ends, continue with assembly (see below).


### Adjusting points III

If concave clearance is greater than 4 mm (0.16 in.), push bracket (B) at adjusting point III onto the combine harvester's frame until clearance at 3rd concave rasp bar is 4 mm (0.18 in.).

If concave clearance is less than 4 mm (0.16 in.), pull bracket (B) at adjusting point III forward along the combine harvester's frame until clearance at 3rd concave rasp bar is 4 mm (0.18 in.).


- A—Adjusting motor
- B—Bracket
- C—Holder
- D—Aluminium bearing
- E—Adjusting screw
- F—Stop plate
- G—Attaching screws
- X—Punch-mark on highest rasp bar
- I—Rear right adjusting point
- II—Rear left adjusting point
- III—Front left adjusting point
- IV—Front right adjusting point

I




ZX009608

II




ZX009610

III



ZX009615

IV



ZX009616

ZX.OMXZC002297-19-01NOV96

## CONCAVE BASIC SETTING (CONTINUED)

### Adjusting point IV

If concave clearance is greater or less than 4 mm (0.16 in.), slacken off the screws that hold on aluminium bearing (D). Also slacken off adjusting screw (E). Set a gap of 4 mm (0.18 in.) at the 3rd rasp bar by moving the adjusting shaft up or down. Once the setting is correct, tighten the attaching screws on the aluminium bearing. Set the adjusting screw so that stop plate (F) is hard against the aluminum bearing. Tighten the locknut.

### Check

The gap at the 9th concave rasp bar should be 1.5 mm (0.06 in.), measured at each end of the highest cylinder rasp bar. If the gap is not correct, turn the eye-bolts at adjusting points I and II until clearance is as quoted.

Check that the cylinder is free to rotate and is not obstructed at any point along its length.


### Adjusting point III

Join bracket (B) to holder (C), using the holes that match each other closest. (Re-)tighten all the screws. The tightening torque for the attaching screws (G) at bracket (B) and holder (C) is 55 N·m (41 lb-ft).

- A—Adjusting motor
- B—Bracket
- C—Holder
- D—Aluminium bearing
- E—Adjusting screw
- F—Stop plate
- G—Attaching screws
- I—Rear right adjusting point
- II—Rear left adjusting point
- III—Front left adjusting point
- IV—Front right adjusting point


I

ZX009608




II

ZX009610




III

ZX009615



IV

ZX009616




ZX.OMXZC0007006-19-01NOV96



## CHANGING THE CONCAVE

**IMPORTANT:** Before changing the concave, adjust it to give the minimum clearance (spindle (A) fully retracted). The infotrak monitor must display a concave clearance of "4".

Once it is removed, do not make any changes to the adjusting motor's spindle, either electrically or manually.




-UN-08NOV96  
ZX009607

ZX,OMXZC0002294-19-01NOV96

## CONCAVE ADJUSTMENT

**IMPORTANT:** Concave must always be horizontal and parallel to cylinder. Speed and clearance determine effectiveness of threshing.

*NOTE: Under certain circumstances, it may be a good idea to open the rear of the concave further at the two adjusting screws.*




-UN-26JAN98  
ZX014339

ZX,OMXZC0002298-19-01APR98

OPENINGS	FRONT	REAR
MINIMUM GAP	3-5 mm	2- 6 mm
MAXIMUM GAP	47-53 mm	20-26 mm

## FINGER RAKE

The finger rake is available for combines harvesting in very dry, brittle crops where additional separation is not required or in high moisture crops where the finger rake enables loose grains to pass through the straw more easily.



ZX004294


-UN-19JUN95  
ZX004294

ZX,OMXZC0002302-19-01MAR95

*Threshing Cylinder and Concave/Concave adjustment*

# Group 15 Beater/Second Cylinder and Second Concave

## BEATER/SECOND CYLINDER



ZX012233

A—Beater/cylinder

B—Shaft

C—Cover

Tighten the M12x100 screws on the inner clamping hubs to 70 N·m (52 lb-ft).


ZX, TMXZC0009619-19-01AUG97

ZX012233 -UN-25SEP97

## SECOND CYLINDER

Opening the cover gives access to the clamping hubs on the cylinder.

**IMPORTANT:** To avoid imbalance, use genuine screws only.




ZX 004291

ZX, TMXZC0010104-19-01AUG97

ZX004291 -UN-19JUN95

**DIFFERENT TYPES OF SECOND CONCAVE**



ZX012234

ZX012234 -UN-25SEP97

A—Second concave  
(grain-crop version)

B—Second concave (rice  
version)

C—Retaining rod  
D—Retaining eye

E—Friction element

ZX.TMXZCO009621-19-01AUG97


## SECOND CONCAVE

The gap to the cylinder can be adjusted to provide the most efficient throughput of material in relation to the harvesting conditions.

Moving the concave closer to the cylinder provides a higher degree of separation for crops that are hard to thresh.

If the concave is moved away from the cylinder, the crop material is threshed more gently.

- I—Setting for grain crops
- II—Setting for corn



ZX007400 -JUN-19-JUN95

ZX,OMXZC0002301-19-01MAR95


*Beater/Second Cylinder and Second Concave*

**SPECIFICATIONS**

Item	Measurement	Specification
Gap between armature baseplate and coil	Gap	1.5 mm (0.06 in.)
Electric clutch to side panel	Clearance	59 mm (2.3 in.)
Shim	Thickness	0.5 mm (0.02 in.)

ZX, TMXZC0009620-19-01AUG97

**SELF-MANUFACTURED GAUGE FOR MEASURING GAP**



A—10 mm (0.4 in.)

B—150 mm (6 in.)

C—1.5 mm (0.06 in.)




D—20 mm (0.8 in.)

ZX, TMXZC0009623-19-01AUG97

## REMOVING THE ELECTRIC CLUTCH

- Remove shield (A).
- Relieve tension on drive belts (B), (C) and (D), and remove.
- Pull the two cables (E) and (F) off the power supply (G).
- Use a 32 mm (1.26 in.) open-ended wrench to unscrew the power supply (G).
- Unfasten clamping screw (H) and lift off the electric clutch assembly.
- If el. clutch has single-speed relationship drive, remove retaining plate (J) and screws (K).
- Replace any parts that are worn. Make gap 1.5 mm (0.06 in.) wide by adding or removing shims.


- A—Shield
- B—Drive belt
- C—Drive belt
- D—Drive belt
- E—Cable
- F—Cable
- G—Power supply
- H—Clamping screw
- J—Retaining plate
- K—Screws (4 used)



ZX, TMXZCO009624-19-05MAR98



**ASSEMBLING THE ELECTRIC CLUTCH**



ZX012240

ZX012240 -UN-25SEP97

A—Power supply  
B—Coil  
C—Drive belt pulley


D—Driven pulley  
E—Armature baseplate  
F—Beater shaft

G—Shim  
H—Clamping hub  
X—Gap: 1.5 mm (0.06 in.)

Y—Clearance: 59 mm  
(2.3 in.)

ZX.TMXZC0009625-19-01AUG97

**ASSEMBLING THE ELECTRIC CLUTCH (WITH SINGLE-SPEED RELATIONSHIP DRIVE)**



ZX012241

ZX012241 -UN-25SEP97

A—Power supply  
 B—Coil  
 C—Drive belt pulley  
 D—Driven pulley


E—Armature baseplate  
 F—Beater shaft  
 G—Shim

H—Drive belt pulley for  
 single-speed relationship  
 drive

X—Gap: 1.5 mm (0.06 in.)  
 Y—Clearance: 59 mm  
 (2.3 in.)

ZX.TMXZCO010005-19-01AUG97

**ELECTRIC CLUTCH, EXPLODED VIEW**



ZX012239

ZX012239 -UN-25SEP97

A—Power supply  
 B—Belt pulley  
 C—0.5 mm (0.02 in.) shim

D—Clamping hub  
 E—Armature baseplate  
 F—Coil

G—Belt pulley  
 H—Ball bearing

J—Spacer ring  
 K—Snap ring


ZX.TMXZCO010006-19-01AUG97

*Electric Clutch/Exploded view*

**ELECTRICAL BOX IN ENGINE COMPARTMENT**

- F 51 — 7.5 A fuse, reverse travel alarm
- F 52 — 7.5 A fuse, header electrical clutch
- K 01 — Starting motor relay
- K 42 — Relay, header electrical clutch
- K 45 — Relay D+

Relays and fuses for electric clutch, from serial no. 061 687



ZX009238

ZX, TMXZC0010007-19-01AUG97

ZX009238 -JUN-22MAY96

**Group 25**

**Countershaft, L.h. Drive Belt Pulley and Belt Guide**

**SPECIFICATIONS**

Item	Measurement	Specification
Screws, belt pulley to clamping hub	Tightening torque	69 N·m (51 lb-ft)
Screw on clamping hub	Tightening torque	85 N·m (63 lb-ft)
Screws on clamping hub to clamping plate	Tightening torque	80 N·m (59 lb-ft)


ZX, TMXZCO010008-19-01AUG97

**OTHER MATERIAL**

Number	Name	Use
TY9370	Loctite 242	Screws, belt pulley to clamping hub

ZX, TMXZCO010009-19-01AUG97

**IDLER, EXPLODED VIEW**



ZX012242

ZX012242 -UN-25SEP97

A—Pointer  
B—Set screw  
C—Spring  
D—Pin  
E—Bushing


F—Lever  
G—Shaft  
H—Screw  
J—Spring pin

K—Seal ring  
L—Taper roller bearing  
M—Bearing cup  
N—Washer

O—Slotted nut  
P—Cotter pin  
Q—Grease cap  
R—Idler

ZX.TMXZCO010010-19-01AUG97

### ASSEMBLING THE IDLER



ZX012243

ZX012243 -UN-25SEP97

A—Lever  
B—Seal ring  
C—Taper roller bearing

D—Bearing cup  
E—Idler

F—Washer  
G—Slotted nut


H—Cotter pin  
J—Grease cap

— Before assembling, apply multi-purpose grease to taper roller bearing and seal ring.  
— Fill cavities in idler and grease cap with multi-purpose grease.

— With idler (E) turning, tighten slotted nut (G) until the idler is braked. Then turn the slotted nut back by 1/16 of a turn, and secure with cotter pin (H).

ZX.TMXZCO010011-19-01AUG97

### COUNTERSHAFT DRIVE ON LEFT-HAND SIDE, EXPLODED VIEW



ZX012244

ZX012244 -UN-25SEP97

A—Bearing housing  
B—Ball bearing

C—Clamping ring  
D—Clamping plate


E—Clamping hub  
F—Belt pulley

G—Key  
H—Countershaft

ZX.TMXZC0010012-19-01AUG97



**ASSEMBLING THE DRIVE PULLEY ON LEFT-HAND SIDE**



A—193 mm (7.6 in.)  
 B—200 mm (7.9 in.)  
 C—284 mm (11.2 in.)

D—Clamping plate  
 E—M10x35 screw

F—Clamping hub  
 G—M12x90 screw

H—M10x45 screw  
 J—M10x35 screw

Coat screws (J) with TY9370 (Loctite 242), insert them and tighten to 69 N·m (51 lb-ft).

Tighten screws (E) to 89 N·m (59 lb-ft).

Align the belt pulley and tighten screw (G) to 85 N·m (63 lb-ft).

**IMPORTANT: Tighten screws (E) evenly, otherwise the clamping plate (D) may become skewed.**

ZX.TMXZCO010013-19-01AUG97



## Group 30 Variable Cylinder Drive

### SPECIAL OR ESSENTIAL TOOLS

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

### ASSEMBLY AND DISASSEMBLY TOOL

Spring tensioning device for lower unit of variable cylinder drive, KMZ10001.



**KMZ10001**

-UN-28AUG96  
KMZ10001

ZX,TMXZCO006631-19-01SEP96

### OTHER MATERIALS

Order no.	Designation	Application
TY9370	Loctite 243	Clamp nut to variable drive
TY15969	Loctite 638	Bolts in variable drive

ZX,TMXZCO006770-19-01SEP96

### SPECIFICATIONS

Item	Measurement	Specification
Clamp nut to variable drive	Torque	300 N·m (221 lb-ft)
Clamp screw on variable drive	Torque	55 N·m (40.6 lb-ft)
Screws on flanged shaft	Torque	31 N·m (23 lb-ft)
Screws to bearing support	Torque	90 N·m (66.4 lb-ft)
Screws to hub and variable sheave	Torque	90 N·m (66.4 lb-ft)

ZX,TMXZCO006771-19-01SEP96

## REPLACING THE V-BELT ON VARIABLE CYLINDER DRIVE

Close the upper variable drive (A).

On the lower variable drive (B), insert at least two M12x65 screws into the threaded bores provided. This holds the variable drive sheaves apart.





Run the separator and bleed the pressure in hydraulic line (D) by separating the upper variable drive sheaves (A).

Unscrew elbow fitting (E) from countershaft.

Take V-belt (F) off the upper variable drive.

Unbolt support (G).

- A—Variable drive
- B—Variable drive
- C—Threaded bores
- D—Hydraulic line
- E—Elbow fitting
- F—V-belt
- G—Support




ZX.TMXZCO006587-19-01AUG96

## REPLACING THE V-BELT ON VARIABLE CYLINDER DRIVE (CONTINUED)

Take two screws out of the bearing support (H), raise the variable drive, pull the support forward and remove V-belt (F).

*NOTE: On 6-walker combines, the tailings elevator must be partly unfastened and pulled far enough away from the machine to allow V-belt (F) to clear the bearing support (H).*



ZX.TMXZCO006588-19-01AUG96

## INSTALLING THE V-BELT


To install V-belt, follow removal procedure in reverse order.

ZX.TMXZCO006589-19-01AUG96

## REMOVING THE UPPER UNIT OF VARIABLE CYLINDER DRIVE

Before disassembling, close the variable drive hydraulically.

On flange (A) of the lower variable drive, screw in at least two M12x65 screws (three threaded bores (B) are provided). This holds the variable drive sheaves apart.




ZX.TMXZCO006590-19-01AUG96

Variable Cylinder Drive/Special tools

Run the separator and bleed the pressure in hydraulic line by separating the upper variable drive sheaves.

Slacken off clamp screw (C) and square nut (D).




ZX009314 -JUN-29AUG96

ZX009314

ZX,TMXZCO006591-19-01AUG96

Unscrew pressure hose (E). Trap any remaining oil and seal line with plug (F).




ZX009315 -JUN-05SEP96

ZX009315

ZX,TMXZCO006592-19-01AUG96

Remove ring-shaped piston assembly (G) and outer variable drive sheave (H).




ZX009316 -JUN-30AUG96

ZX009316

ZX,TMXZCO006593-19-01AUG96


### REMOVING THE UPPER UNIT OF VARIABLE CYLINDER DRIVE (CONTINUED)

Relieve tension on V-belts to blower variable drive (J) and to elevator drive (K). Remove the V-belt from the rear variable drive sheave.




ZX, TMXZC0006594-19-01AUG96

Put down V-belt (L) and remove the variable drive sheave assembly (M).



ZX, TMXZC0006595-19-01AUG96

**COMPONENTS OF VARIABLE CYLINDER DRIVE, UPPER UNIT**



A—Flanged-head screws  
 B—Rear variable drive sheave  
 C—Hub  
 D—Washers (3 used)

E—Snap ring  
 F—Front variable drive sheave  
 G—Intermediate ring  
 H—Seat of seals

J—Set of seals  
 K—Ring-shaped piston  
 L—Stepped cylinder  
 M—O-ring (2 used)


N—Washer  
 O—Clamp nut and clamp screw  
 P—Seal ring

ZX.TMXZCO006596-19-01AUG96

ZX009320 -UN-30AUG96



### COMPONENTS OF RING-SHAPED PISTON



A—O-ring  
B—Stepped cylinder  
C—O-ring

D—Wiper ring  
E—Spiral back-up ring  
F—O-ring

G—Ring-shaped piston  
H—O-ring  
J—Spiral back-up ring


K—Bushing (3 used)  
L—Pin (3 used)

ZX009321

ZX009321 -UN-28AUG96

ZX.TMXZC0006597-19-01AUG96

**ASSEMBLY OF VARIABLE CYLINDER DRIVE (UPPER UNIT), UP TO SERIAL NO. 064838**



ZX009322

ZX009322 -UN-28AUG96


ZX.TMXZC0006598-19-01AUG96

**INSTALLING THE VARIABLE DRIVE**

The countershaft must be installed with 386 mm (15.2 in.) separating the sidewall from the front edge of the shaft.

Before assembly, coat all bearing points and seals with multi-purpose grease.

A—386 mm (15.2 in.)




ZX009323

ZX009323 -UN-30AUG96

ZX.TMXZC0006599-19-01AUG96

### INSTALLING THE VARIABLE DRIVE (CONTINUED)

Using 8 flat-collar screws coated with Loctite 243 (TY9370), bolt hub (A) onto variable drive sheave (B). Tighten the screws to 90 N·m (66.4 lb-ft).




ZX009324

ZX,TMXZC0006600-19-01AUG96

-JUN-28AUG96  
ZX009324

Place one washer (C) in the hub and secure it in position with a snap ring (D).



ZX009325

ZX,TMXZC0006601-19-01AUG96

-JUN-05SEP96  
ZX009325

Slide the variable drive sheave onto the countershaft and install two more washers in front of the snap ring.

See detail (A) in "Assembly of Variable Cylinder Drive".



ZX009326

ZX,TMXZC0006602-19-01AUG96

-JUN-28AUG96  
ZX009326

## INSTALLING THE VARIABLE DRIVE (CONTINUED)


Install the front variable drive sheave and ring-shaped piston. Insert clamp nut (E) (treated with Loctite TY 9370), and tighten to 300 N·m (221 lb-ft).

Tighten clamp screw (F) to 55 N·m (40.6 lb-ft).

Apply sealing tape to the pressure hose and elbow fitting (G), and screw the latter tight.


Check that the connection is tight.

With the variable drive sheaves closed, lubricate the variable drive using the grease fitting provided.



ZX, TMXZC0006603-19-01AUG96

**ASSEMBLY OF VARIABLE CYLINDER DRIVE (UPPER UNIT), FROM SERIAL NO. 064839**



ZX009328

ZX009328 -JUN-28AUG96

This assembly differs from the previous one in having a modified countershaft (A) and an additional spacer ring (B).


ZX.TMXZC0006604-19-01AUG96

**REMOVING THE LOWER UNIT OF VARIABLE CYLINDER DRIVE**

Remove the large side guard on the right-hand side (see Section 80).

Remove the tailings elevator (see Section 130).

Take variable drive V-belt (A) off the upper variable drive (B). See description at "Replacing The V-Belt On Variable Cylinder Drive".




ZX009334

ZX009334 -JUN-29AUG96

ZX.TMXZC0006605-19-01AUG96

Variable Cylinder Drive/Components of ring-shaped piston

Relieve tension on power band to cylinder drive (C), and take it off belt sheave (D).




ZX,TMXZC0006606-19-01AUG96

Support the variable drive unit with a forklift truck (E), and secure with wooden chocks (F).

**CAUTION:** The variable drive unit weighs approx. 100 kg (220 lb).


Unbolt the variable drive mounting assembly (G) at the four points where it is attached to the sidewall, and lower the complete variable drive unit.



ZX,TMXZC0006607-19-01AUG96


Here are the points where the variable drive mounting is attached.

H—Threaded bores  
J—Threaded pin



ZX,TMXZC0006608-19-01AUG96

**COMPONENTS OF VARIABLE CYLINDER DRIVE, LOWER UNIT**



ZX009347

ZX009347 -JUN-28AUG96

A—Snap ring  
 B—Ball bearing  
 C—Bearing support  
 D—Flanged shaft  
 E—Key  
 F—Sheave

G—V-belt  
 H—Seal ring  
 J—Brass bushing  
 K—Sheave  
 L—Seal ring


M—Ring with lugs  
 N—Stud  
 O—O-ring  
 P—Washer  
 Q—Spring

R—Double snap ring  
 S—Belt sheave  
 T—Variable drive mounting  
 U—Ball bearing  
 V—Bearing ring

ZX.TMXZC0006632-19-01AUG96


### DISASSEMBLING THE LOWER UNIT OF THE VARIABLE CYLINDER DRIVE

Take two screws (B) out of the bearing support (A).



ZX.TMXZCO006633-19-01AUG96

Take snap ring (C) off flanged shaft (D), and disassemble variable drive mounting (E).




ZX.TMXZCO006634-19-01AUG96

Place the thrust ring (F) of tool KMZ10001 on the belt sheave (J) and use an M12x40 screw (G) to press the thrust ring onto the belt sheave.

Remove snap ring (H).

- F—Thrust ring
- G—Screw
- H—Snap ring
- J—Belt sheave



ZX.TMXZCO006635-19-01AUG96

Lift off belt sheave (J) from above.



ZX.TMXZCO006636-19-01AUG96




### DISASSEMBLING THE LOWER UNIT OF THE VARIABLE CYLINDER DRIVE (CONTINUED)

Lift variable drive sheave (K) off the flanged shaft and place it on the spindle of tool KMZ10001. By using thrust ring (L) to compress spring (M), it becomes possible to remove the double snap ring (N).

- K—Variable drive sheave
- L—Thrust ring
- M—Spring
- N—Double snap ring

ZX009351




-JUN-28AUG96  
ZX009351

ZX.TMXZCO006637-19-01AUG96

By slackening the nut on the spindle of the tool, the pressure on spring (O) is relieved, and it becomes possible to remove double snap ring (N), washer (P), spring (O) and the ring with lugs (Q).

- N—Double snap ring
- O—Spring
- P—Washer
- Q—Ring with lugs

ZX009353




-JUN-29AUG96  
ZX009353

ZX.TMXZCO006638-19-01AUG96

- A—Double snap ring
- B—Washer
- C—Spring
- D—Ring with lugs
- E—Variable drive sheave

ZX009354




-JUN-28AUG96  
ZX009354

ZX.TMXZCO006639-19-01AUG96

### REPAIRING THE LOWER UNIT OF THE VARIABLE CYLINDER DRIVE

Insert locating screws (A) into the ring with lugs (B). Use Loctite 638 (TY15969) on the screws.


Replace all O-rings (C) with new ones.



ZX.TMXZC0006640-19-01AUG96

-UN-28AUG96  
ZX009355

If brass bushings (D) and seal ring (E) are worn, replace them.




ZX.TMXZC0006641-19-01AUG96

-UN-30AUG96  
ZX009356

### ASSEMBLING THE LOWER UNIT OF THE VARIABLE CYLINDER DRIVE

Use screws (F) to bolt flanged shaft (G) to the variable drive sheave (H). Apply Loctite 243 (TY9370) to the screws before inserting them, and tighten to 31 N·m (23 lb-ft).




ZX.TMXZC0006642-19-01AUG96

-UN-28AUG96  
ZX009357

Fill the cavity between the lugged rings and the spring with approx. 0.86 kg (30 oz.) of multi-purpose grease.

Apply Molykote to the end surfaces of the lugged rings.



ZX.TMXZC0006643-19-01AUG96

-UN-28AUG96  
ZX009358


**ASSEMBLING THE LOWER UNIT OF THE  
VARIABLE CYLINDER DRIVE (CONTINUED)**

For further assembly, follow removal procedure in reverse order.

Tighten the two screws on the bearing support to 90 N·m (66.4 lb-ft).

ZX, TMXZC0006644-19-01AUG96

**ASSEMBLY, LOWER UNIT OF VARIABLE CYLINDER DRIVE**



ZX009360

ZX009360 -JN-28AUG96

ZX, TMXZC006645-19-01AUG96

# Group 35 Cylinder Drive and Reduction Gear

## SPECIFICATIONS


Item	Measurement	Specification
Screws on flanged shaft	Tightening torque	130 N·m (96 lb-ft)
Screws, reduction gear attachment	Tightening torque	130 N·m (96 lb-ft)
With gear disengaged	Speed range	370 - 1110 rpm
With gear engaged	Speed range	150 - 440 rpm

ZX, TMXZC0010014-19-01AUG97

## DISASSEMBLE CYLINDER DRIVE REDUCTION GEAR

Remove attaching screws of cover (A).

Remove cover (A).




-UN-24APR95  
ZX004082

ZX, TMXZC0002130-19-05OCT92

Use a mandrel or similar tool to hold locking ball between sliding sleeve (B) and shaft in place.


Before removing sliding sleeve, take out locking ball and spring through bore.



-UN-24APR95  
ZX004083

ZX, TMXZC0002131-19-05OCT92

Drive flanged shaft (C) out of gearcase.




-UN-24APR95  
ZX004084

ZX, TMXZC0002132-19-05OCT92


## Cylinder Drive and Reduction Gear/Repair

Using an M6 screw, pull the three planet gear shafts (D) out of gearcase.




ZX, TMXZC0002133-19-05OCT92

Take individual planet gears (3 used) out of gearcase.



ZX, TMXZC0002134-19-05OCT92

Remove snap ring and drive sun gear out of gearcase.



ZX, TMXZC0002135-19-05OCT92

### REPAIR CYLINDER DRIVE REDUCTION GEAR

Check all parts of cylinder drive reduction gear for wear or damage.

Replace worn or damaged parts as necessary.

Whenever seals are removed, install new ones.

ZX, TMXZC0002136-19-05OCT92

## INSTRUCTIONS FOR ASSEMBLY OF CYLINDER DRIVE REDUCTION GEAR

1. Before assembly, wash all parts. Make sure that all parts are clean and free of chips.

2. Lubricate all bearing points and seals with SAE multipurpose grease before assembly.

Fill space between dust and sealing lips of seals with grease.

3. Before pressing bearing (H) on flanged shaft, position snap ring (J).

4. When installing planet gears, note "zero" position.

5. Apply sealant to screws before installation.


Seal sun gear against side wall by means of sealant before installation.

6. Fill gearcase with 2.2 L (0.6 U.S.gal) of SAE 90 gear case oil.

ZX.TMXZCO002137-19-05OCT92


## ADJUST PLANET GEARS

Install planet gears with marked teeth facing center of reduction gear unit.



ZX.TMXZCO002138-19-05OCT92

**ASSEMBLE CYLINDER DRIVE REDUCTION GEAR**



- |                              |                  |                |                        |
|------------------------------|------------------|----------------|------------------------|
| A—Cover                      | F—Sun gear       | L—Shaft seal   | P—Spacer               |
| B—Sliding sleeve             | G—Needle bearing | M—Shaft seal   | Q—Ball bearing         |
| C—Flanged shaft              | H—Ball bearing   | N—Snap ring    | R—Snap ring            |
| D—Planet gear shaft (3 used) | J—Snap ring      | O—Ball bearing | S—Pulley with gearcase |
| E—Planet gear                | K—Shaft seal     |                |                        |


Assemble cylinder drive reduction gear, using above illustration as a guide.

**ZX004089**

ZX004089  
-UN-02MAY95



**CYLINDER DRIVE REDUCTION GEAR (FROM A CERTAIN SERIAL NUMBER)**



ZX012254

ZX012254  
-UN-25SEP97

A—Back-up ring  
B—Snap ring

C—Shift collar  
D—Screws

E—Screws

F—Face

This reduction gear differs in relation to the previous one in having back-up ring (A) and snap ring (B). In addition, shift collar (C) can now be locked.

Tighten screws (D) and (E) to 130 N·m (96 lb-ft).  
Coat face (F) with a commercially-available sealant.

ZX.TMXZC0010015-19-01AUG97

## SELECTING THE CYLINDER DRIVE REDUCTION GEAR


The cylinder drive reduction gear allows the cylinder speed to be reduced by about half. It is used to harvest corn (maize) and sunflowers.

The angled end of lug (A) indicates the position to which the camshaft is set:

- F-Lock position
- S-Select position


### Changing Speeds

- Turn lug (A) from position "F" to position "S".
- Pull out shifter sleeve (B) (reduction gear disengaged) for speeds in the 370—1110 rpm range
- Push in shifter sleeve (B) (reduction gear engaged) for speeds in the 150—440 rpm range.
- Turn lug (A) from position "S" to position "F".



ZX008399

-UN-22NOV95  
ZX008399



ZX008400


-UN-22NOV95  
ZX008400

ZX.TMXZCO010016-19-01AUG97

**Group 40**

**Countershaft for Straw Walker and Cleaning Shoe Drive**

**COUNTERSHAFT, EXPLODED VIEW**



ZX012255

ZX012255 -UN-25SEP97

A—Drive belt (V-belt)  
 B—Washer  
 C—V-belt pulley  
 D—Bushing


E—Disk with teeth  
 F—Carrier  
 G—Spring  
 H—Snap ring

J—Ball bearing  
 K—Bearing housing  
 L—Shaft

M—Retaining plate  
 N—Clamping hub  
 O—Gear

ZX.TMXZCO010017-19-01AUG97

**ASSEMBLING THE COUNTERSHAFT**



ZX012256

ZX012256 -UN-25SEP97

A—V-belt pulley  
B—Shaft

C—Spring  
D—Slip clutch

E—Gear  
F—Clamping hub

G—Straw walker crankshaft  
X—Setting: 52 mm (2.0 in.)

ZX.TMXZCO010018-19-01AUG97

# Group 45 Straw Walkers and Straw Walker Crankshaft

## SPECIFICATIONS


Item	Measurement	Specification
Screws through bearing halves	Tightening torque	8 - 10 N·m (6 - 7 lb-ft)
Screws on walker bearing to walker	Tightening torque	50 N·m (37 lb-ft)
Straw walkers	Weight (each)	80 kg (176 lb)

ZX, TMXZC0010019-19-01AUG97

## REMOVING THE STRAW WALKERS

- To gain access to the front walker bearing, remove the chaffer and sieve.
- Also unbolt the two cross-shaker tines above the straw walker that is to be removed.
- Take four screws (A) out of the front walker bearing, and four screws out of the rear walker bearing.
- Remove straw walker through the rear cleaning flap.

**CAUTION:** Each straw walker weighs 80 kg (176 lb) and is awkward to handle.




ZX, TMXZC0010020-19-01AUG97

## INSTALLING THE STRAW WALKERS

- Same as removal procedure, but in reverse order.
- On the bearing support, the front straw walker bearings are bolted onto the square holes (A).
- On the bearing support, the rear straw walker bearings are bolted onto the rectangular holes (B).
- Tighten screws to 50 N-m (37 lb-ft).

**IMPORTANT:** Before tightening the bolts on the rear bearings, turn straw walker crankshaft two or three times to allow the straw walkers to settle on bearing support.



ZX012258


-UN-25SEP97  
ZX012258

ZX.TMXZC0010021-19-01AUG97

## REMOVING THE STRAW WALKER BEARINGS


- Take out screws (A). Raise walker and insert a support (C).
- Take out screws (B) and pull off metal housing (D).
- Take the bearing halves off the crankshaft.

- A—Screws
- B—Screws
- C—Support
- D—Metal housing



ZX012259

-UN-25SEP97  
ZX012259



ZX012260



-UN-26SEP97  
ZX012260

ZX.TMXZC0010022-19-01AUG97

## INSTALLING THE STRAW WALKER BEARINGS


- Check bearing halves (A) for signs of wear.
- Check plastic insert (B) for signs of wear.
- Before installing the bearing halves and plastic insert, coat them all with grease.
- Install with holes (C; for screws) at the bottom.
- Install metal housing, and screw the bearing together with two screws in holes (D).

A—Bearing halves  
 B—Plastic insert  
 C—Holes for screws  
 D—Holes




ZX.TMXZC0010023-19-01AUG97

- Tighten screws (B) to between 8 and 10 N·m (6 and 7 lb-ft).
- Install bearings on straw walker (4 screws per bearing).
- Tighten screws (A) to 50 N·m (37 lb-ft).



ZX.TMXZC0010024-19-01AUG97

### STRAW WALKER CRANKSHAFT AND CRANKSHAFT BEARINGS



ZX012263

ZX012263 -UN-27SEP97

A—Bearing support  
B—Ball bearing

C—Clamping ring  
D—Crankshaft

E—Plastic insert  
F—Bearing halves

G—Metal housing




ZX.TMXZCO010025-19-01AUG97



## REMOVING THE FRONT STRAW WALKER CRANKSHAFT

- Remove the chaffer and sieve.
- Remove bolts from all straw walker bearings.
- Support the straw walkers with a plank of wood. Pull them through the opening in the grain tank floor and secure them so they cannot slip.
- Remove bolts from the front right bearing (A) of the walker shaft.
- On the left-hand side, remove drive belts (B) and (C).
- Unbolt gear (D).
- Unfasten clamping hub (E), unbolt the bearing retainer at screws (F) and remove it.
- Pull the straw walker crankshaft out to the left.
- Installation of straw walker crankshaft is same as removal procedure, but in reverse order.
- Align the straw walker crankshaft so that the gap between the straw walkers and the side wall is the same at left and right.

- A—Bearing
- B—Drive belt
- C—Drive belt
- D—Gear
- E—Clamping hub
- F—Screws







ZX,TMXZCO010026-19-01AUG97

## REMOVING THE REAR STRAW WALKER CRANKSHAFT

- Remove bolts from all the straw walker bearings. Support the walkers with a plank of wood and a wooden prop (A).
- Remove bolts that hold the bearing halves onto the crankshaft.
- Remove bolts that hold the right rear ball bearing (B).
- On the left-hand side, remove cross-shaker drive (C).
- Unfasten the driven pulley (D) and ball bearing (E), and remove.
- Pull the straw walker crankshaft out to the left.
- Installation of straw walker crankshaft is same as removal procedure, but in reverse order.
- Align the straw walker crankshaft so that the gap between the straw walkers and the side wall is the same at left and right.

- A—Plank and wooden prop
- B—Ball bearing
- C—Cross-shaker drive belt
- D—Driven pulley
- E—Ball bearing



ZX, TMXZCO010027-19-01AUG97

## Group 50 Cleaning Fan and Drive Fan



### SPECIFICATIONS

Item	Measurement	Specification
Screws on fan variator	Tightening torque	30 N·m (22 lb-ft)
Gap between middle and outer sheaves	Gap	approx. 1 mm (0.04 in.)

ZX.TMXZCO010028-19-01AUG97


### REMOVING THE CLEANING FAN VARIATOR

- Unfasten nut on screw (A).
- Screw back the nut on adjusting fork (B) to relieve the tension on the drive belt.
- Unfasten the screw clamping hub (C) and remove the sheave.
- Pull out screw (A) and remove the variator.
- Replace any parts that are worn; re-install variator in reverse order.



ZX.TMXZCO010029-19-01AUG97

### ADJUSTING THE CLEANING FAN VARIATOR



ZX012273

A—Electric motor  
B—Spindle housing

C—Spindle  
D—Variator mounting


E—Adjusting fork  
F—Bracket

G—Threaded pin

ZX012273 -JUN-27/SEP97

ZX.TMXZC0010030-19-01AUG97

### CLEANING FAN VARIATOR, EXPLODED VIEW



ZX012274

ZX012274 -UN-27SEP97


A—Fitted screw  
B—M8x25 screw  
C—Sheave halves

D—Ball bearing  
E—Hub

F—Seal ring  
G—Thrust ring

H—Middle sheave  
J—Hollow shaft

ZX.TMXZCO010031-19-01AUG97



ZX012275

ZX012275 -JUN-27/SEP97

A—Sheave half  
B—Middle sheave  
C—Sheave half

D—Hub  
E—Hollow shaft

F—Grease fitting  
G—Screw

H—Ball bearing  
J—Fitted screw

Tighten screws (G) and (J) to 30 N·m (22 lb-ft).

*NOTE: Holes for fitted screws are marked with a punch-mark.*

ZX.TMXZCO010032-19-01AUG97

## ADJUSTING FAN VARIATOR


**CAUTION:** Before adjusting the machine or performing service work, always switch off all drives, shut off the engine and wait until all moving parts have come to a stop.

### Tension drive belts:

Once belts (A) and (B) are in position, tension the belts by means of fork (C). First slacken off screw (D).

### Variator stroke adjustment:

- Slacken off nuts (E) and locknuts (F) fully.
- With the machine running, set variator to low speed until the middle disk moves outward.
- With the machine stopped, turn nut (E1) as far as pin (G). Tighten locknut (F1).
- With the machine running, set variator to high speed until the middle disk moves inward.
- With the machine stopped, turn nut (E2) as far as pin (G). Tighten locknut (F2).
- Set the variator to medium speed.
- With the machine stopped, turn nuts (E) and locknuts (F) half a revolution in the direction of the arrow.



ZX009622

A—Drive belt  
 B—Drive belt  
 C—Adjusting fork  
 D—Screw  
 E—Adjusting nuts  
 F—Locknuts  
 G—Threaded pin

-UN-08NOV96

ZX009622

ZX,OMXZC0002254-19-01NOV96

*Cleaning Fan and Drive Fan/Adjusting the fan variator*



**Section 130**

# **Grain Recovery and Unloading System**

**Contents**

Page

**Group 05—Tailings Elevator**  
Removing the tailings elevator . . . . . 130-05-1

**Group 10—Clean Grain Elevator**  
Removing the clean grain elevator . . . . . 130-10-1

**Group 15—Filling the Grain Tank**  
Drives for filling the grain tank . . . . . 130-15-1

**Group 20—Unloading the Grain Tank**  
Special tool . . . . . 130-20-1  
Specifications . . . . . 130-20-1


**Group 25—Unloading Auger**  
Unloading tube and auger . . . . . 130-25-1

*Contents*

**REMOVING THE TAILINGS ELEVATOR**


Remove the large side guard (A; see description in Section 80).

Remove drive chain (B) and sprocket (C).



ZX.TMXZCO006649-19-01AUG96


Take 6 screws out of housing (D) and lift off cover (E).



ZX.TMXZCO006650-19-01AUG96

Take out screw (F).


Slacken off nuts (G) on the bearing flange.



ZX.TMXZCO006651-19-01AUG96

Remove lower drive chain (H) and sprocket (J).


Slacken off nuts (K) on the bearing flange.



ZX.TMXZCO006652-19-01AUG96


### REMOVING THE TAILINGS ELEVATOR (CONTINUED)

Slacken off screws (L) on the sheet-metal cover.




ZX.TMXZCO006653-19-01AUG96

Take screws (M) out of the support.




ZX.TMXZCO006654-19-01AUG96

Takes screws (N) and (O) out of the central attaching element.



ZX.TMXZCO006655-19-01AUG96

Suspend the elevator by a cable from a forklift truck, and move it to the side.



ZX.TMXZCO006656-19-01AUG96


## Group 10 Clean Grain Elevator

### REMOVING THE CLEAN GRAIN ELEVATOR

Before the clean grain elevator can be removed, it is first necessary to remove the tailings elevator.

Relieve the tension on drive chain (A), and remove.

Take out the screws on both sides of the elevator top section (B).




ZX.TMXZCO006658-19-01AUG96

Relieve the tension on drive belt (C), and remove.


Take out the screws and remove drive (D) from the elevator.

Disconnect attaching element (E).



ZX.TMXZCO006659-19-01AUG96


Disconnect the elevator from inlet (F).



ZX.TMXZCO006660-19-01AUG96

Remove the tensioning ring and slacken off screws (G) at the bearing flange.


Then use a forklift to lift the elevator sideways off the machine.



ZX.TMXZCO010033-19-01AUG97

*Clean Grain Elevator/Removing the clean grain elevator*

DRIVES FOR FILLING THE GRAIN TANK




A—Engine                      B—Countershaft                      C—Drive                      D—Angle drive

Drive (C) and angle drive (D) are described in this Group (see below).

ZX.TMXZCO010034-19-01AUG97

**DRIVE (C), EXPLODED VIEW**



ZX012276

ZX012276 -UN-27SEP97

A—Washer  
B—Bushing  
C—Belt pulley with gear  
D—Hub

E—Carrier  
F—Disk with teeth  
G—Spring


H—Belt pulley  
J—Snap ring  
K—Ball bearing

L—Keys  
M—Shaft  
N—Support

ZX.TMXZC0010035-19-01AUG97



**ASSEMBLING DRIVE (C)**




ZX012277

A—59.5 mm (2.34 in.)

ZX012277 -UN-27SEP97

ZX.TMXZCO010036-19-01AUG97

### ANGLE DRIVE (D) FOR FILLING THE GRAIN TANK



ZX012278

A—Sealing disk  
B—Output shaft  
C—Sealing ring

D—Snap ring  
E—Ball bearing  
F—Housing


G—Bevel gear  
H—Cover

J—Locating pin  
K—Input shaft

ZX012278 -UN-27SEP97

ZX.TMXZC0010037-19-01AUG97

**ASSEMBLING ANGLE DRIVE (D)**



ZX012279


ZX012279 -JUN-27SEP97

- Coat cover (A) with sealant.
- Fill housing (B) with multi-purpose grease.

ZX.TMXZC0010038-19-01AUG97

*Filling the Grain Tank/Drives for filling the grain tank*

**SPECIAL TOOL (SELF-MANUFACTURED)**



- A—70 mm (2.8 in.)                      C—45 mm (1.8 in.)                      E—7 mm (0.3 in.)                      G—M20x20 screw
- B—55 mm (2.2 in.)                      D—10 mm (0.4 in.)                      F—4 mm (0.16 in.)

This tool is required to tighten the slotted nut on the angle drive at the unloading tube.


ZX, TMXZCO010049-19-01AUG97

**SPECIFICATIONS**

Item	Measurement	Specification
Slotted nut on angle drive	Tightening torque	150 - 250 N·m (110 - 184 lb-ft)

ZX, TMXZCO010039-19-01AUG97

**DRIVES FOR UNLOADING THE GRAIN TANK**



ZX012281

ZX012281 -UN-27SEP97

A—Engine  
 B—Pivoting arm drive  
 C—Angle drive, unloading tube drive

D—Unloading tube angle drive  
 E—Unloading drive, right


F—Feed augers  
 G—Grain tank unloading auger

H—Angle drives for feed augers

The drives for unloading the grain tank are described in detail in this Group (see below).

ZX, TMXZC0010040-19-01AUG97

**PIVOTING ARM DRIVE (5-WALKER COMBINES; B), EXPLODED VIEW**




ZX012282

- |                |                |                |                  |
|----------------|----------------|----------------|------------------|
| A—Pivoting arm | D—Ball bearing | G—Sprocket     | K—Bushing        |
| B—Shaft        | E—Washer       | H—Belt pulley  | L—Retainer       |
| C—Key          | F—Snap ring    | J—Clamping hub | M—Thrust bushing |

ZX012282 -JUN-27/SEP97

ZX.TMXZCO010041-19-01AUG97

**PIVOTING ARM DRIVE (6-WALKER COMBINES; B), EXPLODED VIEW**



ZX012283

ZX012283 -UN-27SEP97

A—Seal ring  
B—Taper roller bearing  
C—Bearing cup  
D—Hub

E—Belt pulley  
F—Washer  
G—Slotted nut  
H—Dust cap

J—Pivoting arm  
K—Snap ring  
L—Retainer

M—Thrust bushing  
N—Sprocket  
O—Ball bearing

— Before assembly, coat the seal ring (A) and taper roller bearing (B) with multi-purpose grease.

— Fill the cavity in hub (D) 3/4 full with multi-purpose grease.


— Install hub assembly on shaft of pivoting arm.

— With the hub turning, tighten slotted nut (G) until the hub is braked, then turn the nut back by 1/16 of a turn and secure it with a cotter pin.

— Axial play should be 0.1 - 0.2 mm (0.004 - 0.008 in.).



**ANGLE DRIVE OF UNLOADING TUBE DRIVE (C)**



ZX012284

ZX012284 -UN-27SEP97

A—Bevel gears  
B—Sleeve  
C—Snap ring

D—Ball bearing  
E—Cover  
F—Housing


G—Carrier  
H—Shear bolt  
J—Sprocket

K—Bushing  
L—Input shaft

Install components as shown and fill cavity in housing (F) with multi-purpose grease before closing cover (E).

ZX.TMXZC0010043-19-01AUG97

**ASSEMBLING ANGLE DRIVE (C)**



ZX012285

ZX012285 -UN-27SEP97


A—Sprocket  
B—Input shaft

C—Shear bolt  
D—Drive shaft to r.h. side

E—Vertical auger to  
unloading tube

ZX.TMXZC0010044-19-01AUG97

**ASSEMBLING ANGLE DRIVE (D)**



**A—Housing**  
**B—Shaft and bevel gear**

**C—Ball bearing**  
**D—Slotted nut**

**E—Snap ring**

**F—Cavity in housing**

— Join shafts and bevel gears (B) to ball bearings (C) and slotted nuts (D).


— Using the self-manufactured wrench, tighten the slotted nut to between 150 and 250 N·m (110 and 184 lb-ft).

— Fill the cavity (F) in the housing with multi-purpose grease.

— Insert the two shafts and bevel gears into housing (A) and install snap rings (E).

ZX, TMXZCO010045-19-01AUG97

**GRAIN TANK UNLOADING DRIVE, RIGHT (E)**



ZX012287

ZX012287 -UN-27SEP97

A—Drive shaft from angle drive (C)


B—Tensioning sprocket

C—Drive for grain tank unloading auger

D—Drive for feed augers

ZX.TMXZCO010046-19-01AUG97

**ANGLE DRIVES FOR FEED AUGERS (H)**



ZX012288


ZX012288 -UN-27SEP97

A—Drive shaft

B—Feed auger drive shaft

ZX.TMXZCO010050-19-01AUG97

**ASSEMBLING ANGLE DRIVES (H)**



ZX012289

ZX012289 -JUN-27SEP97

A—Drive shaft  
B—Feed auger drive shaft

C—Drive to second angle drive


D—Bevel gears  
E—Housing

F—Cavity (filled with multi-purpose grease)

ZX.TMXZCO010047-19-01AUG97

*Unloading the Grain Tank/Specifications*

UNLOADING TUBE AND AUGER



ZX012290

ZX012290  
-UN-27SEP97

A—Extra-long unloading  
auger  
B—Central support  
C—Ball bearing

D—Clamping ring  
E—Standard unloading auger  
F—Bearing flange  
G—Retaining plate

H—Cover plate  
J—Unloading tube  
K—End-cover  
L—Rubber curtain

M—Turret ring  
N—Ball  
O—Plug  
P—Grease fitting

ZX.TMXZC0010048-19-01AUG97

*Unloading Auger/Unloading tube and auger*



# Section 140 Special Equipment

## Contents

### Page

#### Group 05—Straw Chopper


Special tool . . . . .	140-05-1
Specifications . . . . .	140-05-1
Drive for straw chopper . . . . .	140-05-2
Removing the rotor . . . . .	140-05-2
Chopper rotor with knives . . . . .	140-05-3
Replacing rotating knives . . . . .	140-05-4
Rotor engagement clutch . . . . .	140-05-5
Removing adapter sleeve bearings . . . . .	140-05-6
Adapter sleeve bearing, exploded view . . . . .	140-05-7

#### Group 10—Chaff Spreader

Chaff spreader hydraulic components . . . . .	140-10-1
Removing the chaff spreader . . . . .	140-10-7

*Contents*

**SELF-MANUFACTURED SPECIAL TOOL**



- A—250 mm (10 in.)      C—65 mm (2.56 in.)      E—7 mm (0.275 in.)      G—M20x20 screw  
 B—76 mm (3 in.)      D—10 mm (0.4 in.)      F—6 mm (0.236 in.)

For removing and installing the adapter sleeve bearing

ZX, TMXZCO010051-19-01AUG97

**SPECIFICATIONS**


Item	Measurement	Specification
Position of r.h. ball bearing (loose bearing)	Clearance	8 mm (0.32 in.)
Slotted nut on adapter sleeve bearing	Tightening torque	140 n·m (100 lb-ft)
Screws on rotating knives	Tightening torque	65 N·m (47 lb-ft)

ZX, TMXZCO010052-19-01AUG97

## DRIVE FOR STRAW CHOPPER

Align the drive at struts (A) until the drive is parallel to the side wall.


- A—Strut
- B—Retainer
- C—Belt pulley



ZX.TMXZCO010054-19-01AUG97


## REMOVING THE ROTOR

- Remove straw chopper assembly.
- Remove drive pulley (A).
- Remove adapter sleeve bearing with bearing supports on both sides.
- Lift rotor out of chopper housing.



ZX.TMXZCO010053-19-01AUG97

### CHOPPER ROTOR WITH KNIVES



ZX012292

ZX012292 -UN-27SEP97

A—Rotor  
B—Knife

C—Knife guide  
D—Washer

E—M10x50 screw

F—Self-locking nut

— Knives (B) must move freely within knife guide (C).

ZX.TMXZCO010055-19-01AUG97

## REPLACING ROTATING KNIVES

**CAUTION:** Always jam the rotor to prevent accidents when replacing rotating knives.


**IMPORTANT:** Note the following to avoid unbalancing the straw chopper:

Excessive vibration may be caused by broken knives. Remove the broken knife (together with the knife that is most nearly opposite) at once, and install replacements.

Do not sharpen knives that go dull. Instead, turn them round or replace them. This ensures that all the knives on the rotating knife shaft weigh approximately the same.


Always use M10x50 screws of 10.9 grade together with self-locking nuts. Tighten the cap screws to 65 N·m (47 lb-ft).

Install the screws from right to left (in direction of forward travel).



ZX,OMXZC0002339-19-04DEC92

**ROTOR ENGAGEMENT CLUTCH**



ZX012293

ZX012293 -UN-27SEP97


- |                |                            |                                  |                |
|----------------|----------------------------|----------------------------------|----------------|
| A—Rotor shaft  | D—Detent ball              | G—Flanged pulley for<br>2700 rpm | H—Clutch       |
| B—Snap ring    | E—Spring                   |                                  | J—M12x20 screw |
| C—Ball bearing | F—Belt pulley for 3600 rpm |                                  |                |

**⚠ CAUTION:** Before switching the chopper on or off, switch off the drive and wait till all the moving parts stop moving.

ZX.TMXZCO010056-19-01AUG97

## REMOVING ADAPTER SLEEVE BEARINGS

- Remove bearing cap (A).
- Unlock and loosen slotted nut.
- Loosen adapter sleeve.
- Loosen bearing support attaching screws and remove bearing support with bearing.



-UN-26FEB98  
Z114394




-UN-26FEB98  
Z114395

ZX,TMXZC0010057-19-01AUG97



**ADAPTER SLEEVE BEARING, EXPLODED VIEW**



ZX012294

A—Guard  
B—Reinforcement  
C—Felt seal

D—Bearing support  
E—Clamping ring

F—Ball bearing  
G—Lock washer

H—Slotted nut  
J—Bearing cap

ZX012294 -UN-27SEP97


ZX.TMXZC0010058-19-01AUG97

## INSTALLING ADAPTER SLEEVE BEARINGS

Bearing on drive side (fixed bearing):

- Attach bearing support (C).
- Slide clamping ring (E) onto shaft.
- Install bearing (D) in bearing support and press against stop.
- Align rotor so that rotor knives are centered between counter-knives.
- Install slotted nut (F) on clamping ring, tighten to 140 N·m (100 lb-ft) and secure by means of lock washer (H).

- A—Rotor
- B—Reinforcement
- C—Bearing support
- D—Bearing
- E—Clamping ring
- F—Slotted nut
- G—Felt seal
- H—Lock washer



ZX, TMXCO010059-19-01AUG97

-UN-26FEB98  
Z114200


Bearing opposite drive side (loose bearing):

- Attach bearing support (C).
- Slide clamping ring (E) onto shaft.
- Install bearing (D) in bearing support and adjust dimension (X).

*NOTE: When adjusting dimension (X), bearing on drive side must be tight.*

- Install slotted nut on clamping ring, tighten to 140 N·m (100 lb-ft) and secure by means of lock washer (H).


- A—Rotor
- B—Reinforcement
- C—Bearing support
- D—Bearing
- E—Clamping ring
- F—Slotted nut
- G—Felt seal
- H—Lock washer
- X—Dimension, bearing opposite drive side (8 mm; 0.32 in.)



ZX, TMXCO010060-19-01AUG97

-UN-26FEB98  
Z114201

CHAFF SPREADER HYDRAULIC COMPONENTS



ZX004317

A—Hydraulic tank  
B—Chaff spreader pump

C—Pressure regulating valve  
D—Pressure hose


E—Hydraulic motor, left  
F—Connecting line

G—Hydraulic motor, right  
H—Return

ZX,OMXZC0002358-19-05OCT92

ZX004317 -JUN-20JUN95

### HYDRAULIC LINES TO CHAFF SPREADER



ZX012295

A—Hydraulic reservoir  
B—Suction line

C—Hydraulic pump  
D—Pressure line


E—Pressure regulating valve

F—Return line

ZX012295  
-JUN-27/SEP97

ZX.TMXZC0010061-19-01AUG97

### HYDRAULIC LINES TO HYDRAULIC MOTORS



ZX012296

A—Pressure line  
B—Coupler

C—Connecting line  
D—Hydraulic motor


E—Dust cap

F—Return line

ZX012296 -UN-27SEP97

ZX.TMXZCO010062-19-01AUG97

**HYDRAULIC PUMP FOR CHAFF SPREADER**



ZX012297

-JUN-03/MAR98  
ZX012297

A—Housing  
B—Seal ring  
C—Back-up ring


D—Seal ring  
E—Cover  
F—Screw

G—Bushing  
H—Endplate

J—Gasket  
K—Snap ring

ZX.TMXZC0010063-19-01AUG97

**CHAFF SPREADER SPEED CONTROLLER**



-JUN-27SEP97  
ZX012298

A—Dust cap  
B—Coupler  
C—O-ring  
D—Screw union


E—Pressure regulating valve  
F—Pressure relief valve  
G—Spring  
H—Shim for regulating pressure

J—Screw plug  
K—Screw  
L—Washer

M—Valve spool  
N—Controller  
O—Hand-wheel

ZX, TMXZC0010064-19-01AUG97

**DRIVE WITH PUMP FOR CHAFF SPREADER**



ZX012299 -UN-27SEP97

A—Strut

B—Retainer

C—Belt pulley

D—Hydraulic pump

Align the drive at struts (A) until the drive is parallel to the side wall.

ZX.TMXZCO010065-19-01AUG97



## REMOVING THE CHAFF SPREADER

### Hydraulic Connections

To disconnect the quick-couplers, pull the collar ring at pressure hose (A) to the rear, and pull the collar ring on return hose (B) to the front.





Insert the two ends of the hydraulic hoses together. This makes the chaff spreader inoperative. Secure the hydraulic hoses so that they cannot be damaged during operation.

Use the protective caps to prevent dirt from getting into the openings in the chaff spreader.

### Electrical Plug Connection

If the combine harvester has both a straw chopper and a chaff spreader installed at the same time, and the chaff spreader is to be removed, bridging plug (D) must be inserted at connecting point (C).

- I—Pressure connection
- II—Return connection
- III—Electrical plug connection
- A—Pressure hose
- B—Return hose
- C—Connecting point
- D—Bridging plug



ZX.OMXZC0002178-19-01NOV96

*Chaff Spreader/Removing the chaff spreader*

# Section 210 General

## Contents

Page

Group 05—Specifications . . . . . 210-05-1

*Contents*

**SPEEDS OF ROTATION, 2254, 2256, 2258, 2264 AND 2266 STANDARD AND HILLMASTER COMBINES**

Speeds shown are average and can vary from machine to machine. Speeds are rated at high idle with separator engaged, and no load.

**ENGINE**

Slow idle . . . . .	1250 ± 50 rpm
Fast idle . . . . .	2350 + 50 rpm
Rated speed . . . . .	2200 rpm

**HYDROSTATIC DRIVE**

Hydrostatic pump speed . . . . .	3385 rpm
----------------------------------	----------

**SEPARATOR**

Main countershaft speed . . . . .	1220 rpm
Primary cylinder speed range	
— without reduction gear . . . . .	370—1110 rpm
— with reduction gear	
• disengaged . . . . .	370—1110 rpm
• engaged . . . . .	150—440 rpm
Secondary cylinder speed . . . . .	910 rpm
Variable secondary cylinder speed . . . . .	370—1110 rpm

**FEEDER HOUSE LOWER SHAFT**

Fixed speed . . . . .	520 rpm
Variable speed . . . . .	520—820 rpm

**STRAW WALKERS**

Standard . . . . .	160 rpm
Optional . . . . .	170 rpm

**CROSS-SHAKER DRIVE SHAFT**

Speed . . . . .	380 rpm
-----------------	---------

**CLEANING TURBO FAN**

Speed range . . . . .	750—1500 rpm
-----------------------	--------------

**CHOPPER SPEED**

For grain . . . . .	3615 rpm
For corn (maize) . . . . .	2720 rpm

ZX, TMXZCO010066-19-01AUG97

## Specifications

### **SPECIFICATIONS, 2254, 2256 AND 2258 (STANDARD AND HILLMASTER, WITH FIVE STRAW WALKERS)**

#### **FEEDER HOUSE**

Conveyor chains . . . . .	3
Slats . . . . .	bolted T-slats
Fixed speed (engine rated speed) . . . . .	490 rpm
Variable speed (engine rated speed) . . . . .	490—770 rpm
Header reverser . . . . .	mechanical
Pivoting feeder house front shield on 2254, 2256 and 2258 (standard) . . . . .	optional
2254, 2256 and 2258 Hillmasters . . . . .	standard

#### **SEPARATOR**

##### **Primary Cylinder and Concave**

Cylinder diameter . . . . .	660 mm (26 in.)
Cylinder width . . . . .	1400 mm (55 in.)
No. of rasp bars . . . . .	10
Cylinder speed (engine rated speed) . . . . .	345—1040 rpm
Speed with reduction gear . . . . .	140—1040 rpm
Circumferential velocity . . . . .	4.8—35.9 m/sec. (15.7—117.8 fps)
Cylinder speed adjustment . . . . .	hydraulic
Drive type . . . . .	POSI-TORQ™

##### **Concave**

No. of concave bars (grain crops / maize) . . . . .	12 / 13
Concave width . . . . .	1400 mm (55 in.)
Concave length . . . . .	680 mm (26.8 in.)
Concave wrap . . . . .	121°
Concave area . . . . .	0.9 m <sup>2</sup> (9.7 sq ft)
Concave adjustment . . . . .	electric motor
No. of de-awning plates	
Grain-crop concave . . . . .	3
Universal concave . . . . .	4

##### **Secondary Cylinder and Concave**

Cylinder diameter . . . . .	400 mm (15.7 in.)
Cylinder width . . . . .	1400 mm (55 in.)
No. of cylinder wings . . . . .	8
Fixed cylinder speed (engine rated speed) . . . . .	850 rpm
Variable cylinder speed (optional) . . . . .	100% of primary cylinder speed
Concave area . . . . .	0.53 m <sup>2</sup> (5.70 sq ft)

ZX, TMXCO010067-19-05MAR98

Specifications

**SPECIFICATIONS, 2254, 2256 AND 2258 (STANDARD AND HILLMASTER, WITH FIVE STRAW WALKERS) (CONTINUED)**

**Stone Trap**

Actuation . . . . . 2 levers

**Grain Pan**

No. of removable sections . . . . . 7

**STRAW WALKERS**

No. of walkers . . . . . 5  
No. of walker steps  
with cross-shaker . . . . . 4  
without cross-shaker . . . . . 5  
Walker length . . . . . 4600 mm (181 in.)  
Walker throw . . . . . 150 mm (5.9 in.)  
Walker speed (engine rated speed) . . . . . 150 rpm  
Walker area . . . . . 6.4 m<sup>2</sup> (68.9 sq ft)  
Walker area with cross-shaker . . . . . 8.13 m<sup>2</sup> (87.50 sq ft)  
Open-type walkers . . . . . yes

**CROSS-SHAKER**

No. of rotating units . . . . . 5  
No. of spring tines . . . . . 40  
Lateral tine kicks . . . . . 720 per min.  
Rotating speed (engine rated speed) . . . . . 17 rpm

**CLEANING SYSTEM**

Chaffer area including extension . . . . . 2.76 m<sup>2</sup> (29.70 sq ft)  
Grain sieve area . . . . . 2.08 m<sup>2</sup> (22.40 sq ft)  
Total cleaning area . . . . . 4.84 m<sup>2</sup> (52.10 sq ft)  
Sieve type . . . . . adjustable louver type  
Shoe movement . . . . . reciprocating  
Dual-flow cleaning . . . . . pre-cleaning  
Slope Master system . . . . . standard

**CLEANING TURBO FAN**

Type of fan . . . . . turbo, 4 rotors  
Fan speed range . . . . . 750—1500 rpm  
Fan speed adjustment . . . . . electrical, from the cab

ZX, TMXZCO010068-19-01AUG97

**SPECIFICATIONS, 2254, 2256 AND 2258 (STANDARD AND HILLMASTER, WITH FIVE STRAW WALKERS) (CONTINUED)**

**GRAIN TANK**

Capacity

2254 (standard) . . . . .	6000 L (170 bu)
2254 Hillmaster . . . . .	6000 L (170 bu)
2256 (standard) . . . . .	6500 L (185 bu)
2256 Hillmaster . . . . .	6500 L (185 bu)
2258 (standard) . . . . .	7000 L (198 bu)
2258 Hillmaster . . . . .	7000 L (198 bu)

Unloading auger swing range . . . . .	110°
Unloading height, spout . . . . .	320 cm (126 in.)
Unloading rate . . . . .	4300 L/min. (122 bu/min.)

ZX, TMXZC0010069-19-05MAR98



**SPECIFICATIONS, 2254, 2256 AND 2258 (STANDARD AND HILLMASTER, WITH FIVE STRAW WALKERS) (CONTINUED)**

**FUEL TANK**

Capacity . . . . . 450 L (119 U.S. gal)

**GROUND DRIVE**

Transmission type . . . . . three-speed  
Foot brake type . . . . . 305 mm (12 in.) dia., hydraulically operated shoe type  
Parking brake . . . . . pedal-operated, two brake circuits  
Rear axle . . . . . rigid or adjustable, with or without rear-wheel drive

**SLOPE MASTER SYSTEM**

Automatic self-leveling to 11% on  
2254 Hillmaster, 2256 Hillmaster and  
2258 Hillmaster . . . . . standard

**GROUND TRAVEL SPEEDS**

20 km/h (12.5 mph) version:

1st gear . . . . . 6 km/h ( 3.7 mph)  
2nd gear . . . . . 10 km/h ( 6.3 mph)  
3rd gear . . . . . 20 km/h (12.5 mph)

25 km/h (15.5 mph) version:

1st gear . . . . . 7.5 km/h ( 4.7 mph)  
2nd gear . . . . . 12.5 km/h ( 7.8 mph)  
3rd gear . . . . . 25 km/h (15.5 mph)

ZX, TMXZCO010070-19-05MAR98

**SPECIFICATIONS, 2254, 2256 AND 2258 (STANDARD AND HILLMASTER, WITH FIVE STRAW WALKERS) (CONTINUED)**

**ELECTRICAL SYSTEM**

Alternator ..... 120 A / 12 V  
Batteries ..... 2, each 12 V, 88 AH, 395 A

**STEERING**

Type ..... hydrostatic  
Steering column ..... height and tilt adjustment

**SOUND LEVEL**

Max. sound level at operator's ear in accordance with Directive 86/188/EEC. Measurement method in accordance with ISO5131 with cab closed (average value)

2254 (standard and Hillmaster) ..... 76 dB(A)  
2256 (standard and Hillmaster) ..... 76 dB(A)  
2258 (standard and Hillmaster) ..... 79 dB(A)

ZX, TMXZCO010071-19-05MAR98

## SPECIFICATIONS, 2264 AND 2266 (STANDARD AND HILLMASTER, WITH SIX STRAW WALKERS)

### FEEDER HOUSE

Conveyor chains . . . . .	3/4
Slats . . . . .	bolted T-slats
Fixed speed (engine rated speed) . . . . .	490 rpm
Variable speed (engine rated speed) . . . . .	490 / 770 rpm
Header reverser . . . . .	mechanical
Pivoting feeder house front shield on	
2264 and 2266 (standard) . . . . .	optional
2264 and 2266 Hillmasters . . . . .	standard

### SEPARATOR

#### Primary Cylinder and Concave

Cylinder diameter . . . . .	660 mm (26 in.)
Cylinder width . . . . .	1670 mm (65.7 in.)
No. of rasp bars . . . . .	10
Cylinder speed (engine rated speed) . . . . .	345—1040 rpm
Speed with reduction gear . . . . .	140—1040 rpm
Circumferential velocity . . . . .	4.8—35.9 m/sec. (15.7—117.8 fps)
Cylinder speed adjustment . . . . .	hydraulic
Drive type . . . . .	POSI-TORQ™

#### Concave

No. of concave bars (grain crops / maize) . . . . .	12 / 13
Concave width . . . . .	1670 mm (65.7 in.)
Concave length . . . . .	680 mm (26.8 in.)
Concave wrap . . . . .	121°
Concave area . . . . .	1.08 m <sup>2</sup> (11.60 sq ft)
Concave adjustment . . . . .	electric motor
No. of de-awning plates	
Grain-crop concave . . . . .	3
Universal concave . . . . .	4

#### Secondary Cylinder and Concave

Cylinder diameter . . . . .	400 mm (15.7 in.)
Cylinder width . . . . .	1670 mm (65.7 in.)
No. of cylinder wings . . . . .	8
Fixed cylinder speed (engine rated speed) . . . . .	850 rpm
Variable cylinder speed (optional) . . . . .	100% of primary cylinder speed
Concave area . . . . .	0.63 m <sup>2</sup> (6.80 sq ft)

ZX, TMXZCO010072-19-05MAR98

**SPECIFICATIONS, 2264 AND 2266 (STANDARD AND HILLMASTER, WITH SIX STRAW WALKERS) (CONTINUED)**

**Stone Trap**

Actuation . . . . . 2 levers

**Grain Pan**

No. of removable sections . . . . . 8

**STRAW WALKERS**

No. of walkers . . . . . 6  
 No. of walker steps  
 with cross-shaker . . . . . 4  
 without cross-shaker . . . . . 5  
 Walker length . . . . . 4600 mm (181 in.)  
 Walker throw . . . . . 150 mm (5.9 in.)  
 Walker speed (engine rated speed) . . . . . 150 rpm  
 Walker area . . . . . 7,67 m<sup>2</sup> (82.60 sq ft)  
 Walker are with cross-shaker . . . . . 8,13 m<sup>2</sup> (87.50 sq ft)  
 Open-type walkers . . . . . yes

**CROSS-SHAKER**

No. of rotating units . . . . . 6  
 No. of spring tines . . . . . 48  
 Lateral tine kicks . . . . . 720 per min.  
 Rotating speed (engine rated speed) . . . . . 17 rpm

**CLEANING SYSTEM**

Chaffer area including extension . . . . . 3,32 m<sup>2</sup> (35.70 sq ft)  
 Grain sieve area . . . . . 2,51 m<sup>2</sup> (27.00 sq ft)  
 Total cleaning area . . . . . 5,83 m<sup>2</sup> (62.70 sq ft)  
 Sieve type . . . . . adjustable louver type  
 Shoe movement . . . . . reciprocating  
 Dual-flow cleaning . . . . . pre-cleaning  
 Slope Master system . . . . . standard

**CLEANING TURBO FAN**

Type of fan . . . . . turbo, 5 rotors  
 Fan speed range . . . . . 750—1500 rpm  
 Fan speed adjustment . . . . . electrical, from the cab

ZX, TMXZCO010073-19-05MAR98

**SPECIFICATIONS, 2264 AND 2266 (STANDARD AND HILLMASTER, WITH SIX STRAW WALKERS) (CONTINUED)**

**GRAIN TANK**

Capacity

2264 (standard) . . . . . 7000 L (198 bu)

2264 Hillmaster . . . . . 7000 L (198 bu)

2266 (standard) . . . . . 7500 L (212 bu)

2266 Hillmaster . . . . . 7000 L (198 bu)

Unloading auger swing range . . . . . 110°

Unloading height, spout . . . . . 320 cm (126 in.)

Unloading rate . . . . . 4300 L/min. (122 bu/min.)

ZX, TMXZC0010074-19-05MAR98

**SPECIFICATIONS, 2264 AND 2266 (STANDARD AND HILLMASTER, WITH SIX STRAW WALKERS) (CONTINUED)**

**FUEL TANK**

Capacity

2264 (standard and Hillmaster) . . . . . 450 L (119 U.S. gal)

2266 (standard and Hillmaster) . . . . . 550 L (145.3 U.S. gal)

**GROUND DRIVE**

Transmission type . . . . . three-speed

Foot brake type . . . . . 305 mm (12 in.) dia., hydraulically operated shoe type

Parking brake . . . . . pedal-operated, two brake circuits

Rear axle . . . . . rigid or adjustable, with or without rear wheel drive

**SLOPE MASTER SYSTEM**

Automatic self-leveling to 11% on

2264 Hillmaster and 2266 Hillmaster . . . . . standard

**GROUND TRAVEL SPEEDS**

20 km/h (12.5 mph) version:

1st gear . . . . . 6 km/h ( 3.7 mph)

2nd gear . . . . . 10 km/h ( 6.3 mph)

3rd gear . . . . . 20 km/h (12.5 mph)

25 km/h (15.5 mph) version:

1st gear . . . . . 7.5 km/h ( 4.7 mph)

2nd gear . . . . . 12.5 km/h ( 7.8 mph)

3rd gear . . . . . 25 km/h (15.5 mph)

ZX, TMXZCO010075-19-05MAR98

Specifications

**SPECIFICATIONS, 2264 AND 2266 (STANDARD AND HILLMASTER, WITH SIX STRAW WALKERS) (CONTINUED)**

**ELECTRICAL SYSTEM**

Alternator . . . . . 120 A / 12 V  
Batteries . . . . . 2, each 12 V, 88 AH, 395 A

**STEERING**

Type . . . . . hydrostatic  
Steering column . . . . . height and tilt adjustment

**SOUND LEVEL**

Max. sound level at operator's ear in accordance with Directive 86/188/EEC. Measurement method in accordance with ISO5131 with cab closed (average value)  
2264 (standard and Hillmaster) . . . . . 77 dB(A)  
2266 (standard and Hillmaster) . . . . . 79 dB(A)

ZX,OMXZCO010076-19-05MAR98

**PERMISSIBLE TOTAL WEIGHT**

The maximum permissible total weight for all 2200 Series combine harvesters is 14500 kg (31967 lb.)

ZX,OMXZCO006499-19-01NOV96

**VIBRATIONS AT OPERATOR'S POSITION**

Measured according to Directive VDI 2057,  
page 4.2, May 1987


- 1. Max. acceleration value to which the feet of the operator are subjected . . . . . 2.1 m/s<sup>2</sup> at 20 Hertz
- 2. Max. acceleration value to which the seat surface is subjected . . . . . 2.0 m/s<sup>2</sup> at 20 Hertz
- 3. Max. acceleration value to which the body of the operator is subjected . . . . . 5.35 m/s<sup>2</sup> at 50 Hertz

ZX.OMXZCO003410-19-22JUN94



Specifications

**DIMENSIONS, 2254 AND 2256 COMBINES**



A—Overall length  
B—Wheel base

C—Ground clearance  
D—Overall height

X—Front tires

Y—Rear tires


	X	Y	A	B	C	D
2254	620/75-R34	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3780 mm (12.40 ft)
	24.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	550 mm (1.80 ft)	3790 mm (12.43 ft)
2256	620/75-R34	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3840 mm (12.60 ft)
	24.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	550 mm (1.80 ft)	3850 mm (12.63 ft)
	30.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3840 mm (12.60 ft)

ZX004168 -JUN-23MAY95

ZX.TMXZCO010105-19-01AUG97

Specifications

**DIMENSIONS, 2254 AND 2256 COMBINES (CONTINUED)**




- A—Front axle width
- B—Max. discharge height
- C—Outreach of unloading auger
- D—Width of standard (fixed) rear axle
- E—Width of adjustable rear axle
- F—Width of rear wheel drive axle
- X—Front tires
- Y—Rear tires

	X	Y	A	B	C	D	E	F
2254	620/75-R34	14.9-24	3300 mm (10.83 ft)	3980 mm (13.06 ft)	2570 mm (8.43 ft)	2940 mm (9.65 ft)	2940—3530 mm (9.65—11.58 ft)	3110—3720 mm (10.20—12.20 ft)
	24.5-32	14.9-24	3300 mm (10.83 ft)	3960 mm (13.00 ft)				
2256	620/75-R34	14.9-24	3300 mm (10.83 ft)	3980 mm (13.06 ft)	2570 mm (8.43 ft)	2940 mm (9.65 ft)	2940—3530 mm (9.65—11.58 ft)	3110—3720 mm (10.20—12.20 ft)
	24.5-32	14.9-24	3300 mm (10.83 ft)	3960 mm (13.00 ft)				
	30.5-32	14.9-24	3500 mm (11.48 ft)	3980 mm (13.06 ft)				

ZX.TMXZCO010106-19-01AUG97

Specifications

**DIMENSIONS, 2258 AND 2264 COMBINES**



A—Overall length  
B—Wheel base

C—Ground clearance  
D—Overall height


X—Front tires

Y—Rear tires

	X	Y	A	B	C	D
2258	620/75-R34	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3910 mm (12.83 ft)
	24.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	550 mm (1.80 ft)	3940 mm (12.93 ft)
	30.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3910 mm (12.83 ft)
2264	620/75-R34	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3910 mm (12.83 ft)
	24.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	550 mm (1.80 ft)	3940 mm (12.93 ft)
	30.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3910 mm (12.83 ft)

ZX.TMXZCO010107-19-01AUG97

**DIMENSIONS, 2258 AND 2264 COMBINES (CONTINUED)**



ZX002592


- A—Front axle width
- B—Max. discharge height
- C—Outreach of unloading auger
- D—Width of standard (fixed) rear axle
- E—Width of adjustable rear axle
- F—Width of rear wheel drive axle
- X—Front tires
- Y—Rear tires

	X	Y	A	B	C	D	E	F
2258	620/75-R34	14.9-24	3300 mm (10.83 ft)	3980 mm (13.06 ft)	2570 mm (8.43 ft)	2940 mm (9.65 ft)	2940—3530 mm (9.65—11.58 ft)	3110—3720 mm (10.20—12.20 ft)
	24.5-32	14.9-24	3300 mm (10.83 ft)	3960 mm (13.00 ft)				
	30.5-32	14.9-24	3500 mm (11.48 ft)	3980 mm (13.06 ft)				
2264	620/75-R34	14.9-24	3300 mm (10.83 ft)	3980 mm (13.06 ft)	2570 mm (8.43 ft)	2940 mm (9.65 ft)	2940—3530 mm (9.65—11.58 ft)	3110—3720 mm (10.20—12.20 ft)
	24.5-32	14.9-24	3500 mm (11.48 ft)	3960 mm (13.00 ft)				
	30.5-32	14.9-24	3800 mm (12.47 ft)	3980 mm (13.06 ft)				

ZX.TMXZCO010108-19-01AUG97

Specifications

**DIMENSIONS, 2266 COMBINE**



A—Overall length  
B—Wheel base

C—Ground clearance  
D—Overall height

X—Front tires

Y—Rear tires


	X	Y	A	B	C	D
2266	620/75-R34	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3980 mm (13.06 ft)
	24.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	550 mm (1.80 ft)	4000 mm (13.12 ft)
	30.5-32	14.9-24	8630 mm (28.31 ft)	3820 mm (12.53 ft)	540 mm (1.77 ft)	3980 mm (13.06 ft)

ZX.TMXZCO010109-19-01AUG97

ZX004168 -JUN-23MAY95

Specifications

**DIMENSIONS, 2266 COMBINE (CONTINUED)**



ZX002592

- A—Front axle width
- B—Max. discharge height
- C—Outreach of unloading auger
- D—Width of standard (fixed) rear axle
- E—Width of adjustable rear axle
- F—Width of rear wheel drive axle
- X—Front tires
- Y—Rear tires

	X	Y	A	B	C	D	E	F
	620/75-R34	14.9-24	3300 mm (10.83 ft)	3980 mm (13.06 ft)				
2266	24.5-32	14.9-24	3500 mm (11.48 ft)	3960 mm (13.00 ft)	2570 mm (8.43 ft)	2940 mm (9.65 ft)	2940—3530 mm (9.65—11.58 ft)	3110—3720 mm (10.20—12.20 ft)
	30.5-32	14.9-24	3800 mm (12.47 ft)	3980 mm (13.06 ft)				

ZX.TMXZCO010110-19-01AUG97

ZX002592 -JUN-23MAY95

# Section 220 Engine

## Contents

Page

Group 05—Specifications . . . . . 220-05-1

*Contents*



**ENGINE SPECIFICATION DATA FOR MODEL 6068HZ001 (2254)**

**GENERAL DATA**

Number of cylinders . . . . .	6
Bore . . . . .	106.5 mm (4.19 in.)
Stroke . . . . .	127 mm (5 in.)
Displacement . . . . .	6.8 L (415 in. <sup>3</sup> )
Compression ratio . . . . .	17.2:1
Compression at starting motor speed . . . . .	2380—2790 kPa (23.8—27.9 bar; 345—405 psi)
Starting motor speed . . . . .	150—200 rpm
Valves per cylinder — intake/exhaust . . . . .	1/1
Firing order . . . . .	1-5-3-6-2-4
Combustion system . . . . .	direct injection
Engine type . . . . .	in-line 4-cycle
Aspiration . . . . .	turbocharged
Charge air cooling system . . . . .	air to air
Engine crankcase vent system . . . . .	open
Maximum crankcase pressure . . . . .	0.5 kPa (2 in. H <sub>2</sub> O)

**DIMENSIONS**

Length . . . . .	1097 mm (43.2 in.)
Width . . . . .	630 mm (24.8 in.)
Height . . . . .	1023 mm (40.3 in.)
Weight, without oil (includes flywheel and flywheel housing) . . . . .	700 kg (1543 lb)

ZX, TMXZCO010077-19-01AUG97

**ENGINE SPECIFICATION DATA FOR MODEL 6068HZ001 (CONTINUED)**

**FUEL SYSTEM**

Fuel injection pump . . . . . Stanadyne DB4  
Governor regulation . . . . . 7—9 percent  
Governor type . . . . . mechanical  
Fuel filter micron size  
at 98 percent efficiency . . . . . 8

**LUBRICATION SYSTEM**

Oil pressure at rated speed . . . . . 345 kPa (3.45 bar; 50 psi)  
Oil pressure at low idle . . . . . 105 kPa (1.05 bar; 15 psi)  
Oil pan capacity, high . . . . . 16 L (4.2 U.S. gal)  
Oil pan capacity, low . . . . . 15 L (4 U.S. gal)  
Total engine oil capacity with filters . . . . . 19 L (5 U.S. gal)  
Engine angularity limits (intermittent)  
Any direction . . . . . 35°

**EXHAUST SYSTEM**

Maximum allowable back pressure . . . . . 7.5 kPa (2.2 in. Hg)

**COOLING SYSTEM**

Thermostat starts to open at . . . . . 82°C (180°F)  
Thermostat fully open at . . . . . 94°C (202°F)  
Coolant capacity (engine only) . . . . . 11.3 L (3 U.S. gal)

ZX, TMXZC0010078-19-01AUG97

**ENGINE SPECIFICATION DATA FOR MODEL 6068HZ001 (CONTINUED)**

**AIR INTAKE SYSTEM**

Maximum allowable temperature rise  
 — ambient air to engine inlet . . . . . 8°C (15°F)

Maximum air intake restriction  
 Dirty air cleaner . . . . . 6.25 kPa (25 in. H<sub>2</sub>O)  
 Clean air cleaner . . . . . 3 kPa (12 in. H<sub>2</sub>O)

Intake manifold pressure . . . . . 105 kPa (31 in. Hg)

**ELECTRICAL SYSTEM**

Max. starting motor current consumption  
 when starting (12 V system)  
 At 0°C (32°F) . . . . . 950 A  
 At -30°C (-22°F) . . . . . 1300 A

Starter power . . . . . 3.1 kW (4 hp)

Alternator (2 used) . . . . . 120 A

**PERFORMANCE DATA**

Power according to ECE R24  
 (at rated speed) . . . . . 132 kW (180 hp)

Rated speed . . . . . 2200 rpm

Peak torque speed . . . . . 1500 rpm

Slow idle speed . . . . . 1250 rpm

Fast idle . . . . . 2350 rpm

Smoke at rated speed — Bosch number . . . . . 1.5

Smoke at peak torque — Bosch number . . . . . 3.0

Radiator screen . . . . . self-cleaning

ZX, TMXZCO010079-19-01AUG97

Specifications

**ENGINE SPECIFICATION DATA FOR MODELS 6081HZ001, HZ002, HZ003 AND HZ005  
(CONTINUED)**

**GENERAL DATA**

Number of cylinders . . . . .	6
Bore . . . . .	116 mm (4.56 in.)
Stroke . . . . .	129 mm (5.06 in.)
Displacement . . . . .	8.1 L (496 in. <sup>3</sup> )
Compression ratio . . . . .	15.7:1
Compression at starting motor speed . . . . .	2380—2790 kPa (23.8—27.9 bar; 345—405 psi)
Starting motor speed . . . . .	200—250 rpm
Valves per cylinder — intake/exhaust . . . . .	1/1
Firing order . . . . .	1-5-3-6-2-4
Combustion system . . . . .	direct injection
Engine type . . . . .	in-line 4-cycle
Aspiration . . . . .	turbocharged
Charge air cooling system . . . . .	air to air
Engine crankcase vent system . . . . .	open
Maximum crankcase pressure . . . . .	0.5 kPa (2 in. H <sub>2</sub> O)

**DIMENSIONS**

Length . . . . .	1208 mm (47.6 in.)
Width . . . . .	555 mm (21.8 in.)
Height . . . . .	1040 mm (40.9 in.)
Weight, without oil (includes flywheel and flywheel housing) . . . . .	776 kg (1710 lb)

ZX, TMXZCO010080-19-11MAR98

**ENGINE SPECIFICATION DATA FOR MODELS 6081HZ001, HZ002, HZ003 AND HZ005  
(CONTINUED)**

**FUEL SYSTEM**

Fuel injection pump (HZ002, HZ003, HZ005)	Bosch P3000
Fuel injection pump (HZ001)	Bosch P7100
Governor regulation	7—9 percent
Governor type	mechanical
Fuel filter micron size at 98 percent efficiency	8

**LUBRICATION SYSTEM**

Oil pressure at rated speed	345 kPa (3.45 bar; 50 psi)
Oil pressure at low idle	210 kPa (2.1 bar; 30 psi)
Oil pan capacity, high	28.5 L (7.5 U.S. gal)
Oil pan capacity, low	25.5 L (6.7 U.S. gal)
Total engine oil capacity with filters	30 L (7.9 U.S. gal)
Engine angularity limits (intermittent) Any direction	35°

**EXHAUST SYSTEM**

Maximum allowable back pressure	7.5 kPa (2.2 in. Hg)
---------------------------------	----------------------

**COOLING SYSTEM**

Thermostat starts to open at	82°C (180°F)
Thermostat fully open at	94°C (202°F)
Coolant capacity (engine only)	14.2 L (3.8 U.S. gal)

ZX, TMXZCO010081-19-11MAR98

Specifications

**ENGINE SPECIFICATION DATA FOR MODELS 6081HZ001, HZ002, HZ003 AND HZ005  
(CONTINUED)**

**AIR INTAKE SYSTEM**

Maximum allowable temperature rise — ambient air to engine inlet . . . . .	8°C (15°F)
Maximum air intake restriction	
Dirty air cleaner . . . . .	6.25 kPa (25 in. H <sub>2</sub> O)
Clean air cleaner . . . . .	3 kPa (12 in. H <sub>2</sub> O)
Intake manifold pressure . . . . .	189 kPa (27.3 in. Hg)

**ELECTRICAL SYSTEM**

Max. starting motor current consumption when starting (12 V system)	
At 0°C (32°F) . . . . .	950 A
At -30°C (-22°F) . . . . .	1300 A
Starter power . . . . .	4 kW (5.4 hp)
Alternator (2 used) . . . . .	120 A

ZX, TMXZCO010082-19-11MAR98

**PERFORMANCE DATA, 2256**

Power according to ECE R24 (at rated speed) . . . . .	154 kW (210 hp)
Rated speed . . . . .	2200 rpm
Peak torque speed . . . . .	1600 rpm
Slow idle speed . . . . .	1250 rpm
Fast idle speed . . . . .	2350 rpm
Smoke at rated speed — Bosch number . . . . .	1.2
Smoke at peak torque — Bosch number . . . . .	3.5
Radiator screen . . . . .	self-cleaning

ZX, TMXZCO010083-19-01AUG97

*Specifications*

**PERFORMANCE DATA, 2258**

Power according to ECE R24 (at rated speed) . . . . .	173 kW (235 hp)
Rated speed . . . . .	2200 rpm
Peak torque speed . . . . .	1600 rpm
Slow idle speed . . . . .	1250 rpm
Fast idle speed . . . . .	2350 rpm
Smoke at rated speed — Bosch number . . . . .	1.2
Smoke at peak torque — Bosch number . . . . .	3.5
Radiator screen . . . . .	self-cleaning

ZX, TMXZC0010084-19-01AUG97

**PERFORMANCE DATA, 2264**

Power according to ECE R24 (at rated speed) . . . . .	184 kW (250 hp)
Rated speed . . . . .	2200 rpm
Peak torque speed . . . . .	1600 rpm
Slow idle speed . . . . .	1250 rpm
Fast idle speed . . . . .	2350 rpm
Smoke at rated speed — Bosch number . . . . .	1.2
Smoke at peak torque — Bosch number . . . . .	3.5
Radiator screen . . . . .	self-cleaning

ZX, TMXZC0010085-19-01AUG97

*Specifications*

**PERFORMANCE DATA, 2266**

Power according to ECE R24 (at rated speed) . . . . .	199 kW (270 hp)
Rated speed . . . . .	2200 rpm
Peak torque speed . . . . .	1600 rpm
Slow idle speed . . . . .	1250 rpm
Fast idle speed . . . . .	2350 rpm
Smoke at rated speed — Bosch number . . . . .	1.2
Smoke at peak torque — Bosch number . . . . .	3.5
Radiator screen . . . . .	self-cleaning

ZX.TMXZC0010086-19-01AUG97



**Section 230**

# **Fuel, Air Intake and Cooling Systems**


## **Contents**

Page

<b>Group 05—Fuel System</b> . . . . .	<b>230-05-1</b>
---------------------------------------	-----------------

*Contents*

**FUEL SYSTEM ON 6.8-L ENGINE**



ZX007424

A—Fuel tank  
B—Fuel gauge sending unit  
C—Water trap

D—Mechanical fuel transfer pump

E—Fuel filter  
F—Injection pump

G—Injection nozzle  
H—Return line

ZX007424 -UN-20JUN95


ZX,OMXZCO002087-19-01MAR95

**SPECIFICATIONS**

Fuel injection pump .....	Stanadyne DB4
Governor regulation .....	7—9 percent
Governor type .....	mechanical
Fuel filter micron size at 98 percent efficiency .....	8

ZX,TMXZCO010087-19-01AUG97

**FUEL SYSTEM ON 8.1-L ENGINE**



ZX009860

A—Fuel tank  
B—Fuel gauge sending unit  
C—Water trap

D—Mechanical fuel transfer pump (2256—2266)  
E—Fuel filter

F—Injection pump (2256—2266)

G—Injection nozzle  
H—Return line

ZX,OMXZC0002088-19-01NOV96

ZX009860 -JUN-15NOV96

**SPECIFICATIONS**

Fuel injection pump (HZ002, HZ003, HZ005) . . . . .	Bosch P3000
Fuel injection pump (HZ001) . . . . .	Bosch P7100
Governor regulation . . . . .	7—9 percent
Governor type . . . . .	mechanical
Fuel filter micron size at 98 percent efficiency . . . . .	8

ZX,TMXZC0010088-19-01AUG97

# Section 240

# Electrical System to Serial Number 066832

## Contents

	Page	Page
<b>Group 05 —Test Equipment</b>		
Multimeter . . . . .	240-05-1	
Wiring harness tester . . . . .	240-05-1	
<b>Group 06—Test Equipment</b>		
Multimeter . . . . .	240-06-1	
Wiring harness tester . . . . .	240-06-1	
<b>Group 10—Functional Schematic and Harness Diagrams</b>		
Section survey . . . . .	240-10-1	
Wiring harness survey . . . . .	240-10-2	
Component survey . . . . .	240-10-3	
Functional schematic, sections 1, 2, 3A and 3B . . . . .	240-10-17	Functional schematic, section 26, Part 2 . . . . .
Functional schematic, sections 4, 5 and 6 . . . . .	240-10-18	240-10-36
Functional schematic, sections 7 and 8 . . . . .	240-10-19	Functional schematic, sections 27 and 28 . . . . .
Functional schematic, section 9 . . . . .	240-10-20	240-10-37
Functional schematic, section 10 . . . . .	240-10-21	Functional schematic, section 29 . . . . .
Functional schematic, sections 11 and 12 . . . . .	240-10-22	240-10-38
Functional schematic, sections 13A and 13B . . . . .	240-10-23	Functional schematic, sections 30, 31 and 32 . . . . .
Functional schematic, sections 14 and 15 . . . . .	240-10-24	240-10-39
Functional schematic, sections 16 and 17 . . . . .	240-10-25	Wiring diagrams, location of harnesses . . . . .
Functional schematic, sections 18 and 19 . . . . .	240-10-26	240-10-40
Functional schematic, section 20 . . . . .	240-10-27	
Functional schematic, section 21 . . . . .	240-10-28	<b>Group 15A—Current Supply/Starting Motor</b>
Functional schematic, section 22 . . . . .	240-10-29	Specifications . . . . .
Functional schematic, section 23 . . . . .	240-10-30	240-15A-1
Functional schematic, section 24 . . . . .	240-10-31	Operational information . . . . .
Functional schematic, section 25A . . . . .	240-10-32	240-15A-1
Functional schematic, section 25B, Part 1 . . . . .	240-10-33	Theory of operation . . . . .
Functional schematic, section 25B, Part 2 . . . . .	240-10-34	240-15A-1
Functional schematic, section 26, Part 1 . . . . .	240-10-35	Functional schematic, section 1 . . . . .
		240-15A-2
		Diagnostic schematic, section 1 . . . . .
		240-15A-3
		<b>Group 15B—Cold Weather Starting Aid</b>
		Operational information . . . . .
		240-15B-1
		Theory of operation . . . . .
		240-15B-1
		Functional schematic, section 2 . . . . .
		240-15B-2
		Diagnostic schematic, section 2 . . . . .
		240-15B-3
		<b>Group 15C—Engine Shut-Off Device</b>
		Operational information . . . . .
		240-15C-1
		Theory of operation . . . . .
		240-15C-1
		Functional schematic, sections 3A and 3B . . . . .
		240-15C-2
		Diagnostic schematic, sections 3A and 3B . . . . .
		240-15C-3
		<b>Group 15E—Instruments</b>
		Operational information . . . . .
		240-15E-1
		Theory of operation . . . . .
		240-15E-1
		Functional schematic, section 5 . . . . .
		240-15E-2
		Diagnostic schematic, section 5 . . . . .
		240-15E-3
		<b>Group 15F—Chopper Distributor Adjustment</b>
		Operational information . . . . .
		240-15F-1
		Theory of operation . . . . .
		240-15F-1
		Functional schematic, section 6 . . . . .
		240-15F-2
		Diagnostic schematic, section 6 . . . . .
		240-15F-3

Continued on next page

Page	Page
<b>Group 15G—Windshield Wiper/Washer System</b>	
Operational information . . . . .	240-15G-1
Theory of operation . . . . .	240-15G-1
Functional schematic, section 7 . . . . .	240-15G-2
Diagnostic schematic, section 7 . . . . .	240-15G-3
<b>Group 15H—Radio, Interior Lighting</b>	
Operational information . . . . .	240-15H-1
Theory of operation . . . . .	240-15H-1
Functional schematic, section 8 . . . . .	240-15H-2
Diagnostic schematic, section 8 . . . . .	240-15H-3
<b>Group 15L—Cigarette Lighter, Seat Compressor</b>	
Operational information . . . . .	240-15L-1
Functional schematic, section 11 . . . . .	240-15L-1
Diagnostic schematic, section 11 . . . . .	240-15L-2
<b>Group 15M—Lighting System</b>	
Operational information . . . . .	240-15M-1
Theory of operation . . . . .	240-15M-1
Functional schematic, section 12 . . . . .	240-15M-2
Diagnostic schematic, section 12 . . . . .	240-15M-3
<b>Group 15N—Flasher Functions</b>	
Operational information . . . . .	240-15N-1
Theory of operation . . . . .	240-15N-1
Functional schematic, section 13 . . . . .	240-15N-2
Diagnostic schematic, section 13 . . . . .	240-15N-3
<b>Group 15O—Beacon Lights</b>	
Operational information . . . . .	240-15O-1
Theory of operation . . . . .	240-15O-1
Functional schematic, section 14 . . . . .	240-15O-2
Diagnostic schematic, section 14 . . . . .	240-15O-3
<b>Group 15P—Fan, Air Conditioning System</b>	
Operational information . . . . .	240-15P-1
Theory of operation . . . . .	240-15P-1
Functional schematic, section 15 . . . . .	240-15P-2
Diagnostic schematic, section 15 . . . . .	240-15P-3
<b>Group 15Q—Electrical Mirror Adjustment</b>	
Operational information . . . . .	240-15Q-1
Theory of operation . . . . .	240-15Q-1
Functional schematic, section 16 . . . . .	240-15Q-2
Diagnostic schematic, section 16 . . . . .	240-15Q-3
<b>Group 15R—Work Lights</b>	
Operational information . . . . .	240-15R-1
Theory of operation . . . . .	240-15R-1
Functional schematic, section 17 . . . . .	240-15R-2
Diagnostic schematic, section 17 . . . . .	240-15R-3
<b>Group 15S—Straw Warning Device</b>	
Operational information . . . . .	240-15S-1
Theory of operation . . . . .	240-15S-1
Functional schematic, section 18 . . . . .	240-15S-2
Diagnostic schematic, section 18 . . . . .	240-15S-3
<b>Group 15T—Reel Speed Adjustment</b>	
Operational information . . . . .	240-15T-1
Theory of operation . . . . .	240-15T-2
Speed ratio switch S9 . . . . .	240-15T-2
Diagnostic mode . . . . .	240-15T-3
Error codes . . . . .	240-15T-4
Micro switch operating adjustment . . . . .	240-15T-6
Functional schematic, section 19 . . . . .	240-15T-7
Diagnostic schematic, section 19 . . . . .	240-15T-8
<b>Group 15U—Dial-A-Matic</b>	
Operational information . . . . .	240-15U-1
Theory of operation . . . . .	240-15U-1
Testing the Dial-A-Matic . . . . .	240-15U-2
Functional schematic, section 20 . . . . .	240-15U-3
Diagnostic schematic, section 20 . . . . .	240-15U-4
<b>Group 15V—Separator, Header</b>	
Operational information . . . . .	240-15V-1
Theory of operation . . . . .	240-15V-1
Functional schematic, section 21 . . . . .	240-15V-2
Diagnostic schematic, section 21 . . . . .	240-15V-3
<b>Group 15W—Infotrak Monitor</b>	
Operational information . . . . .	240-15W-1
Specific machine data . . . . .	240-15W-1
Error codes . . . . .	240-15W-4
Operational information, speed monitoring system . . . . .	240-15W-5
Functional schematic, section 22 . . . . .	240-15W-6
Diagnostic schematic, section 22 . . . . .	240-15W-8
<b>Group 15X—Harvest Performance Monitor</b>	
Operational information . . . . .	240-15X-1
Operational adjustment . . . . .	240-15X-3

Continued on next page

Page	Page		
Operational check . . . . .	240-15X-5	Theory of operation . . . . .	240-15AC-1
Functional schematic, section 23 . . . . .	240-15X-6	Functional schematic, section 27 . . . . .	240-15AC-2
Diagnostic schematic, section 23 . . . . .	240-15X-8	Diagnostic schematic, section 27 . . . . .	240-15AC-4
<b>Group 15Y—Hillmaster Leveling System</b>		<b>Group 15AD—Four-Wheel Drive</b>	
Operational information . . . . .	240-15Y-1	Operational information . . . . .	240-15AD-1
Theory of operation . . . . .	240-15Y-1	Theory of operation . . . . .	240-15AD-1
Functional schematic, section 24 . . . . .	240-15Y-2	Functional schematic, section 28 . . . . .	240-15AD-2
Diagnostic schematic, section 24 . . . . .	240-15Y-3	Diagnostic schematic, section 28 . . . . .	240-15AD-3
<b>Group 15Z—Separator Adjustment</b>		<b>Group 15AE—Header Lateral Tilt Function</b>	
Operational information . . . . .	240-15Z-1	Operational information . . . . .	240-15AE-1
Theory of operation . . . . .	240-15Z-1	Theory of operation . . . . .	240-15AE-1
Functional schematic, section 25A . . . . .	240-15Z-2	Functional schematic, section 29 . . . . .	240-15AE-2
Diagnostic schematic, section 25A . . . . .	240-15Z-3	Diagnostic schematic, section 29 . . . . .	240-15AE-4
<b>Group 15AA—Separator Adjustment, Combine Data Center</b>		<b>Group 15AF—Header Float Control</b>	
Operational information . . . . .	240-15AA-1	Operational information . . . . .	240-15AF-1
System components . . . . .	240-15AA-2	Theory of operation . . . . .	240-15AF-1
Combine data center . . . . .	240-15AA-3	Functional schematic, sections 30, 31	
Area counter . . . . .	240-15AA-6	and 32 . . . . .	240-15AF-2
Setting combine data center and area		Diagnostic schematic, section 30 . . . . .	240-15AF-4
counter . . . . .	240-15AA-7	Diagnostic schematic, section 31 . . . . .	240-15AF-5
Theory of operation . . . . .	240-15AA-23	Diagnostic schematic, section 32 . . . . .	240-15AF-6
Functional schematic, section 25B,			
Part 1 . . . . .	240-15AA-24		
Diagnostic schematic, section 25B,			
Part 1 . . . . .	240-15AA-26		
Functional schematic, section 25B,			
Part 2 . . . . .	240-15AA-27		
Diagnostic schematic, section 25B,			
Part 2 . . . . .	240-15AA-29		
<b>Group 15AB—Header Adjustments</b>			
Operational information . . . . .	240-15AB-1		
Theory of operation . . . . .	240-15AB-1		
Functional schematic, section 26,			
Part 1 . . . . .	240-15AB-2		
Diagnostic schematic, section 26,			
Part 1 . . . . .	240-15AB-5		
Functional schematic, section 26,			
Part 2 . . . . .	240-15AB-6		
Diagnostic schematic, section 26,			
Part 2 . . . . .	240-15AB-8		
<b>Group 15AC—Grain Tank Unloading System</b>			
Operational information . . . . .	240-15AC-1		

*Contents*



**SPECIAL OR ESSENTIAL TOOLS**

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

**MULTIMETER**

Multimeter . . . . . JT05791



ZX001756

ZX,TMSPFH001915-19-17JAN94

-UN-27APR95  
ZX001756

**WIRING HARNESS TESTER**

Wiring harness tester . . . . . FKM10438

*NOTE: By means of this "Wiring Harness Tester" electrical system checks can be carried out. The electrical signals are received by inserting T-adapters into connectors.*

Case . . . . . JT02048

Test box with extension cable . . . . . JT02006

- T-adapter, 37-pin . . . . . KJD10176
- T-adapter, 21-pin . . . . . KJD10175
- T-adapter, 16-pin . . . . . KJD10174
- T-adapter, 37-pin . . . . . JT02013
- T-adapter, 16-pin . . . . . JT02009
- T-adapter, 9-pin . . . . . JT02008
- T-adapter, 4-pin . . . . . JT02007



ZX001760

ZX,TMSPFH001916-19-22APR92

-UN-24APR95  
ZX001760

## USE OF WIRING HARNESS TESTER



Disconnect connector to be tested and insert suitable T-adapter (A) into the connector.

Connect third T-adapter terminal to test box (C) via extension cable (B).

Connect clip (D) to machine frame (ground connection).

The individual signals coming from the connector can be received at the test box by means of the multimeter.

- A—T-adapter
- B—Extension cable (test box)
- C—Test box
- D—Ground clip



ZX, TMSPFH001914-19-22APR92

**SPECIAL OR ESSENTIAL TOOLS**

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

**MULTIMETER**

Multimeter . . . . . JT05791



ZX001756

ZX,TMSPFH001915-19-17JAN94

-UN-27APR95  
ZX001756

**WIRING HARNESS TESTER**

Wiring harness tester . . . . . FKM10438

*NOTE: By means of this "Wiring Harness Tester" electrical system checks can be carried out. The electrical signals are received by inserting T-adapters into connectors.*

Case . . . . . JT02048

Test box with extension cable . . . . . JT02006

- T-adapter, 37-pin . . . . . KJD10176
- T-adapter, 21-pin . . . . . KJD10175
- T-adapter, 16-pin . . . . . KJD10174
- T-adapter, 37-pin . . . . . JT02013
- T-adapter, 16-pin . . . . . JT02009
- T-adapter, 9-pin . . . . . JT02008
- T-adapter, 4-pin . . . . . JT02007



ZX001760

ZX,TMSPFH001916-19-22APR92

-UN-24APR95  
ZX001760

## USE OF WIRING HARNESS TESTER



Disconnect connector to be tested and insert suitable T-adapter (A) into the connector.

Connect third T-adapter terminal to test box (C) via extension cable (B).

Connect clip (D) to machine frame (ground connection).

The individual signals coming from the connector can be received at the test box by means of the multimeter.

- A—T-adapter
- B—Extension cable (test box)
- C—Test box
- D—Ground clip



ZX, TMSPFH001914-19-22APR92

# Group 10 Functional Schematic and Harness Diagrams

## SECTION SURVEY

- |  |   |
|--|---|
| SE 01 — Power supply / starting motor  | SE 19 — Stop lights, reel speed adjustment                          |
| SE 02 — Cold weather starting aid      | SE 20 — DIAL-A-MATIC™   |
| SE 03A — Engine stop, Waterloo engine  | SE 21 — Separator, header engagement                                |
| SE 03B — Engine stop, Saran engine     | SE 22 — Digital infotrak monitor,<br>speed monitoring system        |
| SE 04 — Fuse tester                    | SE 23 — Harvest performance monitor                                 |
| SE 05 — Instruments                    | SE 24 — Hillmaster leveling system                                  |
| SE 06 — Chopper distributor adjustment | SE 25A — Separator adjustment                                       |
| SE 07 — Windshield washer system       | SE 25B — Separator adjustment,<br>combine data center, part 1       |
| SE 08 — Radio, CB radio, clock         | SE 25B — Separator adjustment,<br>combine data center, part 2       |
| SE 09 — Alarm module, stop function    | SE 26 — Header adjustments (cutting height,<br>reel, float), part 1 |
| SE 10 — Indicator lights               | SE 26 — Header adjustments (cutting height,<br>reel, float), part 2 |
| SE 11 — Cigarette lighter, sockets     | SE 27 — Grain tank unloading system                                 |
| SE 12 — Light functions                | SE 28 — Four-wheel drive  |
| SE 13A — Flasher function              | SE 29 — Header horizontal adjustment                                |
| SE 13B — Flasher function              | SE 30 — Float control   |
| SE 14 — Beacon lights                  | SE 31 — Back-up Alarm   |
| SE 15 — Air conditioning system        | SE 32 — Timer Relay   |
| SE 16 — Electrical mirror adjustment   | SE 34 — ContourMaster (2266 only)                                   |
| SE 17 — Worklights                     |   |
| SE 18 — Straw warning device           |   |

ZX, TM4543009500-19-30JUN97

## WIRING HARNESS SURVEY

W 1 — Main distribution wiring harness	W 28 — Ground cable, straw warning device
W 2 — Cab wiring harness	W 29 — Leveling system wiring harness
W 3 — Switch console wiring harness	W 30 — Antenna for CB radio
W 4 — Corner post wiring harness	W 31 — Radio antenna
W 5 — Armrest wiring harness	W 32 — Header lighting wiring harness
W 6 — Air conditioning and fan wiring harness	W 33 — Wiring harness, ultrasonic sensors
W 7 — Basic wiring harness, front	W 34 — Wiring harness, logic relay board
W 8 — Steering column wiring harness	W 35 — Frame wiring harness switch
W 9 — Basic wiring harness, rear	W 36 — Wiring harness switch, batt. neg. terminal
W 10 — Feeder house wiring harness	W 37 — Four-wheel drive wiring harness
W 12 — Wiring harness, Saran engine	W 39 — Wiring harness, electrical mirror adjustment
W 13 — Wiring harness, Waterloo engine	W 40 — Header wiring harness
W 14 — Optional equipment wiring harness	W 41 — Header wiring harness, without hydraulics (Europe)
W 15 — Grain tank wiring harness	W 42 — Underslung chopper wiring harness
W 18 — Positive battery cable	W 44 — Engine/cab wiring harness
W 20 — Straw hood wiring harness	W 45 — Wiring harness, 25 ft. header (USA)
W 21 — Power supply cable	W 46 — Header wiring harness with DIAL-A-MATIC™
W 22 — Wiring harness, 20 ft. header	W 47 — Adapter cable for header electr. clutch
W 23 — Wiring harness, combine data center	W 55 — Beacon light wiring harness
W 24 — Sieve motor wiring harness	W 56 — Wiring harness, header lateral tilt
W 25 — Chopper wiring harness	W 59 — Adapter cable for row-crop unit

## COMPONENT SURVEY

	Section	Wiring harness
A 1 — Reel speed control . . . . .	19	W 1
A 2 — DIAL-A-MATIC™ relay board . . . . .	20	W 1
A 3 — Electronic speed monitoring system . . . . .	22	W 1
A 4 — Harvest performance monitor (105,152 IMP) . . . . .	23	W 2
A 5 — Combine data center . . . . .	25	W 23
A 6 — Header control . . . . .	26	W 1
A 7 — Electronics for Automatic Header Control . . . . .	—	
A 8 — Leveling control box, Hillmaster . . . . .	24	W 29
A 9 — Control board, combine data center . . . . .	25	W 1
A 10 — Float control . . . . .	30	W 3
A 11 — Relay board, combine data center . . . . .	25	W 1
A 12 — Radio . . . . .	08	W 2
A 13 — CB radio . . . . .	08	W 2
A 14 — Relay and diode board . . . . .	—	W 2
A 15 — Fuse board . . . . .	—	W 1
A 16 — Warning module I . . . . .	09	W 4
A 17 — Warning module II . . . . .	10	W 4
A 18 — Infotrak monitor . . . . .	22	W 2
B 1 — Sending unit, brake fluid level . . . . .	09	W 7
B 2 — Sending unit, engine oil pressure . . . . .	09	W 12; W 13
B 4 — Sending unit, coolant temperature . . . . .	05	W 12; W 13
B 5 — Sending unit, reel speed . . . . .	19	W 22
B 6 — Sending unit, ground speed . . . . .	22	W 7
B 7 — Sending unit, hydraulic oil filter . . . . .	10	W 9
B 8 — Sending unit, hydraulic oil temperature . . . . .	09	W 9
B 9 — Thermostat (protection against freezing) . . . . .	15	W 6
B 10 — Sending unit, air cleaner . . . . .	10	W 12; W 13
B 11 — Sending unit, fuel tank . . . . .	05	W 9
B 12 — Horn . . . . .	18	W 7
B 13 — Temperature switch, air conditioning . . . . .	15	W 2
B 14 — Low pressure switch, air conditioning . . . . .	15	W 2
B 15 — High pressure switch, air conditioning . . . . .	15	W 12; W 13
B 16 — Speed sending unit, straw chopper . . . . .	22	W 25
B 17 — Speed sending unit, tailings elevator . . . . .	22	W 7
B 18 — Speed sending unit, cross-shaker . . . . .	22	W 9
B 19 — Speed sending unit, clean grain elevator . . . . .	22	W 7
B 20 — Speed sending unit, chaff spreader . . . . .	22	W 26
B 21 — Straw walker sensor, right-hand . . . . .	23	W 20
B 22 — Straw walker sensor, left-hand . . . . .	23	W 20
B 23 — Sieve sensor (5-walker machine) . . . . .	23	W 9
B 24 — Sieve sensor (6-walker machine) . . . . .	23	W 9
B 25 — Sending unit, grain tank indicator 1/2 . . . . .	10	W 15
B 26 — Sending unit, grain tank indicator 3/4 . . . . .	10	W 15
B 27 — Sending unit, grain tank indicator 4/4 . . . . .	10	W 15

ZX, TM4543009503-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	Section	Wiring harness
B 28 — Sending unit, engine speed . . . . .	22	W 12; W 13
B 29 — Sending unit, threshing cylinder speed . . . . .	22	W 7
B 30 — Sending unit, fan speed . . . . .	22	W 7
B 31 — Pressure switch, main clutch . . . . .	27	W 9
B 32 — Sending unit, empty grain tank . . . . .	--	
B 34 — Sending unit, hydr. oil fill level 1 . . . . .	10	W 9
B 35 — Sending unit, hydr. oil fill level 2 . . . . .	09	W 9
B 36 — Ultrasonic sensor, left . . . . .	--	
B 38 — Ultrasonic sensor, right . . . . .	--	
B 39 — Loudspeaker, left-hand . . . . .	08	W 2
B 40 — Loudspeaker, right-hand . . . . .	08	W 2
B 41 — Sending unit, oil temp., underslung chopper . . . . .	--	
B 42 — Sending unit, charged air temperature . . . . .	--	
B 43 — Back-up alarm, buzzer . . . . .	31	W 20
E 1 — Headlight, left-hand . . . . .	12	W 7
E 2 — Headlight, right-hand . . . . .	12	W 7
E 3 — Rear worklight . . . . .	17	W 20
E 4 — Cab roof worklight, outer r.h. . . . .	17	W 2
E 5 — Cab roof worklight, inner r.h. . . . .	17	W 2
E 6 — Cab roof worklight, outer l.h. . . . .	17	W 2
E 7 — Cab roof worklight, inner l.h. . . . .	17	W 2
E 8 — Unloading auger worklight . . . . .	17	W 15
E 9 — Cigarette lighter . . . . .	11	W 3
E 10 — Grain tank lighting . . . . .	07	W 15
E 11 — Lighting (according to local requirements) . . . . .	12	W 7
E 12 — Cab interior lighting . . . . .	07	W 2
E 13 — Tail light, left-hand . . . . .	12	W 20
E 14 — Tail light, right-hand . . . . .	12	W 20
E 15 — Clearance light, left-hand . . . . .	12	W 7
E 16 — Clearance light, right-hand . . . . .	12	W 7
E 17 — Straw hood lighting . . . . .	07	W 20
E 18 — Platform worklight, right-hand . . . . .	17	W 7
E 19 — Platform worklight, left-hand . . . . .	17	W 7
E 20 — Worklight, US cutting platform, right-hand . . . . .	--	
E 21 — Work light, US cutting platform, left-hand . . . . .	--	
E 22 — Registration plate lighting . . . . .	12	W 20
E 23 — Clearance light, header, left-hand . . . . .	12	W 32
E 24 — Clearance light, header, right-hand . . . . .	12	W 32
E 25 — Worklight, mirror bracket, right . . . . .	17	W 2
E 26 — Worklight, mirror bracket, left . . . . .	17	W 2
F 1 — Fuse, 7.5 amp., spare . . . . .	--	A 15
F 2 — Fuse, 7.5 amp., spare . . . . .	--	A 15
F 3 — Fuse, 7.5 amp., spare . . . . .	--	A 15
F 4 — Fuse, 7.5 amp., spare . . . . .	--	A 15
F 5 — Fuse, 15 amp., spare . . . . .	--	A 15
F 6 — Fuse, 15 amp., spare . . . . .	--	A 15

ZX.TM4543009504-19-30JUN97



*Functional Schematic and Harness Diagrams/Component survey*

	Section	Wiring harness
F 7 — Fuse, 30 amp., spare . . . . .	--	A 15
F 8 — Fuse, 7.5 amp., fan and threshing cylinder speed adjustment . . . . .	25	A 15
F 9 — Fuse, 7.5 amp., parking light, r.h. . . . .	12	A 15
F 10 — Fuse, 7.5 amp., parking light, l.h. . . . .	12	A 15
F 11 — Fuse, 30 amp., fan adjustment . . . . .	25	A 15
F 12 — Fuse, 15 amp., stop lights, reel speed adjustment . . . . .	19	A 15
F 13 — Fuse, 30 amp., cab roof worklights . . . . .	17	A 15
F 14 — Fuse, 7.5 amp., straw warning device electronic infotrak monitor . . . . .	18	A 15
F 15 — Fuse, 15 amp., distributor adjustment on straw chopper . . . . .	6B	A 15
F 16 — Fuse, 7.5 amp., engine shut-off solenoid . . . . .	03A/B	A 15
F 17 — Fuse, 7.5 amp., instrument lighting . . . . .	12	A 15
F 18 — Fuse, 7.5 amp., radio, CB radio, clock . . . . .	08	A 15
F 19 — Fuse, 30 amp., platform worklights and rear worklight . . . . .	21	A 15
F 20 — Fuse, 7.5 amp., flasher functions . . . . .	13	A 15
F 21 — Fuse, 15 amp., radiator cleaner motor . . . . .	21	A 15
F 22 — Fuse, 7.5 amp., radio, CB radio, clock . . . . .	08	A 15
F 23 — Fuse, 15 amp., separator and header clutch . . . . .	21	A 15
F 24 — Fuse, 7.5 amp., indicator lights, temperature gauge . . . . .	05	A 15
F 25 — Fuse 7.5 amp., low-beam headlight, l.h. . . . .	12	A 15
F 26 — Fuse, 7.5 amp., header controls . . . . .	26	A 15
F 27 — Fuse, 15 amp., horn . . . . .	18	A 15
F 28 — Fuse, 7.5 amp., combine data center . . . . .	25	A 15
F 29 — Fuse, 15 amp., leveling system . . . . .	24	A 15
F 30 — Fuse, 7.5 amp., four-wheel drive . . . . .	28	A 15
F 31 — Fuse, 7.5 amp., speed monitoring system . . . . .	22	A 15
F 32 — Fuse, 7.5 amp., low-beam headlight, r.h. . . . .	12	A 15
F 33 — Fuse, 15 amp., raise/lower header . . . . .	26	A 15
F 34 — Fuse, 15 amp., hazard warning lights . . . . .	13	A 15
F 35 — Fuse, 15 amp., beacon lights . . . . .	14	A 15
F 36 — Fuse, 15 amp., windshield wiper, grain tank lighting . . . . .	07	A 15

ZX, TM4543009505-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	<b>Section</b>	<b>Wiring harness</b>
F 37 — Fuse, 7.5 amp., mirror adjustment . . . . .	16	A 15
F 38 — Fuse, 7.5 amp., performance monitor . . . . .	23	A 15
F 39 — Fuse, 15 amp., grain tank unloading system . . . . .	27	A 15
F 40 — Fuse, 30 amp., starter switch . . . . .	01	A 15
F 41 — Fuse, 15 amp., concave adjustment . . . . .	25	A 15
F 42 — Fuse, 30 amp., air conditioning system . . . . .	15	A 15
F 43 — Fuse, 7.5 amp., DIAL-A-MATIC™ . . . . .	20	A 15
F 44 — Fuse, 7.5 amp., full-beam headlight, l.h. . . . .	12	A 15
F 45 — Fuse, 15 amp., reel control . . . . .	26	A 15
F 46 — Fuse, 15 amp., starting aid . . . . .	02	A 15
F 47 — Fuse, 15 amp., spare . . . . .	—	A 15
F 48 — Fuse, 7.5 amp., alternator D+ . . . . .	01	A 15
F 49 — Fuse, 15 amp., cigarette lighter, seat compressor . . . . .	11	A 15
F 50 — Fuse, 7.5 amp., full-beam headlight, r.h. . . . .	12	A 15
F 51 — Fuse, 7.5 amp., electro-clutch for header drive . . . . .	31	W12/W13
F 52 — Fuse, 7.5 amp., back-up alarm . . . . .	31	W12/W13
G 1 — Battery, 12 V, 88 AH . . . . .	01	W 12; W 13
G 2 — Alternator . . . . .	01	W 12; W 13
H 1 — Brake fluid indicator light . . . . .	09	W 4
H 2 — Engine oil pressure indicator light . . . . .	09	W 4
H 3 — Parking brake indicator light . . . . .	09	W 4
H 4 — Coolant temperature indicator light . . . . .	09	W 4
H 5 — Indicator light, unloading auger swing . . . . .	10	W 4
H 6 — Fuel level indicator light . . . . .	10	W 4
H 7 — Hydraulic oil filter indicator light . . . . .	10	W 4
H 8 — Hydraulic oil temperature indicator light . . . . .	09	W 4
H 9 — Four-wheel drive indicator light . . . . .	10	W 4
H 10 — Air cleaner indicator light . . . . .	09	W 4
H 11 — Alternator indicator light . . . . .	10	W 4
H 12 — Alarm light ("STOP") . . . . .	09	W 4
H 13 — Turn signal light, rear left-hand . . . . .	13	W 20
H 14 — Turn signal light, rear right-hand . . . . .	13	W 20
H 15 — Turn signal light, front left-hand . . . . .	13	W 7
H 16 — Turn signal light, front right-hand . . . . .	13	W 7
H 17 — Additional turn signal light, left-hand . . . . .	13	W 7
H 18 — Additional turn signal light, right-hand . . . . .	13	W 9
H 19 — Indicator light, straw warning device . . . . .	09	W 4
H 20 — Buzzer . . . . .	09	W 2
H 21 — Beacon light . . . . .	14	W 2
H 22 — High pressure indicator light (AC system) . . . . .	10	W 4
H 23 — Indicator light, straw chopper speed . . . . .	09	W 4
H 24 — Indicator light, tailings elevator speed . . . . .	09	W 4
H 25 — Indicator light, cross-shaker speed . . . . .	09	W 4
H 26 — Indicator light, grain elevator speed . . . . .	09	W 4
H 27 — Grain tank fill indicator light 1/2 . . . . .	10	W 4

ZX, TM4543009506-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	<b>Section</b>	<b>Wiring harness</b>
H 28 — Grain tank fill indicator light 3/4 . . . . .	10	W 4
H 29 — Grain tank fill indicator light 4/4 . . . . .	10	W 4
H 31 — Indicator light, fan speed . . . . .	09	W 4
H 32 — Indicator light, cylinder speed . . . . .	09	W 4
H 33 — Full-beam indicator light . . . . .	12	W 8
H 34 — Turn signal indicator light 1, combine . . . . .	13	W 8
H 35 — Turn signal indicator light 2, trailer . . . . .	13	W 8
H 36 — Beacon light . . . . .	14	W 9
H 37 — Hillmaster combine, automatic operation . . . . .	10	W 4
H 38 — Hillmaster combine, manual operation . . . . .	10	W 4
H 39 — Hillmaster combine, end stop . . . . .	10	W 4
H 40 — Hydraulic oil level indicator light . . . . .	10	W 4
H 41 — Turn signal light, header, left-hand . . . . .	13	W 32
H 42 — Turn signal light, header, right-hand . . . . .	13	W 32
H 43 — Stop light, left-hand . . . . .	19	W 20
H 44 — Stop light, right-hand . . . . .	19	W 20
K 1 — Starting motor relay . . . . .	01	W 12; W 13
K 2 — Basic relay . . . . .	01	A 15
K 3 — Basic relay . . . . .	01	A 15
K 4 — Buzzer timer relay . . . . .	09	A 14
K 5 — Flasher . . . . .	13	A 14
K 6 — Relay, straw warning device . . . . .	18	A 14
K 7 — Relay, work lights . . . . .	17	A 15
K 8 — Float control relay . . . . .	24	A 14
K 9 — Hillmaster leveling relay . . . . .	24	A 14
K 10 — Relay, fan speed alarm . . . . .	22	A 14
K 11 — Relay, cylinder speed alarm . . . . .	22	W 14
K 12 — Relay, field operation/road travel . . . . .	22	A 15
K 13 — Relay, lower header quickly . . . . .	26	A 14
K 14 — Relay, lower header slowly . . . . .	26	A 14
K 15 — Relay, raise header quickly . . . . .	26	A 14
K 16 — Relay, raise header slowly . . . . .	26	A 14
K 17 — Relay, lower reel . . . . .	26	A 14
K 18 — Relay, raise reel . . . . .	26	A 14
K 19 — Relay, move reel to the rear . . . . .	26	A 14
K 20 — Relay, move reel to the front . . . . .	26	A 14
K 21 — Relay, separator clutch . . . . .	21	A 15
K 22 — Relay, straw warning device . . . . .	18	A 14
K 23 — Safety relay, header drive . . . . .	21	A 14
K 24 — Safety relay, unloading auger drive . . . . .	27	A 14
K 25 — Timer relay, unloading auger swing . . . . .	27	A 14
K 26 — Relay, enlarge concave clearance . . . . .	25B	A 11 integrated
K 27 — Relay, reduce concave clearance . . . . .	25B	A 11 integrated
K 28 — Relay, adjust feeder house speed . . . . .	26	A 14
K 29 — Relay, adjust feeder house speed . . . . .	26	A 14

ZX, TM4543009507-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	Section	Wiring harness
K 30 — Relay, cylinder faster . . . . .	25B	A 11 integrated
K 31 — Relay, cylinder slower . . . . .	25B	A 11 integrated
K 32 — Relay, adjust reel speed . . . . .	17	A 14
K 33 — Relay, adjust reel speed . . . . .	17	A 14
K 34 — Flasher (USA) . . . . .	--	
K 35 — Timer relay, header drive . . . . .	21	A 14
K 36 — Relay, adjust fan speed . . . . .	25	W 9
K 37 — Relay, adjust fan speed . . . . .	25	W 9
K 38 — Relay, increasing fan speed . . . . .	25B	A 11 integrated
K 39 — Relay, decreasing fan speed . . . . .	25	A 11 integrated
K 40 — Relay, right . . . . .	--	
K 41 — Relay, left . . . . .	--	
K 42 — Relay, header el.-clutch (moving motor) . . . . .	31	
K 43 — Relay, automatic resume potentiometer . . . . .	--	
K 44 — 2-sec. timer relay . . . . .	--	
K 45 — Relay, dynamo + (moving motor) . . . . .	31	
K 46 — Separator timer relay . . . . .	32	
K 48 — Relay, grain tank gauge . . . . .	14	
K 51 — Relay, unloading auger drive . . . . .	27	
K 52 — Relay, unloading auger drive . . . . .	27	
M 1 — Starting motor . . . . .	01	W 12; W 13
M 2 — Reel speed adjusting motor . . . . .	19	W 22
M 3 — Windshield wiper motor . . . . .	07	W 2
M 4 — Cab fan . . . . .	15	W 6
M 5 — Seat compressor . . . . .	11	W 5
M 6 — Chaffer adjusting motor . . . . .	--	
M 7 — Sieve adjusting motor . . . . .	--	
M 8 — Concave adjusting motor . . . . .	25	W 7
M 9 — Fan speed adjusting motor . . . . .	25	W 9
M 10 — Sieve extension . . . . .	--	
M 11 — Windshield washer pump . . . . .	07	W 9
M 12 — Radiator cleaner motor . . . . .	21	W 12; W 13
M 13 — Distributor adjusting motor . . . . .	06	W 25
M 14 — Reel variable drive (USA) . . . . .	--	
M 15 — Mirror . . . . .	--	
M 16 — Mirror . . . . .	--	
P 1 — Coolant temperature gauge . . . . .	05	W 4
P 2 — Fuel gauge . . . . .	05	W 4
P 3 — Header height gauge . . . . .	05	W 4
P 4 — Steering wheel positioning gauge . . . . .	--	
P 5 — Grain loss indicator . . . . .	05	W 4
P 6 — Digital clock . . . . .	--	
P 7 — Analog clock . . . . .	08	W 2
P 8 — Distributor gauge . . . . .	06	W 4
R 1 — Fan resistor . . . . .	15	W 6
R 2 — Potentiometer, concave adjustment . . . . .	25	W 7
R 3 — Potentiometer, header height . . . . .	26	W 14

ZX, TM4543009508-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	<b>Section</b>	<b>Wiring harness</b>
R 4 — Sending unit, header height . . . . .	26	W 7
R 5 — Potentiometer, reel height . . . . .	26	W 14
R 6 — Sending unit, reel height . . . . .	26	W 22
R 7 — Potentiometer, reel horizontal position . . . . .	26	W 14
R 8 — Sending unit, reel horizontal position . . . . .	26	W 22
R 9 — Resistor, LED fuse tester . . . . .	04	A 15
R 10 — Potentiometer, chaffer . . . . .	--	
R 11 — Potentiometer, sieve . . . . .	--	
R 12 — Potentiometer, sieve extension . . . . .	--	
R 13 — Potentiometer, header float . . . . .	26	W 14
R 14 — Potentiometer, distributor position . . . . .	06	W 25
R 15 — Potentiometer, steering wheel position . . . . .	--	
R 16 — Glow-type starting aid . . . . .	--	
R 17 — 2 kilo-ohm resistor, engine speed . . . . .	--	
R 18 — 2 kilo-ohm resistor, engine tuning . . . . .	--	
S 1 — Starter switch . . . . .	01	W 8
S 2 — Hydrostatic safety switch . . . . .	01	W 5
S 3 — Cold-weather starting aid switch . . . . .	02	W 8
S 4 — Indicator light test switch . . . . .	10	W 2
S 5 — Parking brake control switch . . . . .	09	W 7
S 6 — Header float switch . . . . .	30	W 5
S 7 — Stop light switch . . . . .	19	W 7
S 8 — Horn button . . . . .	18	W 8
S 9 — Potentiometer, reel speed . . . . .	17	W 14
S 10 — Reel speed switch . . . . .	17	W 5
S 11 — Hazard warning light switch . . . . .	13	W 2
S 12 — Turn signal light switch . . . . .	13	W 8
S 13 — Light switch . . . . .	12	W 2
S 14 — Grain tank lighting switch . . . . .	07	W 2
S 15 — Switch, straw warning device (cross-shaker) . . . . .	18	W 9
S 16 — Switch, straw warning device (walkers) . . . . .	18	W 20
S 17 — Switch, straw warning device (chopper) . . . . .	18	W 20
S 18 — Beacon light switch . . . . .	14	W 2
S 19 — Switch for cab roof worklights . . . . .	17	W 2
S 20 — Windshield wiper switch . . . . .	07	W 2
S 21 — Windshield washer switch . . . . .	07	W 2
S 22 — Fan switch . . . . .	15	W 2
S 23 — DIAL-A-MATIC™ switch . . . . .	20	W 14
S 24 — Speed monitoring switch, chopper . . . . .	22	W 25
S 25 — Air conditioning switch . . . . .	25	W 2
S 26 — Speed monitoring switch, chaff spreader . . . . .	15	
S 27 — Switch, raise/lower header . . . . .	26	W 5
S 28 — Automatic function switch . . . . .	26	W 5
S 29 — Switch, reel height adjustment . . . . .	26	W 5
S 30 — Switch, reel horizontal adjustment . . . . .	26	W 5

ZX, TM4543009509-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	Section	Wiring harness
S 31 — Road safety switch . . . . .	21	W 2
S 32 — Switch, header control . . . . .	26	W 14
S 33 — Separator drive switch . . . . .	21	W 3
S 34 — Header drive switch . . . . .	21	W 3
S 35 — Unloading auger drive switch . . . . .	27	W 3
S 36 — Switch, concave adjustment . . . . .	25	W 5
S 38 — Switch, combine data center . . . . .	25	W 14
S 39 — Switch, unloading auger swing . . . . .	27	W 3
S 40 — Switch, cylinder speed adjustment . . . . .	25	W 5
S 41 — Switch, fan speed adjustment . . . . .	25	W 5
S 42 — Parking brake switch . . . . .	09	W 5
S 44 — Four-wheel drive switch . . . . .	28	W 7
S 45 — Switch, seat . . . . .	--	
S 46 — Hazard warning light switch (USA) . . . . .	--	
S 47 — Emergency cut-off switch . . . . .	21	W 5
S 48 — Worklight switch . . . . .	17	W 2
S 49 — Full-beam headlight switch . . . . .	12	W 2
S 50 — Manual leveling control switch . . . . .	24	W 3
S 51 — Leveling control switch automatic/manual . . . . .	24	W 3
S 52 — Demoisturizer switch (air conditioning) . . . . .	15	W 3
S 53 — Switch, header variable drive . . . . .	26	W 3
S 54 — Switch, distributor adjustment . . . . .	06	W 14
S 55 — Reverse travel switch . . . . .	25	W 5
S 56 — Switch, chaffer . . . . .	--	
S 57 — Switch, sieve . . . . .	--	
S 58 — Sieve extension switch . . . . .	--	
S 59 — End switch, leveling to the left . . . . .	24	W 29
S 60 — End switch, leveling to the right . . . . .	24	W 29
S 61 — ContourMaster switch . . . . .	--	
S 62 — Switch, header horizontal adjustment . . . . .	29	W 3
S 63 — Battery switch . . . . .	01	W 12; W 13
S 64 — Mirror adjusting switch . . . . .	16	W 39
S 65 — Mirror heater switch . . . . .	16	W 39
S 66 — Switch, header lateral tilt . . . . .	26	
S 67 — Engine speed switch . . . . .	--	
S 68 — AHC switch, header lateral tilt . . . . .	--	
S 69 — Switch, back-up alarm . . . . .	--	
S 70 — Unloading auger drive switch . . . . .	--	
S 71 — Area counter height cut-off switch . . . . .	--	
S 72 — DIAL-A-MATIC™ switch on header . . . . .	--	
V 1 — Fuse tester . . . . .	04	A 15
V 2 — Diode, pressure switch . . . . .	26	A 14
V 3 — Diode, raising header . . . . .	26	A 14
V 4 — Diode, increase feeder house speed . . . . .	26	A 14
V 5 — Diode, reel raising function . . . . .	26	A 14
V 6 — Diode, reel back function . . . . .	26	A 14

ZX.TM4543009510-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	Section	Wiring harness
V 7 — Diode, reel forward function . . . . .	26	A 14
V 8 — Diode, swinging unloading auger in . . . . .	26	A 14
V 9 — Diode, swinging unloading auger out . . . . .	26	A 14
V 10 — Diode, cylinder speed . . . . .	26	A 14
V 11 — Diode, concave indicator . . . . .	26	A 14
V 12 — Diode, concave indicator . . . . .	--	
V 13 — Diode Y 6 . . . . .	26	A 14
V 14 — Diode Y 4 . . . . .	26	A 14
V 15 — Diode Y 2 . . . . .	26	A 14
V 16 — Diodes Y 3 and Y 5 . . . . .	26	A 14
V 17 — Diode Y 18 . . . . .	26	A 14
V 18 — Diode Y 19 . . . . .	26	A 14
V 19 — Diode Y 16 . . . . .	26	A 14
V 20 — Diode Y 17 . . . . .	26	A 14
V 21 — Diodes Y 22 and Y 23 . . . . .	21	A 15
V 22 — Diode Y 28 . . . . .	--	
V 23 — Diode Y 29 . . . . .	--	
V 24 — Diodes Y 26 and Y 27 . . . . .	27	A 14
V 25 — Diode Y 10 . . . . .	27	A 14
V 26 — Diode Y 11 . . . . .	27	A 14
V 27 — Diode Y 34 . . . . .	21	A 14
V 28 — Diode Y 31 . . . . .	26	A 14
V 29 — Diode Y 30 . . . . .	26	A 14
V 30 — Diode Y 12 . . . . .	24	A 14
V 31 — Diode Y 13 . . . . .	24	A 14
V 32 — Diode K 13 . . . . .	26	A 14
V 33 — Diode K 14 . . . . .	26	A 14
V 34 — Diode K 15 . . . . .	26	A 14
V 35 — Diode K 16 . . . . .	26	A 14
V 36 — Diode K 17 . . . . .	26	A 14
V 37 — Diode K 18 . . . . .	26	A 14
V 38 — Diode K 19 . . . . .	26	A 14
V 39 — Diode K 20 . . . . .	26	A 14
V 40 — Diode K 28 . . . . .	26	A 14
V 41 — Diode K 29 . . . . .	26	A 14
V 42 — Diode, raise header . . . . .	26	A 14
V 43 — Diode, lower header . . . . .	26	A 14
V 44 — Diode, header horizontal adjustment . . . . .	29	A 14
V 45 — Diode, header horizontal adjustment . . . . .	29	A 14
V 46 — Diode, leveling to the left . . . . .	24	A 14
V 47 — Diode, leveling to the right . . . . .	24	A 14
V 48 — Diode, header float control . . . . .	30	A 14
V 51 — Diode K8 . . . . .	24	A 14
V 52 — Diode K9 . . . . .	24	A 14
V 53 — Diode Y14 . . . . .	29	A 14
V 54 — Diode Y15 . . . . .	29	A 14
V 55 — Diode Y13 . . . . .	--	A 14

ZX, TM4543009511-19-30JUN97

Functional Schematic and Harness Diagrams/Component survey

	Section	Wiring harness
V 56 — Diode Y6 . . . . .	--	
V 57 — Diode Y6 . . . . .	--	
V 58 — Diode DIAL-A-MATIC™ . . . . .	--	
V 59 — Diode K43 . . . . .	--	
V 60 — Diode K41 . . . . .	--	
V 61 — Diode K40 . . . . .	--	
V 62 — Zener diode 1N5344B . . . . .	--	
V 63 — Zener diode 1N5344B . . . . .	--	
V 64 — Zener diode 1N5444B . . . . .	--	
V 65 — Diode, grain tank 3/4 full . . . . .	--	
V 66 — Diode, air-conditioning compressor . . . . .	--	
X 0 — Ground connection, cab wiring harness . . . . .	--	W 2
X 1 — Ground connection, distribution harness . . . . .	--	W 1
X 2 — Disconnect point, radio (USA) . . . . .	--	W 2
X 3 — Disconnect point, CB radio . . . . .	--	
X 4 — Disconnect point, DIAL-A-MATIC™ . . . . .	--	
X 5 — Fuse tester socket . . . . .	04	A 15
X 6 — Connection, relay board . . . . .	--	W 2
X 7 — Connection, relay board . . . . .	--	W 2
X 8 — Connection, relay board . . . . .	--	W 2
X 9 — Connection, relay board . . . . .	--	W 2
X 10 — Connection, relay board . . . . .	--	W 2
X 11 — Connection, relay board . . . . .	--	W 2
X 12 — Connection, relay board . . . . .	--	W 2
X 13 — Connection, relay board . . . . .	--	W 2
X 14 — Connection, relay board . . . . .	--	W 2
X 15 — Trailer socket . . . . .	--	W 9
X 16 — Terminal, fuse board . . . . .	--	W 21; W 12
X 17 — Connection, fuse board, l.h. . . . .	--	W 1
X 18 — Connection, fuse board, r.h. . . . .	--	W 1
X 19 — Plug for warning light block . . . . .	--	
X 20 — Plug for alarm light block . . . . .	--	
X 21 — Disconnect point, header wiring harness . . . . .	--	W 10; W 22
X 22 — Disconnect point, chopper wiring harness . . . . .	--	W 9; W 25
X 23 — Disconnect point, cab . . . . .	27	W 7; W 2
X 24 — Disconnect point, solenoid valve block, basic hydraulics . . . . .	--	W 9
X 25 — Disconnect point, cab . . . . .	--	W 1; W 2
X 26 — Disconnect point, cab . . . . .	--	W 1; W 2
X 27 — Disconnect point, cab . . . . .	--	W 1; W 2
X 28 — Disconnect point, cab . . . . .	--	W 1; W 2
X 29 — Splice 071 . . . . .	--	W 2
X 30 — Electr. ground, adjusting potentiometers . . . . .	--	
X 31 — Programming window flasher . . . . .	13	W A 14
X 32 — Plug for solenoid block 2 . . . . .	--	W 22
X 33 — Ground distributor, hydraulic block 1 . . . . .	--	W 9
X 34 — Ground distributor, hydraulic block 2 . . . . .	--	W 22

ZX.TM4543009512-19-30JUN97



*Functional Schematic and Harness Diagrams/Component survey*

	Section	Wiring harness
X 35 — 37-terminal armrest plug . . . . .	--	W 2; W 5
X 36 — Plug for forward/reverse lever . . . . .	--	W 5
X 37 — Plug for dashboard 1 . . . . .	--	W 2; W 3
X 38 — Plug for dashboard 2 . . . . .	--	W 2; W 14
X 39 — 18-term. plug on data center relay board . . . . .	--	W 1
X 40 — Cross-shaker switch plug . . . . .	--	W 9
X 41 — Straw chopper plug . . . . .	--	W 20
X 42 — Data center control board plug . . . . .	--	W 1
X 43 — Straw hood wiring harness plug . . . . .	--	W 20; W 9
X 44 — Plug for basic harness, r.h. . . . .	--	W 2; W 9
X 45 — Plug for basic harness, l.h. . . . .	--	W 2; W 9
X 46 — Plug for platform wiring harness . . . . .	--	W 7; W 2
X 47 — Plug for Hillmaster wiring harness . . . . .	--	W 29; W 1
X 48 — Plug for grain tank harness . . . . .	--	W 15; W 9
X 49 — Plug for corner post harness . . . . .	--	W 2; W 4
X 50 — Plug for electronic box of speed monitoring system . . . . .	--	W 1
X 51 — Plug for header control . . . . .	--	W 1
X 52 — Plug for DIAL-A-MATIC™ electronic box . . . . .	--	W 1
X 53 — Spare plug . . . . .	--	W 1
X 54 — Ground connection, engine wiring harness . . . . .	--	W 12; W 13
X 55 — Plug for combine data center . . . . .	--	W 2; W 23
X 56 — Plug for reel speed control . . . . .	--	W 1
X 57 — Plug for electronic row guidance . . . . .	--	
X 58 — Plug for flex. cable on chaffer . . . . .	--	
X 59 — Plug for flex. cable on sieve . . . . .	--	
X 60 — Plug for flex. cable on sieve extension . . . . .	--	
X 61 — Plug for beacon light . . . . .	--	
X 62 — Plug for engine wiring harness . . . . .	--	W 12; W 13
X 63 — Plug (according to local requirements) . . . . .	--	
X 64 — Ground connection, basic harness, l.h. . . . .	--	W 1
X 65 — Plug for steering column harness . . . . .	--	W 7; W 8
X 66 — Plug for air-conditioning harness . . . . .	--	W 2; W 6
X 67 — Socket, rear axle . . . . .	09	W 9
X 68 — Socket, engine . . . . .	--	
X 69 — Plug for battery + clock; radio; CB radio . . . . .	--	
X 70 — Plug for sieve motors . . . . .	--	
X 71 — Plug for chaff spreader harness . . . . .	--	W 25; W 26
X 72 — Plug for data center relay board . . . . .	--	W 1
X 73 — 16-terminal plug for hydraulic block . . . . .	--	W 10
X 74 — Plug for Hillmaster solenoid block . . . . .	--	W 29
X 75 — Connection, leveling control box . . . . .	--	W 29
X 76 — Plug for corner post harness . . . . .	--	W 2; W 4
X 77 — Plug for feeder house harness . . . . .	--	W 7; W 10
X 78 — Splice 245 . . . . .	--	W 2
X 79 — Splice 075 . . . . .	--	W 1

ZX, TM4543009513-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	Section	Wiring harness
X 80 — Splice 1, ground for electronics . . . . .	--	W 1
X 81 — Splice 2, ground for electronics . . . . .	--	W 1
X 82 — Plug for ultrasonic sensors . . . . .	29	W 7; W 1
X 83 — Splice 256 . . . . .	--	W 1
X 84 — Splice 327 . . . . .	--	
X 85 — Splice 050 . . . . .	--	
X 86 — Splice 147 . . . . .	--	W 20
X 87 — Splice 148 . . . . .	--	W 20
X 88 — Dashboard plug . . . . .	--	W 2; W 3
X 89 — Splice 151 . . . . .	--	W 20
X 90 — Ground connection, straw hood . . . . .	--	W 20
X 91 — Plug for walker sensor, l.h. . . . .	--	W 20
X 92 — Plug for walker sensor, r.h. . . . .	--	W 20
X 93 — Plug for sieve sensor . . . . .	--	W 9
X 94 — Plug for straw hood lighting . . . . .	--	W 20
X 95 — 5-terminal plug for ultrasonic sensors . . . . .	--	W 22
X 96 — Bosch plug for float control . . . . .	30	W 3
X 97 — Plug for electrical mirror adjustment . . . . .	--	W 2; W 39
X 98 — Ground connection, electrical mirror adjustment . . . . .	--	
X 99 — 2-terminal plug, 4-wheel drive solenoid . . . . .	--	
X 100 — Ground connection, hydraulic block 3 . . . . .	--	W 10
X 101 — Plug for header lighting . . . . .	--	W 22; W 32
X 102 — Plug for underslung chopper . . . . .	--	
X 103 — Float control bridging plug . . . . .	30	
X 104 — Plug for seat compressor . . . . .	--	
X 105 — Plug for data bus . . . . .	--	W 2
X 117 — 9-terminal plug for power board . . . . .	--	W 1
X 118 — 9-terminal plug for power board . . . . .	--	W 1
X 119 — Service plug for engine electronics . . . . .	--	
X 120 — Service plug for engine electronics . . . . .	--	
X 121 — Service plug for engine electronics . . . . .	--	
X 122 — Splice, engine harness . . . . .	--	
X 123 — Splice, engine harness . . . . .	--	
X 159 — Plug for Hillmaster end-switch . . . . .	--	W 29
X 160 — Plug for Hillmaster end-switch . . . . .	--	W 29
X 161 — 6-terminal plug, header electrical clutch . . . . .	--	
X 162 — 2-terminal plug, back-up alarm . . . . .	--	
X 163 — 2-terminal plug, grain tank switch . . . . .	--	

ZX, TM4543009514-19-30JUN97

Functional Schematic and Harness Diagrams/Component survey

	Section	Wiring harness
X 164 — Splice, platform wiring harness . . . . .	--	
X 165 — 2-terminal plug, header float pressure . . . . .	--	
X 166 — 1-terminal plug, a/c compressor . . . . .	--	
X 167 — Splice 215 . . . . .	--	
X 168 — 1-terminal plug, to S61 . . . . .	--	
X 169 — 19-terminal plug, to A7 . . . . .	--	
X 170 — 1-terminal plug, beacon light . . . . .	--	
X 171 — 4-terminal plug, header lateral tilt . . . . .	--	
X 172 — Splice 050 . . . . .	--	
X 173 — Splice 327 . . . . .	--	
X 174 — Splice 310 . . . . .	--	
X 175 — Splice 431 . . . . .	--	
X 176 — Splice 433 . . . . .	--	
X 177 — Splice 421 . . . . .	--	W 7
X 178 — Splice 423 . . . . .	--	W 7
X 179 — Splice 421 . . . . .	--	W 22
X 180 — Splice 423 . . . . .	--	W 23
X 181 — 4-term. plug, header potentiometer, l.h. . . . .	--	
X 182 — 4-term. plug, header potentiometer, r.h. . . . .	--	
X 183 — 3-terminal plug . . . . .	--	
Y 1 — Main valve, solenoid control block . . . . .	27	W 9
Y 2 — Header solenoid valve . . . . .	26	W 9
Y 3 — Solenoid, raise header . . . . .	26	W 9
Y 4 — Solenoid, lower header . . . . .	26	W 9
Y 5 — Solenoid, raise header . . . . .	26	W 9
Y 6 — Solenoid, lower header . . . . .	26	W 9
Y 8 — Solenoid, ether starting aid . . . . .	02	W 13
Y 9 — Solenoid, shut off engine . . . . .	03A/B	W 12
Y 10 — Solenoid, swing in unloading auger . . . . .	27	W 9
Y 11 — Solenoid, swing out unloading auger . . . . .	27	W 9
Y 12 — Solenoid, leveling to the left . . . . .	24	W 29
Y 13 — Solenoid, leveling to the right . . . . .	24	W 29
Y 14 — Solenoid, header horizontal position, left-hand . . . . .	29	W 10; W 11
Y 15 — Solenoid, header horizontal position, right-hand . . . . .	29	W 10; W 11
Y 16 — Solenoid, move reel forward . . . . .	26	W 11; W 22
Y 17 — Solenoid, move reel back . . . . .	26	W 11; W 22
Y 18 — Solenoid, lower reel . . . . .	26	W 11; W 22
Y 19 — Solenoid, raise reel . . . . .	26	W 11; W 22
Y 20 — Solenoid, lower combine . . . . .	24	W 29
Y 21 — Solenoid, raise combine . . . . .	--	
Y 22 — Solenoid, engage separator . . . . .	21	W 9
Y 23 — Solenoid, engage separator . . . . .	21	W 9
Y 26 — Solenoid, unloading grain . . . . .	27	W 9


ZX.TM4543009515-19-30JUN97

*Functional Schematic and Harness Diagrams/Component survey*

	<b>Section</b>	<b>Wiring harness</b>
Y 27 — Solenoid, unloading grain . . . . .	27	W 9
Y 28 — Solenoid, reduce cylinder speed . . . . .	25	W 9
Y 29 — Solenoid, increase cylinder speed . . . . .	25	W 9
Y 30 — Solenoid, reduce feeder house speed . . . . .	26	W 10
Y 31 — Solenoid, increase feeder house speed . . . . .	26	W 10
Y 32 — Solenoid, four-wheel drive . . . . .	28	W 9
Y 33 — Compressor clutch . . . . .	15	W 13; W 12
Y 34 — Header clutch . . . . .	21	W 7
Y 35 — Engine shut-off solenoid . . . . .	03A	W 13
Y 36 — Solenoid, underslung chopper . . . . .	--	

ZX, TM4543009516-19-30JUN97


FUNCTIONAL SCHEMATIC, SECTIONS 1, 2, 3A AND 3B



SE1	SE2	SE3A	SE3B
POWER SUPPLY / STARTING MOTOR		ENGINE STOP	START AID

ZX012426


FUNCTIONAL SCHEMATIC, SECTIONS 4, 5 AND 6



SE4	SE5	SE6
F-TEST	INSTRUMENTS	CHOPPER DISTRIBUTOR ADJ.


ZX012427

FUNCTIONAL SCHEMATIC, SECTIONS 7 AND 8



ZX012428

FUNCTIONAL SCHEMATIC, SECTION 9




SE9  
ALARMMODUL – STOP-FUNKTIONEN

ZX012429






FUNCTIONAL SCHEMATIC, SECTIONS 11 AND 12



SE11	SE12
CIGARETT LIGHTER / SOCKETS	LIGHT FUNCTION

ZX012431


FUNCTIONAL SCHEMATIC, SECTIONS 13A AND 13B



SE13A	SE13B
FLASHER FUNCTION	FLASHER FUNCTION

ZX012432


FUNCTIONAL SCHEMATIC, SECTIONS 14 AND 15



SE14	REVOLVING LIGHTS
SE15	AIR CONDITION

ZX012433

FUNCTIONAL SCHEMATIC, SECTIONS 16 AND 17




SE16	REAR VIEW MIRROR ADJUSTMENT
SE17	WORK LIGHTS

ZX012434



**FUNCTIONAL SCHEMATIC, SECTION 20**




ZX012436

ZX012436 -UN-11MAR98

ZX.TM4543009527-19-30JUN97

FUNCTIONAL SCHEMATIC, SECTION 21




SE21  
SEPARATOR ; HEADER CLUTCH ; RADIATOR CLEANER MOTOR

ZX012437



FUNCTIONAL SCHEMATIC, SECTION 22



SE16 109 264 310

SE24 SE21

SE19 SE20

SE20B SE1 SE20A SE20C

SE10 SE20

SE1 SE20B SE1

SE20A SE20C

051

268 269 050 1 7 8

154 155 046

054

055

310

SE9 209

179

178

177

176

175

174

173

172

171

170

169

168

167

166

165

164

163

162

161

160

159

158

157

156

155

154

153

152

151

150

149

148

147

146

145

144

143

142

141

140

139

138

137

136

135

134

133

132

131

130

129

128

127

126

125

124

123

122

121

120

119

118

117

116

115

114

113

112

111

110

109

108

107

106

105

104

103

102

101

100

99

98

97

96

95

94

93

92

91

90

89

88

87

86

85

84

83

82

81

80

79

78

77

76

75

74

73

72

71

70

69

68

67

66

65

64

63

62

61

60

59

58

57

56

55

54

53

52

51

50

49

48

47

46

45

44

43

42

41

40

39

38

37

36

35

34

33

32

31

30

29

28

27

26

25

24

23

22

21

20

19

18

17

16

15

14

13

12

11

10

9

8

7

6

5

4

3

2

1

SE9 310



SE9 310

SE22

INFOTRAK MONITOR / SPEED MONITORING SYSTEM

ZX012438

**FUNCTIONAL SCHEMATIC, SECTION 23**




ZX012439

ZX012439 -UN-11MAR98

ZX.TM4543009530-19-30JUN97




FUNCTIONAL SCHEMATIC, SECTION 25A



SE25A  
CYLINDER , CONCAVE , FAN ADJUSTMENT

ZX012441


FUNCTIONAL SCHEMATIC, SECTION 25B - PART 1



SE25B  
CYLINDER ;CONCAVE ; FAN ADJUSTMENT  
-PART 1

ZX012442


FUNCTIONAL SCHEMATIC, SECTION 25B - PART 2



SE25B  
CYLINDER , CONCAVE , FAN ADJUSTMENT  
-PART 2

ZX012443

FUNCTIONAL SCHEMATIC, SECTION 26 - PART 1




SE26  
HEADER ADJUSTMENT (CUTTING HEIGHT; REEL; FLOAT)

-PART 1

ZX012444

FUNCTIONAL SCHEMATIC, SECTION 26 - PART 2




SE26  
 HEADER ADJUSTMENT (CUTTING HEIGHT; REEL; FLOAT)  
 --PART 2

ZX012445



FUNCTIONAL SCHEMATIC, SECTIONS 27 AND 28




SE27	GRAIN TANK UNLOADING SYSTEM
SE28	FOUR WHEEL DRIVE

ZX012446




FUNCTIONAL SCHEMATIC, SECTIONS 30, 31 AND 32



SE30	SE31	SE32
FLOAT CONTROL	BACK UP ALARME	TIMER RELAY 4,5S MD 2054

ZX012448


WIRING AND HARNESS DIAGRAM, CAB WIRING HARNESS W2 - PART 1



Z012464




**LOCATION OF CAB WIRING HARNESS W2 (PART 1), ARMREST WIRING HARNESS W5  
AND AIR CONDITIONING WIRING HARNESS W6 WITH COMPONENTS**



ZX 003984




WIRING AND HARNESS DIAGRAM, CAB WIRING HARNESS W2 - PART 2



ZK012465




**LOCATION OF CAB WIRING HARNESS W2 (PART 2) WITH COMPONENTS**



ZX 003985




**LOCATION OF CAB WIRING HARNESS W2 (PART 3) AND REAR VIEW MIRROR WIRING HARNESS W39 WITH COMPONENTS**



WIRING AND HARNESS DIAGRAM, CAB WIRING HARNESS W2 - PART 4

A114  
RELAY AND  
DIODE BOARD




Z0012459








**WIRING AND HARNESS DIAGRAM, CAB WIRING HARNESS W2 - PART 6**







WIRING AND HARNESS DIAGRAM, CAB WIRING HARNESS W2 - PART 7




ZX012472







### WIRING AND HARNESS DIAGRAM, OPTIONAL EQUIPMENT HARNESS W14 ON SWITCH CONSOLE




R5	188	▲
R7	189	▲
S9	081	▲
S9	082	▲
S9	083	▲
S9	084	▲
R13	240	▲
R3	192	▲
R5	090	▲
R5	090A	▲
R7	090B	▲
S3	090C	▲
S3	090D	▲
S23	231	▲
S23	232	▲
S23	233	▲
S23	234	▲
S23	235	▲
S23	236	▲
S23	237	▲
S23	238	▲
S38	103	▲
S38	310	▲
S38	219	▲
S38	099	▲
S72	178	▲
S56	185	▲
S56	314	▲
S57	306	▲
S57	309	▲
S56	298	▲
S56	306	▲
S54	317 2.8*	▲
S54	318 2.8*	▲
S54	319 2.8*	▲
S54	310 2.8*	▲
R13	338	▲

Z012468




**WIRING AND HARNESS DIAGRAM, SWITCH CONSOLE WIRING HARNESS W3**



ZK012467




LOCATION OF SWITCH CONSOLE WIRING HARNESS W3 AND OPTIONAL EQUIPMENT WIRING HARNESS W14 WITH COMPONENTS



ZX003982

WIRING AND HARNESS DIAGRAM, ARMREST WIRING HARNESS W5




ZK012463





### LOCATION OF CORNER POST WIRING HARNESS W4 WITH COMPONENTS




ZX003983

-UN-03APR98  
ZX003983

ZX, TMXZC002158-19-06OCT92


WIRING AND HARNESS DIAGRAM, STEERING COLUMN WIRING HARNESS W8



X65  
W 7

ZK012574

### LOCATION OF STEERING COLUMN WIRING HARNESS W8 WITH COMPONENTS




ZX003987

ZX003987 -UN-03APR98

ZX, TMXZCO002162-19-06OCT92


### WIRING AND HARNESS DIAGRAM, FRONT BASIC WIRING HARNESS W7



Z012573




**LOCATION OF FRONT BASIC WIRING HARNESS W7 WITH COMPONENTS**




ZX003981

WIRING AND HARNESS DIAGRAM, LEVELING SYSTEM WIRING HARNESS W29



Z4012578

**LOCATION OF LEVELING SYSTEM WIRING HARNESS W29 WITH COMPONENTS**











**LOCATION OF FEEDER HOUSE WIRING HARNESS W10, HEADER WIRING HARNESS W22 AND HEADER LIGHTING WIRING HARNESS W32 WITH COMPONENTS**




WIRING AND HARNESS DIAGRAM, MAIN DISTRIBUTION WIRING HARNESS W1 - PART 1








## WIRING AND HARNESS DIAGRAM, MAIN DISTRIBUTION WIRING HARNESS W1 - PART 2



Z101 2568

**LOCATION OF MAIN DISTRIBUTION WIRING HARNESS W1 WITH COMPONENTS**




ZX004159






**WIRING AND HARNESS DIAGRAM, REAR BASIC WIRING HARNESS W9, GRAIN TANK WIRING HARNESS W15, CHOPPER WIRING HARNESS W25 AND CHAFF SPREADER WIRING HARNESS W26 - PART 2**






**LOCATION OF REAR BASIC WIRING HARNESS W9, GRAIN TANK WIRING HARNESS W15 AND CHOPPER WIRING HARNESS W25**






**LOCATION OF STRAW HOOD WIRING HARNESS W20 WITH COMPONENTS**



ZX003991


WIRING AND HARNESS DIAGRAM, ENGINE WIRING HARNESSES W12 AND W13 - PART 1




ZX012571




**WIRING AND HARNESS DIAGRAM, ENGINE WIRING HARNESSES W12 AND W13 - PART 2**



LOCATION OF ENGINE WIRING HARNESS W12 AND W13 WITH COMPONENTS, AND OF ADAPTER WIRING HARNESS W47 FOR THE HEADER CLUTCH




**WIRING AND HARNESS DIAGRAM, FUSE BOARD A15**



ZX012585



**LOCATION OF COMPONENTS ON FUSE BOARD A15**



ZX012584



## Group 15A Current Supply/Starting Motor

### SPECIFICATIONS

Item	Measurement	Specification
Alternator	Capacity	120 A
Batteries	Number	2
Batteries	Voltage	12 V
Battery	Capacity	88 AH

ZX, TMXZCO002403-19-17JAN94

### OPERATIONAL INFORMATION

Clearance lights, hazard warning lights, work lights and horn may be switched on regardless of starter switch position.

With starter switch in position (I), all electrical systems may be switched on, with the exception of gauges and indicator lights. These components are activated when starter switch is turned to position (II).

With hydrostatic ground speed drive lever in neutral position, starting motor may be operated by turning starter switch to position (III).

*NOTE: Power is supplied to memory functions of clock, radio and citizen band from a point located in front of the battery switch which may be installed. This ensures correct operation of these components with battery switch in "OFF" position.*

ZX, TMXZCO002405-19-25NOV92

### THEORY OF OPERATION


On all combine models, the negative battery terminal is connected to the machine frame via the main battery switch (S63). The positive battery terminal is connected to terminal (30) of starting motor and to the fuse board on which the fuses and basic relays (K2) and (K3) are located.

The starter switch is supplied with current via fuse (F40).

The hydrostatic ground speed control lever must be in neutral position when starting the engine. This will activate switch (S2) and change switch (S63) from a positive conductor to a negative one.

ZX, TMXZCO005138-19-15MAR96

**FUNCTIONAL SCHEMATIC OF SECTION 1**




ZX003994

-UN-02MAY95  
ZX003994

- |   |  |   |  |
|---|--|---|--|
| <p>A15 — Fuse board<br/>                 F40 — Fuse, 30 amps.<br/>                 F48 — Fuse, 7.5 amps.<br/>                 G1 — Batteries<br/>                 G2 — Alternator<br/>                 K1 — Starting motor relay<br/>                 K2 — Basic relay<br/>                 K3 — Basic relay<br/>                 M1 — Starting motor<br/>                 S1 — Starter switch<br/>                 S2 — Hydrostatic safety switch<br/>                 S63 — Battery switch<br/>                 X17 — Connection, distribution harness (W1) to fuse board</p> | <p>X18 — Connection, distribution harness (W1) to fuse board<br/>                 X25 — Disconnect point, distribution harness (W1), cab harness (W2)<br/>                 X27 — Disconnect point, distribution harness (W1), cab harness (W2)<br/>                 X35 — Disconnect point, cab harness (W2), armrest harness (W5)</p> | <p>X44 — Disconnect point, cab harness (W2), rear basic harness (W9)<br/>                 X45 — Disconnect point, cab harness (W2), rear basic harness (W9)<br/>                 X46 — Disconnect point, cab harness (W2), front basic harness (W7)</p> | <p>X62 — Disconnect point, rear basic harness (W9), engine harness (W13)<br/>                 X65 — Disconnect point, front basic harness (W7), steering column harness (W8)<br/>                 X117 — Connection, distribution harness (W1) to fuse board</p> |
|---|--|---|--|

DIAGNOSTIC SCHEMATIC OF SECTION 1





## Group 15B Cold Weather Starting Aid


### OPERATIONAL INFORMATION

The cold weather starting aid injects ether fluid into the intake manifold while cranking engine by means of starting motor.

Ether is highly flammable. The heat created in the combustion chamber is sufficient to ignite the injected ether. This in turn will ignite the fuel/air mixture.

Operating cold weather starting aid:

Turn starter switch to position III. As soon as the engine is cranking, push ether starting aid button (A). After the engine has started, release starter switch and starting aid button.



ZX002398 -UN-10APR95


### THEORY OF OPERATION

With starter switch in position III, voltage is supplied to starting motor relay coil via hydrostatic safety switch. At the same time, voltage is supplied to starting aid switch (S3) via wire 295.

Solenoid (Y8) is activated by actuating switch (S3), which will inject ether into the intake manifold.

ZX, TMXZCO003183-19-17JAN94

**FUNCTIONAL SCHEMATIC OF SECTION 2**



ZX005243 -JUN-28APR95

**ZX005243**

- A15—Fuse board
- F46—Fuse, 15 amps.
- S3 —Ether starting aid switch
- X17—Connection, distribution harness (W1) to fuse board
- X25—Disconnect point, distribution harness (W1), cab harness (W2)


- X44—Disconnect point, cab harness (W2), basic harness (W9)
- X46—Disconnect point, cab harness (W2), front basic harness (W7)

- X62—Disconnect point, rear basic harness (W9), engine harness (W12/W13)
- X65—Disconnect point, front basic harness (W7), steering column harness (W8)

- Y8 —Solenoid, ether starting aid

ZX, TMXZCO003184-19-17JAN94

**DIAGNOSTIC SCHEMATIC OF SECTION 2**



ZX003997 -JUN-02MAY95

ZX003997

ZX, TMXZCO003185-19-17JAN94





## OPERATIONAL INFORMATION

When starter switch is moved back from position (II) to position (I), the engine is shut off electrically.

On the 7.6 Liter engine, a shut-off lever is moved by interrupting current supply to the lever retaining solenoid.

On the 6.8 Liter engine, the fuel supply is shut off by means of a solenoid valve in the fuel pump.

ZX, TMXZC0002408-19-25NOV92

## THEORY OF OPERATION

### 7.6 LITER ENGINE

When moving starter switch from position (I) to position (II), coil of (Y35) is supplied with current via wire (018).

In addition, the second coil of (Y35) is activated via wire (085) during the starting procedure, moving the shut-off lever at fuel injection pump.

The engine is ready for starting.

After starting procedure is completed, the second coil is again without current.

The engine shut-off lever is held in operating position by the retaining coil.

For shutting off the engine current supply to the retaining coil is interrupted.

A return spring moves shut-off lever at fuel injection pump to the zero position.

### 6.8 LITER ENGINE

Fuel supply at injection pump is interrupted by a solenoid.

With engine running, solenoid coil is supplied with current, keeping solenoid valve open.

When current supply is interrupted, the valve is closed by spring force.


*NOTE: If fuse (F16) fails, the machine will stop.*

#### SWITCH POSITIONS:

- Position III: Wire 085 is live only when starting.
- Position II: Wire 018 is live.
- Position I: No current at wires 018 or 085. Current available for lighting only.
- Position 0: Everything off.

ZX, TM4543010317-19-30JUN97

**FUNCTIONAL SCHEMATIC OF SECTIONS 3A AND 3B**



ZX003998

ZX003998 -UN-02MAY95

- A15 —Fuse board
- F16 —Fuse, 7.5 amps.
- X44 —Disconnect point, cab harness (W2), basic harness (W9)
- X26 —Disconnect point, distribution harness (W1), cab harness (W2)




- X62 —Disconnect point, rear basic harness (W9), engine harness (W12/W13)

- X118—Connection, distribution harness (W1) to fuse board
- Y9 —Engine shut-off solenoid


- Y35 —Engine shut-off solenoid

ZX, TMXZCO002410-19-17JAN94

**DIAGNOSTIC SCHEMATIC OF SECTIONS 3A AND 3B**



SE3A



SE3B

ZX003999

ZX003999 -JUN-02MAY95  
7X.TMXZCO002411-19-25NOV92



## **OPERATIONAL INFORMATION**

The combine is equipped with analog gauges to display coolant temperature, fuel level, grain losses and header height.

When certain limit values are reached, the coolant or fuel level sending units activate indicator lights and buzzer.

ZX, TMXZCO002412-19-25NOV92

## **THEORY OF OPERATION**

With starter switch in position (II), the gauges are supplied with current via fuse (F24).

The COOLANT TEMPERATURE GAUGE (P1) is connected to sending unit (B4) via wire (034).

Sending unit (B4) is a variable resistor.

At a coolant temperature of 20°C (68°F) resistance is very high. The gauge shows a very low temperature.

At a coolant temperature of 110°C (240°F) resistance is low. The gauge shows a high temperature.

The FUEL GAUGE (P2) is connected to sending unit (B11) via wire (033).

Sending unit (B11) is a variable resistor.

At a low fuel level in fuel tank, resistance is low. Gauge shows empty tank.


At a high fuel level in fuel tank, resistance is high. Gauge shows full tank.

The HEADER HEIGHT GAUGE receives signals from potentiometer (R4) on feeder house.

Display of GRAIN LOSS GAUGE is controlled by harvest performance monitor (A4).

ZX, TMXZCO002413-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 5**



ZX012579

-UN-26MARS8

ZX012579

**B4** —Coolant temperature sending unit  
**B11**—Fuel tank sending unit  
**B12**—Horn  
**F24**—Fuse, 7.5 amps.


**P1** —Coolant temperature gauge  
**P2** —Fuel gauge  
**P3** —Header height gauge  
**P5** —Grain loss indicator

**P8** —Distributor gauge  
**X44**—Disconnect point, cab harness (W2), rear basic harness (W9)

**X62**—Disconnect point, rear basic harness (W9), engine harness (W12/W13)

ZX, TM4543010318-19-30JUN97

DIAGNOSTIC SCHEMATIC OF SECTION 5



ZX012449







## Group 15F Chopper Distributor Adjustment

### OPERATIONAL INFORMATION

With separator engaged, it is possible to distribute chopped material to the right or left by repositioning distributor plates. Gauge (B) shows direction of material distribution.

- A—Chopper distributor switch
- B—Chopper distributor gauge



ZX 004015

ZX, TMXZC0002416-19-25NOV92

ZX004015  
-UN-28APR95

### THEORY OF OPERATION

Switch (S54) is supplied with current via wire (202) (depending on position of separator switch) and via fuse (F15). Ground connection is also established by means of switch (S54).


Rotating direction of electric motor (M13) depends on position of switch (S54).

An internal mechanical slip clutch prevents overloading of the system.

Gauge (P8) is controlled by potentiometer (R14) integrated in electric motor.

ZX, TMXZC0002417-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 6**



ZX012580

ZX012580 -JUN-26MARS88

A15 —Fuse board  
 F15 —Fuse, 15 amps.  
 M13 —Distributor adjusting motor  
 R14 —Potentiometer  
 S54 —Switch, distributor adjustment


X22 —Disconnect point, rear basic harness (W9), chopper harness (W25)  
 X27 —Disconnect point, distribution harness (W1), cab harness (W2)

X38 —Disconnect point, cab harness (W2), switch console harness (W14)  
 X49 —Disconnect point, cab harness (W2), corner post harness (W4)

X118—Connection, cab harness to fuse board

ZX,TMXZCO002418-19-30JUN97

**DIAGNOSTIC SCHEMATIC OF SECTION 6**



ZX012450

ZX012450 -UN-11MAR98

ZX, TMXZCO003127-19-30JUN97



## Group 15G Windshield Wiper/Washer System


### OPERATIONAL INFORMATION

With starter switch in position (I), windshield wiper/washer may be switched on by actuating switches (A) or (B).

Windshield wiper switch (A) is a tumbler/rocker switch, for one-cycle or continuous wiper operation.

Windshield washer rocker switch (B) can be actuated regardless of position of switch (A).

Cab, grain tank and straw hood lighting are located in the same circuit.



**ZX004091**

ZX004091 -UN-28APR95

ZX.TMXZCO002420-19-25NOV92

### THEORY OF OPERATION

With starter switch in position (I), current is supplied to switches (S20) and (S21) via fuse (F36).


Windshield wiper will operate in wiper switch position (I) or (II). Position (I) is for one-cycle operation, position (II) for continuous operation.

After shutting off windshield wiper, wiper motor (M3) will automatically return it to "park" position.

Switch (S21) activates the windshield washer pump.

ZX.TMXZCO002421-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 7**



**SE7**  
**LIGHTING, WINDSHIELD WASHER**


ZX004016

ZX004016 -UN-02MAY95

- |                            |  |   |   |
|----------------------------|--|---|---|
| A15—Fuse board             | S14—Grain tank lighting switch                     | X25—Disconnect point, distribution harness — cab harness      | X44—Disconnect point, cab harness — rear basic harness        |
| E10—Grain tank lighting    | S20—Windshield wiper switch                        | X43—Disconnect point, rear basic harness — straw hood harness | X48—Disconnect point, rear basic harness — grain tank harness |
| E12—Cab interior lighting  | S21—Windshield washer switch                       |   |   |
| E17—Straw hood lighting    | X18—Connection, fuse board to distribution harness |   |   |
| F36—Fuse, 15 amps.         |  |   |   |
| M3—Windshield wiper motor  |  |   |   |
| M11—Windshield washer pump |  |   |   |

ZX.TMXZCO002422-19-25NOV92

DIAGNOSTIC SCHEMATIC OF SECTION 7



ZX004017





### **OPERATIONAL INFORMATION**

With starter switch in position (I), display of digital clock will light up. When parking lights are switched on, display is dimmed by 50%.

At the same time the radio, citizen band or interior light may be switched on with starter switch in position (I).

ZX,TMSPFH001734-19-22FEB92

### **THEORY OF OPERATION**

With starter switch in position (I), power is supplied to radio (A12) and citizen band (A13) via fuse (F22), allowing the operator to switch on these components.

Digital clock, radio and citizen band are continuously supplied with current via fuse (F18).


Display of digital clock (P7) will light up.

*NOTE: Connection from line (075) to relay (K46) in Section 32 applies only in the case of the 2054 combine.*

When current is supplied to digital clock via wire (103) (with lights switched on), display is dimmed by 50%.

ZX,TMXZCO006479-19-15MAR96

**FUNCTIONAL SCHEMATIC OF SECTION 8**



ZX004018

-UN-02MAY95  
ZX004018

A12—Radio  
A13—Citizen band  
A15—Fuse board  
F18—Fuse, 7.5 amps.

F22—Fuse, 7.5 amps.  
P7—Digital clock  
X2—Disconnect point, radio (USA)

X18—Connection, fuse board to distribution harness  
X25—Disconnect point, distribution harness — cab harness

X117—Connection, fuse board to distribution harness

ZX, TMXZCO006554-19-15MAR96





# Group 15L Cigarette Lighter, Seat Compressor


## OPERATIONAL INFORMATION

The machine is equipped with sockets for auxiliary equipment which are powered with starter switch in position (II).

When the machine is equipped with an air-cushioned seat, the seat compressor is connected to socket (X104) located inside cab.

ZX, TMXZCO002427-19-25NOV92

## FUNCTIONAL SCHEMATIC OF SECTION 11



ZX004033

-UN-02MAY95


ZX004033

- A15 — Fuse board
- E9 — Cigarette lighter
- F49 — Fuse 15 amps.
- X18 — Connection, main distribution harness (W1) to fuse board
- X25 — Disconnect point, main distribution harness (W1), cab harness (W2)

- X35 — Disconnect point, cab harness (W2), armrest harness (W5)
- X37 — Disconnect point, cab harness (W2), switch console harness (W3)
- X45 — Disconnect point, cab harness (W2), rear basic wiring harness (W9)
- X67 — Socket
- X68 — Socket
- X104 — Socket

ZX, TMXZCO002428-19-13MAY93

**DIAGNOSTIC SCHEMATIC OF SECTION 11**



ZX004034

ZX, TMXZC0002743-19-13MAY93

ZX004034 -JUN-02MAY95



## OPERATIONAL INFORMATION


In position (II) of dual-stage, double contact switch (S13), parking lights are switched on and in position (III) full or low-beam headlights.

Parking lights can be switched on regardless of starter switch position.

To switch on full or low-beam headlights, starter switch must be in position (I) or (II).

When parking lights are switched on, switch and instrument lighting is also switched on. At the same time, infotrak monitor and digital clock displays are dimmed.

- I—Light functions off
- II—Parking lights, switch and instrument lighting
- III—Low-beam headlights, only with starter switch positions (I) or (II)



ZX.TMXZCO002429-19-25NOV92

ZX000394 -JUN-04MAY95

## THEORY OF OPERATION

Light switch (S13) is a dual-stage, double contact switch.

The first contact is used for parking lights and instrument lighting, the second contact for low/full-beam headlights.

The parking light system is divided into three circuits which are protected individually.


One circuit is provided for left-hand parking lights, one for right-hand parking lights and another circuit for switch and instrument lighting.

The low/full-beam headlight circuit is connected to the starter switch.

In light switch position (III), low- or full-beam headlights are switched on, depending on position of low/full-beam headlight switch.

ZX.TMXZCO002430-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 12**



- |   |   |   |
|---|---|---|
| <p>E1 —Headlight, l.h.<br/>                 E2 —Headlight, r.h.<br/>                 E13 —Tail light, l.h.<br/>                 E14 —Tail light, r.h.<br/>                 E15 —Clearance light, l.h.<br/>                 E16 —Clearance light, r.h.<br/>                 E22 —Registration plate light<br/>                 E23 —Clearance light, header, l.h.<br/>                 E24 —Clearance light, header, r.h.<br/>                 F9 —Fuse 7.5 amps.<br/>                 F10 —Fuse 7.5 amps.<br/>                 F17 —Fuse 7.5 amps.<br/>                 F25 —Fuse 7.5 amps.<br/>                 F32 —Fuse 7.5 amps.<br/>                 F44 —Fuse 7.5 amps.<br/>                 F50 —Fuse 7.5 amps.<br/>                 H33 —Full-beam indicator light<br/>                 S13 —Light switch</p> | <p>S49 —Full-beam switch<br/>                 X15 —Trailer socket<br/>                 X17 —Connection, main distribution harness (W1) to fuse board<br/>                 X18 —Connection, main distribution harness (W1) to fuse board<br/>                 X21 —Disconn. point, feeder house harness (W10), header harness (W22)<br/>                 X25 —Disconn. point, main distribution harness (W1), cab harness (W2)<br/>                 X26 —Disconn. point, main distribution harness (W1), cab harness (W2)<br/>                 X37 —Disconn. point, cab harness (W2), switch console harness (W3)<br/>                 X38 —Disconn. point, cab harness (W2), optional equipment harness (W14)</p> | <p>X43 — Disconn. point, rear basic harness (W9), straw hood harness (W20)<br/>                 X45 — Disconn. point, cab harness (W2), rear basic harness (W9)<br/>                 X46 — Disconn. point, cab harness (W2), front basic harness (W7)<br/>                 X65 — Disconn. point, front basic harness (W7), steering column harness (W8)<br/>                 X77 — Disconn. point, front basic harness (W7), feeder house harness (W10)<br/>                 X101 — Disconn. point, header harness (W22), header lighting harness (W32)<br/>                 X117 — Connection, main distribution harness (W1) to fuse board<br/>                 X118 — Connection, main distribution harness (W1) to fuse board</p> |
|---|---|---|

ZX004031

ZX.TMXZCO002431-19-13MAY93







## **OPERATIONAL INFORMATION**

When driving on public roads, use turn signal switch to indicate direction of machine travel.

switch regardless of starter switch position (hazard warning light function).

In emergency situations both turn signal lights can be switched on by means of the hazard warning light

ZX.TMXZCO002432-19-25NOV92

## **THEORY OF OPERATION**

### **TURN SIGNAL LIGHTS**

Power is supplied to terminal (49) of flasher via fuse (F20) and hazard warning light switch (S11). Terminal (31) establishes ground connection.

When actuating turn signal switch (S12), current flows to the right or left-hand turn signal lights. Flasher (K5) generates the required flashing frequency and activates the corresponding turn signal indicator light via terminal (C2) or (C3).


### **HAZARD WARNING LIGHTS**

With hazard warning light switch (S11) in position (I), power is supplied to terminal (49) of flasher via fuse (F34) regardless of starter switch position.

At the same time the turn signal lights on both sides of the machine are connected to terminal (49A) of flasher. This generates the required flashing frequency.

ZX.TMXZCO002433-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 13**



SE 13  
FLASHER FUNCTION

ZX004035

-UN-02MAY95  
ZX004035

- |                                   |   |  |   |
|-----------------------------------|---|--|---|
| A14—Relay and diode board         | H34—Turn signal indicator light 1, combine                | X14—Connection, cab harness (W2) to relay and diode board            | X31—Soldered connection on board                                      |
| A15—Fuse board                    | H35—Turn signal indicator light 2, trailer                | X15—Trailer socket   | X43—Disconn. point, rear basic harness (W9), straw hood harness (W20) |
| F20—Fuse 7.5 amps.                | H41—Turn signal light, header, l.h.                       | X17—Connection, main distribution harness (W1) to fuse board         | X45—Disconn. point, cab harness (W2), rear basic harness (W9)         |
| F34—Fuse 15 amps.                 | H42—Turn signal light, header, r.h.                       | X21—Disconn. point, feeder house harness (W10), header harness (W22) | X46—Disconn. point, cab harness                                       |
| H13—Turn signal light, rear l.h.  | K5—Flasher  | X25—Disconn. point, main distribution harness (W1), cab harness (W2) |   |
| H14—Turn signal light, rear r.h.  | S11—Hazard warning light switch                           | X26—Disconn. point, main distribution harness (W1), cab harness (W2) |   |
| H15—Turn signal light, front l.h. | S12—Turn signal switch                                    |  |   |
| H16—Turn signal light, front r.h. | X13—Connection, cab harness (W2) to relay and diode board |  |   |
| H17—Add. turn signal light, l.h.  |   |  |   |
| H18—Add. turn signal light, r.h.  |   |  |   |

ZX.TMXCO002434-19-13MAY93





### **OPERATIONAL INFORMATION**

With starter switch in position (I) or (II) the revolving hazard warning lights may be switched on by means of switch (S18).

ZX.TMXZCO002435-19-25NOV92

### **THEORY OF OPERATION**


With starter switch in position (I) or (II), switch (S18) is powered via fuse (F35).

current. The revolving motion is accomplished by means of an electric motor.

If switch (S18) is activated, revolving hazard warning lights (H21) and (H36) are directly supplied with

ZX.TMXZCO002436-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 14**



ZX012581

-UN-26MARS8  
ZX012581

A15—Fuse board  
 F35—Fuse 15 amps.  
 H21—Beacon light  
 H36—Beacon light  
 K48—Relay, grain tank gauge

S18—Beacon light switch  
 V65—Diodes, grain tank gauge  
 X17—Connection, main distribution harness (W1) to fuse board


X25—Disconn. point, main distribution harness (W1), cab harness (W2)

X44—Disconn. point, cab harness (W2), basic harness (W9)

ZX, TM4543009713-19-30JUN97



**DIAGNOSTIC SCHEMATIC OF SECTION 14**



ZX012451

-UN-11MAR98

ZX012451

ZX.TM4543009714-19-30JUN97



## Group 15P Fan, Air Conditioning System

### OPERATIONAL INFORMATION


With starter switch in position (I) or (II) fan may be switched on by means of rotary switch (A).

Fan can be adjusted to four speeds.


With fan running, the air conditioning system can be adjusted to the desired temperature by means of rotary switch (B).

Even if air conditioning system is switched off at rotary switch (B) (e.g. switch turned to heating position), it can be switched on to maximum output by means of switch (C).

*NOTE: The above combination is used, for example, to reduce moisture content of cab air when windows are misted.*



ZX 000962



ZX 000963

ZX.TMXZCO002438-19-25NOV92

ZX000962 -UN-02MAY95

ZX000963 -UN-28APR95

### THEORY OF OPERATION

With starter switch in position (I) or (II), switch (S22) is supplied with current via fuse (F42).

Fan (M4) can be adjusted to four speeds by means of resistor (R1).

As soon as rotary switch (S22) is turned to position (I) or further, switch (S25) is supplied with current.

Either air conditioning system or heater can be switched on by means of switch (S25).

In neutral position or when heater is switched on, the contact of switch (S25) is in "0" position. Thus


switch (S52) is supplied with current, making it possible to switch air conditioning system to maximum output.

With air conditioning system switched on by means of switch (S25), electromagnetic clutch (Y33) is activated via thermostat (B9), low pressure switch (B14) and high pressure switch (B15).

If pressure in air conditioning system is too high, high pressure switch (B15) is activated and the corresponding indicator light in SE10 will glow.

ZX.TMXZCO002439-19-25NOV92

FUNCTIONAL SCHEMATIC OF SECTION 15




-JUN-02MAY95  
ZX004039

ZX004039

- |   |  |   |   |
|---|--|---|---|
| A15—Fuse board                              | F42—Fuse 30 amps.  | X26—Disconn. point, main distribution harness (W1), cab harness | X62—Disconn. point, rear basic harness (W9), engine harness (W12/W13)       |
| B9—Thermostat (protection against freezing) | M4—Cab fan   | X37—Disconn. point, cab harness (W2)                            | X66—Disconn. point, cab harness (W2), air conditioning and fan harness (W6) |
| B13—Temperature switch, air conditioning    | R1—Fan resistor  |   |   |
| B14—Low pressure switch, air conditioning   | S22—Fan switch   |   |   |
| B15—High pressure switch, air conditioning  | S25—Air conditioning switch                                  |   |   |
|   | S52—Demoisturizer switch                                     |   |   |
|   | X18—Connection, main distribution harness (W1) to fuse board |   |   |

ZX, TMXZC0002440-19-13MAY93

DIAGNOSTIC SCHEMATIC OF SECTION 15



ZK004040




## Group 15Q Electrical Mirror Adjustment

### OPERATIONAL INFORMATION

For mirror adjustment starter switch must be turned to position (I) or further.

Move mirrors up/down or to the right/left according to arrows on switch.

- I—Adjusting l.h. outside mirror
- II—Adjusting r.h. outside mirror




ZX 002452

ZX, TMXZCO002441-19-25NOV92

ZX002452 -UN-28APR95

Switching on mirror heater is only possible with starter switch turned to position (I) or further.

- I—Mirror heater off
- II—Mirror heater on



ZX 002451

ZX, TMXZCO002442-19-25NOV92

ZX002451 -UN-28APR95

### THEORY OF OPERATION


Mirror heater switch (S65) and mirror adjusting switch (S64) are powered via fuse (F37).

Turn mirror adjusting switch knob to select mirror to be adjusted. Mirror adjustment is carried out by tilting

switch to the right/left or up/down. This will reposition mirror surface by activating electric motors integrated in mirror housing.

ZX, TMXZCO002443-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 16**



**SE16**  
**REAR VIEW MIRROR ADJUSTMENT**

ZX004041

-UN-02MAY95  
ZX004041

A15—Fuse board  
F37—Fuse 7.5 amps.  
S64—Mirror adjusting switch  
S65—Mirror heater switch


X18—Connection, main distribution harness (W1) to fuse board  
X25—Disconn. point, main distribution harness (W1), cab harness (W2)

X97—Disconn. point, cab harness (W2), harness for electrical mirror adjustment (W39)

ZX, TMXZC0002444-19-13MAY93



**DIAGNOSTIC SCHEMATIC OF SECTION 16**



ZX,TMXCC0002748-19-13MAY93

ZX004042 -JUN-02MAY95



### OPERATIONAL INFORMATION

With parking lights on, the work lights on cab roof and unloading auger may be switched on by actuating switch (S19).

With road safety switch in field position, work lights on mirror arms, straw hood and operator's platform may also be switched on.

ZX, TMXZCO002445-19-25NOV92

### THEORY OF OPERATION


With parking lights switched on, switch (S19) is supplied with current via wire (103).

When switch (S19) is activated, relay (K7) is also activated and thus cab roof and unloading auger work lights are switched on directly.

Work lights on operator's platform, mirror arms and straw hood may be switched on in any starter switch position by means of switch (S48), depending on position of road safety switch, even if parking lights are not switched on.

ZX, TMXZCO002446-19-25NOV92

FUNCTIONAL SCHEMATIC OF SECTION 17




-UN-02MAY95  
ZX004043

ZX004043

- |                                    |  |   |   |
|------------------------------------|--|---|---|
| A15—Fuse board                     | E18—Platform work light, r.h.  | X27—Disconn. point, main distribution harness (W1), cab harness (W2)  | X45—Disconn. point, cab harness (W2), rear basic harness (W9)         |
| E3—Rear work light                 | E19—Platform work light, l.h.  | X29—Splice  | X46—Disconn. point, cab harness (W2), front basic harness (W7)        |
| E4—Cab roof work light, outer r.h. | E25—Work light, mirror bracket                                       | X43—Disconn. point, rear basic harness (W9), straw hood harness (W20) | X48—Disconn. point, rear basic harness (W9), grain tank harness (W15) |
| E5—Cab roof work light, inner r.h. | E26—Work light, mirror bracket                                       | X44—Disconn. point, cab harness (W2), rear basic harness (W9)         |   |
| E6—Cab roof work light, outer l.h. | X18—Connection, main distribution harness (W1) to fuse board         |   |   |
| E7—Cab roof work light, inner l.h. | X25—Disconn. point, main distribution harness (W1), cab harness (W2) |   |   |
| E8—Unloading auger work light      |  |   |   |

ZX.TMXCO002447-19-13MAY93

**DIAGNOSTIC SCHEMATIC OF SECTION 17**



ZX004044

ZX, TMXCO002749-19-31MAY95



## Group 15S Straw Warning Device

### OPERATIONAL INFORMATION

The straw warning device is provided to detect plugging of material in the entire straw walker area. The first sensor is located in front of the cross shaker, the second one behind the cross shaker and the third one above the straw chopper.

When plugging of material occurs, the "STOP" light of the indicator light unit will glow. In addition the buzzer and horn will sound.

ZX.TMXZCO002448-19-25NOV92

### THEORY OF OPERATION

Horn (B12) is continuously supplied with current via fuse (F27).

When actuating switch (S8), the horn is connected to ground and the horn signal will be heard.


With starter switch in position (I), relays (K6) and (K22) are supplied with current via fuse (F14). Switches (S15), (S16) and (S17) are in "OFF"

position (closed). This causes relay (K6) to open and relay (K22) to close, interrupting ground connection to horn, buzzer and indicator light.

If one of the switches (S15), (S16) or (S17) is actuated due to excessive straw accumulation in the straw hood, relay (K6) establishes ground connection to horn, buzzer and indicator light.

ZX.TMXZCO002449-19-25NOV92

**FUNCTIONAL SCHEMATIC OF SECTION 18**



ZX004045

-UN-02MAY95  
ZX004045

- A14—Relay and diode board
- A15—Fuse board
- B12—Horn
- F14—Fuse 7.5 amps.
- F27—Fuse 15 amps.
- K6—Relay, straw warning device
- K22—Relay, straw warning device
- S8—Horn button
- S15—Switch, straw warning device (cross shaker)
- S16—Switch, straw warning device (walkers)


- S17—Switch, straw warning device (chopper)
- X12—Connection, cab harness (W2) to relay board
- X17—Connection, main distribution harness (W1) to fuse board
- X18—Connection, main distribution harness (W1) to fuse board

- X25—Disconn. point, main distribution harness (W1), cab harness (W2)
- X27—Disconn. point, main distribution harness (W1), cab harness (W2)
- X43—Disconn. point, rear basic harness (W9), straw hood harness (W20)
- X45—Disconn. point, cab harness (W2), rear basic harness (W9)

- X46—Disconn. point, cab harness (W2), front basic harness (W7)
- X49—Disconn. point, cab harness (W2), corner post harness (W4)
- X65—Disconn. point, front basic harness (W7), steering column harness (W8)



**DIAGNOSTIC SCHEMATIC OF SECTION 18**



ZX004046

ZX.TMXZCO002750-19-13MAY93

ZX004046 -JUN-02MAY95



## Group 15T Reel Speed Adjustment

### OPERATIONAL INFORMATION


Reel height, reel horizontal position and reel speed may be adjusted for best performance according to harvesting conditions. A variable drive controlled by an electric motor permits infinite reel speed adjustment within a certain range.

The reel speed adjusting motor can be activated by a switch in the cab or by the reel speed control system.

*NOTE: Diodes (V62) and (V63) are installed only in conjunction with motor (M14).*

ZX.TMXZCO005146-19-15MAR96

Depending on position of double sprocket (C), reel speed may be adjusted within a range of 14—30 rpm [this equals 3.2—6.8 km/h (2—4.2 mph)] or 23—50 rpm [5.2—10.8 km/h (3.2—6.7 mph)].



ZX.TMXZCO002511-19-01DEC92

The reel speed control system activates the electric motor which controls variable reel drive. In this case the following adjusting ranges are also obtained:  
14—30 rpm [this equals 3.2—6.8 km/h (2—4.2 mph)]  
or 22—50 rpm [5.2—10.8 km/h (3.2—6.7 mph)].

*NOTE: The reel speed control system will only operate within a ground speed range from 1.2 km/h (0.75 mph) to 10 km/h (6 mph).*

ZX.TMXZCO002512-19-01DEC92

## THEORY OF OPERATION

With starter switch in position (I) or (II), current is supplied to switch (S10) and reel speed control system (A1).


Stop light switch (S7) is also supplied with current.

When actuating switch (S10), relay (K32) or (K33) is activated. This will increase or reduce reel speed.

ZX, TMXZCO002513-19-01DEC92

With header running (wire 289 powered), a diagnostic mode is activated when turning speed ratio switch (potentiometer) (S9) to first position. The other switch positions will provide various reel speed ratios.

The speed ratio switch (S9) is connected to reel speed control system (A1) by means of four wires, providing 13 possible switch positions.



ZX, TMXZCO002521-19-25NOV92

## POSITIONS OF SPEED RATIO SWITCH S9

BIT	OFF	TEST	0.80	1.00	1.10	1.15	1.20	1.25	1.30	1.50	1.80	2.00	2.20
1	0	X	0	X	0	X	0	X	0	X	0	X	0
2	0	X	X	0	0	X	X	0	0	X	X	0	0
3	0	X	X	X	X	0	0	0	0	X	X	X	X
4	0	X	X	X	X	X	X	X	X	0	0	0	0

NOTE: (X) means that the corresponding switch connection is grounded.

ZX, TMXZCO002522-19-25NOV92

## **DIAGNOSTIC MODE**

The program of the reel speed control system provides a diagnostic mode. In this mode input and output signals of the system are tested.

### **Diagnostic Procedure:**

1. Move micro switch 1 to "ON" position (switches 2 to 5 are already "ON").
2. Move speed ratio switch (S9) to "OFF" position.
3. Start engine; engage separator and header.
4. Drive combine with a speed of 5.5 km/h (3.5 mph).
5. At a ground speed of 5.5 km/h (3.5 mph) move speed ratio switch (S9) to test position.
6. Continue to drive combine with an exact speed of 5.5 km/h (3.5 mph) for 30 seconds.
7. Stop combine. Keep separator and header running. Read error displays at LED's.

ZX, TMXZC0002523-19-25NOV92

## ERROR CODE DISPLAY

0 — LED off

X — LED on

Error Code	Problem	Solution
A—0 B—0 C—0 D—0	No voltage	Check fuse (F12)
A—X B—0 C—0 D—0	No ground speed signal	Check sending unit on 3-speed transmission
A—0 B—X C—0 D—0	Ground speed signal not within operating range	See "Operating Range of Reel Speed Control System" in "Controls and Instruments" Section of Operator's Manual
A—X B—X C—0 D—0	No reel speed signal	Check sending unit at cutting platform
A—0 B—0 C—X D—0	Reel speed signal not within operating range	See "Operating Range of Reel Speed Control System" in "Controls and Instruments" Section of Operator's Manual
A—X B—0 C—X D—0	Error "Bit 1" at reel speed control switch	
A—0 B—X C—X D—0	Error "Bit 2" at reel speed control switch	
A—X B—X C—X D—0	Error "Bit 3" at reel speed control switch	
A—0 B—0 C—0 D—X	Error "Bit 4" at reel speed control switch	

ZX, TMXZCO002514-19-01DEC92

**ERROR CODE DISPLAY (CONTINUED)**


0 — LED off  
X — LED on

Error Code	Problem	Solution
A—X B—0 C—0 D—X	Option A, output 1 shorted to ground	
A—0 B—X C—0 D—X	Option A, output 2 shorted to ground	
A—X B—X C—0 D—X	Reel does not accelerate	
A—0 B—0 C—X D—X	Reel does not slow down	
A—X B—0 C—X D—X	Reel speed control switch not in diagnostic position	See "Reel Speed Control Switch" in "Controls and Instruments" Section of Operator's Manual
A—0 B—X C—X D—X	Fault not found	
A—X B—X C—X D—X	All contacts to reel speed control switch open	

ZX, TMXZCO002515-19-01DEC92

## OPERATING ADJUSTMENT OF MICRO SWITCHES

During normal operation, micro switch 1 on board of reel speed control system is in "OFF" position, while switches 2 to 5 are in "ON" position.




ZX, TMXZC0002516-19-01DEC92

ZX004060 -UN-24A PR95



FUNCTIONAL SCHEMATIC, SECTION 19




-JUN-02MAY95  
ZX004054

- |  |  |   |   |
|--|--|---|---|
| <p>A1—Reel speed control<br/>                 A14—Relay and diode board<br/>                 A15—Fuse board<br/>                 B5—Sending unit, reel speed<br/>                 F12—Fuse 15 amps.<br/>                 H43—Stop light, l.h.<br/>                 H44—Stop light, r.h.<br/>                 K32—Relay, adjust reel speed<br/>                 K33—Relay, adjust reel speed<br/>                 M2—Reel speed adjusting motor<br/>                 M14—Reel speed adjusting motor<br/>                 S7—Stop light switch</p> | <p>S9—Potentiometer, reel speed<br/>                 S10—Reel speed switch<br/>                 X10—Connection, cab harness (W2) to relay board<br/>                 X11—Connection, cab harness (W2) to relay board<br/>                 X17—Connection, main distribution harness (W1) to fuse board<br/>                 X21—Disconn. point, feeder house harness (W10), header harness (W22)</p> | <p>X23—Disconn. point, cab harness (W2), front basic harness (W7)<br/>                 X25—Disconn. point, main distribution harness (W1), cab harness (W2)<br/>                 X28—Disconn. point, main distribution harness (W1), cab harness (W2)<br/>                 X35—Disconn. point, cab harness (W2), armrest harness (W5)<br/>                 X38—Disconn. point, cab harness (W2), optional equipment harness (W14)</p> | <p>X43—Disconn. point, rear basic harness (W9), straw hood harness (W20)<br/>                 X45—Disconn. point, cab harness (W2), rear basic harness (W9)<br/>                 X46—Disconn. point, cab harness (W2), front basic harness (W7)<br/>                 V62—Diode<br/>                 V63—Diode</p> |
|--|--|---|---|

ZX, TMXCO005147-19-15MAR96

DIAGNOSTIC SCHEMATIC, SECTION 19



ZK005377

## **OPERATIONAL INFORMATION**

The ground pressure once adjusted by the operator on 900 Series cutting platforms will be kept constant by the DIAL-A-MATIC™.

Three different ground pressures can be preselected by means of the rotary switch on switch console.

By raising cutting platform manually the DIAL-A-MATIC™ is switched off. It is actuated again by lowering the platform manually (even for a short period of time only).

ZX, TMXZCO002752-19-13MAY93

## **THEORY OF OPERATION**

Rotary switch (S23) in switch console is supplied with current via fuse (F43). By moving switch (S23) to positions 1, 2 or 3, electronic box (A2) and sending unit at cutting platform (S66) are supplied with current.

This preselection via switch determines which of the three center contacts in sending unit (S66) is without connection to electronic box (A2).

The contact revolving in relation to cutting platform ground pressure transmits a signal to the electronic control box (A2) until the revolving contact reaches the stationary contact without connection to electronic control box (A2).


The input signal is converted in the electronic control box (A2) and used for raising and lowering cutting platform (via wires 238 and 239).

ZX, TMXZCO002753-19-13MAY93

## TESTING THE DIAL-A-MATIC

DIAL-A-MATIC test can be carried out by bridging various terminals at connection (X4) to cutting platform. Proceed as follows:

1. Run engine at fast idle.
2. Move road safety switch to field position. Engage separator drive.


 **CAUTION: It is possible during DIAL-A-MATIC test that feeder house moves up or down. DANGER OF ACCIDENTS.**

3. Move rotary switch (S23) in switch console to position 1,2 or 3 and press switch for a short period of time to lower cutting platform.
4. Check according to the following chart by bridging connection terminals.

CONNECTION X4	SWITCH POSITION			FEEDER HOUSE
	1	2	3	
Bridge contacts	4—5	4—5, 6	4—5, 6, 1	Feeder house rising
Bridge contacts	4—6	4—1	4—2	Feeder house not moving
Bridge contacts	4—1, 2, 3	4—2, 3	4—3	Feeder house lowering

ZX, TMXZCO002754-19-13MAY93

**FUNCTIONAL SCHEMATIC OF SECTION 20**



ZX004056

ZX004056 -JUN-02MAY95

A2—Electronic box  
DIAL-A-MATIC  
A15—Fuse board  
F43—Fuse 7,5A  
S23—DIAL-A-MATIC switch  
S66—DIAL-A-MATIC sending  
unit  
X18—Connection main  
distribution harness  
(W1) to fuse board


X21—Disconnect point feeder  
house harness (W10),  
cutting platform  
harness (W22)  
X23—Disconnect point front  
basic wiring harness  
(W7)-cab wiring  
harness (W2)

X27—Disconnect point main  
distribution harness  
(W1)-cab wiring  
harness (W2)  
X38—Disconnect point cab  
wiring harness (W2),  
optional equipment  
wiring harness (W14)

X52—Connection main  
distribution harness  
(W1)-electronic box  
DIAL-A-MATIC

ZX.TMXZCO002755-19-13MAY93

DIAGNOSTIC SCHEMATIC OF SECTION 20



ZX012452

## OPERATIONAL INFORMATION

By moving road safety switch to field position all hydraulic functions (including all hillmaster functions) can be used. At the same time fan in front of radiator is rotating.

Now separator and rear work lights can be switched on as well.

A safety device prevents the separator from being switched on when road safety switch is moved to field position.

With separator engaged, harvesting unit can be engaged as well.

A similar safety device prevents that the harvesting unit is engaged at the same time separator is switched on.

ZX, TMXZC0002757-19-13MAY93

## THEORY OF OPERATION

With engine running, the road safety switch is supplied with current from terminal (D+) of alternator via fuse (F48). When switching to field position, relay (K12) is activated and wire (222) is supplied with current.

With switch (S33) in neutral position, relay (K21) has been activated. When separator drive is engaged, relay (K21) is kept in position and wire (202) is supplied with current.

Solenoids (Y22) and (Y23) are now supplied with current via fuse (F23). The hydraulic cylinder activated by the solenoids tensions the separator drive V-belt.

Harvesting unit is basically engaged in the same way as the separator.


The time delay relay integrated in the circuit is not used. Harvesting unit is directly engaged and disengaged via switch (S34).

Actuating emergency cut-off switch interrupts the input signal of wire (198) to time delay relay. Wire (289) is without current supply and harvesting unit drive is interrupted by the electromagnetic clutch.

*NOTE: Interruption of wire 259 or connection of terminal (S) to ground causes harvesting unit to be disengaged 5 seconds after engagement. Switch (S45) prevents the disengagement of the electric clutch for the feeder house drive.*

ZX, TM4543009572-19-30JUN97

FUNCTIONAL SCHEMATIC OF SECTION 21




- |   |   |   |  |
|---|---|---|--|
| A14 —Relay and diode board                    | V2 —Diode, pressure switch                                      | X24 —Conn.solenoid valve block  | X37 —Disconn. point cab harness (W2)-switch console harness (W3)       |
| A15 —Fuse board                               | X10 —Connection cab harness (W2)-relay board                    | X25 —Disconnect point main distribution harness (W1)-cab harness (W2) | X44 —Disconnect point cab harness (W2)-rear basic harness (W9)         |
| F19 —Fuse 30A                                 | X11 —Connection cab harness (W2)-relay board                    | X26 —Disconn. point main distribution harness (W1)-cab harness (W2)   | X45 —Disconnect point cab harness (W2)-rear basic harness (W9)         |
| F21 —Fuse 15A                                 | X12 —Connection cab harness (W2)-relay board                    | X28 —Disconnect point main distribution harness (W1)-cab harness (W2) | X62 —Disconnect point rear basic harness (W9)-engine harness (W12/W13) |
| F23 —Fuse 15A                                 | X17 —Connection main distribution harness (W1)-fuse board       | X35 —Disconnect point cab harness (W2)-armrest harness (W5)           | X117 —Conn. main distribution harness (W1)-fuse board                  |
| K12 —Relay, field operation-road travel       | X18 —Connection main distribution harness (W1)-fuse board       | X36 —Conn. master control lever-armrest harness (W5)                  | Y22 —Solenoid,engage separator   |
| K21 —Relay, separator clutch                  | X23 —Disconnect point cab harness (W2)-front basic harness (W7) |   | Y23 —Solenoid,engage separator   |
| K35 —Time delay relay, cutting platform drive |   |   | Y34 —Harvesting unit clutch  |
| M12 —Radiator cleaner motor                   |   |   |  |
| S31 —Road safety switch                       |   |   |  |
| S33 —Separator drive switch                   |   |   |  |
| S34 —Harvesting unit drive switch             |   |   |  |
| S47 —Emergency cut-off switch                 |   |   |  |

ZX, TMXCO002759-19-13MAY93



### DIAGNOSTIC SCHEMATIC OF SECTION 21



ZK012453



## OPERATIONAL INFORMATION, INFOTRAK-MONITOR

With starter switch in position (I) the infotrak monitor is ready for operation.

The infotrak monitor is identical with the ones in other John Deere products.

By the input of certain specific machine data the infotrak monitor is adjusted to the combine's needs.

All important separator drives are monitored by the speed monitoring system for decreasing of speed. An optical and an acoustical signal indicate the operator if the speed drops below a certain level.

ZX,TMXZCO002761-19-13MAY93

## INPUT OF SPECIFIC MACHINE DATA

**IMPORTANT:** Each time different size drive wheels are installed or tire radius changes due to wear, the infotrak monitor must be calibrated accordingly. This will also ensure correct area counter operation.

### Activate Input Status

Press key combination (C + D) and simultaneously turn starter switch from position (0) to position (I). The position indicator will move to upper left-hand position.

### Data Input


Press key (C): displayed value will increase.  
Press key (E): displayed value will decrease.

### Data Storage

Press key combination (D + F). At the same time the position indicator will move to another field (upper right-hand, lower right-hand, lower left-hand field).

### Deactivate Input Status

After input and storage of all data, turn starter switch to position (0).



**ZX 002352**

- A—Position indicator
- B—Display panel
- C—Key for ground speed display
- D—Key for cylinder speed display
- E—Key for engine speed display
- F—Key for fan speed display


-UN-28APR95  
ZX002352

ZX,OMXZCO001834-19-14NOV92

### MACHINE CODE

Input code for mph:  
03 — Combine

Input code for km/h:  
23 — Combine



ZX 002483

ZX.OMXZCO001835-19-13APR92

-UN-28APR95  
ZX002483


### TRANSMISSION SPEED RATIO CODE

00 — Final drive (85/11)  
Z12231 (I)


01 — Final drive (97/11)  
Z12232 (II)

02 — Planetary final drive

I—Final drive 85/11  
II—Final drive 97/11



ZX 000 843



ZX 000 531

ZX.OMXZCO001836-19-13APR92


-UN-28APR95  
ZX000843

-UN-03MAY95  
ZX000531

### TIRE RADIUS CODE

For input of tire radius code, use actual tire radius. On machines with machine code 03 the radius must be keyed in in inches. On machines with machine code 23 the radius must be keyed in in millimeters.

*NOTE: Refer to the tire chart in the operator's manual (Section "Wheels and Axles") for tire radius. Radius can also be determined by proceeding according to the following instructions.*



ZX 000 532

ZX.TMXZCO002762-19-13MAY93

-UN-28APR95  
ZX000532

## DETERMINING TIRE RADIUS

### Requirements:

- Combine on solid ground
- Correct tire pressures
- Combine steering wheels in straight-ahead position

Mark tire and ground with dashes.


Drive combine until marked tire has completed one revolution.

Transfer tire mark to ground.

Measure distance (X) between ground marks.

Divide measured distance (X) by 6.28.

The value obtained is the tire radius for infotrak monitor input.



ZX 002484


ZX,OMXZC0001838-19-14NOV92

ZX002484 -JUN-28APR95

## ENGINE IMPULSE CODE

24 — 2254 combine

27 — 2256—2266 combines



ZX012635

ZX,OMXZC0001839-19-01APR98

ZX012635 -JUN-20AUG97

## ERROR CODES, INFOTRAK-MONITOR

As soon as the infotrak monitor displays a three digit number followed by an "E" a malfunction or error of the operator is indicated.

The cause of a machine malfunction may be a broken wire etc.

Error code	Problem	Solution
101E	Counter of engine operating hours in infotrak monitor is defective	Replace infotrak monitor
102E	Counter of working hours in infotrak monitor is defective	Replace infotrak monitor
122E	Concave adjustment impossible, Sensor signal in wrong range (too low)	Voltage between pin 4 and 9 on infotrak monitor not between 1 and 4 Volts, wire on potentiometer (R2) may not be correctly connected
123E	Concave adjustment impossible, Sensor signal in wrong range (too high)	Voltage between pin 4 and 9 on infotrak monitor not between 1 and 4 Volts, wire on potentiometer (R2) may not be correctly connected
128E	No reaction from infotrak monitor	Check data lines 268 and 269 for correct connection, malfunction of infotrak monitor possible
129E	No reaction from control board	Check data lines 268 and 269 for correct connection, possibly control board of machine computer defective
130E	Adjusting motor can not reduce fan speed to the desired rpm	Check fuses F3, F25
131E	Variator can not reduce cylinder speed to the desired rpm	Check fuse F3
132E	Adjusting motor can not reduce concave clearance to desired gap	Check fuse F41
135E	Adjusting motor can not increase fan speed to the desired rpm	Check fuses F3, F25
136E	Variator can not increase cylinder speed to the desired rpm	Check fuse F3
137E	Adjusting motor can not increase concave clearance to desired gap	Check fuse F41

ZX, TMXZCO002763-19-13MAY93

## OPERATIONAL INFORMATION, SPEED MONITORING SYSTEM

For better monitoring of drive systems the machines are equipped with a speed monitoring system.

The following speeds are monitored:

- Cylinder speed
- Fan speed

- Clean grain elevator
- Tailings elevator
- Cross shaker
- Straw chopper
- Chaff spreader

*NOTE: Cylinder and fan speeds are monitored via infotrak monitor.*

ZX, TMXZC0002764-19-13MAY93

## THEORY OF OPERATION

Impulse pick-up units are installed at tailings elevator, clean grain elevator, cross shaker, straw chopper and chaff spreader shafts. On the shafts magnet rings are attached which influence the impulse pick-up units.

If speed of one shaft drops to below 65% of rated shaft speed, the corresponding indicator light is connected to ground and the buzzer sounds.

If shaft speed exceeds 85% of the rated speed, the corresponding alarm is switched off again.


Shaft alarm speeds are:

Clean grain elevator	370 rpm
Tailings elevator	300 rpm
Cross shaker	210 rpm
Straw chopper	1730 rpm
Chaff spreader	130 rpm

*NOTE: If straw chopper or chaff spreader are disengaged, the additional switch (S24) or (S26) switches off the speed monitoring system for the shaft concerned.*

ZX, TMXZC0002765-19-13MAY93

FUNCTIONAL SCHEMATIC OF SECTION 22



SE22  
INFOTRAK MONITOR / SPEED MONITORING SYSTEM

ZX012438




## FUNCTIONAL SCHEMATIC OF SECTION 22

A3 —Electronic speed monitoring system	B30—Fan speed sending unit	X25—Disconnect point, main distribution harness (W1)-cab harness (W2)	X49—Disconnect point, cab harness (W2)-corner post harness (W4)
A14—Relay and diode board	K10—Relay, fan speed alarm	X27—Disconnect point, main distribution harness (W1)-cab harness (W2)	X50—Connection, main distribution harness(W1)-electronic speed monitoring system
A15—Fuse board	K11—Relay, cylinder speed alarm	X28—Disconnect point, main distribution harness (W1)-cab harness (W2)	X62—Disconnect point, rear basic harness (W9)-engine harness (W12/W13)
A18—Infotrak monitor	S24—Speed monitoring switch, straw chopper	X44—Disconnect point, cab harness (W2)-rear basic harness (W9)	X71—Disconnect point, rear basic harness (W9)-chaff spreader harness (W26)
B6 —Ground speed sending unit	X12—Connection, cab harness (W2)-relay and diode board	X45—Disconnect point, cab harness (W2)-rear basic harness (W9)	
B16—Straw chopper speed sending unit	X13—Connection, cab harness (W2)-relay and diode board	X46—Disconnect point, cab harness (W2)-front basic harness (W7)	
B17—Tailings elevator speed sending unit	X18—Connection, main distribution harness (W1)-fuse board		
B18—Cross shaker speed sending unit	X22—Disconnect point, rear basic harness (W9)-chopper harness (W25)		
B19—Clean grain elevator speed sending unit	X23—Disconnect point, cab harness (W2)-front basic harness (W7)		
B20—Chaff spreader speed sending unit			
B28—Engine speed sending unit			
B29—Cylinder speed sending unit			

ZX,TM4543010495-19-02AUG97

DIAGNOSTIC SCHEMATIC OF SECTION 22



## **OPERATIONAL INFORMATION**


Sensors are located at the end of the cleaning shoe and straw walkers which record the amount of grains falling on the sensor surface.

Ground speed is measured by sensor (F) and light conditions (day/night) and moisture by sensor (C). Once these factors have been taken into account, the loss rate is shown at display unit (D). Display unit (D) indicates the loss level in relation to the level that is acceptable to the user.

The performance monitor enables the operator to use maximum combine capacity within the performance range selected by him. After the operator has adjusted the combine and cutting platform to suit the harvesting conditions, he must set the monitor to these conditions by means of the adjusting/selecting unit (E).

ZX, TMXZCO003211-19-17JAN94

**HARVEST PERFORMANCE MONITOR**



ZX007939

A—Cleaning shoe sensor  
B—Straw walker sensors

C—Display unit

D—Adjusting/selecting unit

E—Ground speed sensor

ZX.OMXZCO001973-19-02MAY96

## OPERATIONAL ADJUSTMENT OF HARVEST PERFORMANCE MONITOR

While threshing, adjust potentiometers (A) and (B) so that needle of display unit (C) moves to the center of the green sector (X) at a given, accepted loss level.


I — Set potentiometer for straw walker losses:

- Move selector switch (D) to position (II).
- Use potentiometer (A) to bring the needle into the green sector (X).

II — Set potentiometer für cleaning shoe losses:


- Move selector switch (D) to position (III).
- Use potentiometer (B) to bring the needle into the green sector (X).

- A—Potentiometer, straw walker sensitivity
- B—Potentiometer, cleaning shoe sensitivity
- C—Display unit
- D—Selector switch
- X—Green sector




ZX 002570

-UN-08MAY95  
ZX002570



ZX 002571

-UN-08MAY95  
ZX002571




ZX 002572

-UN-08MAY95  
ZX002572

ZX, TMXZCO003186-19-17JAN94

**SETTING SENSOR SENSITIVITY**



ZX002568

-UN-09MAY95  
ZX002568

**A**—Switch for grain size setting at straw walker sensor

**B**—Switch for grain size setting at cleaning shoe sensor

**X**—Higher sensor sensitivity for fine grain crops  
**Y**—Medium sensor sensitivity for medium grain crops

**Z**—Lower sensor sensitivity for coarse grain crops

ZX,TMXZCO003212-19-17JAN94

## OPERATIONAL CHECK OF HARVEST PERFORMANCE MONITOR

**CAUTION:** Before carrying out the operational check, remove fuse F23. This prevents the separator from being engaged while at the same time ensuring that the harvest performance monitor is supplied with power.

Start the engine.  
Put road safety switch in field position.  
Move separator switch to ON position.

### I — Check straw walker sensors:



- Turn potentiometer (A) clockwise as far as it will go.
- Set selector switch (B) to position (II) (straw walkers).
- Rotary switch (C) should be in the medium position at both sides.
- Actuate the left and right straw walker sensors by tapping them lightly with a hard object or by dropping kernels on them. A second person is required to observe the needle at the display. The needle must be seen to move.

### II — Check cleaning shoe sensor:



- Turn potentiometer (D) clockwise as far as it will go.
- Set selector switch (B) to position (III) (cleaning shoe).
- Tumbler switch (E) should be in the middle position.
- Check cleaning shoe sensor in the same way as the straw walker sensors.
- Switch on the parking light and check whether the display light is on.
- Switch off the parking light. Disengage the separator and remove the switch key.
- If a fault occurs during the check described above, rectify the fault as necessary.

**NOTE:** Once the operational check is completed, put fuse F23 back in place.

- A—Potentiometer, straw walker sensitivity
- B—Selector switch
- C—Rotary switch
- D—Potentiometer, cleaning shoe sensitivity
- E—Tumbler switch



ZX002573




ZX002574

-UN-08MAY95  
ZX002573

-UN-08MAY95  
ZX002574

ZX,TMXZCO003213-19-17JAN94

**FUNCTIONAL SCHEMATIC OF SECTION 23**



ZX012439

ZX012439 -UN-11MAR98

ZX, TMXZCO003214-19-30JUN97



## FUNCTIONAL SCHEMATIC OF SECTION 23

A4 —Harvest performance monitor	B23—Cleaning shoe sensor (5 walkers)	X43—Disconnect point, rear basic harness (W9), straw hood harness (W20)	X87—Splice
A15—Fuse board	B24—Cleaning shoe sensor (6 walkers)	X44—Disconnect point, cab harness (W2), rear basic harness (W9)	X88—Splice
F38—Fuse, 7.5 amps.	X18—Connection, distribution harness (W1) to fuse board	X86—Splice	X91—Connection, straw walker sensor, left
B3 —Light sensor	X25—Disconnect point, distribution harness (W1), cab harness (W2)		X92—Connection, straw walker sensor, right
B21—Straw walker sensor, right			X93—Connection, cleaning shoe sensor
B22—Straw walker sensor, left			


ZX.TM4543011400-19-30JUN97



## OPERATIONAL INFORMATION

Two switches for Hillmaster leveling system operation are provided in the switch console. Switch (B) is used as selector switch. Depending on switch position, the system operates manually, automatically or the combine may be lowered for driving on public roads.

Switch (A) is used to tilt the machine manually to the right or left. With selector switch (B) in position (III), hydraulic oil from the retracting cylinder is routed to the hydraulic oil reservoir when tilting combine to the right or left.



ZX 004064

-UN-02MAY95  
ZX004064

ZX, TMXZCO003216-19-17JAN94

## THEORY OF OPERATION


With road safety switch in field position and engine running, power is supplied to switches (S50) and (S51) via fuse (F29). When actuating switch (S50), solenoids (Y12) or (Y13) are activated. Pressure valve (Y7) is also activated via relay (K9). In addition, solenoid (Y20) is activated with selector switch (S51) in position (T) to lower the combine.

With selector switch (S51) in position (M), leveling control box (A8) is supplied with power. The output signals of the leveling control box also activate solenoids (Y12) and (Y13) and pressure valve (Y7).

When maximum tilt is reached, end switch (S59) or (S60) changes position and the indicator light in the cab will glow.

ZX, TMXZCO003217-19-17JAN94

FUNCTIONAL SCHEMATIC OF SECTION 24



ZX005249

-JUN-02MAY95  
ZX005249

- |  |  |  |  |
|--|--|--|--|
| A8 —Leveling control box                       | V52 —Diode   | X37 —Disconnect point, cab harness (W2), switch console harness (W3)       | X76 —Disconnect point, cab harness (W2), corner post harness (W4)    |
| A14 —Relay and diode board                     | V55 —Diode   | X47 —Disconnect point, distribution harness (W1), Hillmaster harness (W29) | X88 —Disconnect point, cab harness (W2), switch console harness (W3) |
| A15 —Fuse board                                | V56 —Diode   | X74 —Connection, Hillmaster harness (W29) to solenoid valve block          | X159—Connection, Hillmaster harness (W29) to left end switch         |
| F29 —Fuse, 15 amps.                            | X8 —Connection, cab harness (W2) to relay and diode board          | X75 —Connection, Hillmaster harness (W29) to leveling control box          | X160—Connection, Hillmaster harness (W29) to right end switch        |
| S50 —Manual leveling control switch            | X10 —Connection, cab harness (W2) to relay and diode board         |  |  |
| S51 —Leveling control switch, automatic/manual | X11 —Connection, cab harness (W2) to relay and diode board         |  |  |
| S59 —End switch, leveling to the left          | X18 —Connection, distribution harness (W1) to fuse board           |  |  |
| S60 —End switch, leveling to the right         | X27 —Disconnect point, distribution harness (W1), cab harness (W2) |  |  |
| V31 —Diode                                     |  |  |  |
| V46 —Diode                                     |  |  |  |
| V47 —Diode                                     |  |  |  |

ZX.TMXZCO003218-19-17JAN94





## OPERATIONAL INFORMATION

The concave and threshing cylinder/fan speeds may be adjusted by means of rocker switches in the cab.

Current cylinder speed may be displayed at the Infotrak monitor. When adjusting concave spacing, the

corresponding value is also displayed at the Infotrak monitor.

*NOTE: Separator must be running when adjusting cylinder and fan speeds.*

ZX, TMXZCO003222-19-17 JAN94

## THEORY OF OPERATION

Adjusting threshing cylinder speed:

With separator engaged, power is supplied to switch (S40) via fuse (F8). When actuating the switch, relays on board (A11) are activated, which in turn activate solenoids (Y28) or (Y29) and provide hydraulic adjustment of cylinder variable drive.

Adjusting fan speed:

With separator engaged, power is supplied to switch (S41) via fuse (F8). When actuating the switch, relays on board (A11) are activated which in turn activate


relay (K36) or (K37). Motor (M9) will then adjust variable fan speed drive.

Adjusting concave:

With starter switch in position (I), power is supplied to switch (S36) via fuse (F41). When actuating the switch, motor (M8) is activated via relays on board (A11). Motor (M8) is used for concave adjustment. Potentiometer (R2) integrated in motor (M8) will transmit the concave spacing value to the Infotrak monitor.

ZX, TMXZCO003223-19-17 JAN94

FUNCTIONAL SCHEMATIC OF SECTION 25A



ZX005250

- A11 —Relay board, combine data center
- A14 —Relay and diode board
- A15 —Fuse board
- F8 —Fuse, 7.5 amps.
- F11 —Fuse, 30 amps.
- F28 —Fuse, 7.5 amps.
- F41 —Fuse, 15 amps.
- K36 —Relay, adjust fan speed
- K37 —Relay, adjust fan speed
- M8 —Concave adjusting motor
- M9 —Fan speed adjusting motor
- R2 —Potentiometer, concave adjustment
- S36 —Switch, concave adjustment
- S40 —Switch, cylinder speed adjustment

- S41 —Switch, fan speed adjustment
- V10 —Diode
- X9 —Connection, cab harness (W2) to relay and diode board
- X17 —Connection, distribution harness (W1) to fuse board
- X23 —Disconnect point, cab harness (W2), front basic harness (W7)
- X24 —Connection, rear basic harness (W9) to solenoid valve block
- X25 —Disconnect point, distribution harness (W1), cab harness (W2)

- X26 —Disconnect point, distribution harness (W1), cab harness (W2)
- X27 —Disconnect point, distribution harness (W1), cab harness (W2)
- X28 —Disconnect point, distribution harness (W1), cab harness (W2)
- X35 —Disconnect point, cab harness (W2), armrest harness (W5)
- X38 —Disconnect point, cab harness (W2), optional harness (W14)
- X39 —Connection, distribution harness (W1) to data center relay board

- X40 —Connection, distribution harness (W1) to data center control board
- X44 —Disconnect point, cab harness (W2), rear basic harness (W9)
- X45 —Disconnect point, cab harness (W2), rear basic harness (W9)
- X55 —Disconnect point, cab harness (W2), data center harness (W23)
- X79 —Splice
- X118 —Connection, distribution harness (W1) to fuse board

ZX.TMXZCO003224-19-17JAN94







## Group 15AA

# Separator Adjustment, Combine Data Center

### OPERATIONAL INFORMATION

The combine data center integrated in the right-hand armrest essentially consists of an area counter and a system for automatic separator adjustments.


Area counting is based on travel distance during harvesting and cutting width.

Automatic settings are performed depending on the type of crop selected on the combine data center.

A data or signal transfer takes place between the mentioned components. Actual settings (speeds, clearances) and error codes (in case of malfunctions) are displayed on the Infotrak monitor.

ZX,TMXZCO003227-19-17JAN94

**SYSTEM COMPONENTS (“AREA COUNTER” AND “AUTOMATIC SEPARATOR ADJUSTMENTS”)**



ZX 002487

A—Combine data center  
 B—Infotrak monitor  
 C—Control board (for automatic machine adjustments only)

D—Relay board  
 E—Combine (sensors, switches, solenoids, motors)

ZX, TMXZCO003187-19-15JUL96


ZX002487 -UN-21JUN95

### COMBINE DATA CENTER

With starter switch in position (I), the combine data center is ready for operation.

**Functions:**


- A—Controls (6 keys)
- X—Area counter
- Y—Display (6 digits)
- Z—Setting unit



ZX, TMXZCO003228-19-15JUL96

### CONTROL KEYS


- A—Up
- B—Down
- C— • Clear
  - Calibrate
  - Cancel
- D—Automatic function (AUTO)
- E—Page change
- M— • Modify
  - Memory



ZX, OMXZCO001847-19-20JUL92

### Keys A and B

These keys are used to run through the various functions of area counter, display panel or setting unit. If "Modify" mode is activated by pressing key (M), displayed values may be increased or decreased at given increments by pressing these keys.




**ZX 002513**

ZX, OMXZCO001848-19-20JUL92

### Key C

This key is used to set data center displays to “zero” (e.g. area, header width) and to clear crop settings created by the operator.

This key is also used to interrupt automatic settings, to leave the automatic or modify mode and for input of partial header width.



**ZX 002516**


ZX,OMXZCO001851-19-20JUL92

-UN-27APR95  
ZX002516

### Key D

This key is used to activate automatic functions for setting combine components according to the values of the previously selected crop (cylinder speed, fan speed and concave spacing). During the setting procedure, the “AUTO” light of the setting unit will glow. The light will go out as soon as the setting procedure is completed.


*NOTE: During the setting procedure, the automatic mode may be left by pressing key (C).*



**ZX 002517**

ZX,OMXZCO001852-19-20JUL92

-UN-28APR95  
ZX002517



**ZX 002516**


-UN-27APR95  
ZX002516

### Key E

This key is used to “jump” from one unit of combine data center to another:

- From area counter to display
- From display to setting unit
- From setting unit back to area counter

This key is also used for the “Select Language” mode.




**ZX 002514**

ZX,OMXZCO001849-19-20JUL92

-UN-27APR95  
ZX002514

**Key M**

If a certain setting (e.g. fan speed for a crop version created by the operator or header width) is to be changed, select the corresponding function and press key (M). Now the setting can be changed, using the "arrow" keys. The new setting is saved by pressing key (M) once again.



**ZX 002515**

ZX,OMXZCO001850-19-20JUL92

ZX002515  
-UN-27APR95

## AREA COUNTER

### Requirements:

- Starter switch in position (I) or (II).
- Infotrak monitor correctly programmed
- The area counter "ON" switch must be set for relevant crop (see "Feeder House" Section), and the header must be at its operating height. (The display gives a reading even without these preconditions being met).

### Setting Instructions

Display (A) of area counter always lights up when unit is switched on.

### Area Counter:


- Area-per-day values can only be cleared, but not changed.
- Total area values can neither be cleared nor changed.
- The smallest area per day that can be displayed is 0.001 hectare or 0.001 acre.
- The smallest total area that can be displayed is 0.1 hectare or 0.1 acre.

### Header Width:

- The smallest setting increment for header width is 0.1 m or 0.5 ft.

When full width of header is not used during operation, partial width may be set in 1/4 increments. Header width will return to the previously saved value if header moves out of range of header height gauge.

*NOTE: The displayed measurement units for width and area are determined by infotrak monitor programming (see this Section).*



A—Area-per-day function light  
 B—Total area function light  
 C—Header width function light

ZX002492 -JUN-16-JUN95

ZX,OMXZC001845-19-01NOV96




## DISPLAY

With ignition turned on, the following data are displayed:

- Preloaded settings for various crops
- Area counter data (area, total area, header width)
- Preloaded crops (9), crops created by the operator (14)
- Languages available:

German	DEUTSC
French	FRANCA
Spanish	ESPANI
Italian	ITALIA
Dutch	NEDERL
Danish	DANSK
Swedish	SVENSK
English	ENGLIS



ZX 002488


ZX002488 -UN-28APR95

ZX,OMXZCO001842-19-20JUL92

## Factory-Loaded Crops

- Barley
- Corn
- Beans
- Peas
- Wheat
- Rye
- Sunflowers
- Oats
- Rape

*NOTE: The names of the factory-loaded (permanent memory) crops end with a number 1.*



ZX 002489


ZX002489 -UN-28APR95

ZX,OMXZCO001843-19-20JUL92

### Crop Codes Created by the Operator

For each of the previously mentioned crops (all of which are entered into the memory at the factory), the operator may enter one modified crop into the data center memory, including all necessary settings according to harvesting conditions. The names of these crop versions, created by the operator, end with a number 2.

*NOTE: The crops entered into data center memory by the operator may be recorded on the bottom of right-hand armrest.*



ZX 002490


ZX002490 -UN-28APR95

ZX,OMXZC0001844-19-13NOV92

### Special Crops

The operator may enter five additional special crops into the data center memory. These crops are named CROP1 — CROP5.

*NOTE: The crops entered into data center memory by the operator may be recorded on the bottom of right-hand armrest.*



ZX 002491

ZX002491 -UN-16JUN95

ZX,OMXZC0001910-19-01MAR95

## SETTING UNIT

### Requirements:

To start automatic setting of functions (A, B and C):

- Engine must be running (throttle lever pushed all the way forward)
- Separator must be engaged
- Switch for automatic machine adjustments must be ON

### Setting Instructions

Values of functions (A—F) for the previously selected crop are displayed and may be changed as follows:

Function	Increments	Setting range
A	10 rpm	150—1150 rpm
B	10 rpm	600—1750 rpm
C	1 mm *	4—52 mm
D	1 mm (1/16 in.)	0—25 mm (0—1 in.)
E	1 mm (1/16 in.)	0—20 mm (0—1-1/4 in.)
F	1 mm (1/16 in.)	0—20 mm (0—1-1/4 in.)

**NOTE:** Concave spacing (\*) is displayed in millimetres only. The figures in brackets are displayed in machine code 03.

Values of functions (A—F) for crops ending with a number “1” (e.g. “CORN1”) are factory loaded (permanent memory) and cannot be changed.


Values of functions (A—F) for crops ending with a number “2” (e.g. “CORN2”) may be cleared or changed.

Values of functions (A—F) for “CROP1” to “CROP5” may also be cleared or changed.

Functions (A—C) are set automatically by pressing the “AUTO” key (if the above requirements are met).

Values of functions (D—F) are only displayed. Setting must be carried out manually.

Lights (A—C) and (G) will glow during automatic setting procedure.




- A—Cylinder speed function light
- B—Fan speed function light
- C—Concave spacing function light
- D—Chaffer function light
- E—Sieve function light
- F—Chaffer extension function light
- G—Automatic function light

## OPERATIONAL DIAGRAMS

### Explanation of Symbols:

- A—Switch on automatic machine adjustments
- B—Shows the combine data center unit to be selected:
  - X-Area counter
  - Y-Display
  - Z-Setting unit
- C—Shows individual functions of area counter/setting unit (blue light)
- D—Shows the key to be pressed (bold enclosure)
- E—Display information
- F—Shows possible choices
- G—Shows time required for individual procedure




ZX 002518

ZX,OMXZCO001853-19-21JUL92

ZX002518 -UN-16JUN95

### SELECTING COMBINE DATA CENTER UNITS

- Turn starter switch to position (I).
- Combine data center will switch to area counter (X).
- Press "PAGE" key.
- Combine data center will switch to display (Y).
- Press "PAGE" key.
- Combine data center will switch to setting unit (Z).



ZX 002328

ZX002328 -UN-16.JUN95

ZX,OMXZCO001854-19-21.JUL92

## SELECTING AREA COUNTER FUNCTIONS

- Select “Area Counter” unit.

Light of “Area” function will glow.

The harvesting area (for each day) is displayed.

- Press “Down” key.

Light of “Total Area” function will glow.


The total harvesting area is displayed.

- Press “Down” key.

Light of “Header Width” function will glow.

Header width (cutting width) is displayed.

*NOTE: Running through the various crop displays or setting unit functions is done in a similar way as described above.*



ZX 002519

-UN-16JUN95

ZX002519

ZX,OMXZCO001983-19-21JUL92


### CLEARING "AREA" DISPLAY

- Select "Area Counter" unit.
- Select "Area" function.

The harvesting area for the day will be displayed.

- Press key (C) ("Clear").

Display will change to "zero".



ZX 002520

ZX002520 -UN-16JUN95

ZX,OMXZCO001855-19-21JUL92

## CHANGING HEADER WIDTH

- Select "Area Counter" unit.
- Select "Header Width" function.

The current header width (cutting width) will be displayed.

- Press "Modify" key (M).

An "M" will appear at the left of the display.


- Press "Up" or "Down" key.

The changed header width will be displayed.

- Press key (M) again.

The displayed setting is saved; the "M" at the left of the display will disappear.

**NOTE:** After pressing the "M" key, it is always possible to interrupt the setting of the new header width by pressing "Cancel" key (C). The previous header width will be displayed once again.



ZX 002521

-JUN-16JUN95  
ZX002521

ZX\_OMXZCO001984-19-21JUL92



## SETTING PARTIAL HEADER WIDTH

- Select "Area Counter" unit.
- Select "Header Width" function.

The current header width will be displayed.

- Press "Calibrate" key (C).

"3/4" will be displayed = 3/4 of the previous header width (cutting width).

- Press "Calibrate" key (C).


"1/2" will be displayed = 1/2 of the previous header width (cutting width).

- Press "Calibrate" key (C).

"1/4" will be displayed = 1/4 of the previous header width (cutting width).

- Press "Calibrate" key (C).

The cutting width saved previously will be displayed.



ZX 002522

ZX002522 -UN-16JUN95

ZX,OMXZCO001856-19-21JUL92


## SELECTING LANGUAGE

- Press “Page” key while turning starter switch to position (I).

The language saved previously will be displayed.

- Press “Up” or “Down” key until desired language is displayed.
- Press “Memory” key (M).
- Turn starter switch to position (0).

The desired language is saved.



ZX 002523

ZX,OMXZCO001857-19-21JUL92

ZX002523 -UN-16JUN95

## SELECTING CROP

*NOTE: This procedure is required to start automatic settings and to change to a different crop.*

- Select "Display" unit.

The crop selected previously will be displayed.

- Press "Up" or "Down" key until desired crop is displayed.


- Press "Modify" key (M).

A flashing "M" will appear at the left of the display.

- Press key (M) again.

The selected crop is saved; the "M" at the left of the display will disappear.

*NOTE: After pressing the "M" key, it is possible to interrupt crop selecting procedure by pressing "Cancel" key (C).*



ZX002524 -UN-16/JUN95

ZX,OMXZCO001985-19-21JUL92

## AUTOMATIC MACHINE SETTING ACCORDING TO CROP SELECTED

- Separator must be engaged.
- Switch on function “Automatic Machine Adjustments”.
- Select “Display” unit.

The selected crop will be displayed.


- Press “AUTO” key.

Lights of functions

- Cylinder speed
  - Fan speed
  - Concave spacing and
  - Automatic operation (“AUTO”)
- will glow until the corresponding setting is completed.

After setting procedure for all functions is completed, the “AUTO” light will go out.

*NOTE: It is possible to interrupt setting procedure by pressing “Cancel” key (C).*




ZX,OMXZCO001960-19-21JUL92

### CLEARING CROPS CREATED BY THE OPERATOR

- Select "Display" unit.
- Select crop to be cleared (ending with a number "2" or named "CROP1"—"CROP5").
- Press "Clear" key (C) for 2 seconds.

Display will change to crop version ending with a number "1".



ZX007339

ZX,OMXZCO001986-19-01MAR95

ZX007339 -JUN-19-JUN95

## READING SETTINGS FOR SELECTED CROP

- Select "Display" unit.

The previously selected crop will be displayed.

- Select "Setting Unit" function.


- Select "Cylinder Speed" function.

The cylinder speed for the selected crop is displayed.

- Select "Fan Speed" function.

The fan speed for the selected crop is displayed.

*NOTE: The remaining settings may be displayed in the same way.*



ZX 002527

ZX002527 -UN-16/JUN95

ZX,OMXZCO001858-19-21JUL92

## CHANGING CROP SETTINGS

### (Crops Created by the Operator)

- Select "Display" unit.

The previously selected crop will be displayed.

- Select "Setting Unit" function.

- Select "Cylinder Speed" function.

The cylinder speed for the selected crop is displayed.

- Press "Modify" key (M).

An "M" will appear at the left of the display.


- Press "Up" or "Down" key until desired display appears.

*NOTE: At this time it is possible to interrupt changing procedure by pressing "Cancel" key (C).*

- Press key (M) again.

The crop created by the operator is saved (indicated by a "2" behind the crop name); the "M" at the left of the display will disappear.

*NOTE: The values for the remaining functions are changed in the same way.*



ZX 002528

ZX002528 -UN-16/JUN95

ZX,OMXZCO001987-19-21 JUL92

### INDIVIDUAL SETTING OF CHANGED VALUES (AUTOMATIC SETTING)


- Separator must be engaged.
- Switch on function "Automatic Machine Adjustments".
- Select "Setting Unit" function.
- Select "Cylinder Speed" function.

The corresponding value is displayed.

- Press "AUTO" key.

The light of the selected function and the "AUTO" light will glow during automatic setting procedure.

*NOTE: It is possible to interrupt setting procedure by pressing "Cancel" key (C).*



ZX 002529

ZX,OMXZCO001859-19-21 JUL92

ZX002529 -UN-16.JUN95



## THEORY OF OPERATION

Manual adjustments of cylinder speed, fan speed and concave spacing are identical with the procedures described in Group 240-15Z.

These adjustments may be performed automatically by means of the combine data center.

The relays on the relay board are activated by control board (A9) via connecting wires. Control board (A9) and combine data center (A5) are connected to the

Infotrak monitor via data transfer wires (268) and (269).

Wire 038 transmits the signal from the header height sending unit to the combine data center. Wire 304 transmits a signal from switch (S55) during reverse travel to switch off the area counter.

*NOTE: The infotrak monitor displays error codes in case of combine data center malfunctions.*

ZX,TMXZCO003188-19-17JAN94




## FUNCTIONAL SCHEMATIC, SECTION 25B - PART 1

A5 — Combine data center	R10 — Potentiometer, chaffer	X26 — Disconnect point, distribution harness (W1), cab harness (W2)	X42 — Connection, distribution harness (W1) to data center control board
A9 — Control board, combine data center	R11 — Potentiometer, sieve		
A11 — Relay board, combine data center	R12 — Potentiometer, sieve extension	X27 — Disconnect point, distribution harness (W1), cab harness (W2)	X44 — Disconnect point, cab harness (W2), rear basic harness (W9)
A14 — Relay and diode board	S38 — Switch, combine data center	X28 — Disconnect point, distribution harness (W1), cab harness (W2)	X45 — Disconnect point, cab harness (W2), rear basic harness (W9)
A15 — Fuse board	S55 — Reverse travel switch	X35 — Disconnect point, cab harness (W2), armrest harness (W5)	X55 — Disconnect point, cab harness (W2), data center harness (W23)
B32 — Sending unit, empty grain tank	S71 — Height cut-off switch	X38 — Disconnect point, cab harness (W2), optional harness (W14)	X79 — Splice
F8 — Fuse, 7.5 amps.	V10 — Diode	X39 — Connection, distribution harness (W1) to data center relay board	X118 — Connection, distribution harness (W1) to fuse board
F11 — Fuse, 30 amps.	X9 — Connection, cab harness (W2) to relay and diode board		
F28 — Fuse, 7.5 amps.	X17 — Connection, main distribution harness (W1) to fuse board		
F41 — Fuse, 15 amps.	X23 — Disconnect point, cab harness (W2), front basic harness (W7)		
K36 — Relay, adjust fan speed	X24 — Connection, rear basic harness (W9) to solenoid valve block		
K37 — Relay, adjust fan speed	X25 — Disconnect point, distribution harness (W1), cab harness (W2)		
M8 — Concave adjusting motor			
M9 — Fan speed adjusting motor			
R2 — Potentiometer, concave adjustment			

ZX, TM4543010322-19-30JUN97



DIAGNOSTIC SCHEMATIC, SECTION 25B - PART 2



SE25B  
CYLINDER , CONCAVE , FAN ADJUSTMENT  
-PART 2

ZX012443

## FUNCTIONAL SCHEMATIC, SECTION 25B - PART 2

A5 — Combine data center	M8 — Concave adjusting motor	X26 — Disconnect point, distribution harness (W1), cab harness (W2)	X44 — Disconnect point, cab harness (W2), rear basic harness (W9)
A9 — Control board, combine data center	M9 — Fan speed adjusting motor	X27 — Disconnect point, distribution harness (W1), cab harness (W2)	X45 — Disconnect point, cab harness (W2), rear basic harness (W9)
A11 — Relay board, combine data center	M10 — Sieve extension motor	X28 — Disconnect point, distribution harness (W1), cab harness (W2)	X55 — Disconnect point, cab harness (W2), data center harness (W23)
A14 — Relay and diode board	R2 — Potentiometer, concave adjustment	X35 — Disconnect point, cab harness (W2), armrest harness (W5)	X79 — Splice
A15 — Fuse board	V10 — Diode	X38 — Disconnect point, cab harness (W2), optional harness (W14)	X118 — Connection, distribution harness (W1) to fuse board
F8 — Fuse, 7.5 amps.	X9 — Connection, cab harness (W2) to relay and diode board	X39 — Connection, distribution harness (W1) to data center relay board	Y28 — Decrease cylinder speed
F11 — Fuse, 30 amps. (fan adjustment)	X17 — Connection, main distribution harness (W1) to fuse board	X42 — Connection, distribution harness (W1) to data center control board	Y29 — Increase cylinder speed
F28 — Fuse, 7.5 amps. (ACA board)	X23 — Disconnect point, cab harness (W2), front basic harness (W7)		
F41 — Fuse, 15 amps. (concave adjusting motor)	X24 — Connection, rear basic harness (W9) to solenoid valve block		
F47 — Fuse, 15 amps. (sieve adjusting motor)	X25 — Disconnect point, distribution harness (W1), cab harness (W2)		
K36 — Relay, adjust fan speed			
K37 — Relay, adjust fan speed			
M6 — Chaffer adjusting motor			
M7 — Sieve adjusting motor			

ZX, TM4543010324-19-30JUN97







### OPERATIONAL INFORMATION

All header settings such as header lift, reel lift and horizontal reel adjustment are carried out hydraulically and are controlled electrically.

The basic adjustment preset by the operator can be obtained automatically at any time by pressing a button.

*NOTE: For safety reasons, header or reel can only be adjusted with engine running and road safety switch in "field" position.*

ZX, TMXZCO003191-19-17 JAN94

### THEORY OF OPERATION

As switches (S27, S29 and S30) are not designed for high current draw, a relay is located in front of each hydraulic function solenoid of this Section.

All switches and header control (A6) are protected by fuse (F26).

Operating current for solenoids used for raising/lowering header is supplied via fuse (F33).  
Operating current for solenoids of reel functions and variable feeder house drive is supplied via fuse (F45).

Depending on position of selector switch (S53), switch (S29) activates the solenoids for raising or lowering


reel or the solenoids for increasing or decreasing header speed.

Potentiometers (R4, R6 and R8) indicate reel position (height and horizontal position) and header height (needed for electronic control). Potentiometers (R3, R5 and R7) in the switch console can be used to select desired settings. When actuating switch (S28), the header is automatically set according to the selected values.

*NOTE: Manual control functions will override automatic control functions.*

ZX, TMXZCO003192-19-17 JAN94

FUNCTIONAL SCHEMATIC, SECTION 26 - PART 1



SE26  
 HEADER ADJUSTMENT (CUTTING HEIGHT; REEL; FLOAT)

-PART 1

ZX012444


**FUNCTIONAL SCHEMATIC, SECTION 26 - PART 1**

A6 —Automatic header control	K40 —Relay, tilting header to the left	S32 —Switch, resume controls	X77 —Feeder house plug
A14 —Relay and diode board	K41 —Relay, tilting header to the right	S53 —Selector switch, raise reel/variable header drive	Y2 —Solenoid, header function
F26 —Fuse, 7.5 amps.	R3 —Potentiometer, header height resume	S66 —Selector switch, horizontal reel adjustment/header lateral tilt	Y3 —Solenoid, header function
F33 —Fuse, 15 amps.	R4 —Sending unit, header height	X6 —Connection, relay board	Y4 —Solenoid, header function
F45 —Fuse, 15 amps.	R5 —Potentiometer, reel height	X7 —Connection, relay board	Y5 —Solenoid, header function
K13 —Relay, lower header quickly	R6 —Sending unit, reel height	X8 —Connection, relay board	Y6 —Solenoid, header function
K14 —Relay, lower header slowly	R7 —Potentiometer, reel position	X9 —Connection, relay board	Y16 —Solenoid, move reel forward
K15 —Relay, raise header quickly	R8 —Sending unit, reel position	X10 —Connection, relay board	Y17 —Solenoid, move reel back
K16 —Relay, raise header slowly	S27 —Switch, raise/lower header	X11 —Connection, relay board	Y18 —Solenoid, lower reel
K17 —Relay, lower reel	S28 —Automatic function switch	X21 —37-terminal header plug	Y19 —Solenoid, raise reel
K18 —Relay, raise reel	S29 —Switch, raise reel	X23 —Disconnect point, cab	Y30 —Solenoid, reduce feeder house speed
K19 —Relay, move reel to the rear	S30 —Switch, reel horizontal adjustment	X32 —Plug for solenoid block	Y31 —Solenoid, increase feeder house speed
K20 —Relay, move reel to the front		X73 —16-terminal hydraulic block plug	
K28 —Relay, variable header drive (slow)			
K29 —Relay, variable header drive (fast)			

ZX, TM4543010328-19-30JUN97




DIAGNOSTIC SCHEMATIC, SECTION 26 - PART 1



ZK012460

FUNCTIONAL SCHEMATIC, SECTION 26 - PART 2



SE26  
HEADER ADJUSTMENT (CUTTING HEIGHT; REEL; FLOAT)  
--PART 2

ZX012445

## FUNCTIONAL SCHEMATIC, SECTION 26 - PART 2

A6 —Automatic header control	K29 —Relay, variable header drive (fast)	S32 —Switch, resume controls	X37 —Plug 1, dashboard
A15 —Fuse board	R3 —Potentiometer, header height resume	S53 —Selector switch, raise reel/variable header drive	X38 —Plug 2, dashboard
F26 —Fuse, 7.5 amps.	R4 —Sending unit, header height	S61 —ContourMaster switch	X44 —Plug, basic wiring harness, right
F33 —Fuse, 15 amps.	R5 —Potentiometer, reel height	S66 —Selector switch, horizontal reel adjustment/header lateral tilt	X45 —Plug, basic wiring harness, left
F45 —Fuse, 15 amps.	R6 —Sending unit, reel height	X17 —21-term. plug, distribution board, l.h.	X46 —Plug for platform wiring harness
K13 —Relay, lower header quickly	R7 —Potentiometer, reel position	X24 —Plug, solenoids on hydraulic block	X51 —Plug for header control (electronics)
K14 —Relay, lower header slowly	R8 —Sending unit, reel position	X25 —Plug 1, cab	Y2 —Solenoid, header function
K15 —Relay, raise header quickly	S27 —Switch, raise/lower header	X28 —Plug 4, cab	Y3 —Solenoid, header function
K16 —Relay, raise header slowly	S28 —Automatic function switch	X35 —37-terminal armrest plug	Y4 —Solenoid, header function
K17 —Relay, lower reel	S29 —Switch, raise reel	X36 —Plug for forward/reverse lever	Y5 —Solenoid, header function
K18 —Relay, raise reel	S30 —Switch, reel horizontal adjustment		Y6 —Solenoid, header function
K19 —Relay, move reel to the rear			
K20 —Relay, move reel to the front			
K28 —Relay, variable header drive (slow)			

ZX, TM4543010330-19-30JUN97





## Group 15AC Grain Tank Unloading System


### OPERATIONAL INFORMATION

Switch (A) is used to swing unloading auger in or out.

*NOTE: A timer relay interrupts current supply to electromagnetic control valve after 22 seconds to prevent overheating of the hydraulic system.*

Switch (B) is used to engage unloading auger drive. A switch lock is provided to avoid unintentional engagement of unloading auger drive.

- A—Switch, swing unloading auger in or out
- B—Unloading auger drive switch
- C—Switch lock



ZX, TMXZCO003195-19-17JAN94

ZX005245  
-JUN-19MAY 95

### THEORY OF OPERATION


With road safety switch in “field” position and engine running, power is supplied to switches (S35) and (S39), pressure switch (B31) and timer relay (K25) via fuse (F39).

With switch (S35) in neutral position, relay (K24) is activated. When engaging unloading auger drive, relay (K24) is held in position. Solenoids (Y26) and (Y27) are activated. The pressure valve is activated by pressure switch (B31), depending on pressure.

When swinging unloading auger in or out, double contact switch (S39) connects terminal (S) of timer relay (K25) to ground. Thus terminal (87) of timer relay is supplied with power. The second contact of double contact switch (S39) activates the solenoid for swinging unloading auger in or out. The timer relay powers terminal (87) for 22 seconds.

ZX, TMXZCO003196-19-17JAN94

**FUNCTIONAL SCHEMATIC OF SECTION 27**



ZX012582

-UN-26MARS8  
ZX012582


ZX, TM4543011336-19-30JUN97

## FUNCTIONAL SCHEMATIC OF SECTION 27

A14 —Relay and diode board	V8 —Diode	X23 —Disconnect point, cab	X82 —Plug for ultrasonic sensors
A15 —Fuse board	V9 —Diode	X24 —Connection, rear basic harness (W9) to solenoid valve block	X167—Switch 215
B31 —Pressure switch, main clutch	V24 —Diode	X26 —Disconnect point, distribution harness (W1), cab harness (W2)	Y1 —Main valve, solenoid control block
F39 —Fuse, 15 amps.	V25 —Diode	X27 —Plug 3, cab	Y10 —Solenoid, swing in unloading auger
K25 —Timer relay, unloading auger swing	V26 —Diode	X37 —Disconnect point, cab harness (W2), switch console harness (W3)	Y11 —Solenoid, swing out unloading auger
K51 —Relay, unloading auger drive	X8 —Connection, cab harness (W2) to relay and diode board	X45 —Disconnect point, cab harness (W2), rear basic harness (W9)	Y26 —Solenoid, unloading grain tank
K52 —Relay, unloading auger drive	X9 —Connection, cab harness (W2) to relay and diode board	X49 —Disconnect point, cab harness (W2), corner post harness (W4)	Y27 —Solenoid, unloading grain tank
S39 —Switch, unloading auger swing	X10 —Connection, cab harness (W2) to relay and diode board		
S70 —Unloading auger drive switch	X17 —Connection, main distribution harness (W1) to fuse board		
V2 —Diode			

ZX, TM4543010332-19-30JUN97

DIAGNOSTIC SCHEMATIC OF SECTION 27




ZK012457

### OPERATIONAL INFORMATION

With starter switch in position (II), hydraulic four-wheel drive may be engaged by means of switch (S44).

An indicator light shows that four-wheel drive is engaged.

Four-wheel drive may be selected only when the road safety switch is in the "field" position.



ZX 001660

ZX001660 -UN-28APR95

ZX, TM4543010333-19-30JUN97

### THEORY OF OPERATION


With starter switch in position (II), power is supplied to switch (S44) via fuse (F30).

When actuating switch (S44), solenoid (Y32) is activated and a certain amount of hydrostatic oil flow is directed to the rear axle.

At the same time an indicator light in Section 10 will glow.

ZX, TMXZCO003200-19-17JAN94

**FUNCTIONAL SCHEMATIC OF SECTION 28**



ZX014834

ZX014834 -UN-27MAR98

A15 —Fuse board  
 F30 —Fuse  
 S44 —Four-wheel drive switch  
 X18 —Connection, distribution harness (W1) to fuse board


X27 —Disconnect point, distribution harness (W1), cab harness (W2)  
 X37 —Disconnect point, cab harness (W2), switch console harness (W3)

X45 —Disconnect point, cab harness (W2), rear basic harness (W9)  
 X49 —Disconnect point, cab harness (W2), corner post harness (W4)


Y32 —Four-wheel drive solenoid

ZX, TMXZCO003201-19-30JUN97

**DIAGNOSTIC SCHEMATIC OF SECTION 28**



ZX012458



ZX012458 -UN-11MAR98

ZX, TMXZCO003202-19-30JUN97






## Group 15AE Header Lateral Tilt Function

### OPERATIONAL INFORMATION

This function is provided to tilt the header laterally, e.g. when working on slopes. It will provide a uniform cutting height over the entire header width. Without the lateral tilt function, cutting height on the uphill side would be higher than on the downhill side due to combine weight distribution.



ZX005247

ZX, TMXZCO003203-19-17 JAN94

ZX005247  
-UN-28APR95

### THEORY OF OPERATION

With road safety switch in "field" position and engine running, power is supplied to switch (S22) via fuse (F26). When tilting header to the left or right, solenoid (Y14) or (Y15) is activated.

Pressure valve (Y1) in Section 27 is also activated via diode (V44) or (V45).

*NOTE: Switch (S62) is normally not installed, because Section 26 is used to control the function. Field installation of the switch is possible.*

ZX, TMXZCO003204-19-17 JAN94




## FUNCTIONAL SCHEMATIC OF SECTION 29

A14 —Relay and diode board	X12 —Connection, cab harness (W2) to relay board	X53 —Plug, AHC electronics box	X82 —Plug for ultrasonic sensors
A7 —Electronics for ContourMaster (AHC)	X21 —37-term. header plug, ContourMaster switch	X73 —Connection, feeder house harness (W10) to solenoid block	X95 —5-terminal plug for ultrasonic sensors
B36 —Ultrasonic sensor, l.h.	X25 —Disconn. point, main distribution harness (W1), cab harness (W2)	X77 —Disconnect point, front basic harness (W7), feeder house harness (W10)	X169—19-terminal plug, to A7
B38 —Ultrasonic sensor, r.h.	X27 —Plug 3, cab		Y14 —Solenoid, l.h. side of header
K40 —Header height relay, r.h.	X37 —Disconnect point, cab harness (W2), switch console harness (W3)		Y15 —Solenoid, r.h. side of header
K41 —Header height relay, l.h.			
S61 —ContourMaster switch			
X11 —Connection, cab harness (W2) to relay board			

ZX, TM4543010335-19-30JUN97

DIAGNOSTIC SCHEMATIC OF SECTION 29



ZX012459


## Group 15AF Header Float Control

### OPERATIONAL INFORMATION

A preset float is selected by pressing button (C). Float is obtained by activating hydraulics of header lift system.

Use potentiometer (B) to adjust desired header float.

**IMPORTANT: Do not operate float control for more than one minute without interruption to avoid overheating of the hydraulic oil.**



ZX, TMXZCO003207-19-17JAN94

### THEORY OF OPERATION


Float control system (A10) is powered via wire 184. When switch (S6) is actuated, header control system (A6) in Section 26 is switched off. The function "raise header slowly" is activated via diode (V48) and wire 238.

At the same time, coil of solenoid (Y6) is supplied with voltage via wires 101 and 102.

Depending on potentiometer setting, float control electronics will provide a current between 350 and 900 mA to the solenoid coil. This in turn will provide a lower or higher hydraulic system pressure.

ZX, TMXZCO003208-19-17JAN94

FUNCTIONAL SCHEMATIC OF SECTIONS 30, 31 AND 32



SE30	SE31	SE32
FLOAT CONTROL	BACK UP ALARME	TIMER RELAY 4,5S MD 2054


ZX012448

## FUNCTIONAL SCHEMATIC OF SECTIONS 30, 31 AND 32

A10 —Float control	K42 —Relay, header	X10 —Connection, cab	X88 —Disconnect point, cab
A14 —Relay and diode board	el.-clutch (moving	harness (W2) to relay	harness (W2), switch
B43 —Buzzer, back-up alarm	motor)	and diode board	console harness (W3)
F51 —7.5 amp. fuse, header	K45 —Relay, D + (moving	X35 —Disconnect point,	X96 —Plug for float control
drive clutch	motor)	cab harness (W2),	X103—Float control bridging
F52 —7.5 amp fuse, header	R13 —Potentiometer	armrest harness (W5)	plug
back-up alarm	S6 —Header float switch	X36 —Connection, armrest	Y34 —Header clutch
K8 —Relay	S69 —Back-up alarm switch	harness (W5) to	
		forward/reverse lever	

ZX, TM4543010338-19-30JUN97

**DIAGNOSTIC SCHEMATIC OF SECTION 30**



ZX004128


-JUN-02MAY95

ZX004128

ZX.TM4543010339-19-30JUN97



**DIAGNOSTIC SCHEMATIC OF SECTION 31**




ZX005384

ZX005384 -JUN-26MARS88

ZX, TM4543010340-19-30JUN97

**DIAGNOSTIC SCHEMATIC OF SECTION 32**



ZX005385

ZX005385 -UN-26MAR98

ZX.TM4543010341-19-30JUN97

# Section 241

# Electrical System from Serial Number

# 066833

## Contents

Page

<b>Group 05 —General Information</b> . . . . .	241-05-1
<b>Group 06 —Test Equipment</b> . . . . .	241-06-1
<b>Group 10 —Functional Schematics and Harness Diagrams</b>	
Section survey . . . . .	241-10-1
Wiring and harness diagrams . . . . .	241-10-2
<b>Group 15H —Radio</b>	
Theory of operation . . . . .	241-15H-1
Functional schematic, section 8 . . . . .	241-15H-2
Diagnostic schematic, section 8 . . . . .	241-15H-4
<b>Group 15I —Alarm Module, Stop Function</b>	
Theory of operation . . . . .	241-15I-1
Functional schematic, section 9 . . . . .	241-15I-2
<b>Group 15J —Indicator Lights</b>	
Functional schematic, section 10 . . . . .	241-15J-1
<b>Group 15W —Infotrak Monitor, Speed Monitoring System</b>	
Theory of operation . . . . .	241-15W-1
Functional schematic, section 22 . . . . .	241-15W-2
Diagnostic schematic, section 22 . . . . .	241-15W-5
<b>Group 15AA—Separator Adjustment, Combine Data Center</b>	
Theory of operation . . . . .	241-15AA-1
Functional schematic, section 25B . . . . .	241-15AA-2
Separator adjustment, combine data center . . . . .	241-15AA-3
Diagnostic schematic, section 25B . . . . .	241-15AA-5

*Contents*

**NOTE**

See Section 240, Group 05.

ZXTM4543 011395-19-30JUN97

*General Information*

**NOTE**

For details of test equipment, see Section 240,  
Group 06.

ZXTM4543 011396-19-30JUN97

*Test Equipment*



# Group 10 Functional Schematics and Harness Diagrams

## SECTION SURVEY

The functional schematics for the electrical sections listed below are to be found in Group 15 of this Section.

SE 08 — Radio

SE 09 — Alarm module, stop function

SE 10 — Indicator lights

SE 22 — Digital infotrak monitor, speed monitoring system

SE 25B — Separator adjustment, combine data center

For information on the functional schematics in the other electrical sections, see Section 240, Group 10.

The diagrams in Section 240, Group 10 apply for all the wiring and harness diagrams that are not shown below.


ZX, TM4543011360-19-30JUN97







WIRING AND HARNESS DIAGRAM OF CAB HARNESS W2 - PART 3












**THEORY OF OPERATION**

*NOTE: The clock has been removed from Section 08  
and integrated into the combine data center  
(Section 22).*

ZX.TM4543011361-19-30JUN97

**FUNCTIONAL SCHEMATIC OF SECTION 8**



ZX014218 -UN-12MAR98

ZX.TM4543011362-19-30JUN97

## FUNCTIONAL SCHEMATIC OF SECTION 8

A12 —Radio  
A13 —CB radio  
A15 —Fuse board  
B39 —Loudspeaker, left  
B40 —Loudspeaker, right  
F18 —7.5 amp. fuse


F22 —7.5 amp. fuse  
P7 —Digital clock  
W30 —Antenna  
W31 —Antenna  
X2 —Disconnect point, US  
radio

X18 —Connection, fuse  
board to main  
distribution harness  
X25 —Disconnect point, main  
distr. harness — cab  
harness

X117—Connection, fuse  
board to main  
distribution harness

ZX.TM4543011363-19-30JUN97

**DIAGNOSTIC SCHEMATIC OF SECTION 8**



ZX014215

ZX014215 -UN-12MAR98


ZX.TM4543011364-19-30JUN97

## **THEORY OF OPERATION**

*NOTE: Hydraulic oil level sensor (B34) has been deleted. No warning is given before the system shuts down. Wire 347 is connected to sending unit (B35).*

ZX.TM4543011365-19-30JUN97

FUNCTIONAL SCHEMATIC OF SECTION 9




SE9  
ALARMMODUL – STOP-FUNKTIONEN

Z4014219

# Group 15J Indicator Lights

## FUNCTIONAL SCHEMATIC OF SECTION 10



SE10  
WARNMODUL

ZX014220






**Group 15W**  
**Infotrak Monitor, Speed Monitoring System**

**OPERATIONAL INFORMATION**

*NOTE: The clock has been integrated into the combine data center. The new data center has a double display. See the Operator's Manual for instructions on how to program the clock.*

ZX.TM4543011368-19-30JUN97

FUNCTIONAL SCHEMATIC OF SECTION 22



INFOTRAK MONITOR / SPEED MONITORING SYSTEM

ZX014221


## FUNCTIONAL SCHEMATIC OF SECTION 22

A3 —Electronic speed monitoring system	B30 —Fan speed sending unit	X23 —Disconnect point, cab harness (W2)-front basic harness (W7)	X46 —Disconnect point, cab harness (W2)-front basic harness (W7)
A14 —Relay and diode board	K10 —Relay, fan speed alarm	X25 —Disconnect point, main distribution harness (W1)-cab harness (W2)	X49 —Disconnect point, cab harness (W2)-corner post harness (W4)
A15 —Fuse board	K11 —Relay, cylinder speed alarm	X27 —Disconnect point, main distribution harness (W1)-cab harness (W2)	X50 —Connection, main distribution harness(W1)-electronic speed monitoring system
A18 —Infotrak monitor	S24 —Speed monitoring switch, straw chopper	X28 —Disconnect point, main distribution harness (W1)-cab harness (W2)	X62 —Disconnect point, rear basic harness (W9)-engine harness (W12/W13)
B6 —Ground speed sending unit	X12 —Connection, cab harness (W2)-relay and diode board	X44 —Disconnect point, cab harness (W2)-rear basic harness (W9)	X71 —Disconnect point, rear basic harness (W9)-chaff spreader harness (W26)
B16 —Straw chopper speed sending unit	X13 —Connection, cab harness (W2)-relay and diode board	X45 —Disconnect point, cab harness (W2)-rear basic harness (W9)	
B17 —Tailings elevator speed sending unit	X18 —Connection, main distribution harness (W1)-fuse board		
B18 —Cross shaker speed sending unit	X22 —Disconnect point, rear basic harness (W9)-chopper harness (W25)		
B19 —Clean grain elevator speed sending unit			
B20 —Chaff spreader speed sending unit			
B28 —Engine speed sending unit			
B29 —Cylinder speed sending unit			

ZX.TM4543011370-19-30JUN97



DIAGNOSTIC SCHEMATIC OF SECTION 22



ZX014216




## **THEORY OF OPERATION**

*NOTE: Switch S71 ensures that when the area counter is set to 1/4, 1/2 or 3/4 cutting width, it will return to 1/1 (full width) automatically whenever the header is raised and lowered again.*

ZX.TM4543011372-19-30JUN97

FUNCTIONAL SCHEMATIC OF SECTION 25B



SE25B  
CYLINDER ;CONCAVE ; FAN ADJUSTMENT  
- PART 1

ZX014222




## FUNCTIONAL SCHEMATIC OF SECTION 25B

A5 — Combine data center	R10 — Potentiometer, chaffer	S71 — Height cut-off switch	X38 — Disconnect point, cab harness (W2), optional harness (W14)
A9 — Control board, combine data center	R11 — Potentiometer, sieve	V10 — Diode	X55 — Disconnect point, cab harness (W2), data center harness (W23)
A11 — Relay board, combine data center	R12 — Potentiometer, sieve extension	X9 — Connection, cab harness (W2) to relay and diode board	X79 — Splice
A14 — Relay and diode board	S32 — Header control switch	X23 — Disconnect point, cab harness (W2)-front basic harness (W7)	X82 — Plug for ultrasonic sensors
A15 — Fuse board	S36 — Concave adjustment switch	X25 — Disconnect point, main distribution harness (W1)-cab harness (W2)	
B32 — Sending unit, grain tank empty	S38 — Switch, combine data center	X35 — Disconnect point, cab harness (W2), armrest harness (W5)	
F28 — 7.5 amp fuse	S40 — Cylinder speed adjustment switch		
M8 — Concave adjusting motor	S41 — Fan speed adjustment switch		
R2 — Potentiometer, concave adjustment	S55 — Reverse travel switch		

ZX, TM4543011375-19-30JUN97

*Separator Adjustment, Combine Data Center/Separator adjustment, combine data center*

DIAGNOSTIC SCHEMATIC, SECTION 25B





# Section 250 Power Train

## Contents

### Page

#### Group 05—Hydrostatic Drive

Specifications . . . . .	250-05-1
Hydrostatic system circuit diagram . . . . .	250-05-3
Hydrostatic drive components . . . . .	250-05-4
Theory of operation, hydrostatic drive . . . . .	250-05-7
Four-wheel drive flow-control valves . . . . .	250-05-18

#### Group 10—Testing Hydrostatic System

Special tools . . . . .	250-10-1
Testing the hydrostatic system . . . . .	250-10-1
Specifications . . . . .	250-10-1
Checking charge and flushing pressure . . . . .	250-10-2

#### Group 15—Inspect Parts Subject to

Wear . . . . .	250-15-1
----------------	----------

#### Group 20—Three-Speed Transmission

Operation . . . . .	250-20-1
Lubrication . . . . .	250-20-2

*Contents*

**SPECIFICATIONS**

Item	Measurement	Specification
Variable pump and fixed-displacement motor	Displacement	75 cm <sup>3</sup> /rev. (4.6 cu.in./rev.)
Charge pump	Flow (at max. speed)	13.9 cm <sup>3</sup> /rev. (0.85 cu.in./rev.)
Variable pump swashplate	Angle variation	0° — 18°
Variable pump	Weight	70 kg (154 lb)
Fixed-displacement motor	Weight	38 kg (83.7 lb)
Control valve orifice	Diameter	0.9 mm (0.036 in.)
Hydraulic oil	Operating temperature	50 — 80°C (122 — 176°F)
Charge pump, neutral position	Pressure	1500 kPa (15 bar) (220 psi)
Charge pump, operating position	Pressure	1100 kPa (11 bar) (160 psi)
High pressure relief valves	Test pressure	Flushing pressure plus pressure setting of relief valves
Setting of high pressure relief valves	Pressure	46500 kPa (465 bar) (6750 psi)
Overload valve setting	Pressure	44000 kPa (440 bar) (6400 psi)
Oil cooler relief valve	Relief pressure	100 kPa (1 bar) (14.5 psi)
Pump and motor	Max. speed	3345 rpm
Cam lobe motor	Displacement	1200 cm <sup>3</sup> /rev. (73 cu.in./rev.)
Oil flow (forward or reverse)	Max. displacement	80 L/Min. (21 gpm)
Motor drain to reservoir	Max. oil quantity	Approx. 3.8 L/Min. (1 gpm) (each motor)
Cam lobe motor	Capacity of oil	2.8 L (0.75 U.S.gal)
Cam lobe motor	Weight	160 kg (360 lb)

ZX, TMXZCO010089-19-01AUG97

*Hydrostatic Drive/Specifications*


**2264, 2266 Combines, Option for 2258 Hillmaster  
SPECIFICATIONS**

Item	Measurement	Specification
Variable pump and fixed-displacement motor	Displacement	105 cm <sup>3</sup> /rev. (6.43 cu.in./rev.)
Charge pump	Flow (at max. speed)	17,4 cm <sup>3</sup> /rev. (106 cu.in./rev.)
Variable pump swashplate	Angle variation	0° — 18°
Variable pump	Weight	85 kg (188 lb)
Fixed-displacement motor	Weight	48 kg (106 lb)
Control valve orifice	Diameter	1.32 mm (0.052 in.)
Hydraulic oil	Operating temperature	50 — 80°C (122 — 176°F)
Charge pump, neutral position	Pressure	1500 kPa (15 bar) (220 psi)
Charge pump, operating position	Pressure	1100 kPa (11 bar) (160 psi)
High pressure relief valves	Test pressure	Flushing pressure plus pressure setting of relief valves
Setting of high pressure relief valves	Pressure	43100 kPa (431 bar) (6250 psi)
Overload valve setting	Pressure	39700 kPa (397 bar) (5750 psi)
Oil cooler relief valve	Relief pressure	340 kPa (3.4 bar) (49 psi)
Pump and motor	Max. speed	3384 rpm
Cam lobe motor	Displacement	1200 cm <sup>3</sup> /rev. (73 cu.in./rev.)
Oil flow (forward or reverse)	Max. displacement	80 L/Min. (21 gpm)
Motor drain to reservoir	Max. oil quantity	Approx. 3.8 L/Min. (1 gpm) (each motor)
Cam lobe motor	Capacity of oil	2.8 L (0.75 U.S.gal)
Cam lobe motor	Weight	160 kg (360 lb)

ZX, TMXCC0010090-19-01AUG97



**HYDROSTATIC DRIVE CIRCUIT DIAGRAM**



Y—Charge pump suction line  
Z—Return line to hydraulic system


G—Cam lobe motor, left-hand  
H—Flow control valve  
X—Return line for cam lobe motor leak-off oil

E—Four-wheel drive solenoid valve  
F—Cam lobe motor, right-hand

A—Hydraulic oil reservoir  
B—Pressure relief valve  
C—Variable pump  
D—Fixed-displacement motor

ZX004026

### HYDROSTATIC DRIVE COMPONENTS



ZX002589

A—Variable pump  
B—Hydrostatic oil tank

C—L.h. wheel motor  
D—Four-wheel drive solenoid

E—R.h. wheel motor  
F—Fixed-displacement motor

G—Oil cooler  
H—Hydrostatic oil filter

ZX.OMXZC0002225-19-05OCT92

## **HYDROSTATIC DRIVE — COMPONENTS**

The hydrostatic ground speed drive transmits engine power to the drive wheels via a hydraulic pump and motor.

Variable pump (A) is driven by the Diesel engine via intermediate drive.

Variable pump (A) is connected to fixed-displacement motor (F) by means of hoses. From the motor, power is transmitted to the individual transmission speed ranges via transmission input shaft. Finally, engine power reaches the final drives and front wheels.

When four-wheel drive is engaged, solenoid (D) directs a certain amount of oil to hydraulic (cam lobe) motors (C) and (E).

The hydrostatic drive has no oil circuit of its own, but draws oil from behind the hydraulic oil filter and returns it to the hydraulic oil reservoir via an oil cooler.

ZX, TMXZC0010111-19-01AUG97

## HYDROSTATIC DRIVE OPERATION, NEUTRAL POSITION

A—Variable pump  
B—Charge pump  
C—Charge pressure relief valve  
D—Servo control valve

E—Overload cut-off valve  
F—Fixed-displacement motor  
G—Flushing pressure relief valve  
H—High pressure relief valve

J—High pressure relief valve  
K—Four-wheel drive solenoid valve  
L—Cam lobe motor, right  
M—Cam lobe motor, left

N—Hydrostatic system oil cooler  
O—Hydraulic oil reservoir  
Q—Low pressure oil (return)  
R—Charge pressure

The hydrostatic ground speed drive consists essentially of an axial piston pump and an axial piston hydraulic motor which are connected hydraulically. The axial piston pump is driven by the Diesel engine.

Displacement of axial piston pump per revolution is variable. Therefore, this pump is referred to as "variable pump". Displacement of axial piston hydraulic motor is not variable. Therefore, this motor is called "fixed-displacement motor".

With control lever in cab in neutral position, the variable pump flow is at zero, i.e. when drive shaft rotates at rated speed, no hydraulic oil is delivered to the fixed-displacement motor.

The charge pump draws hydraulic oil into the circuit. The charge pressure relief valve, integrated in the

variable pump, limits pressure to approx. 1500 kPa (15 bar; 220 psi).


Oil flow from the pressure relief valve is routed to the hydraulic oil reservoir via the oil cooler. If housing pressure is too high (cold oil), the pressure relief valve in front of the oil cooler is activated allowing oil to flow directly to the hydraulic oil reservoir.

On machines with four-wheel drive, hydraulic (cam lobe) motors are installed at the rear wheels. When four-wheel drive is engaged, oil flow from variable pump is distributed to fixed-displacement motor and to both cam lobe motors.

The hydrostatic system has no hydraulic oil reservoir of its own, but the charge pump draws hydraulic oil from the hydraulic system return line behind the oil filter.


ZX, TMXZCO003170-19-17JAN94

### HYDROSTATIC DRIVE OPERATION, NEUTRAL POSITION



ZX005233

HYDROSTATIC DRIVE OPERATION, FORWARD TRAVEL



- Q
  - R
  - S
- ZX005234

## HYDROSTATIC DRIVE OPERATION, FORWARD TRAVEL

A—Variable pump  
B—Charge pump  
C—Charge pressure relief valve  
D—Servo control valve  
E—Overload cut-off valve

F—Fixed-displacement motor  
G—Flushing pressure relief valve  
H—High pressure relief valve  
J—High pressure relief valve

K—Four-wheel drive solenoid valve  
L—Cam lobe motor, right  
M—Cam lobe motor, left  
N—Hydrostatic system oil cooler

O—Hydraulic oil reservoir  
Q—Low pressure oil (return)  
R—Charge pressure  
S—High pressure oil

When hydrostatic drive control lever is moved forward with engine running, variable pump delivers pressure oil to the fixed-displacement motor. This motor is attached to the transmission and transmits power to the transmission input shaft. The transmission offers three different speed ratios which can be selected by means of shift lever in cab.

Forward movement of control lever is transmitted to the servo control valve of the variable pump via a

cable. The servo control valve directs oil to one of the servo pistons, which causes the swashplate to move out of neutral position.

*NOTE: On machines operating in Germany, swashplate adjusting angle for forward travel is limited. This in turn will limit max. travel speed on public roads to 20 km/h according to legal requirements.*

ZX,TMXZCO003172-19-17JAN94

## HYDROSTATIC DRIVE OPERATION, FORWARD TRAVEL WITH FOUR-WHEEL DRIVE

A—Variable pump  
B—Charge pump  
C—Charge pressure relief valve  
D—Servo control valve  
E—Overload cut-off valve

F—Fixed-displacement motor  
G—Flushing pressure relief valve  
H—High pressure relief valve  
J—High pressure relief valve

K—Four-wheel drive solenoid valve  
L—Cam lobe motor, right  
M—Cam lobe motor, left  
N—Hydrostatic system oil cooler

O—Hydraulic oil reservoir  
Q—Low pressure oil (return)  
R—Charge pressure  
S—High pressure oil

When four-wheel drive is engaged, the oil delivered by the variable pump is also routed to hydraulic motors located at the rear wheels. Flow control valves at each outlet of the four-wheel drive solenoid valve ensure sufficient oil flow to the fixed-displacement motor of the front axle.

*NOTE: When engaging four-wheel drive, ground speed control lever should be moved in*


*desired direction as far as possible to provide max. oil flow of variable pump.*

**IMPORTANT: To avoid overload damage to the hydrostatic system, four-wheel drive should only be engaged at low speeds and soft ground conditions.**


ZX, TMXZCO003174-19-17JAN94



### HYDROSTATIC DRIVE OPERATION, FORWARD TRAVEL WITH FOUR-WHEEL DRIVE



HYDROSTATIC DRIVE OPERATION, REVERSE TRAVEL



- Q
- R
- S

ZX005236

## HYDROSTATIC DRIVE OPERATION, REVERSE TRAVEL

A—Variable pump  
B—Charge pump  
C—Charge pressure relief valve  
D—Servo control valve  
E—Overload cut-off valve

F—Fixed-displacement motor  
G—Flushing pressure relief valve  
H—High pressure relief valve  
J—High pressure relief valve

K—Four-wheel drive solenoid valve  
L—Cam lobe motor, right  
M—Cam lobe motor, left  
N—Hydrostatic system oil cooler

O—Hydraulic oil reservoir  
Q—Low pressure oil (return)  
R—Charge pressure  
S—High pressure oil

For reverse travel, oil flows to the servo pistons for swashplate angle variation in opposite direction as compared to forward travel. The swashplate moves in opposite direction and the variable pump delivers pressure oil to the fixed-displacement motor, causing the motor to rotate in reverse direction.

A stop at the control lever located in the operator's cab limits swashplate angle variation for reverse

travel. This in turn limits max. oil flow and reverse travel speed.

For this reason the flow control valves at the four-wheel drive solenoid outlets for reverse travel are designed to provide less oil flow.

ZX, TMXZCO003176-19-17JAN94

## **HYDROSTATIC DRIVE OPERATION, OVERLOAD CONDITIONS**

A—Variable pump  
B—Charge pump  
C—Charge pressure relief valve  
D—Servo control valve  
E—Overload cut-off valve

F—Fixed-displacement motor  
G—Flushing pressure relief valve  
H—High pressure relief valve  
J—High pressure relief valve

K—Four-wheel drive solenoid valve  
L—Cam lobe motor, right  
M—Cam lobe motor, left  
N—Hydrostatic system oil cooler


O—Hydraulic oil reservoir  
Q—Low pressure oil (return)  
R—Charge pressure  
S—High pressure oil

When the hydrostatic system is overloaded and pressure in one of the high pressure hoses reaches 44000 kPa (440 bar; 6400 psi) or more, the overload valve in the supply line to servo control valve opens a path to route oil back to the reservoir. The pressure holding the servo pistons will drop and the swashplate moves back towards the center position.

The swashplate moves to a position in which oil delivery is just sufficient to maintain a pressure of 44000 kPa (440 bar; 6400 psi). This will avoid rapid overheating of the system.


ZX, TMXZCO003178-19-17JAN94

**HYDROSTATIC DRIVE OPERATION, OVERLOAD CONDITIONS**



ZX005237

**FOUR-WHEEL DRIVE SOLENOID VALVE, DISENGAGED POSITION**



A—High pressure oil passage (forward)  
 B—High pressure oil passage (reverse)

C—Passage to cam lobe motors (forward)  
 D—Passage to cam lobe motors (reverse)

E—Solenoid valve  
 F—Plunger  
 G—Low pressure oil (return oil)

H—Charge pressure  
 I—High pressure oil


With four-wheel drive shut off, solenoid valve (E) is not activated. Pressure oil from charge pump does not reach plunger (F). Plunger (F) remains in

left-hand end position where there is no connection between front axle drive oil passages and rear axle drive oil passages.

ZX005210 -UN-25JAN98

ZX.TMXZCO003179-19-21JUL98

**FOUR-WHEEL DRIVE SOLENOID VALVE, ENGAGED POSITION**




With four-wheel drive engaged, solenoid valve (E) is activated. Pressure oil is directed from the charge pump to face of plunger (F). Plunger (F) is moved against spring force. Now front axle high pressure

lines and rear axle high pressure lines (to cam lobe motors) are connected to each other. Hydraulic oil flow is distributed to front and rear axles.

ZX.TMXZCO003180-19-21.JUL98

## FOUR-WHEEL DRIVE FLOW CONTROL VALVES



ZX 005209

ZX005209  
-UN-28APR95

A—Housing

B—Insert

C—Piston

D—Spring

Machines with four-wheel drive are provided with four flow control valves. They are located directly at the electromagnetic control valve used for engaging four-wheel drive.

The two flow control valves for forward travel limit oil flow to 80 L/Min (21 gpm). The two flow control valves for reverse travel limit oil flow to 53 L/Min (14 gpm).

Max. delivery of variable pump is 255 L/Min (67 gpm). In Germany, max. delivery is limited to 200 L/Min (53 gpm), because speed limit for road travel is 20 km/h. For this reason the control lever must be moved as far as possible when rear wheels start to spin to ensure an adequate oil supply to fixed-displacement motor.

ZX, TMXZCO003181-19-17JAN94



# Group 10 Testing Hydrostatic System

## SPECIAL OR ESSENTIAL TOOLS

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

## TESTING HYDROSTATIC SYSTEM

Universal pressure test kit (A) . . . . . FKM10002




ZX,TMSPFH001762-19-22FEB92

-UN-02JUN95  
Z110413

## TESTING HIGH PRESSURE RELIEF VALVES

Pressure gauge . . . . . FKM10208



ZX,TMSPFH001763-19-22FEB92

ZX001661 -UN-06JUN95

## TEST PORT CONNECTIONS

Quick coupler . . . . . JT03264



ZX,TMSPFH001764-19-22FEB92

ZX001719 -UN-26APR95

## SPECIFICATIONS

Item	Measurement	Specification
Charge pressure relief valve	Charge pressure	1500 kPa (15 bar; 220 psi)
Flushing pressure relief valve	Flushing pressure	1100 kPa (11 bar; 160 psi)
High-pressure relief valves, 2254-2258	Valve setting	Flushing pressure plus 46500 kPa (465 bar; 6750 psi)
High-pressure relief valves, 2264-2266	Valve setting	Flushing pressure plus 43100 kPa (431 bar; 6250 psi)

ZX,TMXZCO010091-19-01AUG97


## TESTING HYDROSTATIC SYSTEM

**NOTE:** For all checks, oil temperature in reservoir must be 50—80°C (122—176°F).

ZX.TMSPFH001767-19-22FEB92

## CHECKING CHARGE AND FLUSHING PRESSURE

1. Move hydrostatic drive control lever to neutral position. Apply parking brake. Connect a pressure gauge with a measuring range of 0—4000 kPa (0—40 bar; 0—600 psi).
2. Run engine at fast idle. Charge pressure should now be between 1700 and 2400 kPa (17 and 24 bar; 246 and 350 psi).
3. Move hydrostatic drive control lever fully forward or rearward. A flushing pressure of at least 100 kPa (1 bar; 14 psi) below the charge pressure measured in step 2 must be obtained.




ZX001716  
-UN-01JUN95

ZX.TMXZCO010092-19-01AUG97

## CHECKING HIGH PRESSURE RELIEF VALVES — PREPARATIONS

**IMPORTANT:** When checking high pressure relief valves, observe the following points:

1. Block front wheels.
2. On both sides, disconnect drive shafts (A) from transmission by sliding sleeves (B) on shafts.
3. Apply parking brake and engage 3rd gear.



ZX001713  
-UN-01JUN95


ZX.TMSPFH001769-19-22FEB92

### CHECKING HIGH PRESSURE RELIEF VALVE FOR FORWARD TRAVEL

Connect pressure gauge to test port (A). Run engine at fast idle. Operate foot brakes and temporarily move hydrostatic drive control lever forward.

Minimum pressure must be 41 400 kPa (414 bar) (6000 psi) plus flushing pressure measured previously.

If pressure is not as specified, replace high pressure relief valve (rear valve as seen in direction of travel).




ZX,TMSPFH001770-19-22FEB92

### CHECKING HIGH PRESSURE RELIEF VALVE FOR REVERSE TRAVEL

Connect pressure gauge to test port (A). Run engine at fast idle. Operate foot brakes and temporarily move hydrostatic drive control lever rearward.

Minimum pressure must be 41 400 kPa (414 bar) (6000 psi) plus flushing pressure measured previously.

If pressure is not as specified, replace high pressure relief valve (front valve as seen in direction of travel).



ZX,TMSPFH001771-19-22FEB92

*Testing Hydrostatic System/Checking charge and flushing pressure*

## INSPECT PARTS

*NOTE: Some internal parts of the motor and pump are similar in appearance and function; others have the same part number.*

Most part failures are identifiable by inspecting the part and comparing it to the following information to determine the suspected cause of failure.

(Worn) This condition is usually indicated by a smooth but definite wear pattern in or across finished surfaces. A worn condition is usually caused by a lack of lubrication or very fine abrasive contamination suspended in the fluid.

(Scored) This condition is usually indicated by fine scratch marks in or across finished surfaces. Scoring usually is caused by a lack of or improper lubrication or possible abrasive contamination suspended in the fluid.

(Scratched) This condition is usually indicated by small scratches in or across finished surfaces. It is usually caused by abrasive contamination suspended in the fluid.

(Grooved) This condition is usually indicated by grooves cut in or across finished surfaces. Grooves are usually caused by a lack of lubrication or large particle contamination suspended in the fluid.

(Discoloration) This condition is usually indicated by a noticeable change in color on the finished surfaces. Discoloring usually is caused by a lack of or improper lubrication.

Excessive fluid temperature may also cause this condition by increasing the lubricating film loss between rotating mating parts.

(Smearred) This condition is usually indicated by the presence of bronze embedded in or across finished mating surfaces. Smearing is usually caused by a lack of or improper lubrication or possible abrasive contamination suspended in the fluid. Excessive fluid temperature may also cause this condition by the lubricating fluid film loss between rotating mating parts.

(Galled) This condition is usually indicated by the presence of material that has been removed from one surface, normally by friction, and sometimes adhered to its mating component surface. Galling usually is caused by a lack of or improper lubrication. Excessive fluid temperature may also cause this condition by increasing the lubricating fluid loss between rotating mating parts.

(Eroded) This condition is usually indicated by erosion (pitted appearance) or removal of material from finished surfaces. Eroding is usually caused by cavitation or voids in the fluid.

(Rolled) This condition is usually indicated by the extreme outer edge of the finished surface being deformed or rolled over. Rolled usually is caused by a lack of lubrication to the edges of these finished surfaces when subjected to over speeding or block lift conditions.

1401,5020,Y -19-12SEP91

## **LACK OF LUBRICATION**

The following terminology will be used for determining probable causes of system and/or part failure.

Lack of lubrication is probably the most common, yet misinterpreted terminology associated with failure analysis of system and/or part failures. It usually is a result of condition(s) that create an insufficient oil film required to lubricate rotating part surfaces.

Without the proper oil film, rotating metal-to-metal surfaces create friction and excessive temperatures that usually cause premature part failures.

Depending on the severity of the oil film loss and friction, rotating critical surfaces will become severely worn, smeared, galled or noticeably discolored.

1401,5020,AC -19-12SEP91

## **ABRASIVE CONTAMINATION**

Abrasive contamination is probably the second most common, yet identifiable terminology.

This condition usually is system-related by the introduction of abrasive foreign particles that damage the critical surface areas as they pass through the system.

These abrasive particles usually are larger than the lubricating oil film thickness required to lubricate part surfaces.

A lack of lubrication may also be created by abrasive contamination that creates excessive leakage passages between critical rotating surfaces.

Depending on the size and amount of abrasive contamination passing through or contacting parts, the rotating surfaces will become worn, scored, scratched or grooved.

1401,5020,AD -19-12SEP91

## **CAVITATION**

Cavitation is sometimes confused with the lack of lubrication which usually is the result of, but not the cause of cavitation.

This condition usually is created by the presence of air suspended in the oil.

Excessive amounts of air in the oil will not provide an adequate film required to properly lubricate.

Partial or total restriction of the pump inlet will also create cavitation.

Depending on the severity of cavitation, rotating surfaces will become eroded, scored, smeared or galled.

1401,5020,AE -19-12SEP91

## *Inspect Parts Subject to Wear*

Excessive oil temperature is sometimes the result or lack of lubrication, but not necessarily the direct cause. This condition usually is system-created by improper system cooling, high pressure oil passing over relief valves and excessive closed loop leakage. Excessive oil temperatures usually will decrease the fluid viscosity or lubrication oil film thickness required to lubricate rotating surfaces.

Depending on the condition or severity of oil temperature, rotating surfaces usually will become scored, smeared, galled or discolored.

1401,5020,AF -19-12SEP91

The most common cause of improper lubrication is created by chemical contaminants present in the hydraulic fluid, such as water. Water not only creates improper lubrication to rotating surfaces, but also creates undesirable chemical changes to the oil and mating surfaces.

Depending on the severity of the improper lubrication used, component parts usually will become discolored, scored, smeared, or galled.

1401,5020,AG -19-12SEP91

## **OVER SPEEDING**

Over speeding is sometimes associated with the lack of lubrication, which usually is the result of, but not necessarily the direct cause of over speeding.

Hydrostatic transmissions by design, are subject to operate within certain speed limitations. When units are operated above their design limitations, certain parts separate or tip, creating excessive loading to small areas of these parts.

This small area usually is located on the outer edge of rotating parts, and because of the excessive loading subject to this area, the lubrication is removed also. Depending on the severity of over speeding that creates this excessive loading and loss of lubrication to rotating parts, a rolled, scored, smeared or galled condition will occur.

1401,5020,AH -19-12SEP91

## INSPECT SHAFT SEAL

The shaft seal assembly is a pressure-type mechanical seal that consists of two mating parts, a bronze rotating half and a steel stationary half.

To properly seal the shaft, the fine lapped sealing surface located on each seal half must be smooth, flat, and free of all nicks, burrs, and scratches.

The scoring across the sealing surfaces indicates the seal was subject to abrasive contamination.



N36987 -UN-22SEP88

1401,5020,AI -19-12SEP91

The scoring marks across the sealing surface indicate that it was subject to abrasive contamination.



H50349 -UN-20JAN89

1401,5020,AJ -19-12SEP91

The smearing around the center of the sealing surface indicates it was subject to a lack of/or insufficient lubrication. This condition usually is a result of insufficient oil film to properly lubricate rotating part mating surfaces.

The discoloration on this bronze seal half indicates the possibility of excessive oil temperatures.

Water not only creates an improper lubrication condition, but will also cause undesirable chemical changes to the oil. This chemical change to the oil will cause the bronze parts to discolor or turn dark.



H50350 -UN-20JAN89

1401,5020,AK -19-12SEP91



## INSPECT THRUST PLATE

The smearing on this thrust plate surface indicates it was subjected to a lack of/ or insufficient lubrication. This condition usually is a result of insufficient oil film required to properly lubricate rotating part surfaces.

This thrust plate may be reused by installing it with the smeared side toward the swashplate, only if the thrust plate is not damaged in any way. The other finished side must be smooth, flat and free of any nicks, burrs, and scratches.

1401,5020,AL -19-12SEP91

The scoring marks on this thrust plate indicate it was subjected to abrasive contamination. This contamination may have been suspended in the oil.



H50352  
-UN-20JAN89

1401,5020,AM -19-12SEP91

The discoloration on this thrust plate indicates it was subjected to extremely high temperature. This condition is a result of very high oil temperature.

This thrust plate should not be reversed and reused because the excessive temperature created bends.



H50353  
-UN-20JAN89

1401,5020,AN -19-12SEP91


### INSPECT FIXED SWASHPLATE

The scoring on this fixed swashplate indicates it was subjected to abrasive contamination.

1401,5020,AO -19-12SEP91

### INSPECT PISTON SLIPPER

The small scratch marks across this slipper face indicates that it was subjected to some very fine abrasive.



H50355  
-UN-20JAN89

1401,5020,AP -19-12SEP91

The scoring on this piston slipper face indicates it was subjected to abrasive contamination. A small particle of contamination is embedded into the balance land of this piston slipper.



H50356  
-UN-20JAN89

1401,5020,AQ -19-12SEP91

The galling around the underside of this slipper indicates it was subjected to an over speeding condition.

Over speeding usually causes the piston slipper to tip and scrape against the edge of its mating part, creating galling.



H50357  
-UN-20JAN89

1401,5020,AR -19-12SEP91

*Inspect Parts Subject to Wear*

The smearing across this slipper indicates it was subjected to a severe lack of or insufficient lubrication.




1401,5020,AS -19-12SEP91

H50358  
-UN-20JAN89

**INSPECT PISTON RETAINER**

The scoring around the nine holes and center hole indicates it was subjected to a fine abrasive contamination.



1401,5020,AT -19-12SEP91

H50359  
-UN-20JAN89

The scoring around the nine holes indicates it was subjected to fine abrasive contamination.

The galling on the center hole usually is created by a lack of lubrication.




1401,5020,AU -19-12SEP91

H50360  
-UN-20JAN89

The slight scoring around the nine piston slipper holes indicates it was subjected to a fine abrasive.

The galling on the center hole usually is created by a lack of lubrication.



1401,5020,AV -19-12SEP91

H50361  
-UN-20JAN89

## Inspect Parts Subject to Wear

The discoloration on this retainer indicates it was subjected to possible improper lubrication or excessive heat.



1401,5020,AW -19-12SEP91

H50362  
-UN-20JAN89

### INSPECT CYLINDER BLOCK

The scoring in these cylinder barrel bushings indicates it was subjected to abrasive contamination. This contamination between the cylinder bushing and pistons caused two of the bushings to be pulled out of the cylinder barrel.




1401,5020,AZ -19-12SEP91

H50365  
-UN-20JAN89

### INSPECT BEARING PLATE


The grooving between the port or kidneys on this bearing plate indicates it was subjected to particle contamination.



1401,5020,BA -19-12SEP91

H50366  
-UN-20JAN89

The discoloration between the port or kidneys indicates it was possibly subjected to an improper oil. This condition most likely was caused by water in the system. Water under pressure tends to discolor bronze parts.



1401,5020,BB -19-12SEP91

H50367  
-UN-20JAN89

*Inspect Parts Subject to Wear*

The discoloration and grooving between the port or kidneys indicates it was not only subjected to improper fluid but also to particle contamination.



1401,5020,BC -19-12SEP91

H50368  
-UN-20JAN89


The smearing on the balance lands and slight erosion between the port or kidneys indicates it was subjected to a lack of or improper lubrication or possibly cavitation.



1401,5020,BD -19-12SEP91

H50369  
-UN-20JAN89

The corrosion appearance on the back side of the plate indicates possible cavitation. This condition usually is the result of the bearing plate being separated or pulled off its mating part in a fluttering motion.



1401,5020,BE -19-12SEP91

H50370  
-UN-20JAN89

The smearing on the balance lands, inner bearing support area and erosion of the leading edge of the port or kidneys indicates it was subjected to a lack of or improper lubrication or cavitation.




1401,5020,BF -19-12SEP91

H50371  
-UN-20JAN89


*Inspect Parts Subject to Wear*

The corrosion appearance on the back side of the plate indicates possible extended cavitation.




1401,5020,BG -19-12SEP91

The erosion noted between the port or kidneys indicates it was subjected to cavitation.




1401,5020,BH -19-12SEP91

The erosion on the leading edges and grooves between the port or kidneys indicates it was subjected to cavitation and particle contamination.



1401,5020,BI -19-12SEP91


The erosion on the leading edges and in between the port or kidneys indicates it was subjected to extended cavitation. The smearing on the inner and outer balance lands indicates a possible lack of or insufficient lubrication.



1401,5020,BJ -19-12SEP91

## Inspect Parts Subject to Wear


The smearing across the entire face of this bearing plate indicates it was subjected to a lack of or insufficient lubrication.



1401,5020,BK -19-12SEP91

H50376  
-UN-20JAN89

The severe discoloration noted on this bearing plate indicates it was subjected to a very high oil temperature.




1401,5020,BL -19-12SEP91

H50377  
-UN-20JAN89

## INSPECT VALVE PLATE


The smearing on both the inner plate and outer balance lands indicates it was subjected to a lack of or insufficient lubrication.



1401,5020,BM -19-12SEP91

H50378  
-UN-20JAN89

The heavier score marks between the port or kidneys and lighter score marks noted on the balance lands and bearing support areas indicate the valve plate was subjected to abrasive contaminants.




1401,5020,BN -19-12SEP91

H50379  
-UN-20JAN89

*Inspect Parts Subject to Wear*

The scoring marks on the balance lands and bearing support area indicate the valve plate was subjected to abrasive contamination. Also noticeable, is some smearing between the port or kidneys and inner bearing support area indicating a possible lack of or improper lubrication.



1401,5020,BO -19-12SEP91

The scoring on the balance lands and inner part of the bearing support area indicates abrasive contamination. Also noticeable is some smearing between the port or kidneys and extreme outer edge of the bearing support, which indicates possible over speeding. Over speeding usually causes the rotating parts to tip and contact only their outer edges rather than across the entire surface. When tipped, excessive loading to small contact areas occurs.



1401,5020,BP -19-12SEP91

The smearing on the bearing support area indicates the valve plate was subjected to a lack of and possibly improper lubrication. Close inspection shows cracks across this area, likely created by friction, probably as a result of the loss of lubricating oil film required to properly lubricate mating part surfaces. Also shown is some very heavy scoring between the port or kidneys caused by particle abrasive contamination suspended in the system oil.



1401,5020,BQ -19-12SEP91

The discoloration between the balance indicates it was subjected to high fluid temperature or possibly a complete loss of lubrication.



1401,5020,BR -19-12SEP91



## Inspect Parts Subject to Wear


The discoloration of this valve plate indicates it was subjected to a high oil temperature or improper fluid.



1401,5020,BS -19-12SEP91

H50384  
-UN-20JAN89

The discoloration of this valve plate indicates it was subjected to excessive oil temperature. The scoring across the plate surface indicates a possible lack of or improper lubrication.




1401,5020,BT -19-12SEP91

H50385  
-UN-20JAN89

## INSPECT BEARING AND RACE

The discoloration indicates excessive system temperatures.



1401,5020,BU -19-12SEP91

H50386  
-UN-10FEB89

The grooves across this trunnion bearing race indicates it was subjected to an improper bearing preloading. This condition is the result of the insufficient preload, allowing the trunnion to move back and forth during operation.




1401,5020,BV -19-12SEP91

H50387  
-UN-20JAN89

*Inspect Parts Subject to Wear*

**INSPECT SERVO PISTON**


The scratches on this servo piston indicate it was subjected to abrasive contamination.



H50388  
-UN-20JAN89

1401,5020,BW -19-12SEP91

The scoring inside the threaded end on this servo sleeve indicates it was subjected to abrasive contamination or lack of lubrication.




H50389  
-UN-20JAN89

1401,5020,BX -19-12SEP91

**INSPECT DRIVE SHAFT**


This broken shaft end indicates a severe side loading or misalignment.



H50390  
-UN-20JAN89

1401,5020,BY -19-12SEP91

THREE-SPEED TRANSMISSION — OPERATION



A—Transmission input shaft  
B—Countershaft  
C—Differential output shaft,  
left-hand

D—Speed sending unit  
E—Differential ring gear  
F—Differential housing

G—Differential output shaft,  
right-hand

H—Shifter fork  
I—Shifter fork


ZX001627

Power is transmitted from fixed-displacement motor of hydrostatic drive to countershaft (B) via transmission input shaft (A).

Three different speed ratios are obtained by laterally moving shifter forks (H) and (I).

ZX,TMSPFH001130-19-23SEP91

**LUBRICATION OF THREE-SPEED TRANSMISSION**



**E**   
**F**

ZX001628

ZX001628 -UN-28/JAN98

**A**—Suction filter  
**B**—Lube pump

**C**—Transmission input shaft  
**D**—Countershaft

**E**—Low-pressure oil

**F**—Charge pressure

Transmission input shaft and countershaft are pressure lubricated.

via an external line, into lubrication bore of countershaft.

Lube pump (B) draws oil from the sump and forces it into lubrication bore of transmission input shaft and,

ZX,TMSPFH001131-19-16SEP94

# Section 260 Brakes, Steering, Rear Axle

## Contents

Page

### Group 05—Brake operating system

Brake operation . . . . . 260-05-1


Pressure equalizing valve . . . . . 260-05-4

### Group 10—Drum Brakes

Components . . . . . 260-10-1

*Contents*

**BRAKE OPERATION**



ZX002587

- |                                     |                             |               |                                       |
|-------------------------------------|-----------------------------|---------------|---------------------------------------|
| A—Brake master cylinder<br>(2 used) | C—Pressure equalizing valve | F—Brake line  | J—Parking brake operating<br>assembly |
| B—Brake fluid reservoir             | D—Brake slave cylinder      | G—Bleed valve | K—Parking brake cables                |
|                                     | E—Brake line                | H—Bleed valve |                                       |

Drum brakes acting on drive shafts are located on both sides of the transmission.


Pressure equalizing valve (C) ensures equal braking action on both sides.

Brake pedal forces are transmitted hydraulically to slave cylinders (D) via two double-stage master cylinders (A).

The parking brake operated by a pedal to the left of the steering column also acts on the drum brakes. Braking force is transmitted to brake drums via cables (K).

ZX.TMXZCO002455-19-25NOV92

## BRAKE MASTER CYLINDER — OPERATION



ZX000975

A—Piston rod  
B—Double-stage piston  
C—Secondary boot

D—Primary boot (low pressure cylinder)  
E—Primary boot (high pressure cylinder)

F—Valve ball  
G—Plunger

H—Brake fluid inlet  
I—Bleed valve

Drum brakes are actuated in two stages: JOINING brake linings and drum and PRESSING linings against drum.

For joining brake linings and drum — with little pedal travel — only a low pressure is needed. The joining process is accomplished by the large diameter cylinder stage (charging stage).

To press linings against drum, a high pressure must be exerted; a relatively long pedal travel is still available for this purpose. Now the small diameter cylinder stage (pressure stage) is used.

Changing from charging stage to pressure stage is a continuous process.


### Neutral Position

The above illustration shows neutral position of double-stage brake master cylinder.

Piston (B) is in end position, there is some play between piston rod (A) and piston (B). Equalizing bores are free, allowing brake fluid to flow to the brake fluid reservoir.

ZX.TMSPFH000993-19-23JUL91





A—Piston rod  
B—Double-stage piston

C—Low pressure stage  
D—High pressure stage

E—Pressure spring  
F—Ball

G—Plunger

### Low Pressure Braking Action

When brakes are applied and piston of brake master cylinder is moved away from neutral position, the full amount of brake fluid from low pressure stage (C) and high pressure stage (D) flows to the brake slave cylinder.

The brake shoes are rapidly brought into contact with the brake drum.


When brake fluid force acting on ball (F) is bigger than force of spring (E), the ball is moved from its

seat and allows brake fluid from low pressure stage to flow back through hollow plunger.

Now only brake fluid from high pressure stage flows to the brake slave cylinder.

As soon as pressure in high pressure stage increases, pressure in low pressure stage will decrease continuously. The pressure change is transmitted to ball (F) by plunger (G).

Brake operating system/Pressure equalizing valve



- A—Piston rod
- B—Double-stage piston
- C—Low pressure stage
- D—High pressure stage
- E—Pressure spring
- F—Ball
- G—Plunger

**High Pressure Braking Action**

With brakes fully applied, i.e. very high pressure in high pressure stage (D), ball (F) is completely pushed from its seat by plunger (G). Pressure in low pressure stage drops to 0 kPa (0 bar) (0 psi).


The full pedal force is now transmitted to high pressure stage (D). A very high pressure will build up due to the relatively small piston surface, resulting in a very high braking force.

ZX,TMSPFH000995-19-23JUL91

**PRESSURE EQUALIZING VALVE**

The valve equalizes pressure in both brake circuits. This is achieved by moving piston (3) from center position.

- 1—Pressure equalizing valve
- 2—Spring
- 3—Piston
- A—Inlet port (l.h. circuit)
- B—Outlet port (l.h. circuit)
- C—inlet port (r.h. circuit)
- D—Outlet port (r.h. circuit)
- E—Brake fluid




ZX,TMSPFH001094-19-24SEP91

Brake operating system/Pressure equalizing valve

When pressure differs considerably in both brake circuits, e.g. when operating only one brake pedal or when one brake circuit fails to function, piston (3) is moved fully against the stop to maintain pressure.

- 1—Pressure equalizing valve
- 2—Spring
- 3—Piston
- A—Inlet port (l.h. circuit)
- B—Outlet port (l.h. circuit)
- C—Inlet port (r.h. circuit)
- D—Outlet port (r.h. circuit)
- E—Brake fluid




ZX, TMSPFH001095-19-02DEC92

Z25916 -JUN-28/JAN98

*Brake operating system/Pressure equalizing valve*

DRUM BRAKE COMPONENTS



-JUN-03MAY95  
ZX001625

ZX001625

- |                       |                                |                         |                             |
|-----------------------|--------------------------------|-------------------------|-----------------------------|
| A—Brake shoe          | F—Brake operating cylinder     | K—Parking brake cable   | P—Cylinder spring           |
| B—Adjusting cable     | G—Hook                         | L—Brake adjusting screw | Q—Lower retracting spring   |
| C—Eccentric plate     | H—Brake shoe retainer          | M—Support pin           | R—Upper retracting spring   |
| D—Cap screw           | I—Anchor plate attaching screw | N—Brake adjusting lever | S—Parking brake cable guide |
| E—Parking brake lever |                                | O—Retracting spring     |                             |

When operating brakes, the operating cylinder (F) forces brake shoes against the brake drum resulting in braking action.

When front brake shoe (A) moves, cable (B) is tensioned and moves lever (N) upwards. By means of this mechanism the brakes are adjusted automatically.

ZX, TMSPFH001096-19-01DEC92

*Drum Brakes/Components*

# Section 270 Hydraulic System

## Contents

### Page

#### Group 05—General Information

Description . . . . .	270-05-1
Hydraulic symbols . . . . .	270-05-2
Hydraulic system circuit diagram . . . . .	270-05-6
Hydraulic system circuit diagram, Hillmaster . . . . .	270-05-9

#### Group 10—Solenoid Valves

Solenoid valves, basic machine . . . . .	270-10-1
Solenoid valves, Hillmaster . . . . .	270-10-2
Pressure reducing valve . . . . .	270-10-23

#### Group 15—Hillmaster Leveling System

Hillmaster leveling system components . . . . .	270-15-2
Hillmaster leveling system operation . . . . .	270-15-5

#### Group 20—Hydraulic Tests

Special tools . . . . .	270-20-1
Specifications . . . . .	270-20-1
Checking pressure relief valve . . . . .	270-20-2
Checking pressure reduction unit . . . . .	270-20-2
Checking the pressure switch . . . . .	270-20-3
Checking pressure relief valve on Hillmaster block . . . . .	270-20-3

*Contents*



## DESCRIPTION OF HYDRAULIC SYSTEM

The machine is equipped with a so-called “open-center hydraulic system”, i.e. with engine running at constant speed the hydraulic pump conveys a constant amount of hydraulic oil.

The hydraulic pump is a triple pump.

Flow rates for basic machine are as follows:

- Pump (A) conveys 35 L/min. (9.2 gpm)
- Pump (B) conveys 25 L/min. (6.5 gpm)
- Pump (C) conveys 15 L/min. (4.0 gpm)

Flow rates for Hillmaster machines are as follows:





- Pump (A) conveys 45 L/min. (11 gpm)
- Pump (B) conveys 25 L/min. (6.5 gpm)
- Pump (C) conveys 35 L/min. (9.2 gpm)

For pumps (A) and (B), pressure valves are located in solenoid valve block (D) (one pressure valve for each of these pumps). If no pressure oil is required, the pressure valves direct pressure-free oil back to the reservoir via the oil cooler.

On Hillmaster combines, hydraulic pump (A) delivers oil to Hillmaster solenoid valve block (E). An integrated flow divider controls hydraulic oil flow, providing 30 L/min. (7.8 gpm) for the Hillmaster system and 15 L/min. (3.9 gpm) for the basic hydraulic functions, i.e. solenoid valve block (D).

Hydraulic functions of feeder house and header are controlled by solenoid valve blocks (F) and (G). A pressure valve in solenoid valve block (D) is also activated.

- A—Hydraulic pump**
  - Standard machine 35 L/min. (9.2 gpm)
  - Hillmaster 45 L/min. (11 gpm)
- B—Hydraulic pump 25 L/min. (6.5 gpm) (steering system)**
- C—Hydraulic pump**
  - Standard machine 15 L/min. (3.9 gpm)
  - Hillmaster 35 L/min. (9.2 gpm)
- D—Solenoid valve block, basic machine**
- E—Solenoid valve block, Hillmaster**
- F—Solenoid valve block, feeder house**
- G—Solenoid valve block, header**



ZX.TMXZCO002456-19-25NOV92

HYDRAULIC SYMBOLS (AS DEFINED BY ISO 1219)

1	
2	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	
18	

19	
20	
21	
22	
23	
24	
25	
26	
27	
28	
29	
30	

31	
32	
33	
34	
35	
36	
37	
38	
39	
40	
41	

42	
43	
44	
45	
46	
47	
48	
49	
50	
51	
52	


Z103804

## LEGEND — GRAPHIC SYMBOLS FOR HYDRAULICS

- |  |   |   |  |
|--|---|---|--|
| 1—Working (main) line  | 27—Unidirectional variable displacement pump, operating in opposite flow direction as motor                           | 34—Single acting hydraulic cylinder   | 42—Valve connections (ports) are defined by capital letters, e.g.:<br>A, B, C Working lines<br>P Inlet (pressure)lines<br>R, S Return (drain) lines<br>X, Y, Z Pilot (control) lines |
| 2—Pilot (control) line   | 28—Unidirectional fixed displacement pump/motor, operating in one flow direction as pump/motor                        | 35—Double-acting hydraulic cylinder   | 43—Zero position of directional control valves with internal return is the position to which moving valve parts return, when pressure is released.                                   |
| 3—Liquid (drain/return) line   | 29—Unidirectional variable displacement pump/motor, operating in one flow direction as pump/motor                     | 36—Double-acting differential hydraulic cylinder  | 44—Zero position of directional control valves with internal return is the position to which moving valve parts return, when pressure is released.                                   |
| 4—Bleed station  | 30—Bidirectional fixed displacement pump/motor operating in both directions as pump/motor                             | 37—Double-acting unidirectional fixed cushion hydraulic cylinder  | 45—Circulation flow path   |
| 5—Plugged port   | 31—Bidirectional variable displacement pump/motor operating in both directions as pump/motor                          | 38—Direction control valves are symbolized by multiple envelopes. The number of numerically identified envelopes equals the number of valve shift positions.  | 46—Flotation flow path   |
| 6—Port with connector  | 32—Unidirectional hydraulic transmission with unidirectional variable displacement pump and fixed displacement motor  | 39—Arrows and lines within the envelopes connect valve ports and indicate internally open flow paths. Small cross bars indicate internally blocked valve ports.   | 47—Valve ports blocked internally  |
| 7—Shaft, lever or rod  | 33—Bidirectional hydraulic transmission with bidirectional variable displacement pump and variable displacement motor | 40—Directional control valves are defined by the number of ports (ways) followed by the number of valve shift positions   | 48—Advance flow path   |
| 8—Spring   |   | 41—The first digit is the number of ports (ways); the second digit the number of valve shift positions, e.g.: 3/2 or three-way two-position valve, 4/2 or four-way two-position valve, 4/3 or four-way three-position, 5/3 or five-way three-position | 49—Reverse flow path   |
| 9—Orifice  |   |   | 50—Two-position valve with transition  |
| 10—Restriction   |   |   | 51—Direct manual operation   |
| 11—Direction of flow   |   |   | 52—Hand lever operation  |
| 12—Direction of rotation   |   |   |  |
| 13—Adjustable or variable component  |   |   |  |
| 14—Component enclosure   |   |   |  |
| 15—Pressure gauge  |   |   |  |
| 16—Pressure source   |   |   |  |
| 17—Mechanical clutch   |   |   |  |
| 18—Unidirectional fixed displacement pump  |   |   |  |
| 19—Unidirectional variable displacement pump   |   |   |  |
| 20—Bidirectional fixed displacement pump   |   |   |  |
| 21—Bidirectional variable displacement pump  |   |   |  |
| 22—Unidirectional fixed displacement motor   |   |   |  |
| 23—Unidirectional variable displacement motor  |   |   |  |
| 24—Bidirectional fixed displacement motor  |   |   |  |
| 25—Bidirectional variable displacement motor   |   |   |  |
| 26—Unidirectional fixed displacement pump, operating in opposite flow direction as motor |   |   |  |

ZX,TMSPFH000950-19-01JUL91

HYDRAULIC SYMBOLS (AS DEFINED BY ISO 1219)




Z 103805

## LEGEND — GRAPHIC SYMBOLS FOR HYDRAULICS

- |   |  |   |   |
|---|--|---|---|
| 1—Mechanical (roller-head) actuator   | 13—Pressure control valve, 0-position normally blocked                                       | 21—Adjustable pressure control valve, remote operated with internal pilot oil drain | 31—Three-way flow control valve                               |
| 2—Hydraulic actuator  | 14—Pressure control valve, 0-position normally open  | 22—Pressure relief valve, remote operated   | 32—Flow divider   |
| 3—Pneumatic actuator  | 15—Pressure relief valve, fixed spring pressure  | 23—Pressure switch  | 33—Check valve without spring                                 |
| 4—Electromagnetic (solenoid) actuator   | 16—Adjustable pressure relief valve  | 24—Orifice, fixed restriction   | 34—Spring loaded check valve                                  |
| 5—Solenoid pilot and hydraulic actuator   | 17—Adjustable pressure relief valve, remote control connection with external pilot oil drain | 25—Orifice, variable restriction  | 35—Check valve pilot-operated to open with internal oil drain |
| 6—Pneumatic pilot and hydraulic actuator  | 18—Adjustable pressure relief valve, remote control connection with internal pilot oil drain | 26—Viscosity influenced restriction   | 36—Check valve pilot-operated to open with external oil drain |
| 7—Detent actuator   | 19—Fixed pressure reduction valve, remote control connection with external pilot oil drain   | 27—Adjustable flow control valve with bypass  | 37—Pilot operated double check valve in detail                |
| 8—Spring-loaded return  | 20—Adjustable pressure control valve, remote operated with external pilot oil drain          | 28—Fixed unidirectional flow control valve  | 38—Same valve simplified                                      |
| 9—4/2 directional control valve with solenoid actuator and spring loaded return |  | 29—Variable unidirectional flow control valve                                       | 39—Hydraulic accumulator                                      |
| 10—4/2 valve with external hydraulic actuator and return                        |  | 30—Variable unidirectional flow control valve with bypass check valve               | 40—Filter, strainer   |
| 11—4/2 valve with detent and solenoid actuator and return                       |  |   | 41—Cooler   |
| 12—4/3 valve with solenoid actuator, spring centered                            |  |   | 42—Reservoir (vented)   |


ZX,TMSPFH000952-19-01.JUL91

### HYDRAULIC SYSTEM CIRCUIT DIAGRAM — BASIC MACHINE FUNCTIONS, PART 1



ZX015098

### HYDRAULIC SYSTEM CIRCUIT DIAGRAM — BASIC MACHINE FUNCTIONS, PART 2



ZX015099

## EXPLANATION OF SYMBOLS

A—Hydraulic pump	H—Hydraulic cylinder, raise reel	O—Cylinder, variable threshing cylinder drive	V—Hydraulic chaff spreader drive
B—Hydraulic pump	J—Accumulator	P—Tensioning cylinder, main drive	W—Hydraulic oil reservoir
C—Hydraulic pump	K—Hydraulic cylinder, header parallel adjustment	Q—Tensioning cylinder, unloading drive	X—Return connection from powered rear axle
D—Solenoid valve block, basic machine	L—Cylinder, variable feeder house drive	R—Pressure switch	Y—Suction line of hydrostatic ground drive
E—Solenoid valve block, feeder house	M—Hydraulic cylinder, swing out unloading auger	S—Accumulator	Z—Return line of hydrostatic ground drive
F—Solenoid valve block, header	N—Header lift cylinder	T—Hydraulic oil filter	
G—Hydraulic cylinder, horizontal reel adjustment		U—Drain connection	


*NOTE: Connections (X), (Y) and (Z) are continued in hydrostatic system circuit diagram (refer to Section 250).*

*“Y” designations of solenoids are identical with those in the electrical system diagrams.*


ZX, TMXZC0002458-19-25NOV92



### HYDRAULIC SYSTEM CIRCUIT DIAGRAM — HILLMASTER MACHINE FUNCTIONS, PART 1



### HYDRAULIC SYSTEM CIRCUIT DIAGRAM — HILLMASTER MACHINE FUNCTIONS, PART 2



ZX015101

ZX015101 -UN-24APR98

ZX.TM4543011615-19-30JUN97

## EXPLANATION OF SYMBOLS

A—Hydraulic pump	J—Hydraulic cylinder, header parallel adjustment	N—Header lift cylinder	U—Drain connection
B—Hydraulic pump	(master cylinder at final drive)	O—Cylinder, variable threshing cylinder drive	V—Hydraulic chaff spreader drive
C—Hydraulic pump	K—Hydraulic cylinder, header parallel adjustment	P—Tensioning cylinder, main drive	W—Hydraulic oil reservoir
D—Solenoid valve block, basic machine	L—Cylinder, variable feeder house drive	Q—Tensioning cylinder, unloading drive	X—Return connection from powered rear axle
E—Solenoid valve block, feeder house	M—Hydraulic cylinder, swing out unloading auger	R—Pressure switch	Y—Suction line of hydrostatic ground drive
F—Header quick coupler		S—Accumulator	Z—Return line of hydrostatic ground drive
G—Header quick coupler		T—Hydraulic oil filter	
H—Solenoid valve block, Hillmaster			


*NOTE: Connections (X), (Y) and (Z) are continued in hydrostatic system circuit diagram (refer to Section 250).*

*"Y" designations of solenoids are identical with those in the electrical system diagrams.*

ZX.TMXZCO002460-19-25NOV92



SOLENOID VALVES — BASIC MACHINE




ZX004160

- |   |  |
|---|--|
| Y 1 — Pressure valve 1                        | Y 22 — Solenoid, switching on separator        |
| Y 2 — Pressure valve 2                        | Y 23 — Solenoid, switching on separator        |
| Y 3 — Solenoid, raising header                | Y 26 — Solenoid, unloading grain tank          |
| Y 4 — Solenoid, lowering header               | Y 27 — Solenoid, unloading grain tank          |
| Y 5 — Solenoid, raising header                | Y 28 — Solenoid, reducing cylinder speed       |
| Y 6 — Solenoid, lowering header               | Y 29 — Solenoid, increasing cylinder speed     |
| Y 10 — Solenoid, swinging in unloading auger  | Y 30 — Solenoid, reducing feeder house speed   |
| Y 11 — Solenoid, swinging out unloading auger | Y 31 — Solenoid, increasing feeder house speed |
| Y 14 — Solenoid, header leveling, left side   |  |
| Y 15 — Solenoid, header leveling, right side  |  |
| Y 21 — Solenoid not allocated                 |  |

ZX.TMXZCO003067-19-25NOV93

### SOLENOID VALVES — HILLMASTER



Y 7 — Pressure valve 3  
Y 12 — Solenoid, leveling system, left


Y 13 — Solenoid, leveling system, right  
Y 20 — Solenoid, lowering combine

**ZX004161**

ZX004161 -JUN-03/MAY95

ZX.TMXZCO003068-19-25NOV93

**SOLENOID VALVE PLATE FOR HORIZONTAL REEL ADJUSTMENT, NEUTRAL POSITION**



UN-06MAY98  
ZX004137

ZX004137


- |                     |                            |                            |                        |
|---------------------|----------------------------|----------------------------|------------------------|
| A—Solenoid          | F—Control plunger          | L—Check valve seat         | Q—Check valve          |
| B—Solenoid          | G—Return oil passage       | M—Piston                   | R—Return oil passage   |
| C—Needle valve      | H—Check valve              | N—Return oil passage       | S—Needle valve seat    |
| D—Needle valve seat | J—Connection, working line | O—Check valve seat         | T—Needle valve         |
| E—Spring            | K—Thermal relief valve     | P—Connection, working line | U—Pressure oil passage |

The solenoid valve plate for horizontal reel adjustment is a 3/4 directional control valve plate with integrated check valves.

In neutral position, solenoids (A) and (B) are closed (without current). Orifices of control plunger (F) relieve pressure on both sides of plunger, moving it to center position. Both check valves are closed.

ZX.TMXZCO003069-19-25NOV93

**SOLENOID VALVE PLATE FOR HORIZONTAL REEL ADJUSTMENT, WORKING POSITION**



ZX004138 -UN-22APR98

- |                     |                            |                            |                        |
|---------------------|----------------------------|----------------------------|------------------------|
| A—Solenoid          | F—Control plunger          | L—Check valve seat         | Q—Check valve          |
| B—Solenoid          | G—Return oil passage       | M—Piston                   | R—Return oil passage   |
| C—Needle valve      | H—Check valve              | N—Return oil passage       | S—Needle valve seat    |
| D—Needle valve seat | J—Connection, working line | O—Check valve seat         | T—Needle valve         |
| E—Spring            | K—Thermal relief valve     | P—Connection, working line | U—Pressure oil passage |


In working position, needle valve (C) or (T) is opened electromagnetically. Control plunger (F) moves to the right or left and routes pressure oil to the working line

via the check valve. Pressure moves piston (M) to the opposite side, opening return check valve. The reel is moved forward or rearward.

ZX.TMXZCO003070-19-25NOV93



**SOLENOID VALVE PLATE FOR REEL LIFT, NEUTRAL POSITION**



ZX004139

ZX004139 -UN-28AFR98

A—Solenoid  
B—Solenoid  
C—Needle valve

D—Needle valve seat  
E—Cylinder connection

F—Return oil passage  
G—Needle valve seat


H—Needle valve  
J—Accumulator connection

A hydraulic cylinder or a hydraulically adjustable variable drive is connected to (E).

When using solenoid valve plate on cutting platform, an accumulator is connected to (J) to facilitate the coupling process.

ZX.TMXZCO003071-19-25NOV93

**SOLENOID VALVE PLATE FOR REEL LIFT, 'RAISE' POSITION**



ZX004140

ZX004140 -UN-28APR98


- |                |                       |                      |                          |
|----------------|-----------------------|----------------------|--------------------------|
| A—Solenoid     | D—Needle valve seat   | F—Return oil passage | H—Needle valve           |
| B—Solenoid     | E—Cylinder connection | G—Needle valve seat  | J—Accumulator connection |
| C—Needle valve |                       |                      |                          |

Needle valve (C) is opened, routing pressure oil to connection (E).

Needle valve (H) is opened to lower reel.

ZX.TMXZCO003072-19-25NOV93

**SOLENOID VALVE PLATE FOR PRESSURE RELIEF (HEADER LATERAL TILT)**



A—Solenoid (not installed)  
 B—Needle valve  
 C—Needle valve seat

D—Pressure oil passage  
 E—Return oil passage  
 F—Control plunger

G—Hydraulic cylinder connection  
 H—Hydraulic cylinder connection

J—Check valve


This solenoid valve plate is used on machines provided with header lateral tilt function.

When the cutting platform is lowered and touches the ground on one side, high pressure is created on

corresponding side of double-acting hydraulic cylinder. The pressure relief valves installed on right and left-hand side limit pressure to 12500 kPa (125 bar; 1800 psi), controlled by needle valve (B).

ZX.TMXZCO003073-19-25NOV93

**SOLENOID VALVE PLATE FOR HEADER LATERAL TILT, NEUTRAL POSITION**



ZX004142 -UN-23APR98


- |                     |   |                            |                        |
|---------------------|---|----------------------------|------------------------|
| A—Solenoid          | G—Return oil passage                          | L—Check valve seat         | Q—Check valve          |
| B—Solenoid          | H—Check valve                                 | M—Piston                   | R—Return oil passage   |
| C—Needle valve      | J—Connection, working line                    | N—Return oil passage       | S—Needle valve seat    |
| D—Needle valve seat | K—Connecting passage to pressure relief plate | O—Check valve seat         | T—Needle valve         |
| E—Spring            |   | P—Connection, working line | U—Pressure oil passage |
| F—Control plunger   |   |                            |                        |

The function of the solenoid valve plate for header lateral tilt corresponds to the function of the solenoid valve plate for horizontal reel adjustment (refer to information in this Group).

The only difference is that two connecting passages (K) to the solenoid valve plate for pressure relief are provided.

ZX.TMXZCO003074-19-25NOV93

**SOLENOID VALVE PLATE FOR HEADER LATERAL TILT, WORKING POSITION**



ZX004143 -UN-23APR98

- |                     |   |                            |                        |
|---------------------|---|----------------------------|------------------------|
| A—Solenoid          | G—Return oil passage                          | L—Check valve seat         | Q—Check valve          |
| B—Solenoid          | H—Check valve                                 | M—Piston                   | R—Return oil passage   |
| C—Needle valve      | J—Connection, working line                    | N—Return oil passage       | S—Needle valve seat    |
| D—Needle valve seat | K—Connecting passage to pressure relief plate | O—Check valve seat         | T—Needle valve         |
| E—Spring            |   | P—Connection, working line | U—Pressure oil passage |
| F—Control plunger   |   |                            |                        |

In working position, needle valve (C) or (T) is opened electromagnetically. Control plunger (F) is moved to the right or left and directs pressure oil to the working

line via the check valve. Pressure moves piston (M) to the opposite side, opening return check valve. The cutting platform is tilted to the right or left.


ZX.TMXZCO003075-19-25NOV93

## **SOLENOID VALVE PLATE FOR HARVESTING UNIT VARIABLE DRIVE**

*NOTE: The solenoid valve plate for harvesting unit variable drive is identical with the solenoid valve plate for reel lift. Refer to information given in this Group.*

ZX, TMXZC0003076-19-25NOV93

**SOLENOID VALVE PLATE FOR SWINGING OUT UNLOADING AUGER, NEUTRAL POSITION**



ZX004144

ZX004144 -UN-23APR98


- |                     |                            |                            |                        |
|---------------------|----------------------------|----------------------------|------------------------|
| A—Solenoid          | F—Control plunger          | M—Piston                   | R—Return oil passage   |
| B—Solenoid          | G—Return oil passage       | N—Return oil passage       | S—Needle valve seat    |
| C—Needle valve      | H—Check valve              | O—Check valve seat         | T—Needle valve         |
| D—Needle valve seat | J—Connection, working line | P—Connection, working line | U—Pressure oil passage |
| E—Spring            | L—Check valve seat         | Q—Check valve              |                        |

Pilot-operated check valves are located in front of the connections to the double-acting hydraulic cylinder.

This makes it possible to hold the unloading auger securely in any position.

ZX.TMXZCO003077-19-25NOV93

**SOLENOID VALVE PLATE FOR SWINGING OUT UNLOADING AUGER, WORKING POSITION**



ZX004145 -UN-23APR98

- |                     |                            |                            |                        |
|---------------------|----------------------------|----------------------------|------------------------|
| A—Solenoid          | F—Control plunger          | M—Piston                   | R—Return oil passage   |
| B—Solenoid          | G—Return oil passage       | N—Return oil passage       | S—Needle valve seat    |
| C—Needle valve      | H—Check valve              | O—Check valve seat         | T—Needle valve         |
| D—Needle valve seat | J—Connection, working line | P—Connection, working line | U—Pressure oil passage |
| E—Spring            | L—Check valve seat         | Q—Check valve              |                        |


Plunger (F) is pressurized on one side by opening one needle valve. This moves the plunger out of center position to right or left-hand end position, providing a connection between pressure oil passage

(U) and line (J) or (P). The pressure buildup opens the check valve on the opposite side to provide a return oil connection.

ZX.TMXZCO003078-19-25NOV93



**PRESSURE VALVE IN NEUTRAL POSITION**



-UN-23APR98  
ZX004146

- A—Solenoid
- B—Needle valve
- C—Needle valve seat
- D—Pressure test connection
- E—Control plunger

- F—Orifice
- G—Control plunger seat
- H—Connection, pressure oil from hydraulic pump
- J—Return oil passage (with connection to the other valve plates)

- L—Connection, return oil to hydraulic oil reservoir
- M—Check valve plunger


- N—Pressure oil passage (with connection to the other valve plates)

With pressure valve in neutral position, needle valve (B) is open. Space behind control plunger (E) is pressure-free, because this space is connected to return oil passage and, via connection (L), to hydraulic oil reservoir.

Oil from hydraulic pump entering at connection (H) pushes plunger (E) back and returns to hydraulic oil reservoir via connection (L).

ZX.TMXZCO003079-19-25NOV93

**PRESSURE VALVE IN WORKING POSITION**



- A—Solenoid
- B—Needle valve
- C—Needle valve seat
- D—Pressure test connection
- E—Control plunger

- F—Orifice
- G—Control plunger seat
- H—Connection, pressure oil from hydraulic pump
- J—Return oil passage (with connection to the other valve plates)

- L—Connection, return oil to hydraulic oil reservoir
- M—Check valve plunger

- N—Pressure oil passage (with connection to the other valve plates)


With pressure valve in working position, needle valve (B) is pressed on its seat (C) by solenoid (A). There is no connection between space behind plunger (E) and return oil passage.

Orifice (F) builds up pressure behind plunger. Due to the pressure buildup and spring force, control plunger (E) is pressed on its seat (G). The connection to return oil passage is interrupted.

The pressure oil pushes back plunger (M) of check valve and flows into pressure oil passage (N). Pressure oil can flow from pressure oil passage (N) to one of the control valve plates (arranged parallel) to perform any desired hydraulic function.

ZX.TMXZCO003080-19-25NOV93

**PRESSURE VALVE WITH PRESSURE RELIEF VALVE**



-JUN-23/APR98  
ZX004148

**A—Connection, pressure oil from hydraulic pump**

**B—Connection, return oil to hydraulic oil reservoir**

**C—Pressure oil passage**

**D—Pressure relief valve**


Operation of pressure valve with relief valve is similar to operation of pressure valve without relief valve.

incorporated relief valve. Relief valve opening pressure is 22000 kPa (220 bar; 3200 psi).

The only difference is a connecting bore between pressure oil passage and return oil passage with

ZX.TMXZCO003081-19-25NOV93

**SOLENOID VALVE PLATE 'RAISING HARVESTING UNIT', NEUTRAL POSITION**



ZX004149 -UN-28APR98

- A—Solenoid
- B—Solenoid
- C—Needle valve
- D—Orifice
- E—Control plunger, raising

- F—Connecting passage
- G—Return passage
- H—Pressure oil passage
- J—Connecting passage

- K—Control plunger, lowering
- L—Check valve
- M—Orifice
- N—Needle valve


- X—Dimension for lift rate adjustment
- Y—Dimension for rate-of-drop adjustment

In neutral position needle valves (C) and (N) are closed by spring pressure. Pressure can be built up via orifices (M) and (D) in space behind control plungers (E) and (K) and both control plungers are pressed on their seats. Pressure oil passage (H) and return oil passage (G) are closed by lift cylinder connection.

When no hydraulic functions are operated and pressure oil passage is without pressure, check valve (L) prevents hydraulic oil from flowing back. This in turn prevents harvesting unit from lowering.

ZX.TMXZCO003082-19-25NOV93

**SOLENOID VALVE PLATE 'RAISING HARVESTING UNIT', RAISING POSITION**



- A—Solenoid
- B—Solenoid
- C—Needle valve
- D—Orifice
- E—Control plunger, raising

- F—Connecting passage
- G—Return oil passage
- H—Pressure oil passage
- J—Connecting passage

- K—Control plunger, lowering
- L—Check valve
- M—Orifice
- N—Needle valve

- X—Dimension for lift rate adjustment
- Y—Dimension for rate-of-drop adjustment


To raise harvesting unit solenoid (A) is activated. Needle valve (C) opens and so connection between space behind control plunger (E) and passage to harvesting unit lift cylinder (blocked by control plunger, E) is open.

This causes pressure to drop in space behind control plunger (E), and plunger (E) to open. Pressure oil flows past check valve (L) to harvesting unit lift cylinders.

ZX004150 -UN-28APR98

ZX.TMXZCO003083-19-25NOV93

**SOLENOID VALVE PLATE 'RAISING HARVESTING UNIT', LOWERING POSITION**



ZX004151 -UN-28APR98

ZX 004151

K

J

G

F

- A—Solenoid
- B—Solenoid
- C—Needle valve
- D—Orifice
- E—Control plunger, raising

- F—Connecting passage
- G—Return oil passage
- H—Pressure oil passage
- J—Connecting passage

- K—Control plunger, lowering
- L—Check valve
- M—Orifice
- N—Needle valve


- X—Dimension for lift rate adjustment
- Y—Dimension for rate-of-drop adjustment

To lower harvesting unit solenoid (A) is activated. Needle valve (C) opens and so connection between space behind control plunger (E) and return oil passage (G) is open.

This causes pressure to drop in space behind control plunger (E), and plunger (E) to open. Oil can now flow from harvesting unit lift cylinders to return oil passage (G).

ZX.TMXCO003084-19-25NOV93

**SOLENOID VALVE PLATE 'RAISING HARVESTING UNIT', FLOAT POSITION**



A—Solenoid  
B—Steel core  
C—Needle valve  
D—Orifice  
E—Control plunger, raising

F—Connecting passage  
G—Return oil passage  
H—Pressure oil passage  
J—Connection to lift cylinder  
K—Control plunger, lowering


L—Check valve  
M—Orifice  
N—Needle valve  
O—Connecting bore  
P—Bleed screw

X—Dimension for lift rate adjustment  
Y—Dimension for rate-of-drop adjustment

To obtain float function, the solenoid valve plate is equipped with a special solenoid (B). For float function the solenoid is supplied with an electric

current between 300 and 900 mA. Depending on current a certain needle valve (N) opening pressure is obtained which determines ground pressure.

**SOLENOID VALVE PLATE 'CYLINDER VARIABLE DRIVE ADJUSTMENT'**



ZX 004153

ZX004153 -UN-28APR98

A—Solenoid  
B—Solenoid  
C—Needle valve  
D—Needle valve seat

E—Connection, cylinder  
variable drive  
F—Pressure relief valve

G—Return oil passage  
H—Needle valve seat  
J—Needle valve

K—Pressure oil passage  
L—Return connection to  
reservoir

Threshing cylinder variable drive hydraulic cylinder is connected to connection (E) of solenoid valve plate. By activating solenoid (B) and opening needle valve (J) hydraulic oil is discharged from variable drive cylinder.


By activating a pressure valve and solenoid (A) hydraulic oil is directed to variable drive cylinder.

Pressure relief valve (F) limits pressure to 7000 kPa (70 bar; 1015 psi).

ZX, TMXZCO003086-19-14JAN94



**SOLENOID VALVE PLATE 'CYLINDER VARIABLE DRIVE ADJUSTMENT', INCREASING SPEED**



ZX 005230

ZX005230 -JUN-28APR98

A—Solenoid  
B—Solenoid  
C—Needle valve  
D—Needle valve seat

E—Connection, cylinder  
variable drive  
F—Pressure relief valve

G—Return oil passage  
H—Needle valve seat  
J—Needle valve


K—Pressure oil passage  
L—Return connection to  
reservoir

One pressure valve and solenoid (A) are activated to increase threshing cylinder speed. The orifice in the pressure oil passage limits oil flow. Pressure relief valve (F) limits pressure to 7000 kPa (70 bar;

1015 psi). An additional orifice plate is located in connection (E). This ensures that cylinder variable drive adjustment is not carried out too rapidly.

ZX, TMXZCO003167-19-14JAN94

**SOLENOID VALVE PLATE 'CYLINDER VARIABLE DRIVE ADJUSTMENT', DECREASING SPEED**



ZX 005231

ZX005231 -UN-28APR98

A—Solenoid  
B—Solenoid  
C—Needle valve  
D—Needle valve seat

E—Connection, cylinder  
variable drive  
F—Pressure relief valve

G—Return oil passage  
H—Needle valve seat  
J—Needle valve


K—Pressure oil passage  
L—Return connection to  
reservoir

Solenoid (B) is activated to decrease threshing cylinder speed. Hydraulic oil flows via needle valve

seat into the return oil passage and back to the hydraulic oil reservoir.

ZX,TMXZCO003168-19-14JAN94

**PRESSURE REDUCING VALVE**



ZX005202

-JUN-28A-PR88  
ZX005202

**A—Pressure reducing insert**

**B—Return oil passage**

**C—Pressure oil passage to main clutch solenoid valve plate**

**D—Pressure oil passage from pressure valves**


The purpose of pressure reducing valve is to limit oil pressure which is necessary for main clutch operation to 6500 kPa (65 bar; 940 psi) max.

(210 bar; 3050 psi) max. (when other hydraulic functions are operated) to 6500 kPa (65 bar; 940 psi) max. in passage (C).

The pressure reducing insert (A) limits pressure from pressure valves in passage (D) of 21000 kPa

ZX.TMXZCO003087-19-25NOV93

**SOLENOID VALVE PLATE 'ENGAGING SEPARATOR OR UNLOADING DRIVE', NEUTRAL POSITION**



ZX004154

ZX004154 -UN-23APR98

A—Solenoid  
B—Solenoid  
C—Needle valve

D—Needle valve seat  
E—Connection to main  
clutch

F—Return oil passage  
G—Needle valve seat


H—Needle valve  
J—Pressure oil passage

With solenoid valve plate in neutral position, solenoid valve (A) is closed without current and solenoid valve (B) open without current. In this position

connection (E) leading to main clutch, is connected to return oil passage. Main clutch is without pressure and thus disengaged.

ZX.TMXZCO003088-19-25NOV93

**MAIN CLUTCH SOLENOID VALVE PLATE IN OPERATING POSITION**



ZX004155

-JUN-23APR98  
ZX004155

A—Solenoid  
B—Solenoid  
C—Needle valve

D—Needle valve seat  
E—Connection to main  
clutch

F—Return oil passage  
G—Needle valve seat

H—Needle valve  
J—Pressure oil passage


With solenoid valve in operating position solenoid valves (A) and (B) are activated, solenoid valve (A) opens and provides a connection between pressure oil passage and connection (E).

Solenoid valve (B) interrupts connection to return oil passage.

Via connection (E) pressure is built up in main clutch and main clutch is engaged.

ZX.TMXZCO003089-19-25NOV93

**FLOW DIVIDER (HILLMASTER)**



ZX004156

ZX004156 -UN-22APR98

A—Supply from pump  
B—Spool

C—Pressure oil passage  
(primary system)

D—Return oil passage  
E—Connection to main  
solenoid valve block

The first module at hillmaster combine hydraulic valve block is the flow divider. It is supplied from hydraulic pump with 45 L/min (12 US gal/min) oil via connection (A). Hillmaster system is supplied with priority via spool (B) and passage (C) with 27 L/min

(7 US gal/min) oil approx. The surplus amount of oil of 18 L/min (5 US gal/min) approx. flows via connection (E) to secondary system, the combine main valve block with pressure valve (Y1).


ZX.TMXZCO003090-19-25NOV93

## **PRESSURE VALVE, HILLMASTER**

Function of pressure valve of hillmaster combine solenoid valve block is the same as function of pressure valve on basic machine. The difference is that on hillmaster combines no check valve is installed. Opening pressure of pressure relief valve is 22000 KPa (220 bar; 32000 psi).

ZX, TMXZC0003091-19-25NOV93

**SOLENOID VALVE PLATE 'HILLMASTER', TILTING LATERALLY**



ZX004157 -UN-23APR98  
ZX004157

- |                     |                         |                         |                        |
|---------------------|-------------------------|-------------------------|------------------------|
| A—Solenoid          | G—Return oil passage    | N—Return oil passage    | S—Needle valve seat    |
| B—Solenoid          | H—Check valve           | O—Check valve seat      | T—Needle valve         |
| C—Needle valve      | J—Connection, work line | P—Connection, work line | U—Pressure oil passage |
| D—Needle valve seat | L—Check valve seat      | Q—Check valve           | V—Thermal relief valve |
| E—Spring            | M—Plunger               | R—Return oil passage    | W—Thermal relief valve |
| F—Control plunger   |                         |                         |                        |


Function of solenoid valve plate shown is the same as the function of solenoid valve plate for swinging out unloading auger. A difference is, that on hillmaster combines a pressure relief valve (V) and

(W) is integrated in each connection for work line. This is to avoid pressure build-up caused by heating up hydraulic oil by solar radiation.

ZX.TMXZCO003092-19-25NOV93



**SOLENOID VALVE PLATE 'LOWERING MACHINE', NEUTRAL POSITION**



A—Solenoid  
B—Needle valve  
C—Needle valve seat

D—Control plunger  
E—Connection to piston side  
of hillmaster hydraulic  
cylinders

F—Return oil passage  
G—Passage without function  
H—Adjusting screw


X—Dimension for adjustment  
20 mm (0.88 in.)

In neutral position, needle valve (B) is closed. Pressure from connection (E) also builds up behind plunger (D). This closes passage (F) and return line to hydraulic oil reservoir.

With needle valve (B) open, no pressure can build up behind plunger (D). This will open return oil passage and the oil can flow to the hydraulic oil reservoir.

ZX, TMXZCO003166-19-13JAN94

**SOLENOID VALVE PLATE 'LOWERING MACHINE'**



ZX004158

-UN-28APR98  
ZX004158

- |                     |  |                                      |   |
|---------------------|--|--------------------------------------|---|
| A—Solenoid          | D—Control plunger                            | F—Return oil passage                 | H—Adjusting screw                           |
| B—Needle valve      | E—Connection of piston-side connecting lines | G—Passage without function (blocked) | X—Dimension for adjustment 20 mm (0.80 in.) |
| C—Needle valve seat |  |                                      |   |

Connection (E) is connected to hydraulic line connecting hillmaster cylinder piston sides. Oil flowing during normal lateral tilting from one hydraulic cylinder to the other, is directed to return oil passage if

solenoid (A) is activated. This prevents one hydraulic cylinder from extending when the other one is retracted, and the machine is lowering.

ZX.TMXZCO003093-19-25NOV93




## Group 15 Hillmaster Leveling System

### GENERAL INFORMATION

On combines with Hillmaster leveling system, final drives pivot on front axle. Final drive position is determined by hydraulic cylinders (one on each side of the combine).


The cutting platform pivots on feeder house. Cutting platform position in relation to slope angle is determined by a master cylinder on final drive and a slave cylinder on pivoting shield of feeder house.

- A—Pivoting final drive
- B—Final drive hydraulic cylinder
- C—Pivoting shield hydraulic cylinder



ZX, TMXZCO003147-19-07JAN94

## HILLMASTER LEVELING SYSTEM COMPONENTS



ZX015102

ZX,TMXZCO003148-19-30JUN97

-JUN-24APR98  
ZX015102

## HILLMASTER LEVELNG SYSTEM COMPONENTS

A—Final drive, right  
B—Final drive, left  
C—Hillmaster hydraulic cylinder, right

D—Hillmaster hydraulic cylinder, left  
E—Level sensing control box

F—Flow divider  
G—Pressure valve  
H—Solenoid valve plate, tilting to the right/left


J—Solenoid valve plate, lowering combine

The final drives are bolted to two support plates, which can be pivoted around a horizontal axis relative to the axle. The plate is held in a certain position relative to the axle or pivoted by a large hydraulic cylinder.

A pendulum in the level sensing control box is used to sense slope angle. This box transmits a signal until the pendulum is centered in the box and the combine is exactly level.

ZX,TMXZCO003149-19-07JAN94

### PREPARING HILLMASTER LEVELING SYSTEM FOR OPERATION



ZX005222

## PREPARING HILLMASTER LEVELING SYSTEM FOR OPERATION

A—Hydraulic cylinder, right  
B—Hydraulic cylinder, left  
C—Pilot-operated check valve  
D—Pilot-operated check valve

E—Solenoid valve plate, Hillmaster control  
F—Solenoid valve plate, lowering combine

G—Reservoir  
H—Hydraulic oil, high pressure  
J—Hydraulic oil, pressure-free (return oil)

K—Hydraulic oil, trapped  
L—Hydraulic oil, trapped

Before operating Hillmaster leveling system, it is necessary to move the machine from lowered position (for road travel) to higher position (for field operation).

This is done by moving combine to maximum right or left-hand tilt position by operating manual leveling control switch.


During the tilting process, the solenoid valve directs hydraulic oil to the rod side of one hydraulic cylinder

and, via the check valves in the piston, to the piston side of the opposite cylinder. The piston side of the hydraulic cylinder is filled with hydraulic oil, causing the cylinder to extend.

When the combine is moved back to center position, oil flows back from the piston side of the extended hydraulic cylinder. This means that both hydraulic cylinders are halfway extended with combine in center position (on level ground).

ZX, TMXZCO003151-19-07JAN94

### HILLMASTER LEVELING SYSTEM OPERATION, LEVELING TO THE RIGHT



ZX005224

## HILLMASTER LEVELING SYSTEM OPERATION, LEVELING TO THE RIGHT

A—Hydraulic cylinder, right  
B—Hydraulic cylinder, left  
C—Pilot-operated check valve  
D—Pilot-operated check valve

E—Solenoid valve plate, Hillmaster control  
F—Solenoid valve plate, lowering combine

G—Reservoir  
H—Hydraulic oil, high pressure  
J—Hydraulic oil, pressure-free (return oil)

K—Hydraulic oil, trapped  
L—Hydraulic oil, trapped

*NOTE: During leveling system operation, the machine is held in position by pilot-operated check valves integrated in the hydraulic cylinders, e.g. if a hydraulic hose should burst. Hydraulic oil is trapped on the piston side of hydraulic cylinders.*

When leveling to the right, the solenoid valve plate routes hydraulic oil to the right-hand hydraulic cylinder. Oil pressure is directed to the rod side of the hydraulic cylinder. At the same time the pilot-operated check valve in the hydraulic cylinder head is activated, allowing trapped oil to flow out of


the piston side. The right-hand hydraulic cylinder is retracted.

The oil flow from the right-hand cylinder is directed to the piston side of the left-hand cylinder. The left-hand cylinder is extended by the same distance as the right-hand cylinder is retracted.

The oil flowing out of the rod side of the left-hand hydraulic cylinder is directed to the return passage of the solenoid valve plate and returned to the hydraulic oil reservoir.



**HILLMASTER LEVELING SYSTEM OPERATION, LEVELING TO THE LEFT**



ZX005226

## HILLMASTER LEVELING SYSTEM OPERATION, LEVELING TO THE LEFT

A—Hydraulic cylinder, right  
B—Hydraulic cylinder, left  
C—Pilot-operated check valve  
D—Pilot-operated check valve

E—Solenoid valve plate, Hillmaster control  
F—Solenoid valve plate, lowering combine

G—Reservoir  
H—Hydraulic oil, high pressure  
J—Hydraulic oil, pressure-free (return oil)

K—Hydraulic oil, trapped  
L—Hydraulic oil, trapped

*NOTE: During leveling system operation, the machine is held in position by pilot-operated check valves integrated in the hydraulic cylinders, e.g. if a hydraulic hose should burst. Hydraulic oil is trapped on the piston side of hydraulic cylinders.*

When leveling to the left, the solenoid valve plate routes hydraulic oil to the left-hand hydraulic cylinder. Oil pressure is directed to the rod side of the hydraulic cylinder. At the same time the pilot-operated check valve in the hydraulic cylinder head is

activated, allowing trapped oil to flow out of the piston side. The left-hand hydraulic cylinder is retracted.

The oil flow from the left-hand cylinder is directed to the piston side of the right-hand cylinder. The right-hand cylinder is extended by the same distance as the left-hand cylinder is retracted.

The oil flowing out of the rod side of the right-hand hydraulic cylinder is directed to the return passage of the solenoid valve plate and returned to the hydraulic oil reservoir.

ZX, TMXZCO003155-19-07 JAN94




## HILLMASTER LEVELING SYSTEM OPERATION, LOWERING COMBINE

*NOTE: Before driving a Hillmaster combine on public roads, it must be moved to lowered position to ensure that the maximum permissible height of 4 m (13 ft) is not exceeded.*

When lowering a Hillmaster combine, the solenoid valve plate for lowering combine is activated as well as the lateral tilt hydraulic function. In this case the oil displaced from the piston side does not flow to the opposite hydraulic cylinder, but to the hydraulic oil reservoir via the solenoid valve plate for lowering combine.

*NOTE: For more information on solenoid valve plate function, refer to Group 10 of this Section. Electrical system operation is described in Group 240-15Y.*




ZX 005228

ZX005228 -UN-02MAY95

ZX, TMXZCO003157-19-07JAN94

**CHECK VALVE IN HILLMASTER HYDRAULIC VALVE BLOCK**



ZX 005225

ZX006225 -UN-23APR98

A—Connection to piston side of hydraulic cylinder  
 B—Connection to rod side of hydraulic cylinder  
 C—Connection to hydraulic oil reservoir

D—Connection to piston side of opposite hydraulic cylinder  
 H—Hydraulic oil, high pressure

J—Hydraulic oil, pressure-free (return oil)  
 K—Hydraulic oil, trapped

L—Hydraulic oil, trapped

When the solenoid valve plate of Hillmaster leveling system is activated, it will direct hydraulic oil to the rod side of the hydraulic cylinder to be retracted. At the same time, hydraulic oil pressure opens pilot-operated check valve via connection (B). This

allows oil from the piston side to flow to the opposite hydraulic cylinder via connections (A) and (D). Connection (C) to the hydraulic oil reservoir is always pressure-free.

ZX, TMXZCO003158-19-07JAN94



## SPECIAL OR ESSENTIAL TOOLS

*NOTE: Order tools according to information given in the U.S. SERVICEGARD™ Catalog or in the European Microfiche Tool Catalog (MTC).*

DX,TOOLS -19-20JUL95

Universal pressure test kit (A) . . . . . FKM10002



ZX,TMSPFH001812-19-22FEB92

Quick coupler . . . . . JT03264



ZX,TMSPFH001805-19-22FEB92

## SPECIFICATIONS

Item	Measurement	Specification
Hydraulic pump I (standard)	Delivery	35 L/Min. (9.2 gpm)
Hydraulic pump I (Hillmaster)	Delivery	45 L/Min. (11 gpm)
Hydraulic pump III (standard)	Delivery	15 L/Min. (4 gpm)
Hydraulic pump III (Hillmaster)	Delivery	35 L/Min. (9.2 gpm)
Pressure relief valve	Setting	21 000 kPa (210 bar) (3050 psi)
Pressure reduction unit	Setting	6500 kPa (65 bar) (940 psi)
Main clutch pressure	Minimum pressure	5000 kPa (50 bar) (725 psi)
Pressure switch	Shut-off pressure	6000 kPa (60 bar) (870 psi)
Variable threshing cylinder drive pressure	Maximum pressure	7000 kPa (70 bar) (1020 psi)

ZX,TMXZCO003159-19-13JAN94

### CHECKING PRESSURE RELIEF VALVE


Connect a pressure gauge with a measuring range of 0—25 000 kPa (0—250 bar) (0—3600 psi) to test port (A).

Run engine at fast idle.

Press switch for raising header.

Read pressure at gauge. Pressure should be 21 000 kPa (210 bar) (3050 psi).

If this pressure is not obtained, the cause may be a malfunction of the pressure relief valve, the pressure valve or the corresponding hydraulic pump section.



ZX, TMXZCO003160-19-13JAN94


Connect a pressure gauge with a measuring range of 0—25 000 kPa (0—250 bar) (0—3600 psi) to test port (B).

Run engine at fast idle.

Press switch for raising header.

Read pressure at gauge. Pressure should be 21 000 kPa (210 bar) (3050 psi).

If this pressure is not obtained, the cause may be a malfunction of the pressure relief valve, the pressure valve or the corresponding hydraulic pump section.




ZX, TMXZCO003161-19-13JAN94

### CHECKING PRESSURE REDUCTION UNIT

1. Connect a pressure gauge to test port (A).
2. Engage unloading drive with engine running.
3. Swing in unloading auger against stop until pressure relief valve is activated.

The gauge should show a pressure of 6500 kPa (65 bar) (940 psi).



ZX, TMXZCO003162-19-13JAN94




### CHECKING PRESSURE SWITCH

1. Referring to “Checking Pressure Reduction Unit”, perform steps 1 and 3.

2. Temporarily disengage and reengage main clutch to discharge accumulator. When pressure has dropped to 5000 kPa (50 bar) (725 psi), it should increase again to 6000 kPa (60 bar) (8700 psi).

A—Test port




ZX, TMXZCO003163-19-13JAN94

### CHECKING THE PRESSURE RELIEF VALVE ON THE HILLMASTER BLOCK

Connect pressure gauge to test port (B).

Swing out the hillmaster combine automatically. Maximum pressure should be no more than 21000 kPa (210 bar; 3050 psi).

Swing out the hillmaster combine manually as far as the stop. Maximum pressure should be approx. 15000 kPa (150 bar; 2180 psi).



ZX, TMXZCO006773-19-01SEP96

*Hydraulic Tests/Checking pressure relief valve on Hillmaster block*

# Section 290 Operator's Cab

## Contents

### Page

#### **Group 05—Operator's Cab and Seat**

Operator's seat and passenger seat . . . .	290-05-3
Air comfort seat . . . . .	290-05-3
System diagnosis, air comfort seat . . . . .	290-05-4

#### **Group 10—Air Conditioning and Heating**

Compressor with drive . . . . .	290-10-1
Temperature control switch with sensor . .	290-10-4
Evaporator with expansion valve . . . . .	290-10-5
Air control flap . . . . .	290-10-5
Heater control valve and air conditioning low pressure switch . . . . .	290-10-6

#### **Group 15—Troubleshooting - Ventilation and Heating Systems . . . . .**

#### **Group 20—Operational Tests and Troubleshooting**

Refrigerant . . . . .	290-20-5
Special tools . . . . .	290-20-6
Specifications . . . . .	290-20-7
Troubleshooting . . . . .	290-20-8
Pressure deviations . . . . .	290-20-15

#### **Group 25—Operation — Air Conditioning System**


Heat exchange . . . . .	290-25-1
Refrigerant . . . . .	290-25-2
Refrigerant circuit . . . . .	290-25-3
Compressor . . . . .	290-25-6
Condenser . . . . .	290-25-6
Receiver-drier . . . . .	290-25-7
Expansion valve . . . . .	290-25-8
Thermostat switch . . . . .	290-25-9
Evaporator . . . . .	290-25-10

*Contents*

### OPERATOR'S CAB

Located on the machine's center-line, the operator's cab is supported by four silent blocks to minimize vibrations and noise. It also ensures good views to the front and rear as well as to the sides.

The operator's cab, manufactured as an assembly, is delivered fully assembled to the production line. It is available with or without air conditioning system.



ZX013861


ZX013861 -UN-06MAR98

ZXTMXZCO 011389-19-05MAR98

### CAB AIR FILTER

At the cab rear wall, fresh air for heating and air conditioning system is aspirated via plastic tube connected to the cab fan. The air filter will be accessible from outside after opening the housing cover located near the cab door.

With the introduction of the new cab, all plastic parts are identified by a part number and a material code to permit recycling according to the type of material.




ZX002278

ZX002278 -UN-12JUN95

ZX,TMSPFH001907-19-22APR92

### AIR INTAKE AND DISTRIBUTION



ZX007804

A—Air intake channel  
B—Air (main) filter

C—Recirculating air filter

D—Fan

E—Air outlet channels

ZX.OMXZC0002230-19-02MAY96

## OPERATOR'S SEAT AND PASSENGER SEAT

The mechanically suspended operator's seat can be adjusted in length and height and can be adapted to the weight of the operator.

The passenger seat is standard equipment and includes a storage compartment in the folding seat backrest.



ZX, TMSPFH001894-19-22APR92


## AIR COMFORT SEAT

The seat's spring setting can be varied from soft to hard by means of lever (A).

After starting the engine, release lever (B) briefly to bring the seat to its central position.

To adjust the height, pull lever (B) upward or push it down.

- A—Spring setting adjustment
- B—Height and weight adjustment
- C—Horizontal adjustment
- D—Lumbar support adjustment



ZX, OMSPFH003237-19-01MAY94

## SYSTEM DIAGNOSIS ON AIR COMFORT SEATS

Symptom	Problem	Solution
<b>Correct weight adjustment not possible</b>	Springs over-extended	Replace springs.
	Spring broken	See above.
<b>Seat bounces</b>	Shock absorber defective	Replace shock absorber.
<b>Seat cannot be adjusted</b>	Loose screw connections	Tighten or replace screw connections.
	Locking device defective	Replace locking device.
<b>Seat shakes</b>	Loose screw connections	Tighten or replace screw connections.
	Wire not connected or loose	Reconnect or replace wire. See Section 240, Group 10
<b>Seat does not move to center position</b>	Fuse defective	Replace fuse
	Compressor defective	Replace compressor
	Air spring defective	Replace air spring

ZX.TMXZCO010093-19-01AUG97




### COMPRESSOR WITH DRIVE

Compressor (A) of the air conditioning system is driven by a V-belt from the front belt pulley on the engine.

Power is transmitted by the electromagnetic clutch of the compressor.

When starting the engine, a tension spring on the compressor support tensions the drive. During operation, the drive belt is self-tensioning.

The belt can be aligned by shifting the support laterally in the slots.



-JUN-21/APR95  
ZX005684

ZX.TMXZC0010094-19-01AUG97


### AIR CONDITIONING AND HEATER UNIT

The air conditioning and heater unit is located underneath the passenger seat in the operator's cab of the machine.

The heater unit is standard equipment, while the air conditioning system is optional. The cooling compartment is an option for machines equipped with air conditioning system.

The dual housing includes the fan (B), the heater block (I) and the evaporator (G).

Outside air is sucked in by fan (B) via filter (C) and cab air is sucked in via filter (L). Via two hoses located in the cab floor the air is conveyed from the air conditioning and heater unit to the front corner posts with adjustable louvers .



-JUN-01/JUN95  
ZX001791

- A—Operator's seat
- B—Fan
- C—External air filter
- D—Passenger seat
- E—Cooling compartment
- F—Air control flap of cooling compartment
- G—Evaporator
- H—Air conditioning and heater unit
- I—Heater block
- K—Air control flap
- L—Interior air filter

ZX.TMSPFH001896-19-05MAR98

## AIR CONDITIONING HOUSING


The air conditioning housing is attached at three locations (C) (two on the floor and one on the rear wall).

The filtered fresh air enters the cab at the air inlet (B).

Plug (A) connects the fan motor wiring harness with the cab wiring harness.

The air conditioning housing includes the fan, the heater unit, the evaporator and an air control flap.

- A—Plug for fan motor cable
- B—Fresh air inlet
- C—Housing attaching points



ZX001792 -UN-02JUN95

ZX,TMSPFH001897-19-22APR92

## AIR CONDITIONING HOUSING (LEFT-HAND SIDE)

Machines equipped with air conditioning system may also be equipped with a cooling compartment to keep food cool and fresh.


The bottom and the rear of the cooling compartment are double-walled to permit passage of cool air.

The air control flap (B) of the cooling compartment is operated by means of a rotary switch on the switch console via bowden cable (C).

Stale air returns to the air conditioning housing via upper hose connection (A).

On machines without cooling compartment, outlets (A) and (B) for recirculating air must be closed by means of plugs.

To open the housing, remove ten retaining clamps (D).



ZX001793 -UN-02JUN95

- A—Hose connection, stale air from cooling compartment
- B—Hose connection, fresh air to cooling compartment
- C—Lever of fresh air flap
- D—Housing clamps

ZX,TMSPFH001898-19-22APR92


## AIR CONDITIONING HOUSING (RIGHT-HAND SIDE)

The fan sucks in cab air at port (A) through a filter between operator's seat and passenger seat.

Fresh air for corner post louvers is conveyed via two hoses attached to ports (B) and (C) on air conditioning housing.

One of the two screws attaching the housing to the cab floor is located at point (D).

- A—Suction port for cab air
- B—Hose connection for right-hand side
- C—Hose connection for left-hand side
- D—Bottom attaching point



-UN-02JUN95  
ZX001795


ZX,TMSPFH001891-19-22APR92

## AIR CONDITIONING HOUSING (HOSE CONNECTIONS)

Heater block (F) is connected to engine coolant circuit by means of two hoses at ports (A) and (B).

The evaporator is connected to the refrigerant circuit by means of hoses (C) and (D). The housing is sealed at the hoses by a removable seal. This seal must be removed for opening the housing. By doing this the right-hand housing half can be slid over hoses (C) and (D) of the air conditioning system.

A hose is attached to port (E) for draining condensing water through the cab floor down to the ground.



-UN-02JUN95  
ZX001796

- A—Coolant return flow to engine
- B—Coolant flow to heater block
- C—Refrigerant return hose to compressor
- D—Refrigerant hose to expansion valve
- E—Condensing water drain
- F—Heater block


ZX,TMSPFH001892-19-22APR92

## TEMPERATURE CONTROL SWITCH WITH SENSOR

On machines equipped with air conditioning system, cab air temperature is preselected (with system on) by means of temperature control switch (A) via a bowden cable. Simultaneously this cable is used to adjust air control flap via linkage (B).

Temperature sensor (C) controls fresh air blown into the cab directly at the housing outlet and monitors air temperature to the control switch.

- A—Temperature control switch
- B—Lever for air control flap
- C—Temperature sensor



ZX,TMSPFH001899-19-22APR92

## AIR CONDITIONING HOUSING IN OPEN POSITION


To clean heater block or evaporator the housing must be open. Heater block (A) is located in a housing half. To open the housing it is not necessary to remove the heater hoses. The heater block is held in position by means of a rod.

Evaporator (C) is not fixed when the housing is opened. It is kept in proper position when the housing halves are closed.

In the lower housing area a seal is installed to channel condensed water only through the port designed for this purpose.

In the upper housing half a fan (C) is installed, aspirating stale cab air and fresh air from outside which is then conveyed to the lower housing half where the evaporator and the heater block are located.

On machines not equipped with air conditioning system no evaporator (B) is installed in the fan housing.




- A—Heater block
- B—Evaporator with expansion valve
- C—Fan assembly

ZX,TMSPFH001900-19-22APR92

## EVAPORATOR WITH EXPANSION VALVE

Expansion valve (A) is directly connected to the evaporator by means of several expansion pipettes (B). The refrigerant circulates through the evaporator and returns via pipe (C) to the compressor.

- A—Expansion valve
- B—Expansion pipettes
- C—Return pipe



ZX, TMSPFH001901-19-22APR92

ZX001799 -UN-02JUN95

## AIR CONTROL FLAP

Air control flap (A) is located above the heater block.

Adjustment is made at the rotary switch for air conditioning and heating by means of the bowden cable also used for temperature control. If this switch is in neutral position (air conditioning and heating switched off), the air control flap is also closed.

If the heating is switched on by means of the rotary switch, the air control flap is always closed so that all the air will pass through the heater block.

If the air conditioning system is switched on by means of the rotary switch, the air control flap will open accordingly so cold air can bypass the heater block.

Basic adjustment for attaching the bowden cable to the temperature control lever is as follows: turn rotary switch to "MAX" cold, open air control flap fully and pull temperature control lever completely away from the housing.

On machines without air conditioning system, the bowden cable is directly attached to the lever of the air control flap. Basic adjustment is the same as above: Turn rotary switch to "MAX" cold and pull temperature control lever completely away from the housing so air control flap is fully open.



ZX, TMSPFH001902-19-22APR92


ZX002273 -UN-09JUN95

## Air Conditioning and Heating/Heater control valve and air conditioning low pressure switch

Ice protection switch (A) is activated by sensing tube (B) inserted into lower end of evaporator core as soon as evaporator starts icing.

By means of fan resistor (C) the various fan speeds are adjusted.

- A—Ice protection switch
- B—Sensing tube
- C—Fan resistor




ZX002274 -UN-09JUN95

ZX, TMSPFH001903-19-22APR92

## CAB REAR WALL

At the right-hand side of the cab rear wall the following items are easily accessible: cab wiring connectors, a socket, holes for heater and air conditioning hoses, connections for windshield washer unit and the throttle cable.

- A—Disconnecting point X51
- B—Disconnecting point X1
- C—Disconnecting point X5
- D—Disconnecting point X2
- E—Disconnecting point X6
- F—Disconnecting point X3
- G—Disconnecting point X7
- H—Disconnecting point X4
- I—Connections for windshield washer unit
- K—Throttle cable
- L—Air conditioning hoses
- M—Heater hoses
- N—Socket




ZX002275 -UN-09JUN95

ZX, TMSPFH001904-19-22APR92

## HEATER CONTROL VALVE AND AIR CONDITIONING SYSTEM LOW PRESSURE SWITCH

On the cab floor to the right of the operator's seat the heater control valve is located in the coolant line from engine to heater block. This valve is operated by the rotary heater switch via a bowden cable.

Next to it the low-pressure switch is located in the refrigerant hose. If pressure has dropped to 170 kPa (1.7 bar; 24.7 psi), this switch disengages the compressor; if pressure has risen to 350 kPa (3.5 bar; 51 psi), it reengages the compressor.



ZX002277 -UN-12JUN95

- A—Heater control valve
- B—Low pressure switch

ZX, TMSPFH001906-19-22APR92

## Group 15

# Troubleshooting - Ventilation and Heating Systems

Symptom	Problem	Solution
<b>Inadequate flow of fresh air</b>	Main filter or recirculating air filter clogged	Clean or replace filters. See Section 90, Group 10
	Air inlets clogged	Clean air inlets
	Blower motor defective	Replace blower. See Section 90, Group 10
	Blower motor switch defective	Replace switch
	Loose wire connection	Reconnect or replace wires. See Section 240, Group 10
<b>Blower not working</b>	Blower motor defective	Replace blower. See Section 90, Group 10
	Blower motor switch defective	Replace switch
	Wire broken, or loose connection	Reconnect or replace wires. See Section 240, Group 10
	Electrical circuit interrupted	Check circuit. See Section 240, Group 15
<b>Blower operating too slowly or irregularly</b>	Blower motor shaft is jamming	Replace blower. See Section 90, Group 10
	Loose wire	Reconnect wire or replace connection. See Section 240, Group 10
	Blower motor switch defective	Replace switch
<b>Inadequate heating effect</b>	Engine thermostat defective	Replace thermostat. See Component Technical Manual "Engines"
	Foreign bodies in heating element or heater hoses	Clean heater element or heater hoses
	Heater switch not operating correctly	Check heater switch. Replace if necessary. See Section 90, Group 10
	Blower not operating correctly	Clean blower. Replace if necessary
	Blockage at air inlets	Clean air inlets
<b>Ice or misting on windows does not clear properly</b>	Air louvers not directed properly	Direct the air louvers properly

Continued on next page

*Troubleshooting - Ventilation and Heating Systems*

<b>Symptom</b>	<b>Problem</b>	<b>Solution</b>
<b>Heater valve does not turn coolant flow off</b>	Blower not operating correctly	Clean blower. Replace if necessary. See Section 90, Group 10
	Heater switch not operating correctly	Check heater switch. Replace if necessary. See Section 90, Group 10
	Inlet and outlet hoses wrongly connected	Connect inlet and outlet hoses correctly. See Section 90, Group 10
	Heater switch defective	Replace heater switch. See Section 90, Group 10

ZX,TMXZCO003117-19-01DEC93



# Group 20

## Operational Tests and Troubleshooting

### TEST SEQUENCE

Perform the operational checks in 290-05 first. In many cases, this is sufficient to allow the cause of the fault to be identified.

If the operational checks in 290-05 do not identify the fault, perform the checks in 290-10A, 10B and 10C. These lead the user to the cause of the fault one step at a time.

LX,29005003398 -19-01FEB93

### OPERATIONAL CHECKS ON AIR CONDITIONING, HEATER AND OPERATOR'S SEAT

*NOTE: In the following preliminary checks, it is possible to identify a fault without using tools or a testing device.*

LX,29005003399 -19-01FEB93

<p>• <b>Tests with the engine shut off</b></p>	<ul style="list-style-type: none"> <li>• Open cab doors.</li> <li>• A/c compressor switched on.</li> <li>• Temp. selection knob set to max. cooling effect.</li> <li>• Main switch on.</li> <li>• Switch on blower several times.</li> </ul> <p><i>NOTE: The compressor clutch must give an audible click.</i></p> <p>The following preconditions must be met:</p>	<ul style="list-style-type: none"> <li>• Temperature in evaporator housing over 3°C (37°F), so that thermostat is switched on</li> <li>• Static refrigerant pressure over 2 bar (29 psi) (200 kPa), so that high/low pressure switch is switched on</li> </ul>	<p><b>OK:</b> Proceed from Test 1.</p> <p><b>NOT OK:</b> See Section 240-15.</p>
--	--	--	--

LX,29005003400 -19-01SEP97

<p>•</p>	<p>Move blower switch from lowest setting to highest setting.</p>	<p>Blower not operating.</p> <p>Remove and check fuse F42.</p> <p>Re-install fuse.</p>	<p><b>OK:</b> Proceed with Test 2.</p> <p><b>NOT OK:</b> One or both of the blower motors is defective, proceed with Test 3.</p>
----------	---	--	--

ZX,TMXZCO003115-19-01DEC93

*Operational Tests and Troubleshooting*


<p>Æ <b>Air Flow Check</b></p>	<p>Move the fan speed control to high speed.</p> <p>Move the air duct control to all positions.</p> <p>Check the air flow from all ducts and in all positions.</p>	<p><b>OK:</b> Go to Check Å</p> <p><b>NOT OK:</b> Repair the duct control switch and ducts, go to Check Å</p> <p style="text-align: right; font-size: small;">LX,29005003402 -19-31DEC97</p>
--------------------------------	--	--

<p>Å <b>Tests with engine switched on</b></p>	<p>a. Run engine at 2000 rpm.</p> <p>b. Set blower switch to maximum output.</p> <p>c. Set thermostat switch to maximum cooling effect.</p> <p>d. Keep cab doors closed.</p>	<p>Check the following: Cold airflow from air louvers after approx. 6 minutes. Compressor intake line should be cool or cold. Look for bubbles at sight-glass on receiver-drier.</p>	<p><b>OK:</b> Proceed with Test Ö.</p> <p><b>NOT OK:</b> Proceed with Test Ü.</p> <p style="text-align: right; font-size: small;">LX,29005003403 -19-01NOV96</p>
---	--	--	--

<p>Ö <b>Temperature test</b></p>	<p>Measure outside temperature (in the shade).</p> <p>Switch on air conditioning system. Wait 15 to 20 minutes and measure temperature at front air louver (see table).</p>	<table style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left; border-bottom: 1px solid black;">Outside temperature</th> <th style="text-align: left; border-bottom: 1px solid black;">Min. diff. in temperature</th> </tr> </thead> <tbody> <tr> <td style="padding-left: 20px;">less than 24°C (75°F)</td> <td>12°C (20°F)</td> </tr> <tr> <td style="padding-left: 20px;">between 24—32°C (75—90°F)</td> <td>14°C (25°F)</td> </tr> <tr> <td style="padding-left: 20px;">over 32°C (90°F)</td> <td>16°C (30°F)</td> </tr> </tbody> </table>	Outside temperature	Min. diff. in temperature	less than 24°C (75°F)	12°C (20°F)	between 24—32°C (75—90°F)	14°C (25°F)	over 32°C (90°F)	16°C (30°F)	<p><b>OK:</b> Proceed with Test Ü.</p> <p><b>NOT OK:</b> Proceed with Test Ö.</p> <p style="text-align: right; font-size: small;">LX,29005003404 -19-01NOV96</p>
Outside temperature	Min. diff. in temperature										
less than 24°C (75°F)	12°C (20°F)										
between 24—32°C (75—90°F)	14°C (25°F)										
over 32°C (90°F)	16°C (30°F)										

<p>Ü <b>RESULT OF FUNCTIONAL TESTS</b></p> <p>NOT OK: See Groups 10A, 10B and 10C.</p> <p style="text-align: right; font-size: small;">LX,29005003406 -19-01FEB93</p>
---

## SAFETY AT WORK

 **CAUTION:** Certain basic safety regulations apply when dealing with air conditioning systems, and must be observed at all times. They are backed up by legislation covering safety precautions for air conditioning systems. The following excerpts are particularly important:

1. Air conditioning systems may be operated, serviced or repaired by authorized, trained personnel only.
2. Adolescents should not be allowed to carry out service work on air conditioning systems involving the discharge of Category 2 or 3 refrigerants, unless trade training of adolescents over 16 years old requires such work. In this case, the adolescent must be supervised by a trained adult.
3. Before repairing components carrying refrigerant, remove refrigerant as far as necessary to ensure that the work can be carried out safely.


4. Refrigerant should be extracted by suction and re-used. When refrigerant is discharged into the air, there is the danger of asphyxiation, especially if work is being performed in an inspection pit, since refrigerant is heavier than air and concentrates at the lowest level. Moreover, refrigerant is odorless and colorless, so small quantities emerging from a leak cannot be detected. In such a case, ensure that there is adequate ventilation at the place of work.

5. Smoking and naked flames are not permitted in enclosed spaces where refrigerant has been released. High temperatures cause chemical reactions in the refrigerant gas, and highly poisonous substances can form. If inhaled, these substances have serious effects on health.

6. High temperatures produced by welding and soldering cause very high pressures inside components of the air conditioning system, and these pressures may result in an explosion.

ZX.TMXZCO002461-19-25NOV92

## HANDLING REFRIGERANT

 **CAUTION:** When handling refrigerant, always wear safety glasses and leather gloves. Contact with escaping refrigerant may result in serious frostbite, or even blindness if the refrigerant strikes the eye.

Whenever there is the risk of refrigerant encountering high temperatures, wear a suitable breathing mask while working. However, a breathing mask provides no protection against asphyxiation if large quantities of refrigerant escape.

ZX.TMXZCO002462-19-25NOV92

## IN AN EMERGENCY

- Rinse eye with cold water; preferably use a 1% boric acid solution.
- Wash affected parts of the body with water, or preferably with a solution consisting of one part essence of vinegar and five parts water.
- See a doctor as soon as first aid has been administered.

ZX, TMXZC0002520-19-01DEC92

## STORAGE OF REFRIGERANT CONTAINERS



**CAUTION:** Refrigerant containers are under pressure, and this pressure increases rapidly when the temperature of the container rises. The thin-walled refill containers are particularly at risk in this respect. Refrigerant containers must never be exposed to temperatures over 52°C (120°F).

**Never store pressurized containers in the vicinity of heat sources or in places exposed to direct sunlight. Never open pressurized containers by force or damage them in any way.**

ZX, TMXZC0002464-19-25NOV92

## R134A REFRIGERANT

**IMPORTANT:** The air conditioning system operates using R134a refrigerant (tetrafluoroethane). This substance does not contain any chlorine atoms, so it does not have a detrimental effect on the ozone in the Earth's atmosphere.

Even so, the refrigerant must never be discharged straight into the air. It must be trapped in a recycling unit.

Refrigerant stored in a recycling unit may be re-used at any time.

The recycling unit used to do this must be of a type suitable for handling R134a refrigerant.

The boiling point of R134a is minus 26.5°C (minus 15.7°F) and its freezing point is minus 101°C (minus 149.8°F).

R134a has a corrosive effect on copper as well as various seals and components used in the R12 system. For this reason, never use R134a refrigerant in a system that has previously used R12. Before replacing any component, it is vital to check whether it is compatible with the type of refrigerant used.

It is still essential to ensure that the correct refrigerant oil is used. R12 systems were lubricated with mineral oil, which is totally unsuitable for R134a systems. The latter require PAG oil, which mixes very well with the refrigerant and provides ideal lubrication throughout the system.

ZX.TMXZCO002465-19-25NOV92


### SPECIAL TOOLS

Service unit ..... FKM10453

Evacuating, filling, cleaning and checking the air conditioning system.

*NOTE: All work performed with this unit must be carried out in accordance with the service unit operator's manual.*

**IMPORTANT: Use only service units suitable for handling R134a refrigerant.**



**FKM10453**


FKM10453 -JUN-28APR95

ZX,TMXZCO002466-19-15FEB95

Leak tester ..... LX001767

Pinpointing a refrigerant leak.

*NOTE: Use only leak testers suitable for finding R134a leaks.*



**LX 001767**

LX001767 -JUN-28APR95

ZX,TMXZCO002467-19-15FEB95

## SPECIFICATIONS

Item	Measurement	Specification
Air conditioning system	Refrigerant quantity	2400 g (85 oz)
Evacuating system	Vacuum at sea level	100 kPa (1 bar) (14.5 psi)
Air conditioning system with compressor	Oil quantity	300 cm <sup>3</sup> (18.3 cu in.)
Compressor	Oil quantity	160 cm <sup>3</sup> (9.8 cu in.)
Air conditioning system, pressure side (2200 rpm)	Refrigerant pressure	1500—2000 kPa (15—20 bar) (218—290 psi)
Air conditioning system, suction side (2200 rpm)	Refrigerant pressure	80—200 kPa (0.8—2 bar) (11—29 psi)
Compressor clutch coil	Current draw (at 12 volts)	2.2 amps. max.
Temperature control switch set for max. cooling:		
• Contact points open (low limit)	Temperature at capillary tube	-1° to 1°C (30° to 34°F)
• Contact points closed (high limit)	Temperature at capillary tube	1.8° to 3.8°C (35° to 39°F)
Temperature control switch set for min. cooling:		
• Contact points closed (high limit)	Temperature at capillary tube	13.6° to 17.6°C (56° to 64°F)
Ice protection switch		
• Contact points open (low limit)	Temperature at capillary tube	-3° to -1°C (26° to 30°F)
• Contact points closed (high limit)	Temperature at capillary tube	0.5° to 2.5°C (33° to 36°F)
Double radial fan (installed)	Current draw (at 12 volts)	13 amps.

ZX.TMXZCO002468-19-25NOV92

## TROUBLESHOOTING

Symptom	Problem	Solution
<b>No cooling effect</b>	System not in operation.	Switch on compressor switch. Turn temperature control switch counterclockwise. Switch on fan.  If functioning, proceed to checks <b>1</b>
	<b>Inadequate cooling effect</b>	Condenser severely contaminated. Clean condenser.  Evaporator severely contaminated. Clean evaporator.  Actuating cables of temperature control switch not functioning correctly. Check and adjust actuating cables.  Insufficient tension at compressor drive belt. Replace drive belt or belt tensioner.  Coolant leak See checks <b>3</b>  Thermostat switch not functioning correctly. See checks <b>4 A</b>  Compressor not functioning correctly. See checks <b>5</b>
<b>Intermittent or poor cooling effect</b>	System components iced up.	Evacuate refrigerant and refill with recycled or new refrigerant. Replace receiver-drier.
<b>Unusual noises when system is in operation</b>	Insufficient tension at compressor drive belt.	Replace drive belt or belt tensioner.
	Defective compressor	Replace compressor.

ZX.TMXZCO002469-19-25NOV92



## EXPLANATION OF CHECKS

The checks on the following pages show how to find an existing fault and then rectify it.

Visual checks are performed first, as this is the simplest way to eliminate possible causes of the fault.

The preliminary checks reveal whether individual components of the air conditioning system are functioning correctly.

Next, the leak tester is used to check if there is a leak at any point in the air conditioning circuit.

Up to this stage, the checks are relatively straightforward and do not involve lots of tools. The subsequent tests, however, may involve repair work or the replacement of major components, depending on the results of the test.

If the checks do not produce a clear result, observe the note below.

*NOTE: A frequent cause of faults in air conditioning systems is too much moisture in the refrigerant circuit. Moisture results in air conditioning components icing up from the inside and functioning incorrectly. Too much moisture can also produce acid, which destroys the air conditioning system from within.*

*If moisture is suspected, the air conditioning system must be evacuated, cleaned, bled and refilled with new or recycled refrigerant. The refrigerant oil contained in the compressor must be changed.*

*It is particularly important to replace the receiver-drier, as it gradually loses its ability to absorb moisture. Eventually, it loses this ability altogether.*


*NOTE: After replacing a defective component or rectifying a fault, it is advisable to perform the operational check described in 290-05.*

LX,290,10002721-19-01NOV96

## AIR CONDITIONING SYSTEM, CHECKS

ZX,TMXZC0002470-19-25NOV92

; **VISUAL CHECKS**




**ZX 004404**  
ZX004404 -UN-08MAY95

- a. Check tension of compressor belt.
- b. Cab filters must be clean.
- c. Air passages must be clear.
- d. Check for damaged lines.
- e. Hoses must not be deformed or trapped.
- f. Condenser and evaporator must not be contaminated.
- g. All electrical lines must be OK.
- h. Listen for unusual noises while the system is operating.

ZX, TMXZC0002471-19-25NOV92

‘ **A**  
**PRELIMINARY CHECKS**



**ZX004469**  
ZX004469 -UN-08MAY95


Switch on ignition and run the fan at each possible speed.

**NOT OK:** See Section 240-15.

**OK:** Proceed with checks.


ZX, TMXZC0002472-19-25NOV92

B



ZX004405

ZX004405 -UN-08MAY95



ZX 004406

ZX004406 -UN-08MAY95

Switch on ignition and run fan at lowest possible speed. Set temperature control switch (A) to operate the air conditioning system.


Note whether the clicking of the magnetic clutch can be heard at compressor (B).

**NOT OK:** See Section 240-15.

**OK:** Proceed with checks.

ZX, TMXZCO002473-19-25NOV92

C



ZX004407

ZX004407 -UN-08MAY95

Run engine at 2200 rpm and set air conditioning to full output. Observe refrigerant flowing past the sight glass at receiver-drier.




After some time, the bubbles in the refrigerant should disappear completely.

**NOT OK:** The air conditioning system must be topped up.




**OK:** Proceed with checks.

ZX, TMXZCO002474-19-25NOV92


Operational Tests and Troubleshooting/Troubleshooting

<p>D</p>	 <p><b>ZX004408</b> ZX004408 -UN-08MAY95</p>	<p>Run engine at 800 rpm and set temperature control switch to max. cooling position.</p> <p>At the moment the switch trips, the engine sound should change slightly.</p>	<p><b>NOT OK:</b> The compressor or its magnetic clutch must be repaired. See Section 90.</p> <p><b>OK:</b> Proceed with checks.</p> <p>ZX,TMXZCO002475-19-16JUN93</p>
<p>Æ A <b>LEAK TEST</b></p>	 <p><b>LX001762</b> LX001762 -UN-28APR95</p> <p><b>▲ CAUTION: Keep away from moving engine parts at all times. Avoid accidents!</b></p> <p>Hold the leak tester at the air outlets in the cab to test whether there is a leak in the evaporator housing.</p>	<p>Run the engine at 1000 rpm and switch on fan and air conditioning system. Use FKM10444 leak tester to check the entire refrigerant circuit for leaks. Comply with the manufacturer's instructions.</p>	<p><b>NOT OK:</b> If the leak tester indicates a leak while testing at the air outlets, proceed with Æ B.</p> <p>If a leak is found at another part of the system, the leak must be repaired or the leaking component must be replaced. See Section 90.</p> <p><b>OK:</b> Proceed with Å</p> <p>ZX,TMXZCO002476-19-15FEB95</p>
<p>B <b>REFRIGERANT LEAK AT EVAPORATOR HOUSING</b></p>	 <p><b>ZX004409</b> ZX004409 -UN-08MAY95</p>	<p>Open evaporator housing under passenger seat. Run engine at 1000 rpm and switch on fan and air conditioning system.</p> <p>Use leak tester FKM10444 to test evaporator, expansion valve and refrigerant lines for leaks.</p>	<p><b>NOT OK:</b> If a leak is found at any part of the system, the leak must be repaired or the leaking component must be replaced. See Section 90.</p> <p><b>OK:</b> Proceed with Å.</p> <p>ZX,TMXZCO002477-19-15FEB95</p>

Operational Tests and Troubleshooting/Troubleshooting

<p><b>Ä COMPONENT CHECKS</b></p> <p>A Thermostat switch</p>	 <p>ZX004410 -UN-08MAY95</p>	<p>Open evaporator housing under passenger seat.</p> <p>Check that sensing bulb (A) is not damaged.</p> <p>Make sure that thermostat switch (B) is actuated correctly. Do this by actuating the temperature switch several times and observing cable (C).</p> <p>Check all electrical contacts of the thermostat switch.</p>	<p><b>NOT OK:</b> To correct faults, see Section 90.</p> <p><b>OK:</b> Proceed with checks.</p>
<p><b>B Ice protection switch</b></p>	 <p>ZX004411 -UN-08MAY95</p>	<p>Make sure that capillary tube (A) is not damaged and inserted into evaporator.</p> <p>Check all electrical contacts of the ice protection switch.</p>	<p><b>NOT OK:</b> To correct faults, see Section 90.</p> <p><b>OK:</b> Proceed with checks.</p>
<p><b>C Evaporator</b></p>	<p>Remove any contamination and check for signs of damage.</p>	<p><b>NOT OK:</b> If the evaporator shows signs of damage, it must be replaced. See Section 90.</p> <p><b>▲ CAUTION:</b> Before removing the evaporator, first evacuate the refrigerant from the air conditioning system.</p> <p><b>OK:</b> Proceed with checks.</p>	<p>ZX, TMXZCO002478-19-25NOV92</p>
<p><b>D Expansion valve</b></p>	 <p>ZX004412 -UN-08MAY95</p>	<p>Check that there are no signs of damage at thermal head (A). Check all connections.</p>	<p><b>NOT OK:</b> Replace expansion valve.</p> <p><b>▲ CAUTION:</b> Before removing the expansion valve, evacuate refrigerant from the air conditioning system.</p> <p><b>OK:</b> Proceed with checks.</p>

**Ö Compressor, pressure tests**



**ZX004413**

ZX004413 -UN-08MAY95

**A—High pressure connection**  
**B—Low pressure connection**

Connect the pressure gauges of the service unit to the compressor.

Run engine at 2200 rpm. Switch on fan and set temperature control switch to max. cooling position.

On the high pressure side, the pressure reading must be 1500—2000 kPa (15—20 bar) (218—290 psi).

On the low pressure side, the pressure reading must be 80—200 kPa (0.8—2 bar) (11—29 psi).

**NOT OK:** See pressure deviations.

ZX, TMXZCO002482-19-25NOV92

## PRESSURE DEVIATIONS

Symptom	Problem	Solution
<b>Low pressure and high pressure both too high</b>	System has been over-filled.	Reduce amount of refrigerant in system.
	Condenser is contaminated or plugged.	Clean or unplug condenser. Replace condenser, if necessary.
<b>Low pressure too low and high pressure too high</b>	Condenser plugged.	Unplug condenser or replace, if necessary.
	Receiver-drier plugged.	Unplug receiver-drier or replace, if necessary.
	Expansion valve not operating correctly.	Replace expansion valve.
<b>Low pressure too high but high pressure normal</b>	Compressor not operating correctly.	Repair or replace compressor.
<b>Low pressure and high pressure are the same</b>	Compressor not operating.	Check drive belt. Check electrical wiring. Change high/low pressure switch. Check thermostat switch, see Section 240. Check magnetic clutch of compressor.
<b>Low pressure too low but high pressure normal</b>	Not enough refrigerant in circuit.	Top up system.
	Expansion valve not operating correctly.	Replace expansion valve.
	Evaporator contaminated or plugged.	Clean evaporator. Unplug evaporator or replace, if necessary.
<b>Low pressure and high pressure both too low</b>	Not enough refrigerant in circuit.	Top up system.
	Receiver-drier plugged.	Unplug receiver-drier or replace, if necessary.
	Expansion valve not operating correctly.	Replace expansion valve.

Continued on next page





*Operational Tests and Troubleshooting/Pressure deviations*

<b>Symptom</b>	<b>Problem</b>	<b>Solution</b>
<b>Low pressure and high pressure both too low (Continued)</b>	Too much moisture in circuit, causing components to ice up.	Evacuate system, replace receiver-drier and then refill system.
	Compressor not operating correctly.	Repair compressor or replace, if necessary.

ZX.TMXZC0002483-19-25NOV92



**PRINCIPLE OF HEAT EXCHANGE**



LX002148 JUN-07/JAN98

A—Liquid refrigerant under high pressure  
B—Gaseous refrigerant under high pressure

C—Gaseous refrigerant under low pressure

D—Exchange of heat  
E—Energy in the form of heat

The simplified example set out below is intended to show how heat is exchanged in an air conditioning system. Each explanation concludes with the part of the air conditioning system that corresponds to the principle involved.

**Fig. 1:** Gaseous refrigerant is contained in a cylinder which has a certain reserve of energy (E) in the form of heat. (intake line of compressor)

**Fig. 2:** A piston reduces the space in which the gaseous refrigerant is trapped. This concentrates the heat (E) in a smaller space. This means that the temperature inside the cylinder is now higher than it was before. Heat is now exchanged, with the surrounding area absorbing the heat of the gas. Heat always moves from a hotter substance to a colder one. (compressor to condenser)

**Fig. 3:** The pressurized refrigerant condenses on the cylinder wall and becomes a liquid. The gas has transferred its heat through the cylinder wall to the surrounding area. (condenser)

**Fig. 4:** The space inside the cylinder is increased. This means that the pressure drops rapidly and the liquid refrigerant is free to expand. The refrigerant evaporates and returns to its gaseous state. In consequence, the heat remaining in the gas is free to spread through a larger area. The temperature inside the cylinder drops and heat is exchanged once again. This time the heat is absorbed from the surrounding area by the cold cylinder. (expansion valve and evaporator)

LX.290.20002575-19-01APR94

## R134A REFRIGERANT

**IMPORTANT:** The air conditioning system operates using R134a refrigerant (tetrafluoroethane). This substance does not contain any chlorine atoms, so it does not have a detrimental effect on the ozone in the Earth's atmosphere.

Even so, the refrigerant must never be discharged straight into the air. It must be trapped in a recycling unit.

Refrigerant stored in a recycling unit may be re-used at any time.

The recycling unit used to do this must be of a type suitable for handling R134a refrigerant.


The boiling point of R134a is minus 26.5°C (minus 15.7°F) and its freezing point is minus 101°C (minus 149.8°F).

Before replacing any component, it is vital to check whether it is compatible with the type of refrigerant used.

It is still essential to ensure that the correct refrigerant oil is used. R12 systems were lubricated with mineral oil, which is totally unsuitable for R134a systems. The latter require PAG oil, which mixes very well with the refrigerant and provides ideal lubrication throughout the system.

LX,290,20002578-19-01APR94

**LAYOUT OF REFRIGERANT CIRCUIT**




ZX004414

- |                              |                        |                        |                      |
|------------------------------|------------------------|------------------------|----------------------|
| A—Temperature control switch | D—Blower fan           | H—Flow of air into cab | M—High-pressure line |
| B—Cab air filter             | E—Thermostat switch    | J—Condenser            | N—Receiver-drier     |
| C—Evaporator                 | F—Low pressure switch  | K—Compressor           | O—Expansion valve    |
|                              | G—High pressure switch | L—Low-pressure line    |                      |

-JN-08MAY95  
ZX004414

ZX.TMXZCO002484-19-25NOV92

**DESCRIPTION OF REFRIGERANT CIRCUIT FUNCTION**



ZX004415



- |                              |                       |   |  |
|------------------------------|-----------------------|---|--|
| A—Evaporator                 | F—Low pressure switch | M—Thermal head                            | R—Liquid refrigerant under low pressure  |
| B—Sensing bulb               | G—Condenser           | N—Sight glass                             | S—Gaseous refrigerant under low pressure |
| C—Thermostat switch          | H—Magnetic clutch     | O—High pressure switch                    |  |
| D—Temperature control switch | J—Compressor          | P—Liquid refrigerant under high pressure  |  |
| E—Receiver-drier             | K—Variable throttle   | Q—Gaseous refrigerant under high pressure |  |
|                              | L—Expansion valve     |   |  |

-JUN-28/JAN98  
ZX004415

ZX, TMXZCO002485-19-01DEC92

## DESCRIPTION OF REFRIGERANT CIRCUIT FUNCTION (CONTINUED)

The air conditioning system operates on the compression principle. The main components are the compressor (J), condenser (G), receiver-drier (E), expansion valve (L), evaporator (A), temperature control switch (D), thermostat switch (C), high pressure switch (O) and low pressure switch (F).

Gaseous refrigerant is compressed in compressor (J), causing it to absorb heat. Then the pressurized gas is fed through the condenser (G), where it transfers its heat to the cooling fins and condenses.

Now in the form of a pressurized liquid, the refrigerant flows through receiver-drier (E), where a special filter separates out all impurities including moisture and acid.

A sight glass (N) is provided at the receiver-drier (E). Through this can be seen whether the refrigerant is in a completely liquid state at this point, and whether there is enough refrigerant in the circuit.

After it leaves the receiver-drier (E), the refrigerant passes to expansion valve (L), where it is fed through a variable throttle (K). The pressure is still high at the inlet side of the expansion valve. Once the refrigerant has passed through the throttle, however, it is free to expand and cool down.

Expansion is completed in evaporator (A), where the refrigerant returns to its gaseous state and cools down the surrounding area considerably. The refrigerant transfers its cold temperature to the evaporator's cooling fins, and air flowing into the evaporator is cooled down.

High pressure switch (O) and low pressure switch (F) determine the refrigerant pressure. This is required in order to switch off the compressor if the pressure becomes too high or too low.

Thermostat switch (C) controls the cooling output by switching compressor (J) on or off. The thermostat switch can be reset by turning temperature control switch (D).

The refrigerant flows back via the evaporator return line and is unimpeded as it passes through the housing of expansion valve (L). There it comes under the influence of the gas-filled thermal head (M), which actuates variable throttle (K) in relation to the temperature. In this way, the refrigerant always flows to evaporator (A) at the optimum rate.

Then the gaseous refrigerant is fed back into compressor (J), and the circuit is closed.

ZX.TMXZCO002486-19-25NOV92

## COMPRESSOR


The compressor is located on the engine and is driven by a multi-groove drive belt. The compressor is of the axial piston compressor type and is controlled by a swashplate.

The purpose of the compressor is to ingest the gaseous refrigerant from the low pressure area, to compress it and send it on to the condenser.

When this happens, the low pressure gas is compressed into a smaller space, which greatly increases the temperature of the refrigerant.

The compressor drive assembly includes a magnetic clutch, which allows the compressor to be switched on and off while the air conditioning system is in operation. This is necessary to keep the temperature in the cab as nearly constant as possible.

The compressor housing also serves as the reservoir for refrigerant oil. The compressor is normally switched on and off by the thermostat switch. If refrigerant pressure becomes too high or too low, the compressor is switched off by the high or low pressure switch.



- A—Suction line
- B—Pressure line
- C—Test ports
- D—Drive belt pulley
- E—Magnetic clutch

ZX.TMXZCO002487-19-25NOV92

## CONDENSER

The condenser is located in front of the radiator. The purpose of the condenser is to cool down the pressurized refrigerant gas so that it condenses and leaves the condenser as a liquid.

The cooling effect is produced by the airflow created by the fan blades. The condenser's inlet is connected to the compressor's pressure connection, its return line to the receiver-drier.

ZX.TMXZCO002488-19-25NOV92


## RECEIVER-DRIER

The receiver-drier performs two functions. Firstly, it receives high pressure refrigerant from the condenser and stores it until it is required by the evaporator. Secondly, it absorbs moisture that would have a detrimental effect on the system's ability to operate.

The sight glass on the receiver-drier enables the refrigerant to be observed when tests or service work are being performed. The receiver-drier's inlet is connected to the condenser, and its return line to the expansion valve.

The receiver-drier should be replaced every time the air conditioning system is repaired.

- A—To expansion valve
- B—Tube
- C—Screen
- D—Dessicant block
- E—From condenser
- F—Sight glass



ZX004417

ZX.TMXZC0002489-19-25NOV92

ZX004417 -JUN-08MAY95

## EXPANSION VALVE

The expansion valve is located on the left side of the evaporator looking in the direction of forward travel and is connected to the evaporator's inlet and return lines.

The expansion valve is a diaphragm valve with a stainless steel thermal head. Its purpose is to control the throughflow of refrigerant in relation to the return temperature from the evaporator.


If too much refrigerant flows through the evaporator, liquid refrigerant could reach the compressor via the return line and cause damage to the compressor.

Too much liquid refrigerant is one reason why the system may not be performing well, as the refrigerant does not evaporate completely.

A variable throttle is located in the inlet to the expansion valve. This throttle is formed by valve ball (F) and actuating pin (L). At this point the pressure of the liquid refrigerant is reduced considerably. This allows the refrigerant to expand and change into its gaseous state in the evaporator, thus bringing down the temperature.

Once the refrigerant has left the evaporator, it has to flow through the expansion valve once again. However, it does not do so through the throttle, but through a passage where the refrigerant temperature can be registered by thermal head (A).

The thermal head is filled with gas, which expands and contracts as the temperature rises and falls. This process is employed to produce a movement at diaphragm (B) that is passed on to the throttle. This makes it possible to control the throughflow of refrigerant in relation to its temperature.




- A—Thermal head
- B—Diaphragm
- C—Pressure plate
- D—To compressor
- E—From receiver-drier
- F—Valve ball
- G—Ball seat
- H—Spring
- J—Plug
- K—To evaporator
- L—Actuating pin
- M—From evaporator
- N—Liquid high pressure refrigerant
- O—Liquid low pressure refrigerant
- P—Gaseous low pressure refrigerant
- Q—Gas in thermal head

ZX.TMXZCO002490-19-25NOV92



## THERMOSTAT SWITCH



A—Actuating cable

B—Sensing bulb (gas-filled capillary tube)

C—Thermostat switch

D—Evaporator

Thermostat switch (C) is located at the left side of the evaporator (looking in the direction of forward travel), inside the evaporator housing.

It is operated by actuating cable (A), which moves in response to the temperature control switch. The cable also changes position of air control flap.

The thermostat switch controls the cooling output of the air conditioning system by switching the compressor on and off, thus regulating the evaporator's temperature. This effect is determined by the position to which the temperature control switch is set.

The switch consists of a set of contacts which receive current via the fan switch. Current flows on from the thermostat switch to the magnetic clutch for the compressor.

The opening and closing of the electrical contacts is controlled by a gas-filled capillary tube (B), one end of which is fitted with a diaphragm or bellows. The other (spiral) end of the capillary tube protrudes into air flow at housing outlet.

When the thermostat switch is actuated, the switch contacts close, allowing current to flow between the switch and the compressor. However, the compressor comes into operation only if the ventilator fan is also in operation.

Once the temperature in evaporator (D) reaches a preselected lower limit, the switch contacts open and the compressor is shut off. The compressor remains shut off until the temperature in the evaporator reaches the upper limit.

When this happens, the switch contacts close again and the compressor comes into operation once more. In this way, the compressor is switched on and off as required and in relation to the temperature inside the evaporator.

ZX.TMXZCO002493-19-01DEC92

## EVAPORATOR

The evaporator is located in the evaporator housing, underneath the operator's seat. It allows the heat transfer to take place between the refrigerant and the cab air. The same component also includes the heat exchanger for the heating system; this makes use of engine coolant to heat the cab air as required. It is controlled via the heating valve.

The refrigerant is still in its liquid form as it comes from the expansion valve. It expands in the evaporator and becomes a gas. The resulting low

temperature is transferred to the cooling fins and the airflow produced by the fan transfers its heat to the fins.

The moisture in the ambient air condenses when it comes into contact with the cold evaporator fins. The condensation is drained away via a drain hose.

The gaseous refrigerant is removed from the evaporator outlet via the expansion valve to the compressor.


ZX, TMXZC0002491-19-25NOV92

## TEMPERATURE CONTROL SWITCH AND COMPRESSOR SWITCH

Temperature control switch (A) is a combined control element located on the switch console in the cab. Depending on its setting, it activates the heating or air conditioning system by means of two actuating cables.

If the knob is set to the blue sector, the heating valve is shut off and the thermostat switch is on. At the same time, the compressor is switched on by an integrated electric switch.

This situation is reversed when the switch is set to the red sector.



ZX004419  
-UN-08MAY95

ZX, TMXZC0002492-19-25NOV92

# Section 340 Optional Equipment


## Contents

Page

Group 05—Chaff Spreader . . . . . 340-05-1

*Contents*

**SYSTEM DIAGRAM, HYDROSTATIC CHAFF SPREADER DRIVE**



ZX013591

A—Hydraulic oil reservoir  
B—Hydraulic pump

C—Diagnostic port  
D—Speed controller

E—Coupler

F—Hydraulic motor

ZX, TMXZCO010095-19-01AUG97

ZX013591 -UN-16FEB98

### CHECKING PRESSURE RELIEF VALVE OF CHAFF SPREADER DRIVE

Disconnect quick coupler (A).




Engage separator.

Connect a pressure gauge to test port (C).

Read pressure at gauge.

Maximum pressure should be 21000 kPa (210 bar; 3050 psi).

- A—Quick coupler (inlet flow)
- B—Quick coupler (return flow)
- C—Pressure test port



ZX, TMXZCO003165-19-13JAN94

# Index

	Page		Page
<b>A</b>			
Accumulator checks . . . . .	70-25-1	Air intake system	
Accumulators . . . . .	70-25-2	Air-to-air aftercooler . . . . .	30-10-1
Adapter sleeve bearings (straw chopper)		Alternator . . . . .	240-15A-1
Components . . . . .	140-05-7	Angle drive (D), assembling . . . . .	130-15-5
Installation . . . . .	140-05-8	Angle drive for grain tank filling . . . . .	130-15-4
Removal . . . . .	140-05-6	Angle drive on unloading tube	
Air comfort seat . . . . .	290-05-3	Assembling angle drive (C) . . . . .	130-20-6
Air conditioning and heater		Assembling angle drive (D) . . . . .	130-20-7
Functional test . . . . .	290-20-1	Area counter	
Air conditioning system . . . . .	240-15P-1	Components . . . . .	240-15AA-2
Air conditioning system		Setting instructions . . . . .	240-15AA-6
Air intake and distribution . . . . .	290-05-2	Automatic header control (lateral tilt)	
Checking the compressor manifold . . . . .	90-05-16	Components . . . . .	40-26-1
Checks . . . . .	290-20-9	Electronic board, settings . . . . .	40-26-2
Compressor . . . . .	290-25-6	General information . . . . .	40-26-1
Compressor clutch . . . . .	90-05-14	Sensors . . . . .	40-26-2
Compressor oil level . . . . .	90-05-14	Automatic machine settings	
Compressor switch . . . . .	290-25-10	Components . . . . .	240-15AA-2
Condenser . . . . .	290-25-6	<b>B</b>	
Condenser, remove/install . . . . .	90-05-17	Batteries . . . . .	240-15A-1
Discharging the system . . . . .	90-05-8	Bearings . . . . .	80-05-1
Evacuating the system . . . . .	90-05-9	Beater/second cylinder . . . . .	120-15-1
Evaporator . . . . .	290-25-10	Belt guide	
Expansion valve . . . . .	290-25-8	Other material . . . . .	120-25-1
Filling the system . . . . .	90-05-10	Specifications . . . . .	120-25-1
Filling with refrigerant oil . . . . .	90-05-12	Bottom feeder drum	
Installing the compressor . . . . .	90-05-17	Adjustment . . . . .	110-10-3
Leak test . . . . .	90-05-13	Components . . . . .	110-10-2
Leak tester . . . . .	290-20-6	Other materials required . . . . .	110-10-1
Oil capacities of components . . . . .	90-05-13	Specifications . . . . .	110-10-1
Receiver-drier . . . . .	290-25-7	Brake fluid . . . . .	10-05-3, 60-05-1
Refrigerant container storage . . . . .	90-05-6, 290-20-4	Brake operating system . . . . .	260-05-1
Refrigerant R134A . . . . .	290-20-5	Brake operation . . . . .	60-05-1
Rem./inst.evaporator and exp.valve . . . . .	90-05-19	Brakes . . . . .	60-10-1
Remove/inst. high/low pres. switch . . . . .	90-05-20	<b>C</b>	
Remove/install thermostat switch . . . . .	90-05-19	Cam lobe motor	
Removing the compressor . . . . .	90-05-14	Specifications . . . . .	50-40-1
Removing/installing receiver-drier . . . . .	90-05-18	Chaff spreader	
R134a refrigerant . . . . .	90-05-1, 90-05-7	Drive with pump . . . . .	140-10-6
Safety rules . . . . .	290-20-3	Hydraulic connections . . . . .	140-10-7
Special tools . . . . .	290-20-6	Hydraulic lines . . . . .	140-10-2
Special tools — R134a . . . . .	90-05-1	Hydraulic pump . . . . .	140-10-4
Specifications . . . . .	290-20-7	Speed controller . . . . .	140-10-5
Specifications — R134a . . . . .	90-05-4	Chopper distributor adjustment . . . . .	240-15F-1
Temperature control switch . . . . .	290-25-10	Cigarette lighter . . . . .	240-15L-1
Test and service ports . . . . .	90-05-7		
Thermostat switch . . . . .	290-25-9		
Troubleshooting . . . . .	290-20-8		

Index

	<b>Page</b>		<b>Page</b>
Cleaning fan and fan drive		Cutting platform	
Specifications . . . . .	120-50-1	DIAL-A-MATIC . . . . .	240-15U-1
Cleaning fan variator		Cylinder	
Adjustment . . . . .	120-50-2	Rasp bars . . . . .	120-10-9
Assembly . . . . .	120-50-4	Cylinder drive	
Components . . . . .	120-50-3	Specifications . . . . .	120-35-1
Removal . . . . .	120-50-1	Cylinder drive reduction gear . . . . .	120-35-1
Combine data center . . . . .	240-15AA-3	Cylinder drive reduction gear (from a certain ser.no.) . . . . .	120-35-5
Combine data center			
Area counter setting instructions . . . . .	240-15AA-6		
Automatic setting accord. to crop . . . . .	240-15AA-18		
Automatic settings (individual) . . . . .	240-15AA-22		
Changing crop settings . . . . .	240-15AA-21		
Changing header width . . . . .	240-15AA-14		
Clearing "Area" display . . . . .	240-15AA-13		
Clearing crops . . . . .	240-15AA-19		
Crops, factory-loaded . . . . .	240-15AA-7		
Display . . . . .	240-15AA-7		
Operational diagrams . . . . .	240-15AA-10		
Reading crop settings . . . . .	240-15AA-20		
Selecting area counter functions . . . . .	240-15AA-12		
Selecting crop . . . . .	240-15AA-17		
Selecting language . . . . .	240-15AA-16		
Selecting units . . . . .	240-15AA-11		
Setting partial header width . . . . .	240-15AA-15		
Setting unit . . . . .	240-15AA-9		
Compressor . . . . .	290-25-6		
Concave			
Adjusting . . . . .	120-10-15		
Basic setting . . . . .	120-10-12		
Changing . . . . .	120-10-15		
Corn (maize), sunflowers . . . . .	120-10-10		
Finger rake . . . . .	120-10-15		
Grain crops . . . . .	120-10-10		
Second concave . . . . .	120-15-3		
Specifications . . . . .	120-10-1		
Universal . . . . .	120-10-11		
Condenser . . . . .	290-25-6		
Coolant			
Engine . . . . .	10-05-6, 30-15-1, 30-15-2		
Coolant, adding . . . . .	30-15-3		
Cooling elements			
Layout (2254 — 2266) . . . . .	30-15-1		
Countershaft			
Assembly . . . . .	120-40-2		
Components . . . . .	120-40-1		
Other material . . . . .	120-25-1		
Specifications . . . . .	120-25-1		
Countershaft drive, left-hand side			
Components . . . . .	120-25-4		
		<b>D</b>	
		DIAL-A-MATIC . . . . .	240-15U-1
		Diesel engine oil . . . . .	10-05-1
		Differential	
		Disassembly . . . . .	50-10-16
		Material required . . . . .	50-10-1
		Removal . . . . .	50-10-14
		Specifications . . . . .	50-10-2
		Dimensions . . . . .	210-05-13
		Drive belt pulley	
		Assembly . . . . .	120-25-5
		Drive belts . . . . .	80-10-1
		Drive chains . . . . .	80-15-1
		Drives	
		Adjusting belt . . . . .	20-15-3
		Adjusting fan variator . . . . .	120-50-5
		Countershaft components . . . . .	110-20-2
		Feeder house (l.h. side) . . . . .	110-20-1
		Specifications . . . . .	110-20-1
		Drum brake . . . . .	260-10-1
		<b>E</b>	
		Electric clutch	
		Assembly . . . . .	120-20-3
		Components . . . . .	120-20-5
		Removal . . . . .	120-20-2
		Specifications . . . . .	120-20-1
		Electric clutch (with rel'ship drive)	
		Assembly . . . . .	120-20-4
		Electrical box in engine compartment . . . . .	120-20-6
		Electrical components	
		Survey . . . . .	240-10-3
		Electrical system	
		Control box assembly, replacing . . . . .	40-25-3
		Control box, alignment of . . . . .	40-25-3
		Control box, repair of . . . . .	40-25-2



Index

	Page		Page
Electrical system—Continued			
Dashpot, replacement of . . . . .	40-25-2	Final drives	
Electronic boards . . . . .	40-20-1	For 6-walker combines . . . . .	50-20-17
Fuse boards . . . . .	40-20-2	Specifications . . . . .	50-20-3
Relay and diode board . . . . .	40-20-5	Finger rake . . . . .	120-10-15
Solenoid valves . . . . .	70-15-3	Fixed displacement motor	
Starting motor . . . . .	40-15-1	Removal . . . . .	50-30-1
Switch element, replacement of . . . . .	40-25-2	Valve block assembly . . . . .	50-30-3
Tilt limit switches . . . . .	40-25-3	Flasher functions . . . . .	240-15N-1
Tilt limit switches, adjustment of . . . . .	40-25-4	Four-wheel drive . . . . .	50-40-2
Transistor, replacement of . . . . .	40-25-2	Fuel filter with water trap	
Wiring harness, Hillmaster control . . . . .	40-25-1	Exploded view . . . . .	30-05-5
Electrical system diagrams		Fuel system	
Component survey . . . . .	240-10-3	Fuel system (6.8-L engine) . . . . .	230-05-1
Section survey . . . . .	240-10-1, 241-10-1	Fuel system (8.1-L engine) . . . . .	230-05-2
Wiring harness survey . . . . .	240-10-2	Specifications . . . . .	230-05-1, 230-05-2
Electromagnetic control valve . . . . .	70-15-1, 70-15-2, 270-10-3	Fuel tank filler neck . . . . .	30-05-3
Electronic boards . . . . .	40-20-1	Functional tests	
Engine		Air conditioning and heater . . . . .	290-20-1
Air intake system . . . . .	30-10-1	Fuse board	
Cleaning cooling system . . . . .	30-15-3	Fuses . . . . .	40-20-2
Coolant . . . . .	10-05-6, 30-15-1, 30-15-2		
Drive belts (6.8-L engine) . . . . .	40-10-2	<b>G</b>	
Drive belts (8.1-L engine) . . . . .	40-10-3	Gauge for measuring gap at electric	
Fuel system (6.8-L engine) . . . . .	230-05-1	clutch . . . . .	120-20-1
Fuel system (8.1-L engine) . . . . .	230-05-2	Gear shift mechanism	
Impulse code . . . . .	240-15W-3	Adjustment . . . . .	90-15-1
Shut-off device . . . . .	240-15C-1	Components . . . . .	90-15-3
Engine oil		Grain tank unloading drive . . . . .	130-20-8
Diesel . . . . .	10-05-1	Grain tank, filling	
Error codes		Angle drive . . . . .	130-15-4
infotrak monitor . . . . .	240-15W-4	Assembling angle drive (D) . . . . .	130-15-5
Reel speed control system . . . . .	240-15T-4	Assembly of drive (C) . . . . .	130-15-3
<b>F</b>		Components of drive (C) . . . . .	130-15-2
Fan . . . . .	240-15P-1	Drive . . . . .	130-15-1
Fan		Grain tank, unloading . . . . .	130-20-1
Alarm speed . . . . .	40-30-4	Grain tank, unloading	
Variator . . . . .	120-50-5	Drive . . . . .	130-20-2
Feed augers		Specifications . . . . .	130-20-1
Angle drives (H) . . . . .	130-20-8	Grease	
Feeder house		Extreme pressure and multipurpose . . . . .	10-05-3
Adjusting height of conveyor drum . . . . .	110-10-3		
Pivoting shield guide rolls . . . . .	110-30-1	<b>H</b>	
Removal . . . . .	110-05-1	Harvest performance monitor	
Reverser . . . . .	110-25-7	General description . . . . .	40-35-1, 240-15X-2
Shaft, adjusting slip clutch . . . . .	110-15-4	Operational adjustment . . . . .	40-35-3
Tension of feeder conveyor chain . . . . .	110-15-2	Operational check . . . . .	40-35-6, 240-15X-5
Variator, bottom unit . . . . .	110-20-7		
Final drives . . . . .	50-20-1, 50-20-18		

Index

	<b>Page</b>		<b>Page</b>
Harvest performance monitor—Continued			
Preliminary adjustments . . . . .	40-35-2		
Sensor sensitivity . . . . .	40-35-5		
Switching on . . . . .	40-35-2		
Harvesting unit . . . . .	240-15V-1		
Hillmaster leveling system			
Operation . . . . .	270-15-1		
Hydraulic connections			
Chaff spreader . . . . .	140-10-7		
Hydraulic lines			
Capacity of hydrostatic system . . . . .	70-05-1		
Hydraulic lines to chaff spreader . . . . .	140-10-2		
Hydraulic lines to hydraulic motors . . . . .	140-10-3		
Hydraulic motors			
Hydraulic lines . . . . .	140-10-3		
Hydraulic oil . . . . .	10-05-2		
Hydraulic oil			
Oil level indicator light . . . . .	70-05-3		
Hydraulic oil reservoir . . . . .	70-05-2		
Hydraulic pump for chaff spreader . . . . .	140-10-4		
Hydraulic system			
Circuit diagrams . . . . .	270-05-6		
Description . . . . .	270-05-1		
Electro-magnetic valves . . . . .	70-15-5		
Hydraulic symbols . . . . .	270-05-2		
Removing hydraulic pump . . . . .	70-10-1		
Tests . . . . .	270-20-1		
Hydrostatic drive			
Components . . . . .	50-25-4, 250-05-4		
Fixed-displacement motor . . . . .	50-25-1		
Oil change . . . . .	50-35-1		
Hydrostatic steering . . . . .	60-15-1		
Hydrostatic system . . . . .	250-05-1, 250-05-2		
Hydrostatic system			
Specifications . . . . .	50-25-3, 50-30-1, 250-10-1		
Tests . . . . .	250-10-1		
<b>I</b>			
Idler			
Assembly . . . . .	120-25-3		
Components . . . . .	120-25-2		
Inch torque values . . . . .	10-10-1		
Infotrak monitor . . . . .	240-15W-1		
Infotrak monitor			
error codes . . . . .	240-15W-4		
Setting cylinder alarm speed . . . . .	40-30-4		
Setting fan alarm speed . . . . .	40-30-4		
Instruments . . . . .	240-15E-1		
Interior lighting . . . . .	240-15H-1		
<b>L</b>			
Lateral tilt (automatic control)			
Components . . . . .	40-26-1		
Left-hand drive belt pulley			
Other material . . . . .	120-25-1		
Specifications . . . . .	120-25-1		
Lighting system . . . . .	240-15M-1		
Low shaft speed monitor system . . . . .	40-30-2		
Lubricant			
Alternative . . . . .	10-05-4		
Mixing . . . . .	10-05-4		
Storage . . . . .	10-05-4		
Synthetic . . . . .	10-05-4		
<b>M</b>			
Metri Pack connectors . . . . .	40-05-10		
Metric torque values . . . . .	10-10-2		
Mirror adjustment, electrical . . . . .	240-15Q-1		
Mixing lubricants . . . . .	10-05-4		
<b>O</b>			
Oil			
Hydraulic . . . . .	10-05-2		
Transmission . . . . .	10-05-2		
Oil Transmission . . . . .	10-05-2		
Operator's seats			
System diagnosis . . . . .	290-05-4		
<b>P</b>			
Pivoting arm drive			
Components (five-walker; B) . . . . .	130-20-3		
Components (six-walker; B) . . . . .	130-20-4		
Pivoting shield			
Components . . . . .	110-30-1		
Planetary final drive . . . . .	50-15-1, 50-20-1		
Pressure equalizing valve . . . . .	260-05-4		
<b>R</b>			
Radiator			
Exploded view . . . . .	30-15-8		
Radio . . . . .	240-15H-1		
Receiver-drier . . . . .	290-25-7		
Reduction gear . . . . .	120-35-6		

Index

	Page		Page
Reduction gear		Solenoid valve plate	
Specifications . . . . .	120-35-1	Repair . . . . .	70-15-8
Reel speed adjustment		Solenoid valves	
Operational information . . . . .	240-15T-1	Basic machine . . . . .	70-15-3, 270-10-1
Reel speed control system		Hillmaster . . . . .	270-10-2
Diagnostic procedure . . . . .	240-15T-3	Solenoids	
Error codes . . . . .	240-15T-4	Hillmaster . . . . .	70-15-4
Micro switches . . . . .	240-15T-6	Special tools . . . . .	40-05-1
Speed ratio switch S9 . . . . .	240-15T-2	Special tools	
Refrigerant . . . . .	290-25-2	Air conditioning system — R134a . . . . .	90-05-1
Refrigerant circuit . . . . .	290-25-4	Specifications	
Refrigerant R134A . . . . .	290-20-5	Combines . . . . .	210-05-2
Relay and diode board, from		Dimensions (2254, 2256) . . . . .	210-05-13
ser.no.064253 . . . . .	40-20-5	Dimensions (2258, 2264) . . . . .	210-05-15
Relays on fuse board . . . . .	40-20-4	Dimensions (2266) . . . . .	210-05-17
Reverser . . . . .	110-25-1	Engine . . . . .	220-05-1
Reverser		Engines . . . . .	220-05-4
Assembly . . . . .	110-25-4	Five-walker machines . . . . .	210-05-2
Attachment . . . . .	110-25-5	Fuel system . . . . .	230-05-1, 230-05-2
Components . . . . .	110-25-2	Hydrostatic system . . . . .	250-10-1
Shifter fork and control cable . . . . .	110-25-7	Six-walker, 2264, 2266 . . . . .	210-05-7
Specifications . . . . .	110-25-1	Speeds of rotation . . . . .	210-05-1
Revolving hazard warning lights . . . . .	240-15O-1	Standard & Hillmaster combines . . . . .	210-05-7
Ring and Pinion Final Drive		2254, 2256 and 2258 Combines . . . . .	250-05-1
Assemble . . . . .	50-20-8	2258 Hillmaster (option) . . . . .	250-05-2
Disassemble . . . . .	50-20-8	2264, 2266 Combines . . . . .	250-05-2
Ring and pinion final drive		Speed monitoring system . . . . .	240-15W-5
Remove/install . . . . .	50-20-4	Speed ratio switch S9 . . . . .	240-15T-2
Ring and Pinion Final Drive		Speeds of rotation . . . . .	210-05-1
Spindle bearing, adjust . . . . .	50-20-16	Starting motor . . . . .	40-15-1, 240-15A-1
Rotating knives . . . . .	140-05-4	Starting motor	
Rotor removal		Repair . . . . .	40-15-1
Straw chopper . . . . .	140-05-2	Stone trap bottom plate . . . . .	120-05-1
		Storing lubricants . . . . .	10-05-4
		Straw chopper	
<b>S</b>		Adapter sleeve bearing components . . . . .	140-05-7
Safety equipment, air conditioning system . . . . .	90-05-6	Drive . . . . .	140-05-2
Safety precautions, air conditioning		Installing adapter sleeve bearings . . . . .	140-05-8
system . . . . .	90-05-5	Removing adapter sleeve bearings . . . . .	140-05-6
Seat compressor . . . . .	240-15L-1	Removing the rotor . . . . .	140-05-2
Second concave		Replacing rotating knives . . . . .	140-05-4
Concave . . . . .	120-15-2	Rotor engagement clutch . . . . .	140-05-5
Second cylinder/beater . . . . .	120-15-1	Rotor with knives . . . . .	140-05-3
Sections		Specifications . . . . .	140-05-1
Survey . . . . .	240-10-1, 241-10-1	Straw walker bearings	
Separator . . . . .	240-15V-1	Installation . . . . .	120-45-3
Separator		Removal . . . . .	120-45-2
Stone trap bottom plate . . . . .	120-05-1	Straw walker crankshaft	
Shafts . . . . .	80-05-1	Specifications . . . . .	120-45-1
Slip clutch		Straw walker crankshaft (front)	
Feeder house . . . . .	110-15-4	Removal . . . . .	120-45-5

Index

	Page		Page
Straw walker crankshaft (rear)		Unloading tube	
Removal . . . . .	120-45-6	Angle drive . . . . .	130-20-5
Straw walker crankshaft and crankshaft		Assembling angle drive (D) . . . . .	130-20-7
bearings . . . . .	120-45-4	Assembly of angle drive (C) . . . . .	130-20-6
Straw walkers		With unloading auger . . . . .	130-25-1
Installation . . . . .	120-45-2	Upper feeder shaft	
Removal . . . . .	120-45-1	Drive and slip clutch . . . . .	110-15-3
Specifications . . . . .	120-45-1	Upper feeder shaft and conveyor chain . . . . .	110-15-1
Straw warning device . . . . .	240-15S-1		
Synthetic Lubricants . . . . .	10-05-4	<b>V</b>	
System diagnosis		Variable pump	
Operator's seats . . . . .	290-05-4	Charge pump repair . . . . .	50-25-24
Ventilation and heater . . . . .	290-15-1	Control cable installation . . . . .	50-25-25
<b>T</b>		Control valve repair . . . . .	50-25-22
Test equipment, electrical system . . . . .	240-05-1, 240-06-1	Cylinder block spring . . . . .	50-25-13
Three-speed transmission . . . . .	250-20-1	Disassembly . . . . .	50-25-7
Threshing Cylinder . . . . .	120-10-3	Removal . . . . .	50-25-5
Threshing cylinder		Seal overhaul . . . . .	50-25-20
Alarm speed . . . . .	40-30-4	Servo-control valve installation . . . . .	50-25-19
Components . . . . .	120-10-8	Variator	
Drive components . . . . .	120-10-2	Assembly . . . . .	110-20-6
Filler plates . . . . .	120-10-9	Variator drive	
Reduction gear . . . . .	120-35-6	Assembly . . . . .	110-20-4
Second cylinder . . . . .	120-15-1	Components of central unit . . . . .	110-20-3
Specifications . . . . .	120-10-1	Components of lower variator . . . . .	110-20-5
Tires		Ventilation and heater	
Determining tire radius . . . . .	240-15W-3	System diagnosis . . . . .	290-15-1
Torque values		<b>W</b>	
Inch . . . . .	10-10-1	Water trap . . . . .	30-05-6
Metric . . . . .	10-10-2	Windshield washer . . . . .	240-15G-1
Transmission		Windshield wiper . . . . .	240-15G-1
Disassemble . . . . .	50-10-10	Wiring harness tester . . . . .	240-05-1, 240-06-1
Material required . . . . .	50-10-1	Wiring harnesses	
Remove pinion shaft . . . . .	50-10-12	Survey . . . . .	240-10-2
Repair . . . . .	50-10-10	Work lights . . . . .	240-15R-1
Specifications . . . . .	50-10-2		
Transmission oil . . . . .	10-05-2		
Transmission oil			
Reverser . . . . .	110-25-6		
Triple hydraulic pump . . . . .	70-10-1		
Type plates . . . . .	10-15-1		
<b>U</b>			
Unloading drive on grain tank			
Right (E) . . . . .	130-20-8		